



Internet Of Things

Virtual Network Computing



Prepared by:


Dr. Murad Yaghi
Eng. Malek Al-Louzi

School of Computing and Informatics – Al Hussein Technical University

Fall 2024/2025

Introduction

- Sometimes it is not convenient to work directly on Raspberry Pi
- Virtual Network Computing (VNC) facilitates remote desktop sharing
- This is a form of remote access on computer networks



What is VNC

- VNC is a graphical desktop sharing system
- It allows you to remotely control the desktop interface of Raspberry Pi from another computer

**Visual display of
Raspberry Pi**




**Control Raspberry Pi
Remotely**



What is VNC

- You will see the desktop of Raspberry Pi inside a window in your computer once the VNC is connected
- you can access your Raspberry Pi remotely within your local network or over the internet




VNC

- You default, install VNC viewer on your computer default, you have to enable VNC in your Raspberry Pi
- By default, VNC is installed on Raspberry Pi
- We will learn how to install VNC viewer on our computer and enable it in Raspberry Pi

Installing VNC viewer

- Search for “VNC viewer” on google



- Click on download from realvnc webpage

Installing VNC viewer

- Select appropriate OS then click download

VNC® Connect consists of VNC® Viewer and VNC® Server

Download VNC® Viewer to the device you want to control from, below. Make sure you've [installed VNC® Server](#) on the computer you want to control.




Download VNC Viewer

SHA-256: 6d2637db19c0c57d9375dddc15d24dd72e461a45a47fd5c017d529b8b7135599


EXE x86/x64

- Run the downloaded installation file





Enable VNC on Raspberry Pi

- On your Raspberry Pi, open Raspberry Pi configuration
- Go to interfaces tab and enable VNC




Connect to Raspberry Pi remotely

- Open VNC viewer on your computer
- Enter the Raspberry Pi IP address
- You can check the IP address using “ifconfig” command on terminal
- Finally, enter the username and password for your raspberry Pi




Raspberry Pi Configuration

- We can access raspi-config tool in two ways
 - Through terminal
 - Raspberry Pi configuration GUI




Remote file transfer

- We can transfer files from Raspberry Pi to your computer or from your computer to Raspberry Pi using VNC
- To transfer file from Raspberry Pi, VNC should be connected
- Right click on VNC icon then select file transfer
- Select the file then press send files



Remote file transfer

- Same way, you can send files from your computer
- Click send files in VNC viewer file transfer window
- Select the file and send it



Any Questions???