



Yarn Thickness of the thread is defined by the speed of the wheels. You can control them directly in the serial communication in Arduino defined as `DeliverySpeed` and `WriteSpeed`.

Number of Twist is the twist intensity in the yarn. You can also adjust it directly in the serial communication in Arduino defined as `SpindleSpeed`