



Application manual

Robot communication and I/O control

Robot Controller
RobotWare 5.0



Application manual

Robot communication and I/O control

RobotWare 5.0

Document ID: 3HAC020435-001

Revision: C

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damages to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission, and contents thereof must not be imparted to a third party nor be used for any unauthorized purpose. Contravention will be prosecuted.

Additional copies of this manual may be obtained from ABB at its then current charge.

© Copyright 2004-2007 ABB All rights reserved.

ABB Robotics
SE-721 68 Västerås
Sweden

Overview	5
Product documentation, M2004	7
Safety	9
1 File and Serial Channel Handling [620-1]	11
1.1 Overview	11
1.2 Binary and character based communication	12
1.2.1 Overview	12
1.2.2 RAPID components	13
1.2.3 Code examples	14
1.3 Raw data communication	17
1.3.1 Overview	17
1.3.2 RAPID components	18
1.3.3 Code examples	19
1.4 File and directory management	21
1.4.1 Overview	21
1.4.2 RAPID components	22
1.4.3 Code examples	23
2 Fieldbus Command Interface [618-1]	25
2.1 Overview	25
2.2 RAPID components and system parameters	26
2.3 Code example	27
3 Logical Cross Connections [621-1]	29
3.1 Overview	29
3.2 Configuring Logical Cross Connections	30
3.3 Examples	31
3.4 Limitations	33
4 Analog Signal Interrupt [622-1]	35
4.1 Overview	35
4.2 RAPID components	36
4.3 Code example	37
5 PC Interface [616-1]	39
5.1 Overview	39
5.2 Send variable from RAPID	40
5.3 ABB software using PC Interface	42
6 FTP Client [614-1]	43
6.1 Overview	43
6.2 System parameters	45
6.3 Examples	46
7 NFS Client [615-1]	49
7.1 Overview	49
7.2 System parameters	50
7.3 Examples	51
8 Socket Messaging [672-1]	53
8.1 About Socket Messaging	53
8.2 Schematic picture of socket communication	54

Table of Contents

8.3 RAPID components	55
8.4 Code examples	57
Index	61

Overview

About This Manual

This manual explains the basics of when and how to use the following RobotWare options:

- File and Serial Channel Handling
- Fieldbus Command Interface
- Logical Cross Connections
- Analog Signal Interrupt
- PC Interface
- FTP Client
- NFS Client

Usage

This manual can be used either as a reference to find out if an option is the right choice for solving a problem, or as a description of how to use an option. Detailed information regarding syntax for RAPID routines, and similar, is not described here, but can be found in the respective reference manual.

Who Should Read This Manual?

This manual is mainly intended for robot programmers.

Prerequisites

The reader should...

- be familiar with industrial robots and their terminology
- be familiar with the RAPID programming language
- be familiar with system parameters and how to configure them.

Organization of Chapters

The manual is organized in the following chapters:

Chapter	Contents
1.	Describes the option File and Serial Channel Handling.
2.	Describes the option Fieldbus Command Interface.
3.	Describes the option Logical Cross Connections.
4.	Describes the option Analog Signal Interrupt.
5.	Describes the option PC Interface.
6.	Describes the option FTP Client.
7.	Describes the option NFS Client.
8.	Describes the option Socket Messaging.

References

Reference	Document Id
Technical reference manual - RAPID overview	3HAC16580-1

Continues on next page

Reference	Document Id
Technical reference manual - RAPID Instructions, Functions and Data types	3HAC16581-1
Operator's manual - IRC5 with FlexPendant	3HAC 16590-1
Technical reference manual - System parameters	3HAC 17076-1
Operator's manual - RobotStudio Online	3HAC 18236-1

Revisions

Revision	Description
-	First edition
A	Socket Messaging has been added.
B	File and Serial Channel Handling: Limitations added. Socket Messaging: Improved example to avoid <code>SocketClose</code> directly after <code>SocketSend</code> . Fieldbus Command Interface: Corrected code example.
C	Socket Messaging: Added tips and note.

Product documentation, M2004

General

The robot documentation may be divided into a number of categories. This listing is based on the type of information contained within the documents, regardless of whether the products are standard or optional. This means that any given delivery of robot products *will not contain all* documents listed, only the ones pertaining to the equipment delivered.

However, all documents listed may be ordered from ABB. The documents listed are valid for M2004 robot systems.

Product manuals

All hardware, robots and controllers, will be delivered with a **Product manual** which is divided into two parts:

Product manual, procedures

- Safety information
- Installation and commissioning (descriptions of mechanical installation, electrical connections)
- Maintenance (descriptions of all required preventive maintenance procedures including intervals)
- Repair (descriptions of all recommended repair procedures including spare parts)
- Additional procedures, if any (calibration, decommissioning)

Product manual, reference information

- Reference information (article numbers for documentation referred to in Product manual, procedures, lists of tools, safety standards)
- Part list
- Foldouts or exploded views
- Circuit diagrams

The product manual published as a PDF consists of only one file where the two parts are presented together, as one Product manual.

Technical reference manuals

The following manuals describe the robot software in general and contain relevant reference information:

- **RAPID Overview:** An overview of the RAPID programming language.
- **RAPID Instructions, Functions and Data types:** Description and syntax for all RAPID instructions, functions and data types.
- **System parameters:** Description of system parameters and configuration workflows.

Continues on next page

Continued

Application manuals

Specific applications (e.g. software or hardware options) are described in **Application manuals**. An application manual can describe one or several applications.

An application manual generally contains information about:

- The purpose of the application (what it does and when it is useful)
- What is included (e.g. cables, I/O boards, RAPID instructions, system parameters, CD with PC software)
- How to use the application
- Examples of how to use the application

Operating manuals

This group of manuals is aimed at those having first hand operational contact with the robot, i.e. production cell operators, programmers and trouble shooters. The group of manuals includes:

- **Getting started - IRC5 and RobotStudio Online**
- **IRC5 with FlexPendant**
- **RobotStudio Online**
- **Trouble shooting - IRC5** for the controller and robot

Safety

Safety of personnel

A robot is heavy and extremely powerful regardless of its speed. A pause or long stop in movement can be followed by a fast hazardous movement. Even if a pattern of movement is predicted, a change in operation can be triggered by an external signal resulting in an unexpected movement.

Therefore, it is important that all safety regulations are followed when entering safeguarded space.

Safety regulations

Before beginning work with the robot, make sure you are familiar with the safety regulations described in *Operating manual - IRC5 with FlexPendant*.

1 File and Serial Channel Handling [620-1]

1.1. Overview

About File and Serial Channel Handling

The RobotWare option File and Serial Channel Handling gives the robot programmer control of files, fieldbuses and serial channels from the RAPID code. This can, for example, be useful for:

- Reading from a bar code reader.
- Writing production statistics to a log file or to a printer.
- Transferring data between the robot and a PC.

The functionality included in File and Serial Channel Handling can be divided into three groups:

Functionality group	Description
Binary and character based communication	Basic communication functionality. Communication with binary or character based files or serial channels.
Raw data communication	Data packed in a container. Especially intended for fieldbus communication.
File and directory management	Browsing and editing of file structures.

1.2 Binary and character based communication

1.2.1. Overview

Purpose

The purpose of binary and character based communication is to:

- store information in a remote memory or on a remote disk
- let the robot communicate with other devices

What is included

To handle binary and character based communication, the RobotWare option File and Serial Channel Handling gives you access to:

- instructions for manipulations of a file or serial channel
- instructions for writing to file or serial channel
- instruction for reading from file or serial channel
- functions for reading from file or serial channel.

Basic approach

This is the general approach for using binary and character based communication. For a more detailed example of how this is done, see [Code examples on page 14](#).

1. Open a file or serial channel.
2. Read or write to the file or serial channel.
3. Close the file or serial channel.

Limitations

Access to files, serial channels and field busses cannot be performed from different RAPID tasks simultaneously. Such an access is performed by all instruction in binary and character based communication, as well as `WriteRawBytes` and `ReadRawBytes`. E.g. if a `ReadBin` instruction is executed in one task, it must be ready before a `WriteRawBytes` can execute in another task.

1.2.2. RAPID components

Data types

This is a brief description of each data type used for binary and character based communication. For more information, see the respective data type in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Data type	Description
iodev	iodev contains a reference to a file or serial channel. It can be linked to the physical unit with the instruction <code>Open</code> and then used for reading and writing.

Instructions

This is a brief description of each instruction used for binary and character based communication. For more information, see the respective instruction in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Instruction	Description
Open	Open is used to open a file or serial channel for reading or writing.
Close	Close is used to close a file or serial channel.
Rewind	Rewind sets the file position to the beginning of the file.
ClearIOBuff	ClearIOBuff is used to clear the input buffer of a serial channel. All buffered characters from the input serial channel are discarded.
Write	Write is used to write to a character based file or serial channel.
WriteBin	WriteBin is used to write a number of bytes to a binary serial channel or file.
WriteStrBin	WriteStrBin is used to write a string to a binary serial channel or file.
WriteAnyBin	WriteAnyBin is used to write any type of data to a binary serial channel or file.
ReadAnyBin	ReadAnyBin is used to read any type of data from a binary serial channel or file.

Functions

This is a brief description of each function used for binary and character based communication. For more information, see the respective instruction in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Function	Description
ReadNum	ReadNum is used to read a number from a character based file or serial channel.
ReadStr	ReadStr is used to read a string from a character based file or serial channel.
ReadBin	ReadBin is used to read a byte (8 bits) from a file or serial channel. This function works on both binary and character based files or serial channels.
ReadStrBin	ReadStrBin is used to read a string from a binary serial channel or file.

1.2.3. Code examples

Communication with character based file

This example show writing and reading to and from a character based file. The line "The number is :8" is written to FILE1.DOC. The contents of FILE1.DOC is then read and the output to the FlexPendant is "The number is :8" followed by "The number is 8".

```
PROC write_to_file()
  VAR iodev file;
  VAR num number:= 8;

  Open "HOME:" \File:= "FILE1.DOC", file;
  Write file, "The number is :"\Num:=number;
  Close file;
ENDPROC

PROC read_from_file()
  VAR iodev file;
  VAR num number;
  VAR string text;

  Open "HOME:" \File:= "FILE1.DOC", file \Read;
  TPWrite ReadStr(file);
  Rewind file;
  text := ReadStr(file\Delim:=":");
  number := ReadNum(file);
  Close file;
  TPWrite text \Num:=number;
ENDPROC
```

Communication with binary serial channel

In this example, the string "Hello", the current robot position and the string "Hi" is written to the binary serial channel com1.

```
PROC write_bin_chan()
  VAR iodev channel;
  VAR num out_buffer{20};
  VAR num input;
  VAR robtargt target;

  Open "com1:", channel\Bin;

  ! Write control character enq
  out_buffer{1} := 5;
  WriteBin channel, out_buffer, 1;

  ! Wait for control character ack
  input := ReadBin (channel \Time:= 0.1);
  IF input = 6 THEN

    ! Write "Hello" followed by new line
    WriteStrBin channel, "Hello\0A";

    ! Write current robot position
    target := CRobT(\Tool:= tool1\WObj:= wobj1);
    WriteAnyBin channel, target;

    ! Set start text character (2=start text)
    out_buffer{1} := 2;

    ! Set character "H" (72="H")
    out_buffer{2} := 72;

    ! Set character "i"
    out_buffer{3} := StrToByte("i"\Char);

    ! Set new line character (10=new line)
    out_buffer{4} := 10;

    ! Set end text character (3=end text)
    out_buffer{5} := 3;

    ! Write the buffer with the line "Hi"
    ! to the channel
    WriteBin channel, out_buffer, 5;

  ENDF
  Close channel;
```

Continues on next page

1.2.3. Code examples

Continued

```
ENDPROC
```

In this example, the same sequence as above is read from the channel com2.

```
PROC read_bin_chan()
  VAR iodev channel;
  VAR string text;
  VAR num bindata;
  VAR robtarget target;

  Open "com2:", channel \Bin;

  ! Clear input buffer for com2
  ClearIOBuff channel;

  ! Wait for input from com2 and then
  ! write the first 5 characters to FlexPendant
  TPWrite ReadStrBin (channel, 5);

  ! Read the new line character
  ReadStrBin channel, 1;

  ! Read the next input, interpreted as  robtarget
  ! and move robot to that target
  ReadAnyBin channel, target;
  MoveJ target, vmax, fine, tool1;

  ! Read text one character at the time
  ! until end of file
  bindata := ReadBin(channel);
  WHILE bindata <> EOF_BIN DO
    text := text + ByteToStr(bindata\Char);
    bindata := ReadBin(channel);
  ENDWHILE
  TPWrite text;
  Close channel;
ENDPROC
```

1.3 Raw data communication

1.3.1. Overview

Purpose

The purpose of raw data communication is to pack different type of data into a container and send it to a file or serial channel, and to read and unpack data. This is particularly useful when communicating via a fieldbus, such as DeviceNet, Profibus or Interbus.

What is included

To handle raw data communication, the RobotWare option File and Serial Channel Handling gives you access to:

- instructions used for handling the contents of a `rawbytes` variable
- instructions for reading and writing raw data
- a function to get the valid data length of a `rawbytes` variable.

Basic approach

This is the general approach for raw data communication. For a more detailed example of how this is done, see [Write and read rawbytes on page 19](#).

1. Pack data into a `rawbytes` variable (data of type `num`, `byte` or `string`).
2. Write the `rawbytes` variable to a file or serial channel.
3. Read a `rawbytes` variable from a file or serial channel.
4. Unpack the `rawbytes` variable to `num`, `byte` or `string`.

Limitations

Fieldbus communication also require the option Fieldbus Command Interface and the option for the fieldbus in question.

Access to files, serial channels and field busses cannot be performed from different RAPID tasks simultaneously. Such an access is performed by all instruction in binary and character based communication, as well as `WriteRawBytes` and `ReadRawBytes`. E.g. if a `ReadBin` instruction is executed in one task, it must be ready before a `WriteRawBytes` can execute in another task.

1 File and Serial Channel Handling [620-1]

1.3.2. RAPID components

1.3.2. RAPID components

Data types

This is a brief description of each data type used for raw data communication. For more information, see the respective data type in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Data type	Description
rawbytes	<p>rawbytes is used as a general data container. It can be filled with any data of type num, byte or string. It also store the length of the valid data (in bytes).</p> <p>rawbytes can contain up to 1024 bytes of data. The supported data formats are:</p> <ul style="list-style-type: none">• Hex (1 byte)• long (4 bytes)• float (4 bytes)• ASCII (1-80 characters)

Instructions

This is a brief description of each instruction used for raw data communication. For more information, see the respective instruction in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Instruction	Description
ClearRawBytes	ClearRawBytes is used to set all the contents of a rawbytes variable to 0. The length of the valid data in the rawbytes variable is set to 0. ClearRawBytes can also be used to clear only the last part of a rawbytes variable.
PackRawBytes	PackRawBytes is used to pack the contents of variables of type num, byte or string into a variable of type rawbytes.
UnpackRawBytes	UnpackRawBytes is used to unpack the contents of a variable of type rawbytes to variables of type byte, num or string.
CopyRawBytes	CopyRawBytes is used to copy all or part of the contents from one rawbytes variable to another.
WriteRawBytes	WriteRawBytes is used to write data of type rawbytes to any binary file, serial channel or fieldbus.
ReadRawBytes	ReadRawBytes is used to read data of type rawbytes from any binary file, serial channel or fieldbus.

Functions

This is a brief description of each function used for raw data communication. For more information, see the respective function in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Function	Description
RawBytesLen	RawBytesLen is used to get the valid data length in a rawbytes variable.

1.3.3. Code examples

About the examples

These examples are simplified demonstrations of how to use `rawbytes`. For a more realistic example of how to use `rawbytes` in DeviceNet communication, see [Write rawbytes to DeviceNet on page 27](#).

Write and read rawbytes

This example shows how to pack data into a `rawbytes` variable and write it to a device. It also shows how to read and unpack a `rawbytes` variable.

```
VAR iodev io_device;
VAR rawbytes raw_data;

PROC write_rawbytes()
  VAR num length := 0.2;
  VAR string length_unit := "meters";

  ! Empty contents of raw_data
  ClearRawBytes raw_data;

  ! Add contents of length as a 4 byte float
  PackRawBytes length, raw_data,
    (RawBytesLen(raw_data)+1) \Float4;

  ! Add the string length_unit
  PackRawBytes length_unit, raw_data,
    (RawBytesLen(raw_data)+1) \ASCII;

  Open "HOME:" \File:= "FILE1.DOC", io_device \Bin;

  ! Write the contents of raw_data to io_device
  WriteRawBytes io_device, raw_data;

  Close io_device;
ENDPROC

PROC read_rawbytes()
  VAR string answer;

  ! Empty contents of raw_data
  ClearRawBytes raw_data;

  Open "HOME:" \File:= "FILE1.DOC", io_device \Bin;

  ! Read from io_device into raw_data
  ReadRawBytes io_device, raw_data \Time:=1;
```

Continues on next page

1.3.3. Code examples

Continued

```
Close io_device;

! Unpack raw_data to the string answer
UnpackRawBytes raw_data, 1, answer \ASCII:=10;
ENDPROC
```

Copy rawbytes

In this example, all data from raw_data_1 and raw_data_2 is copied to raw_data_3.

```
VAR rawbytes raw_data_1;
VAR rawbytes raw_data_2;
VAR rawbytes raw_data_3;
VAR num my_length:=0.2;
VAR string my_unit:=" meters";

PackRawBytes my_length, raw_data_1, 1 \Float4;
PackRawBytes my_unit, raw_data_2, 1 \ASCII;

! Copy all data from raw_data_1 to raw_data_3
CopyRawBytes raw_data_1, 1, raw_data_3, 1;

! Append all data from raw_data_2 to raw_data_3
CopyRawBytes raw_data_2, 1, raw_data_3,
(RawBytesLen(raw_data_3)+1);
```

1.4 File and directory management

1.4.1. Overview

Purpose

The purpose of the file and directory management is to be able to browse and edit file structures (directories and files).

What is included

To handle file and directory management, the RobotWare option File and Serial Channel Handling gives you access to:

- instructions for handling directories
- a function for reading directories
- instructions for handling files on a file structure level
- functions to retrieve size and type information.

Basic approach

This is the general approach for file and directory management. For more detailed examples of how this is done, see [Code examples on page 23](#).

1. Open a directory.
2. Read from the directory and search until you find what you are looking for.
3. Close the directory.

1 File and Serial Channel Handling [620-1]

1.4.2. RAPID components

1.4.2. RAPID components

Data types

This is a brief description of each data type used for file and directory management. For more information, see the respective data type in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Data type	Description
dir	dir contains a reference to a directory on disk or network. It can be linked to the physical directory with the instruction <code>OpenDir</code> .

Instructions

This is a brief description of each instruction used for file and directory management. For more information, see the respective instruction in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Instruction	Description
OpenDir	OpenDir is used to open a directory.
CloseDir	CloseDir is used to close a directory.
MakeDir	MakeDir is used to create a new directory.
RemoveDir	RemoveDir is used to remove an empty directory.
CopyFile	CopyFile is used to make a copy of an existing file.
RenameFile	RenameFile is used to give a new name to an existing file. It can also be used to move a file from one place to another in the directory structure.
RemoveFile	RemoveFile is used to remove a file.

Functions

This is a brief description of each function used for file and directory management. For more information, see the respective instruction in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Function	Description
ReadDir	ReadDir is used to retrieve the name of the next file or subdirectory under a directory that has been opened with the instruction <code>OpenDir</code> . Note that the first items read by <code>ReadDir</code> are <code>.</code> and <code>..</code> symbolizing the current directory and its parent directory.
FileSize	FileSize is used to retrieve the size (in bytes) of the specified file.
FSSize	FSSize (File System Size) is used to retrieve the size (in bytes) of the file system in which a specified file resides. FSSize can either retrieve the total size or the free size of the system.
IsFile	IsFile test if the specified file is of the specified type. It can also be used to test if the file exist at all.

© Copyright 2004-2007 ABB. All rights reserved.

1.4.3. Code examples

List files

This example shows how to list the files in a directory, excluding the directory itself and its parent directory (. and ..).

```
PROC lsdire(string dirname)
  VAR dir directory;
  VAR string filename;

  ! Check that dirname really is a directory
  IF IsFile(dirname \Directory) THEN

    ! Open the directory
    OpenDir directory, dirname;

    ! Loop through the files in the directory
    WHILE ReadDir(directory, filename) DO
      IF (filename <> "." AND filename <> ".." THEN
        TPWrite filename;
      ENDIF
    ENDWHILE

    ! Close the directory
    CloseDir directory;
  ENDIF
ENDPROC
```

Move file to new directory

This is an example where a new directory is created, a file renamed and moved to the new directory and the old directory is removed.

```
VAR dir directory;
VAR string filename;

! Create the directory newdir
MakeDir "HOME:/newdir";

! Rename and move the file
RenameFile "HOME:/olddir/myfile", "HOME:/newdir/yourfile";

! Remove all files in olddir
OpenDir directory, "HOME:/olddir";
WHILE ReadDir(directory, filename) DO
  IF (filename <> "." AND filename <> ".." THEN
    RemoveFile "HOME:/olddir/" + filename;
  ENDIF
ENDWHILE
CloseDir directory;
```

Continues on next page

1.4.3. Code examples

Continued

```
! Remove the directory olddir (which must be empty)
RemoveDir "HOME:/olddir";
```

Check sizes

In this example, the size of the file is compared with the remaining free space on the file system. If there is enough space, the file is copied.

```
VAR num freesyssize;
VAR num f_size;

! Get the size of the file
f_size := FileSize("HOME:/myfile");

! Get the free size on the file system
freesyssize := FSSize("HOME:/myfile" \Free);

! Copy file if enough space free
IF f_size < freesyssize THEN
    CopyFile "HOME:/myfile", "HOME:/yourfile";
ENDIF
```

2 Fieldbus Command Interface [618-1]

2.1. Overview

Purpose

Fieldbus Command Interface provides an interface to talk to a DeviceNet device.

This interface is used together with raw data communication, see [Raw data communication on page 17](#).

What is included

The RobotWare option Fieldbus Command Interface gives you access to:

- instruction used to create a DeviceNet header

Basic approach

This is the general approach for using Fieldbus Command Interface. For a more detailed example of how this is done, see [Write rawbytes to DeviceNet on page 27](#).

1. Add a DeviceNet header to a `rawbytes` variable.
2. Add the data to the `rawbytes` variable.
3. Write the `rawbytes` variable to the DeviceNet device.
4. Read data from the DeviceNet device to a `rawbytes` variable.
5. Extract the data from the `rawbytes` variable.

Limitations

Fieldbus communication also require the option File and Serial Channel Handling and the option for the fieldbus in question.

2 Fieldbus Command Interface [618-1]

2.2. RAPID components and system parameters

2.2. RAPID components and system parameters

Data types

There are no data types for Fieldbus Command Interface.

Instructions

This is a brief description of each instruction in Fieldbus Command Interface. For more information, see the respective instruction in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Instruction	Description
PackDNHeader	<code>PackDNHeader</code> adds a DeviceNet header to a <code>rawbytes</code> variable. The header specifies a service to be done (e.g. set or get) and a parameter on a DeviceNet board.

Functions

There are no functions for Fieldbus Command Interface.

System parameters

This is a brief description of each parameter in Fieldbus Command Interface. For more information, see the respective parameter in *Technical reference manual - System parameters*.

Parameter	Description
Explicit Messaging	Enables DeviceNet Explicit connection to the device. <i>Explicit Messaging</i> must be set to Enabled for the DeviceNet unit type that you want to use Fieldbus Command Interface to communicate with. <i>Explicit Messaging</i> belongs to the type <i>Unit Type</i> in the topic <i>I/O System</i> .

2.3. Code example

Write rawbytes to DeviceNet

In this example, data packed as a rawbytes variable is written to a DeviceNet board. For more details regarding rawbytes, see [Raw data communication on page 17](#).

```
PROC set_filter_value()
  VAR iodev dev;
  VAR rawbytes rawdata_out;
  VAR rawbytes rawdata_in;
  VAR num input_int;
  VAR byte return_status;
  VAR byte return_info;
  VAR byte return_errcode;
  VAR byte return_errcode2;

  ! Empty contents of rawdata_out and rawdata_in
  ClearRawBytes rawdata_out;
  ClearRawBytes rawdata_in;

  ! Add DeviceNet header to rawdata_out with
  ! service "SET_ATTRIBUTE_SINGLE" and
  ! path to filter attribute on DeviceNet board
  PackDNHeader "10", "6,20 1D 24 01 30 64,8,1",
    rawdata_out;

  ! Add filter value to send to DeviceNet board
  input_int:= 5;
  PackRawBytes input_int, rawdata_out,
    (RawBytesLen(rawdata_out) + 1) \IntX := USINT;

  ! Open FCI device
  Open "/FCI1:" \File:="board328", dev \Bin;

  ! Write the contents of rawdata_out to dev
  WriteRawBytes dev, rawdata_out
    \NoOfBytes := RawBytesLen(rawdata_out);

  ! Read the answer from dev
  ReadRawBytes dev, rawdata_in;

  ! Close FCI device
  Close dev;

  ! Unpack rawdata_in to the variable return_status
  UnpackRawBytes rawdata_in, 1, return_status
    \Hex1;
```

Continues on next page

2.3. Code example

Continued

```
IF return_status = 144 THEN
    TPWrite "Status OK from device. Status code: "
        \Num:=return_status;
ELSE
    ! Unpack error codes from device answer
    UnpackRawBytes rawdata_in, 2, return_errcode
        \Hex1;
    UnpackRawBytes rawdata_in, 3, return_errcode2
        \Hex1;
    TPWrite "Error code from device: "
        \Num:=return_errcode;
    TPWrite "Additional error code from device: "
        \Num:=return_errcode2;
ENDIF
ENDPROC
```

3 Logical Cross Connections [621-1]

3.1. Overview

Purpose

The purpose of Logical Cross Connections is to check combinations of digital signals. This can be used to check or control process equipment that are external to the robot. The functionality can be compared to the one of a simple PLC.

By letting the I/O system handle logical operations with signals, a lot of RAPID code execution can be avoided. Logical Cross Connections can replace the process of reading signal values, calculate new values and writing the values to signals.

Here are some examples of applications:

- Interrupt program execution when either of three input signals is set to 1.
- Set an output signal to 1 when both of two input signals are set to 1.

Description

Cross connections are used to define a digital signal's dependencies to other digital signals. Without the option Logical Cross Connections, a signal can only be defined to have the same value as another signal.

With the option Logical Cross Connections, more complex dependencies can be configured with the logical operators AND, OR and inverted signal values.

The signals that constitute the logical expression (actor signals) and the signals that are the result of the expression (resultant signal) can be either digital input signals or digital output signals.

What is included

The RobotWare option Logical Cross Connections allows you to build logical expressions with up to 5 actor signals and the logical operations AND, OR and inverted signal values.

3 Logical Cross Connections [621-1]

3.2. Configuring Logical Cross Connections

3.2. Configuring Logical Cross Connections

System parameters

This is a brief description of the parameters for cross connections. For more information, see the respective parameter in [Technical reference manual - System parameters](#).


These parameters belong to the type *Cross Connection* in the topic *I/O System*.

Parameter	Description
Resultant	The signal that receives the result of the cross connection as its new value.
Actor 1	The first signal to be used in the evaluation of the <i>Resultant</i> .
Invert actor 1	If <i>Invert actor 1</i> is set to Yes, then the inverted value of the <i>Actor 1</i> signal is used in the evaluation of the <i>Resultant</i> .
Operator 1	Operand between <i>Actor 1</i> and <i>Actor 2</i> . Can be either of the operands: <ul style="list-style-type: none">• AND - Results in the value 1 if both input values are 1.• OR - Results in the value 1 if at least one of the input values are 1. Note: The operators are calculated left to right (<i>Operator 1</i> first and <i>Operator 4</i> last).
Actor 2	The second signal (if more than one) to be used in the evaluation of the <i>Resultant</i> .
Invert actor 2	If <i>Invert actor 2</i> is set to Yes, then the inverted value of the <i>Actor 2</i> signal is used in the evaluation of the <i>Resultant</i> .
Operator 2	Operand between <i>Actor 2</i> and <i>Actor 3</i> . See <i>Operator 1</i> .
Actor 3	The third signal (if more than two) to be used in the evaluation of the <i>Resultant</i> .
Invert actor 3	If <i>Invert actor 3</i> is set to Yes, then the inverted value of the <i>Actor 3</i> signal is used in the evaluation of the <i>Resultant</i> .
Operator 3	Operand between <i>Actor 3</i> and <i>Actor 4</i> . See <i>Operator 1</i> .
Actor 4	The fourth signal (if more than three) to be used in the evaluation of the <i>Resultant</i> .
Invert actor 4	If <i>Invert actor 4</i> is set to Yes, then the inverted value of the <i>Actor 4</i> signal is used in the evaluation of the <i>Resultant</i> .
Operator 4	Operand between <i>Actor 4</i> and <i>Actor 5</i> . See <i>Operator 1</i> .
Actor 5	The fifth signal (if all five are used) to be used in the evaluation of the <i>Resultant</i> .
Invert actor 5	If <i>Invert actor 5</i> is set to Yes, then the inverted value of the <i>Actor 5</i> signal is used in the evaluation of the <i>Resultant</i> .

3.3. Examples

Logical AND

The following logical structure...




xx0300000457

... is created as shown below.

Resultant	Actor 1	Invert actor 1	Operator 1	Actor 2	Invert actor 2	Operator 2	Actor 3	Invert actor 3
do26	di1	No	AND	do2	No	AND	do10	No

Logical OR

The following logical structure...




xx0300000459

... is created as shown below.

Resultant	Actor 1	Invert actor 1	Operator 1	Actor 2	Invert actor 2	Operator 2	Actor 3	Invert actor 3
do26	di1	No	OR	do2	No	OR	do10	No

Inverted signals

The following logical structure (where a ring symbolize an inverted signal) ...




xx0300000460

... is created as shown below.

Resultant	Actor 1	Invert actor 1	Operator 1	Actor 2	Invert actor 2	Operator 2	Actor 3	Invert actor 3
do26	di1	Yes	OR	do2	No	OR	do10	Yes

Several resultant signals

The following logical structure can not be implemented with one cross connection...



xx0300000462

Continues on next page

3 Logical Cross Connections [621-1]

3.3. Examples


Continued

... but with three cross connections it can be implemented as shown below.

Resultant	Actor 1	Invert actor 1	Operator 1	Actor 2	Invert actor 2
di17	di1	No	AND	do2	No
do26	di1	No	AND	do2	No
do13	di1	No	AND	do2	No

Complex conditions

The following logical structure...



xx0300000461

... is created as shown below.

Resultant	Actor 1	Invert actor 1	Operator 1	Actor 2	Invert actor 2	Operator 2	Actor 3	Invert actor 3
do11	di2	No	AND	do3	No			
do14	di12	No	AND	do3	Yes			
di11	di13	No	AND	do3	No			
do23	di13	No	AND	do3	No			
do17	di13	No	AND	do3	No			
do15	do11	No	OR	do14	No	OR	di11	Yes
do33	di11	No	AND	do23	No			
do61	do17	No	AND	do3	No			
do54	do15	No	OR	do33	Yes			

3.4. Limitations

Evaluation order

If more than two actor signals are used in one cross connection, the evaluation is made from left to right. This means that the operation between *Actor 1* and *Actor 2* is evaluated first and the result from that is used in the operation with *Actor 3*.

If all operators in one cross connection are of the same type (only AND or only OR) the evaluation order has no significance. However, mixing AND and OR operators, without considering the evaluation order, may give an unexpected result.



TIP!

Use several cross connections instead of mixing AND and OR in the same cross connection.

Max actor signals

A cross connection may not have more than five actor signals. If more actor signals are required, use several cross connections.

Max cross connections

The maximum number of cross connections is 100.


Max depth

The maximum allowed depth of cross connection evaluations is 20.

A resultant from one cross connection can be used as an actor in another cross connection. The resultant from that cross connection can in its turn be used as an actor in the next cross connection. However, this type of chain of dependent cross connections cannot be deeper than 20 steps.

Do not create a loop

A resultant signal from a cross connection cannot be used as an actor signal for the same cross connection. Nor can a signal be used as an actor signal in a cross connection if its value depends on that cross connection via a number of other cross connections.



xx0300000458

An error message will inform you if the cross connections form a loop.

3.4. Limitations

4 Analog Signal Interrupt [622-1]

4.1. Overview

Purpose

The purpose of Analog Signal Interrupt is to supervise an analog signal and generate an interrupt when a specified value is reached.

Analog Signal Interrupt is faster, easier to implement and require less computer capacity than polling methods.

Here are some examples of applications:

- save cycle time with better timing (start robot movement exactly when a signal reach the specified value, instead of waiting for polling)
- show warning or error messages if a signal value is outside its allowed range
- stop the robot if a signal value reaches a dangerous level

What is included

The RobotWare option Analog Signal Interrupt gives you access to the instructions:

- ISignalAI
- ISignalAO

Basic approach

This is the general approach for using Analog Signal Interrupt. For a more detailed example of how this is done, see [Code example on page 37](#).

1. Create a trap routine.
2. Connect the trap routine using the instruction CONNECT.
3. Define the interrupt conditions with the instruction ISignalAI or ISignalAO.

Limitations

Analog signals can only be used if you have a fieldbus option (e.g. DeviceNet or Profibus).

4 Analog Signal Interrupt [622-1]

4.2. RAPID components

4.2. RAPID components

Data types

Analog Signal Interrupt includes no data types.

Instructions

This is a brief description of each instruction in Analog Signal Interrupt. For more information, see the respective instruction in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Instruction	Description
ISignalAI	Defines the values of an analog input signal, for which an interrupt routine shall be called. An interrupt can be set to occur when the signal value is above or below a specified value, or inside or outside a specified range. It can also be specified if the interrupt shall occur once or repeatedly.
ISignalAO	Defines the values of an analog output signal, for which an interrupt routine shall be called. An interrupt can be set to occur when the signal value is above or below a specified value, or inside or outside a specified range. It can also be specified if the interrupt shall occur once or repeatedly.

Functions

Analog Signal Interrupt includes no RAPID functions.

4.3. Code example

Temperature surveillance

In this example a temperature sensor is connected to the signal `ail`.

An interrupt routine with a warning is set to execute every time the temperature rises 0.5 degrees in the range 120-130 degrees. Another trap routine, stopping the robot, is set to execute as soon as the temperature rise above 130 degrees.

```
VAR intnum ail_warning;
VAR intnum ail_exceeded;

PROC main()
  CONNECT ail_warning WITH temp_warning;
  CONNECT ail_exceeded WITH temp_exceeded;
  ISignalAI ail, AIO_BETWEEN, 130, 120, 0.5,
    \DPos, ail_warning;
  ISignalAI \Single, ail, AIO_ABOVE_HIGH, 130,
    120, 0, ail_exceeded;
  ...
  IDelete ail_warning;
  IDelete ail_exceeded;
ENDPROC

TRAP temp_warning
  TPWrite "Warning: Temperature is "\Num:=ail;
ENDTRAP

TRAP temp_exceeded
  TPWrite "Temperature is too high";
  Stop;
ENDTRAP
```

4.3. Code example

5 PC Interface [616-1]

5.1. Overview

Purpose

PC Interface is used for communication between the controller and a PC.

PC Interface is required for some software products from ABB, such as WebWare and some functionality in RobotStudio^{Online}.

With PC Interface, data can be sent to a PC. This is, for example, used for:

- backup
- production statistics logging
- operator information presented on a PC.

What is included

The RobotWare option PC Interface gives you access to:

- a RAPID instruction used to send data to a PC: `SCWrite`
- an Ethernet communication interface, which is used by some ABB software products.

Basic approach

This is the general approach for using PC Interface.

1. Set up a WebWare client application on a PC. For more information, see documentation for WebWare.
2. Use the instruction `SCWrite` to send data from the RAPID program to the client application on the PC. For more information, see [Send variable from RAPID on page 40](#).

5.2. Send variable from RAPID

SCWrite instruction

SCWrite (Superior Computer Write) is used to send persistent variables to a client application on a PC. For more information, see *Technical reference manual - RAPID Instructions, Functions and Data types*.

Client application

The PC must have a client application that can subscribe to the information sent from the controller with SCWrite.

This client application can be either:

- a WebWare custom database
- a client application developed with WebWare SDK

For more information, see documentation for WebWare.

Code example

In this example the robot moves objects to a position where they can be treated by a process controlled by the PC. When the object is ready the robot moves it to its next station.

The program use SCWrite to inform the PC when the object is in position and when it has been moved to the next station. It also sends a message to the PC about how many objects that have been handled.

```
PERS bool in_position:=FALSE;
PERS num nbr_objects:=0;

WHILE TRUE DO
    ! Wait for next object
    WaitDI di1,1;

    ! Call first routine
    move_obj_to_pos();

    ! Send message to PC that object is in position
    in_position:=TRUE;
    SCWrite in_position;

    ! Wait for object to be ready
    WaitDI di2,1;

    ! Call second routine
    move_obj_to_next();

    ! Send message to PC that object is gone
    in_position:=FALSE;
    SCWrite in_position;

    ! Inform PC how many object has been handled
    nbr_objects:= nbr_objects+1;
    SCWrite nbr_objects;
ENDWHILE
```

5.3. ABB software using PC Interface

Overview

PC Interface provides a communication interface between the controller and a PC connected to an Ethernet network.

This functionality can be used by different software applications from ABB. Note that the products mentioned below are examples of applications using PC Interface, not a complete list.

WebWare

WebWare is a software product created to give extra functionality to the industrial robot user. PC Interface is required to run WebWare.

Functionality	Description
Backup	Backup of all programs and system parameters.
Metrics	Access to status data for the robot and logging of error messages and other data.
Service	Allows a service organization to get remote access to the robot.
OPC Server	OLE for Process Control is an industry standard for uniform interfaces.
SDK	Software Development Kit for creating customized applications that subscribe to data from the controller.

For more information, see documentation for WebWare.

RobotStudio Online

RobotStudio Online is a software product delivered with the robot. However, all its functionality is not accessible by default. Some of the functionality requires PC Interface.

The following table shows some examples of RobotStudio Online functionality that is only available if you have PC Interface:

Functionality	Description
Event recorder	Error messages and similar events can be shown or logged on the PC.
RAPID editor	Allows on-line editing against the controller from the PC.

For more information, see [Operating manual - RobotStudio Online](#).

6 FTP Client [614-1]

6.1. Overview


Purpose

The purpose of FTP Client is to enable the robot to access remote mounted disks, for example a hard disk drive on a PC.

Here are some examples of applications:

- backup to a remote computer
- load programs from a remote computer

Network illustration



Description

Several robots can access the same computer over an Ethernet network.

Once the FTP application protocol is configured, the remote computer can be accessed in the same way as the controller's internal hard disk.

What is included

The RobotWare option FTP Client gives you access to the system parameter type *Application protocol* and its parameters: *Name*, *Type*, *Transmission protocol*, *Server address*, *Trusted*, *Local path*, *Server path*, *Username* and *Password*

Basic approach

This is the general approach for using FTP Client. For more detailed examples of how this is done, see [Examples on page 46](#).

1. Configure an *Application protocol* to point out a disk or directory on a remote computer that will be accessible from the robot.
2. Read and write to the remote computer in the same way as with the controller's internal hard disk.

Continues on next page

6 FTP Client [614-1]

6.1. Overview

Continued

Requirements

The external computer must have:

- TCP/IP stack
- FTP Server

6.2. System parameters

Application protocol

This is a brief description of the parameters used to configure an application protocol. For more information, see the respective parameter in *Technical reference manual - System parameters*.

These parameters belongs to the type *Application protocol* in the topic *Communication*.

Parameter	Description
Name	Name of the application protocol.
Type	Type of application protocol. Set this to "FTP".
Transmission protocol	Name of the transmission protocol the protocol should use. For FTP, this is always "TCP/IP".
Server address	The IP address of the computer with the FTP server.
Trusted	This flag decides if this computer should be trusted, i.e. if losing the connection should make the program stop.
Local path	Defines what the shared unit will be called on the robot. The parameter value must end with a colon (:). If, for example the unit is named "pc:", the name of the test.prg on this unit would be pc:test.prg
Server path	The name of the disk or folder to connect to, on the remote computer. If not specified, the application protocol will reference the directory that is shared by the FTP server. Note: If communicating with an FTP server of type Distinct FTP or MS IIS, the exported path should not be specified.
Username	The user name used by the robot when it logs on to the remote computer. The user account must be set up on the FTP server.
Password	The password used by the robot when it logs on to the remote computer. Note that the password written here will be visible to all who has access to the system parameters.

Transmission protocol

There is a configured transmission protocol called TCP/IP, but no changes can be made to it. This is used by the FTP application protocol.

6.3. Examples

Example configuration

This is an example of how an application protocol can be configured for FTP.


Parameter	Value
Name	my FTP protocol
Type	FTP
Transmission protocol	TCP/IP
Server address	100.100.100.100
Trusted	No
Local path	pc:
Server path	C:\robot_1
Username	Robot1
Password	robot1

Note that if communicating with an FTP server of type Distinct FTP or MS IIS, the value of *Server path* should exclude the exported path.

Example with FlexPendant

This example shows how to use the FlexPendant to make a backup to the remote PC. We assume that the configuration is done according to the example configuration shown above.

1. Tap **ABB** and select **Backup and Restore**.
2. Tap on **Backup Current System**.
3. Save the backup to pc:/Backup/Backup_20031008 (the path on the PC will be C:\robot_1\Backup\Backup_20031008).



Example with RAPID code

This example shows how to open the file C:\robot_1\files\file1.doc on the remote PC from a RAPID program on the controller. We assume that the configuration is done according to the example configuration shown above.

```
Open "HOME:" \File:= "pc:/files/file1.doc", file;
```

6.3. Examples

7 NFS Client [615-1]

7.1. Overview

Purpose

The purpose of NFS Client is to enable the robot to access remote mounted disks, for example a hard disk drive on a PC.

Here are some examples of applications:

- backup to a remote computer
- load programs from a remote computer

Description

Several robots can access the same computer over an Ethernet network.

Once the NFS application protocol is configured, the remote computer can be accessed in the same way as the controller's internal hard disk.

What is included

The RobotWare option NFS Client gives you access to the system parameter type *Application protocol* and its parameters: *Name*, *Type*, *Transmission protocol*, *Server address*, *Trusted*, *Local path*, *Server path*, *User ID* and *Group ID*.

Basic approach

This is the general approach for using NFS Client. For more detailed examples of how this is done, see [Examples on page 46](#).

1. Configure an *Application protocol* to point out a disk or directory on a remote computer that will be accessible from the robot.
2. Read and write to the remote computer in the same way as with the controller's internal hard disk.

Requirements

The external computer must have:

- TCP/IP stack
- NFS Server

7.2. System parameters

Application protocol

This is a brief description of the parameters used to configure an application protocol. For more information, see the respective parameter in [Technical reference manual - System parameters](#)

These parameters belongs to the type *Application protocol* in the topic *Communication*.

Parameter	Description
Name	Name of the application protocol.
Type	Type of application protocol. Set this to "NFS".
Transmission protocol	Name of the transmission protocol the protocol should use. For NFS, this is always "TCP/IP".
Server address	The IP address of the computer with the NFS server.
Trusted	This flag decides if this computer should be trusted, i.e. if losing the connection should make the program stop.
Local path	Defines what the shared unit will be called on the robot. The parameter value must end with a colon (:). If, for example the unit is named "pc:", the name of the test.prg on this unit would be pc:test.prg
Server path	The name of the exported disk or folder on the remote computer. For NFS, Server Path must be specified.
User ID	Used by the NFS protocol as a way of authorizing the user to access a specific server. If this parameter is not used, which is usually the case on a PC, set it to the default value 0. Note that <i>User ID</i> must be the same for all mountings on one robot controller.
Group ID	Used by the NFS protocol as a way of authorizing the user to access a specific server. If this parameter is not used, which is usually the case on a PC, set it to the default value 0. Note that <i>Group ID</i> must be the same for all mountings on one robot controller.

Transmission protocol

There is a configured transmission protocol called TCP/IP, but no changes can be made to it. This is used by the NFS application protocol.

7.3. Examples

Example configuration


This is an example of how an application protocol can be configured for NFS.

Parameter	Value
Name	my NFS protocol
Type	NFS
Transmission protocol	TCP/IP
Server address	100.100.100.100
Trusted	No
Local path	pc:
Server path	C:\robot_1
User ID	Robot1
Group ID	robot1

Example with FlexPendant

This example shows how to use the FlexPendant to make a backup to the remote PC. We assume that the configuration is done according to the example configuration shown above.

1. Tap **ABB** and select **Backup and Restore**.
2. Tap on **Backup Current System**.
3. Save the backup to pc:/Backup/Backup_20031008 (the path on the PC will be C:\robot_1\Backup\Backup_20031008).



en0300000504

Continues on next page

7.3. Examples

Continued

Example with RAPID code

This example shows how to open the file C:\robot_1\files\file1.doc on the remote PC from a RAPID program on the controller. We assume that the configuration is done according to the example configuration shown above.

```
Open "HOME:" \File:= "pc:/files/file1.doc", file;
```

8 Socket Messaging [672-1]

8.1. About Socket Messaging

Purpose

The purpose of Socket Messaging is to allow a RAPID programmer to transmit application data between computers, using the TCP/IP network protocol. A socket represents a general communication channel, independent of the network protocol being used.

Socket communication is a standard that has its origin in Berkeley Software Distribution Unix. Besides Unix, it is supported by, for example, Microsoft Windows. With Socket Messaging, a RAPID program on a robot controller can, for example, communicate with a C/C++ program on another computer.

What is included

The RobotWare option Socket Messaging gives you access to RAPID data types, instructions and functions for socket communication between computers.


Basic approach

This is the general approach for using Socket Messaging. For a more detailed example of how this is done, see [Code examples on page 57](#).

1. Create a socket, both on client and server. A robot controller can be either client or server.
2. Use `SocketBind` and `SocketListen` on the server, to prepare it for a connection request.
3. Order the server to accept incoming socket connection requests.
4. Request socket connection from the client.
5. Send and receive data between client and server.

8.2. Schematic picture of socket communication

Illustration of socket communication



en0600003224

TIP!

Do not create and close sockets more than necessary. Keep the socket open until the communication is completed. The socket is not really closed until a certain time after `SocketClose` (due to TCP/IP functionality).



8.3. RAPID components

Data types

This is a brief description of each data type in Socket Messaging. For more information, see the respective data type in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Data type	Description
socketdev	A socket device used to communicate with other computers on a network.
socketstatus	Can contain status information from a <code>socketdev</code> variable.

Instructions for client

This is a brief description of each instruction used by the a Socket Messaging client. For more information, see the respective instruction in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Instruction	Description
SocketCreate	Creates a new socket and assigns it to a <code>socketdev</code> variable.
SocketConnect	Makes a connection request to a remote computer. Used by the client to connect to the server.
SocketSend	Sends data via a socket connection to a remote computer. The data can be a <code>string</code> or <code>rawbytes</code> variable, or a byte array.
SocketReceive	Receives data and stores it in a <code>string</code> or <code>rawbytes</code> variable, or in a byte array.
SocketClose	Closes a socket and release all resources.



TIP!

Do not use `SocketClose` directly after `SocketSend`. Wait for acknowledgement before closing the socket.

Instructions for server

A Socket Messaging server use the same instructions as the client, except for `SocketConnect`. In addition, the server use the following instructions:

Instruction	Description
SocketBind	<p>Binds the socket to a specified port number on the server. Used by the server to define on which port (on the server) to listen for a connection.</p> <p>The IP address defines a physical computer and the port defines a logical channel to a program on that computer.</p>
SocketListen	Makes the computer act as a server and accept incoming connections. It will listen for a connection on the port specified by <code>SocketBind</code> .
SocketAccept	Accepts an incoming connection request. Used by the server to accept the client's request.

Continues on next page

8 Socket Messaging [672-1]

8.3. RAPID components

Continued



NOTE!

The server application must be started before the client application, so that the instruction `SocketAccept` is executed before any client execute `SocketConnect`.

Functions

This is a brief description of each function in Socket Messaging. For more information, see the respective function in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Function	Description
SocketGetStatus	Returns information about the last instruction performed on the socket (created, connected, bound, listening, closed). <code>SocketGetStatus</code> does not detect changes from outside RAPID (such as a broken connection).

8.4. Code examples

Example of client/server communication

This example shows program code for a client and a server, communicating with each other.

The server will write on the FlexPendant:

```
Client wrote - Hello server
Client wrote - Shutdown connection
```

The client will write on its FlexPendant:

```
Server wrote - Message acknowledged
Server wrote - Shutdown acknowledged
```

In this example, both the client and the server use RAPID programs. In reality, one of the programs would often be running on a PC (or similar computer) and be written in another program language.

Code example for client, contacting server with IP address 192.168.0.2:

```
! WaitTime to delay start of client.
! Server application should start first.
WaitTime 5;
VAR socketdev socket1;
VAR string received_string;
PROC main()
    SocketCreate socket1;
    SocketConnect socket1, "192.168.0.2", 1025;
    ! Communication
    SocketSend socket1 \Str:="Hello server";
    SocketReceive socket1 \Str:=received_string;
    TPWrite "Server wrote - " + received_string;
    received_string := "";
    ! Continue sending and receiving
    ...
    ! Shutdown the connection
    SocketSend socket1 \Str:="Shutdown connection";
    SocketReceive socket1 \Str:=received_string;
    TPWrite "Server wrote - " + received_string;
    SocketClose socket1;
ENDPROC
```

8.4. Code examples

Continued

Code example for server (with IP address 192.168.0.2):

```
VAR socketdev temp_socket;
VAR socketdev client_socket;
VAR string received_string;
VAR bool keep_listening := TRUE;
PROC main()
  SocketCreate temp_socket;
  SocketBind temp_socket, "192.168.0.2", 1025;
  SocketListen temp_socket;
  WHILE keep_listening DO
    ! Waiting for a connection request
    SocketAccept temp_socket, client_socket;
    ! Communication
    SocketReceive client_socket \Str:=received_string;
    TPWrite "Client wrote - " + received_string;
    received_string := "";
    SocketSend client_socket \Str:="Message acknowledged";
    ! Shutdown the connection
    SocketReceive client_socket \Str:=received_string;
    TPWrite "Client wrote - " + received_string;
    SocketSend client_socket \Str:="Shutdown acknowledged";
    SocketClose client_socket;
  ENDWHILE
  SocketClose temp_socket;
ENDPROC
```

Example of error handler

The following error handlers will take care of power failure or broken connection.

Error handler for client in previous example:

```
! Error handler to make it possible to handle power fail
ERROR
  IF ERRNO=ERR_SOCK_TIMEOUT THEN
    RETRY;
  ELSEIF ERRNO=ERR_SOCK_CLOSED THEN
    SocketClose socket1;
    ! WaitTime to delay start of client.
    ! Server application should start first.
    WaitTime 10;
    SocketCreate socket1;
    SocketConnect socket1, "192.168.0.2", 1025;
    RETRY;
  ELSE
    TPWrite "ERRNO = "\Num:=ERRNO;
    Stop;
  ENDIF
```

© Copyright 2004-2007 ABB. All rights reserved.

Continues on next page

Error handler for server in previous example:

```
! Error handler for power fail and connection lost
ERROR
  IF ERRNO=ERR_SOCKET_TIMEOUT THEN
    RETRY;
  ELSEIF ERRNO=ERR_SOCKET_CLOSED THEN
    SocketClose temp_socket;
    SocketClose client_socket;
    SocketCreate temp_socket;
    SocketBind temp_socket, "192.168.0.2", 1025;
    SocketListen temp_socket;
    SocketAccept temp_socket, client_socket;
    RETRY;
  ELSE
    TPWrite "ERRNO = "\Num:=ERRNO;
    Stop;
  ENDIF
```

8.4. Code examples

A

actor signals 29, 30
analog signal 35
AND 30, 31
Application protocol 45, 50

B

Backup 42
binary communication 12

C

character based communication 12
ClearIOBuff 13
ClearRawBytes 18
Close 13
CloseDir 22
CopyFile 22
CopyRawBytes 18
cross connections 29

D

DeviceNet 25, 27
digital signals 29
dir 22
directory management 21

E

Ethernet 43, 49
Event recorder 42
Explicit Messaging 26

F

Fieldbus Command Interface 25
file communication 11
file management 21
file structures 21
FileSize 22
FSSize 22
FTP Client 43

G

Group ID 50

I

interrupt 35
iodev 13
IsFile 22
ISignalAI 36
ISignalAO 36

L

Local path 45, 50
logical operations 29

M

MakeDir 22

N

Name 45, 50
NFS Client 49
NOT 31

O

OPC server 42
Open 13
OpenDir 22
OR 30, 31

P

PackDNHeader 26
PackRawBytes 18
Password 45
PC Interface 39

R

RAPID editor 42
raw data 17
rawbytes 18
RawBytesLen 18
ReadAnyBin 13
ReadBin 13
ReadDir 22
ReadNum 13
ReadRawBytes 18
ReadStr 13
ReadStrBin 13
RemoveDir 22
RemoveFile 22
RenameFile 22
resultant signal 29, 30
Rewind 13
RobotStudioOnline 42

S

safety 9
SCWrite 40
serial channel communication 11
Server address 45, 50
Server path 45, 50
Socket Messaging 53
SocketAccept 55
SocketBind 55
SocketClose 55
SocketConnect 55
SocketCreate 55
socketdev 55
SocketGetStatus 56
SocketListen 55
SocketReceive 55
SocketSend 55
socketstatus 55

T

Transmission protocol 45, 50
Trusted 45, 50
Type 45, 50

U

UnpackRawBytes 18
User ID 50
Username 45

W

WebWare 42

Write 13

WriteAnyBin 13

WriteBin 13

WriteRawBytes 18

WriteStrBin 13



ABB Robotics
S-721 68 VÄSTERÅS
SWEDEN
Telephone: +46 (0) 21 344000
Telefax: +46 (0) 21 132592

3HAC020435-001, Revision C, en