

# FCM developers manual

(c) 2013-2014 Fabian Huslik

This work is licensed under the  
Creative Commons Attribution-ShareAlike 4.0 International License.  
To view a copy of this license, visit  
<http://creativecommons.org/licenses/by-sa/4.0/>.

1 Introduction.....	2
2 License.....	3
3 Bootloader.....	4
3.1 USB Drivers.....	4
3.2 Installing USB Bootloader on Board.....	4
4 Building FCM hardware.....	5
4.1 Placement variant Receiver supply.....	5
4.2 Placement variant Optocoupler.....	5
4.3 Placement variant without optocoupler.....	6
4.4 Final assembly.....	6
5 Definitions & Copter Layout.....	7
5.1 Motor layout - top view:.....	7
5.2 Motor turning directions:.....	7
5.3 Axes positive directions for Vehicle:.....	7
5.4 Axes for Board:.....	7
5.5 Servo input scaling.....	7
6 External electrical connection.....	8
7 Installation on Copter.....	9
7.1 Mechanical alignment.....	9
7.2 Magnetometer considerations.....	9
7.3 Vibration considerations.....	9
8 Source code management.....	10
9 Parameter Description.....	11
10 Firmware internals.....	14
10.1 Folder structure.....	14
10.2 Menue editing.....	14
10.3 Adaptations for your copter.....	14
10.4 Building a hex file.....	15
10.5 Communication protocol.....	15
11 Math – some hints.....	16
11.1 The master plan.....	16
11.2 Quaternion math in code.....	16
11.3 How to get the "difference" of two Quaternions.....	16
11.4 How to filter Gyro, Acc and Mag into one "My actual attitude" quaternion:.....	17
11.5 Some other IMU source – just for reference:.....	17
12 BTM222 Hints.....	18
13 Thanks.....	19
14 MbAQ Might be Asked Questions or FAQ.....	20
14.1 What are the blink codes:.....	20
14.2 LSM303DLHC magnetometer not working.....	20
14.3 Whats this nice diagram on the last page?.....	20

# 1 Introduction

This is a rudimentary try to write down, what is going on in FCM.

The most accurate documentation is the source code itself and the schematic with layout.

The only thing, you really can rely on in this document, are the axis definitions in "5 Definitions & Copter Layout".

## 2 License

If not otherwise stated in the source files, most of the code is copyrighted as follows:

Copyright (c) 2008-2014 by Fabian Huslik

other but not less important parts:

MadgwickAHRS / MahonyAHRS: Copyright (c) 2011 by SOH Madgwick

menu: Copyright (c) 2010-2014 by Jörg Schmidt & Fabian Huslik

hottv4: Copyright (c) 08/2012 by Adam Majerczyk

BMP085 driver: Copyright (C) 2009 Bosch Sensortec GmbH

printf: Copyright (c) 2004,2012 Kustaa Nyholm / SpareTimeLabs

ASF Framework: Copyright (c) 2009-2014 Atmel Corporation. All rights reserved.

Mavlink: Copyright Lorenz Meier and contributors

FCM Android: Copyright (c) 2014 Joachim Weishaupt

For all software parts made by Fabian Huslik and Joachim Weishaupt applies:

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <<http://www.gnu.org/licenses/>>.

**License details for each file are specified inside the source files.**

For the documentation and hardware design the following applies:

This work is licensed under the Creative Commons Attribution-ShareAlike 4.0 International License. To view a copy of this license, visit <http://creativecommons.org/licenses/by->

sa/4.0/.

### 3 Bootloader

To activate bootloader, plug in the FCM via USB and THEN power it up. Version 2.1 is not USB powered.

During bootup, the bootloader looks for USB voltage (5V). If USB is found, the bootloader mode is activated and the main application will not start.

- Blue on and green blinking with 5 Hz: waiting for USB
- Blue blinking with 3 Hz: USB serial port connected.
- Red lit: flash write access.
- 3-colour cycling: Application has started.

The USB-waiting-mode will be repeated, if no application is loaded.

To load a hex file, go to FCM\_Manager and click on "connect". If the bootloader responds , the "load HEX file" button gets activated.  
select "load HEX file".

**Do not forget to compile the hex file for YOUR configuration beforehand.**

Adjust settings in config.h

The FCM\_Manager lets you know, when it's finishes with success.

It does only take a few seconds to load the hex file.

When finished, disconnect USB and cycle power supply.

#### 3.1 USB Drivers

The USB drivers are located in the "Bootloader/Bootloader" directory. Just point windows to this directory, if the board is connected for the first time.


#### 3.2 Installing USB Bootloader on Board

Do this in order:

1. Erase the controller
2. Flash the bootloader hex file (in bootloader directory, there is only one)
3. set fuse bootloader flash size to 16kByte.
4. Do not set the BOD fuse, this will be activated in SW!

## 4 Building FCM hardware

The




schematics of the latest hardware are found at:

versions\hardware V2.0 08-2012\hexa2wide.pdf

The "trunk" already contains hardware adaptations for the next version.

FCM consists of two PCBs. The small PCB carries the connectors and is fixed to the big one at the front. Solder the big PCB between the two lower connector rows. Solder the two extra pads at the left (bottom and top)



### 4.1 Placement variant Receiver supply

For SPEKTRUM satellite operation a P-channel MOSFET "T1" is placed, so that the 3.3V supply become switchable by FCM.

To enable 5V supply for the receiver, connect TP24 to the adjacent MOSFET pad. Usually a solder blob will do the job.

### 4.2 Placement variant Optocoupler

For opto version use the small PCB with resistor pads, Place 5x 2k2 resistors before soldering the pin headers. Use only little solder for the pin headers before fixing it to the main PCB.

### ***4.3 Placement variant without optocoupler***

If the optocouplers are not required, do not place them, place instead 5x **2k2** resistors from the TP19..23 test points to the LED Anode pad. The "other" small PCB has to be used, where all supplies are connected. This small PCB also has NO resistor pads.

### ***4.4 Final assembly***

Use a 1 mm piece of ABS to cover the lower part of the PCB. The components are selected for equal height.

Fix the printed paper cover to the small pcb with a little (hot) glue

Shrinkwrap the whole thing.

Fix it to your copter with double-sided foam adhesive as explained in 7 Installation on Copter.

## 5 Definitions & Copter Layout

For a printout of axis definition, see last page of this manual.

### 5.1 Motor layout - top view:

```
(1)      (2)      ^
          X          |
(4)      (3)  dir of flight
```

```
(1) (2)      ^
(6) X (3)      |
(5) (4)  dir of flight
```

### 5.2 Motor turning directions:

```
(+)      (-)      + = right
          X          - = left
(-)      (+)
```

```
(+) (-)      + = right
(-) X (+)      - = left
(+) (-)
```

### 5.3 Axes positive directions for Vehicle:

Axis	Acceleration	Rotation
X:	left to right	around x backward
Y:	back to front	around Y right
Z:	bottom to top	around Z CCW (looking from above)

Rotation directions follow the right hand rule from each axis direction!

### 5.4 Axes for Board:

Connectors for RX and ESCs face into flight direction.

Flat side with CPU faces down.

### 5.5 Servo input scaling

throttle = 1000 = idle - 9000 full

roll: -4000 = right +4000 = left

elev : +4000 nose down -4000 nose up

yaw: -4000 = right +4000 = left



## 6 External electrical connection

### GND is up!

Connect power supply to the "ESC1" connector. Connecting to the Receiver input may fry your board (3.3V-supply in SPEKTRUM version)

From left (seen in flight direction)

( 1 + - ) RC / serial : Receiver with power supply and Serial / PPM or "classic" channel 1

( 4 3 2 ) "classic" channels 2,3,4 or special function

( 1 + - ) The first ESC with BEC, which also supplies the 5V power for the FCM

( 2 + - ) ESC with BEC (supplies only opto)

( 3 + - ) ESC with BEC (supplies only opto)

( 4 + - ) ESC with BEC (supplies only opto)

( 5 + - ) ESC with BEC (supplies only opto)

( 6 + - ) ESC with BEC (supplies only opto)

At the no-opto variant there is obviously no galvanic separation.

The Comm ports are left of the USB connector.

USART0 is up,

USART2 is bottom side.

Pins LTR: GND, rx, tx, +3.3V

Telemetry (no matter which type) goes to the upper connector.

GPS goes to the LOWER connector.

Absolute max total load at all 3.3V outputs is 200 mA.

## **7 Installation on Copter**

### **7.1 Mechanical alignment**

FCM must be installed flat with the RX and motor connectors facing straight forward.

Up to now, there is no rotation offset possible.

Align the FCM perpendicular to vehicle axes. (naah the multiple of axis..)

### **7.2 Magnetometer considerations**

- Absolutely NO current loops on motor / battery / ESC wires
- Twist all wires and ensure equal length
- The bigger the distance of the FCM to the high current wires, the better.
- The influence is reduced with the squared distance.
- Even batteries can emit a significant magnetic field at high currents.

Try in "direct mode" with the fixed copter and watch the magnetometer values using telemetry. They should not move by more than a few percent of the max-min value during motor running.

### **7.3 Vibration considerations**

Vibration has a big effect on sensor performance. Especially the accelerometer will see all vibration.

Signs of a vibration issue could be poor levelling performance.

Therefore some tips to prevent vibration related issues:

- Balance your props as good as possible
- Balance your props in all dimensions (some props have a significant imbalance perpendicular to the blades – the short way, which you wouldn't expect)
- Center your props (some hubs require 0.1mm additional sheet or some tape to center perfectly)
- Mount the FCM on the 2mm white foam (if no problems exist)
- Mount the FCM on 3mm black foam rubber (if there is residual vibration)
- If there is still unresolvable vibration, reduce the area of foam (cut out two stripes or leave a hole at center)
- Do not mount FCM too softly, as it will not directly follow the airframe movement, which leads to oscillation
- A loosened FCM will lead to a uncontrollable vehicle.
- Make sure, that there are no resonances on the airframe. (GPS-Antenna on long pole etc...)

## 8 Source code management

We use github at the location

<https://github.com/fabianhu/FCM/>

If you are allowed to commit to the repo, please feel free to do so.

PLEASE write in commit message, what you did.

Most important stuff in first line, add a '+' at the end of the first line, if you provide a multi-line commit message, which is highly appreciated.

Or use the github facilities to open an issue or a pull request.

If you need an idea, what to do, look at the todo.txt in the base directory (parent of "trunk").

The versions directory is also found there.

## 9 Parameter Description

Default values for small (800g) quad in "()".

The following text is auto-generated out of the Treebuilder.exe !!! The single source for this is the \*.jmdef file.

GYRO PID	Gyroscope based Governor settings
<back>	
Max Integr	Max Integrator windup (4000)
Gov at Max	Governor intensity at max power [%] (20)
Q Gain	Quaternion turn rate (4000)
*Swash as Poti	Use Potis as PID settings for Swash (x&y)
Swash P	(60)
Swash I	(37)
Swash D	(37)
*Yaw as Poti	Use Potis as PID settings for Yaw (z)
Yaw P	(58)
Yaw I	(21)
Yaw D	(16)
NAV	Navigation Governor Parameters
<back>	
NAV Limits	Navigation Governor Parameters
<back>	
Max Angle	The max lean angle in degrees (30)
Max Accel	The max acceleration out of nav in m/s^2 (2)
Speed NAV	the desired cruise speed m/s (5)
Radius NAV	The radius in meters, at which the cruise speed starts
to decelerate (20)	
Speed h	the desired height change speed m/s (5)
Radius h	The radius in meters, at which the height change speed
starts to decelerate (20)	
NAV Filters	Navigation Governor Parameters
<back>	
Acc Flt glob	global acceleration filter value (1000) 1000 is
unfiltered	
alpha H spd	complementary filter for z speed (9990) 10000 is accel
prio	
alpha speed	complementary filter for x/y speed (9990) 10000 is accel
prio	
alpha pos	complementary filter for position (9990) 10000 is accel
prio	
NAV Compensation	Navigation Compensation
<back>	
Comp On	Activate the compensation algorithm
Min Speed	Minimum speed, at which the vectoring calculation starts

(1)

| | Min Time Minimum time en route, after which the vectoring  
calculation starts (5)

| | Filter 100 is unfiltered

| | Min Distance Minimum distance from target to activate the  
compensation

| \*NAV as Poti Use Potis as PID settings

| NAV P (25)

| NAV I (0)

| NAV D (30)

| \*H as Poti Use potis as PID settings for height governor

| H P (4)

| H I (0)

| H D (0)

Settings General settings

| <back>

| Max Power Max throttle (6500)

| Idle Power Min throttle, use above 1500 for idle running props

| Agility fact How aggressive the copter reacts to RC (1-2)

| wait GPS Fix 1 = Flight is only released if GPS is fixed

| No BT222 cfg 1 = skip BTM222 initialisation sequence at start

| Direct Mode 1 = NO Flight control, throttle directly & without  
unlock  
to all ESC!

Use this to calibrate all ESCs at once.

Negative numbers = single motor control, others off

| SPEKTRUM DSMX 1= try bind in DSMX mode

| \*Bnd SPEKTRUM Do bind Spectrum Sattelite at RC-Port

| \*Start Bootloader Go into bootloader mode

Calibration Sensor calibration

| <back>

| Filters Sensor calibration

| | <back>

| | Gyro Filter Gyroscope filter: 1= unfiltered (1)

| | Accel Filter Accelerometer filter: 1= unfiltered (4)

| | Magneto Flt Magnetometer filter: 1= unfiltered (4)

| | Baro Filter Barometer filter: 1000= unfiltered (990)

| | GPS Filter GPS filter: 1000= unfiltered (990)

| \*Calibrate R+A Calibrate Gyro and Accelometer ? put on flat surface!

| Gyro X Gyro calibration value

| Gyro Y Gyro calibration value

| Gyro Z Gyro calibration value

| Acc X Accelometer calibration value

| Acc Y Accelometer calibration value

Acc Z	Accelometer calibration value
MagCal flight	Magnetometer calibration during engines on allowed ? (0)
Mag X	Magnetometer calibration value (via online calibration)
Mag Y	Magnetometer calibration value (via online calibration)
Mag Z	Magnetometer calibration value (via online calibration)
RC Channels	RC channel assignment. Go to diag mode to see results.
<back>	
Sw PosHold	Which channel is used for Pos hold (ch #)
SwP PosHold	At which pos is the function active (0=lo 1=mid 2=hi)
Pos Hold wins over RTH!	
Sw H Gov	Which channel is used for height governor on (ch #)
SwP H Gov	At which pos is the function active (0=lo 1=mid 2=hi)
Sw RTH	Which channel is used for Return To Home (ch #)
SwP RTH	At which pos is the function active (0=lo 1=mid 2=hi)
Sw Aux	Which channel is used for Auxiliary function (ch #)
SwP Aux	At which pos is the function active (0=lo 1=mid 2=hi)
Poti P	Which channel is used for P potmeter
Poti I	Which channel is used for I potmeter
Poti D	Which channel is used for D potmeter
*Save to Flash	Saves all settings & values to flash
*Diag mode	Display diag page (press enter to leave)

## 10 Firmware internals

The "secret" keywords are:

"fixme" for things, that should be fixed soon or require some more analysis.

"todo" for things, that may be unfinished or prepared new features or just have much room for improvements.

All variables starting with "debug" should have no functional meaning and should be removed in the future.

### 10.1 Folder structure

The FCM flight-Software is in "software".

All sources are in "src".

In the long run, all .h and .c files should move into modular sub-folders.

in "src" the following important folders exist:

menu : here is all menu related

modules: here the "beautiful" code is put, that means, it has somehow clear interfaces.

### 10.2 Menue editing

For editing the menu, use ONLY the "Treebuilder.exe" from the software folder.

The menu content is stored in "quadcopter.jmdef".

If changing a node, do not forget to press "change"

If finished with editing, click on generate and save the "quadcopter.jmdef" file over the old one.

After generating, click into the left output window, this will put the content into the windows clipboard. Paste it into the menu\_variant.h file lower part. Some editors (as the Atmel Studio) insert line breaks. You may have to remove these after inserting. You will see on build...

The menu description for each node is also edited in TreeBuilder. It comes out again as comments with the generated code and also as text to be inserted into this document in 9 Parameter Description.

### 10.3 Adaptations for your copter

In the file config.h are some important switches. These are explained there.

The mixing matrix is defined in /src/modules/servo\_out.c. Look at the existing variants.

## ***10.4 Building a hex file***

Use Atmel Studio 6.2.1153 with

Atmel AVR (32 bit) GNU Toolchain – 3.4.2.1057 Version:  
AVR32\_Toolchain\_Version:3.4.2.435 GCC\_VERSION:4.4.7

Atmel Software Framework - 3.19.0.1334

You need to have TortoiseSVN installed for the pre-build script to work.

Do not change any linker or compiler settings, it is working beautifully as adjusted.

The first instruction goes to 0x80004000, The bootloader will jump there for start.

You may switch off the '-pedantic' option, if you get too many warnings. Ignore all warnings, which are telling "... is a GCC extension".

There are some adaptations inside the framework files regarding the trampoline and exception table (scall) – so be careful with updating the framework not to kill the stuff.

## ***10.5 Communication protocol***

Please see FCMCP.ods.

The parameter part of MAVlink is implemented and working.



## 11 Math – some hints


Excellent source for all math in 3D: <http://www.euclideanspace.com/maths/index.htm>

another "primer" for quaternions:

<http://www.cprogramming.com/tutorial/3d/quaternions.html>

### 11.1 The master plan

(copy of New Governor Math.odg)



An efficient orientation filter for inertial and  
inertial/magnetic sensor arrays

Sebastian O.H. Madgwick

April 30, 2010

The most promising source: (LGPL – but not only because of this)  
madgwick\_algorithm\_c.zip with  
madgwick\_internal\_report.pdf

### 11.2 Quaternion math in code

Look at /modules/quaternion.c

### 11.3 How to get the "difference" of two Quaternions

Just "multiply" them.

Which means, take the first rotation and rotate it further by the second.

### ***11.4 How to filter Gyro, Acc and Mag into one "My actual attitude" quaternion:***

Madgwick or Mahony it. There is some sensor fusion involved.


### ***11.5 Some other IMU source – just for reference:***

GPLV3:

<https://code.google.com/p/gentlenav/downloads/list>

## 12 BTM222 Hints

Referring to the BTM222 datasheet for the pinout, solder the following:



This is a TOP view !!!

Put the wires to the bottom! (the 2 – 17 jumper can stay at top)

Pin 2 + Pin17 = 3.3V supply

Pin 29 = GND (all other required GNDS are already connected to the tin shield)

Pin 26 = connect to FCM TX

Pin 27= connect to FCM RX

Pin 37 = connect a wire of more or less exactly 30.7mm measured from the BTM222 edge (cut after soldering)

To clean superfluous com ports:

Create a batch file and execute as admin with:

```
set devmgr_show_nonpresent_devices=1
set devmgr_show_details=1
start DEVMGMT.MSC
```

Then select "show unused devices" and remove the stuff.

## **13 Thanks**

Many thanks go to my great beta testers:

Uli

Joachim

Jörg

Armin

Christian

## **14 MbAQ Might be Asked Questions or FAQ**

### ***14.1 What are the blink codes:***

- red on, blue&green blinking alternating: No RC signal
- running light: not ready (throttle zero, no GPS lock or FCM not level)
- red on and blue&green blinking together: fatal error state: count number of blinks and search for "emstop(n)", where n is the number of blinks.
- Green blinking: ready to be armed with yaw right and throttle 0
- blue steady on: flight; may be disarmed with yaw left and throttle 0

### ***14.2 LSM303DLHC magnetometer not working***

If the LSM303DLHC delivers irregular values (too low, only one axis working or so...):  
check the external capacitor CA2 or CA3. One of these IS failed.  
Thats easier than changing the chip, as I did, which of course didn't solve the problem.

### ***14.3 Whats this nice diagram on the last page?***


That's the truth. Believe it.

We use a ENU orientation for all 3d stuff.

The navigation is done in a x-y = E-N order, where the rotation is right positive.

All this might be changed to the NED standard later.

## 2D Navigation



## 3D Orientation

