


Firmware Update V1.03

TMCL™ FIRMWARE MANUAL



1-axis stepper
controller / driver module
1A RMS / 2.8A RMS
24V DC
USB, RS485

UNIQUE FEATURES:



coolStep™

stallGuard2™

dcStep™
| | | | |

TRINAMIC Motion Control GmbH & Co. KG
Hamburg, Germany

www.trinamic.com



TRINAMIC
MOTION CONTROL

Table of Contents

1	Features.....	4
2	Overview.....	5
3	Putting the Module into Operation.....	6
3.1	Basic Set-up.....	7
3.1.1	Connecting the Module.....	7
3.1.2	Start the TMCL-IDE Software Development Environment.....	9
3.1.3	Using TMCL™ Direct Mode.....	10
3.1.4	Important Motor Settings.....	11
4	TMCL™ and TMCL-IDE.....	13
4.1	Binary Command Format.....	13
4.2	Reply Format.....	14
4.2.1	Status Codes.....	14
4.3	Standalone Applications.....	14
4.3.1	Testing with a Simple TMCL™ Program.....	15
4.4	TMCL™ Command Overview.....	15
4.4.1	TMCL™ Commands.....	15
4.4.2	Commands Listed According to Subject Area.....	16
4.5	Commands.....	20
4.5.1	ROR (rotate right).....	20
4.5.2	ROL (rotate left).....	21
4.5.3	MST (motor stop).....	22
4.5.4	MVP (move to position).....	23
4.5.5	SAP (set axis parameter).....	25
4.5.6	GAP (get axis parameter).....	26
4.5.7	STAP (store axis parameter).....	27
4.5.8	RSAP (restore axis parameter).....	28
4.5.9	SGP (set global parameter).....	29
4.5.10	GGP (get global parameter).....	30
4.5.11	STGP (store global parameter).....	31
4.5.12	RS GP (restore global parameter).....	32
4.5.13	RFS (reference search).....	33
4.5.14	SIO (set output).....	34
4.5.15	GIO (get input/output).....	35
4.5.16	CALC (calculate).....	37
4.5.17	COMP (compare).....	38
4.5.18	JC (jump conditional).....	39
4.5.19	JA (jump always).....	40
4.5.20	CSUB (call subroutine).....	41
4.5.21	RSUB (return from subroutine).....	42
4.5.22	WAIT (wait for an event to occur).....	43
4.5.23	STOP (stop TMCL™ program execution).....	44
4.5.24	SCO (set coordinate).....	45
4.5.25	GCO (get coordinate).....	46
4.5.26	CCO (capture coordinate).....	47
4.5.27	ACO (accu to coordinate).....	48
4.5.28	CALCX (calculate using the X register).....	49
4.5.29	AAP (accumulator to axis parameter).....	50
4.5.30	AGP (accumulator to global parameter).....	51
4.5.31	CLE (clear error flags).....	52
4.5.32	VECT (set interrupt vector).....	53
4.5.33	EI (enable interrupt).....	54
4.5.34	DI (disable interrupt).....	55
4.5.35	RETI (return from interrupt).....	56
4.5.36	Customer Specific TMCL™ Command Extension (UF0... UF7 - User Function).....	56
4.5.37	Request Target Position Reached Event.....	57
4.5.38	TMCL™ Control Functions.....	58

5	Axis Parameters.....	59
5.1	stallGuard2™ Related Parameters.....	65
5.2	coolStep™ Related Parameters	67
5.3	Reference Search.....	69
5.3.1	Reference Search Modes (Axis Parameter 193)	70
5.4	Encoder	72
5.4.1	Changing the Prescaler Value of an Encoder.....	72
5.5	Calculation: Velocity and Acceleration vs. Microstep- and Fullstep-Frequency	73
5.5.1	Microstep Frequency.....	74
5.5.2	Fullstep Frequency	74
6	Global Parameters	76
6.1	Bank 0	76
6.2	Bank 1	78
6.3	Bank 2	78
6.4	Bank 3	79
7	TMCL™ Programming Techniques and Structure.....	80
7.1	Initialization	80
7.2	Main Loop	80
7.3	Using Symbolic Constants.....	80
7.4	Using Variables.....	81
7.5	Using Subroutines	81
7.6	Mixing Direct Mode and Standalone Mode.....	82
8	Life Support Policy.....	83
9	Revision History	84
9.1	Firmware Revision.....	84
9.2	Document Revision	84
10	References.....	85

1 Features

The TMCM-1110 stepRocker is a single axis motor controller/driver board for 2-phase bipolar stepper motors. It features the TRINAMIC controller/driver chain consisting of TMC429 and TMC262 in combination with a Samsung S3FN41F processor. The Module is intended to be a fully functional development platform. A stepRocker can be extended to a full 3-axes system using two additional boards, because the TMCM-1110 stepRocker board can be both, master or slave.

Software wise two different approaches are possible: it is possible to use the stepRocker with the TrinamicMotionControlLanguage TMCL™. The board comes with the preinstalled firmware. The integrated development environment TMCL-IDE for PC can be downloaded and used free of charge. It is possible to remote control the stepRocker or to write and download complete command sequences for standalone use.

The alternative is to write the firmware for the microcontroller using downloadable software tools and motion control libraries (refer to www.motioncontrol-community.org).

Applications

- Highly compact single axis stepper motor controller/driver board for 2-phase bipolar stepper motors
- 2- and 3-axis systems using additional boards as slaves

Electrical data

- Supply voltage: +24V DC (+10... +30V DC)
- Motor current: up to 1A RMS or 2.8A RMS (can be selected with jumpers)

Mechanical data

- Board size: 85mm x 55mm, height 15mm max. without mating connectors
- 4 mounting holes for M3 screws

Interfaces

- RS485 host interface
- USB 2.0 host interface (mini-USB connector)
- Step/Dir input (TTL level)
- Step/Dir outputs (TTL level) for multi axis applications
- 3 multi-purpose inputs (can be used for ABN-encoder)
- 2 limit switch inputs per motor
- 6 multi-purpose I/Os
- 2 open-drain outputs
- µC programming interface SWD (single wire debug / pads on PCB)
- Retro-fit option: CAN 2.0B communication interface

Features

- TMC429 stepper motor controller IC for on-the-fly alteration of many motion specific parameters
- TMC262 advanced stepper motor driver IC with stallGuard2™ and coolStep™ features. Using the spreadCycle chopper the µstep current sine wave is well formed with smooth zero crossing.
- Ready for dcStep™
- Up to 256 microsteps per fullstep through microPlyer technology
- 2 x end switch for all three axes.
- EEPROM

Software

- TMCL™ remote (direct mode) and standalone operation (memory for up to 2048 TMCL™ commands)
- Fully supported by TMCL-IDE (PC based integrated development environment)

Please note that the TMCM-1110 stepRocker can be used with a special TMCL™ firmware version with its source codes in order to provide new developments, too. Here is your platform for individual TMCL™ extensions: www.motioncontrol-community.org or www.steprocker.com.

2 Overview

The software running on the microprocessor of the TMC-1110 consists of two parts, a boot loader and the firmware itself. Whereas the boot loader is installed during production and testing at TRINAMIC and remains untouched throughout the whole lifetime, the firmware can be updated by the user. New versions can be downloaded free of charge from the TRINAMIC website (<http://www.trinamic.com>).

The firmware is related to the standard TMCL™ firmware with regard to protocol and commands. Corresponding, this module is based on the TMC429 stepper motor controller and the TMC262 power driver and supports the standard TMCL™ with a special range of values.

The TMC262 is a new energy efficient high current high precision microstepping driver IC for bipolar stepper motors and offers TRINAMICs patented coolStep™ feature with its special commands. Please mind this technical innovation.

All commands and parameters available with this unit are explained on the following pages.

3 Putting the Module into Operation

In this chapter you will find basic information for putting your module into operation. This includes a simple example for a TMCL™ program and a short description of operating the module in direct mode.

The stepRocker is able to control up to three motors. In this chapter it is explained how to start with one motor (motor number 0), only. If you want to use the module for controlling more motors, refer to the Hardware Manual, please. There you will find information about extensions.

THINGS YOU NEED

- TMC-1110 with appropriate stepper motor (e.g. QSH4218)
- Interface (RS485 or USB) suitable to your TMC-1110 module
- Nominal supply voltage +24V DC (+9... +28V DC) for your module
- TMCL-IDE program (can be downloaded free of charge from www.trinamic.com. Please refer to the TMCL-IDE User Manual, too)
- Appropriate cables – at least for power supply, communication and motor

PRECAUTIONS

Do not mix up connections or short-circuit pins.
Avoid bounding I/O wires with motor power wires.
Do not exceed the maximum power supply of +30V DC!
Do not connect or disconnect the motor while powered on!
START WITH POWER SUPPLY OFF!




Figure 3.1: TMC-1110 stepRocker connectors

3.1 Basic Set-up

The following paragraph will guide you through the steps of connecting the unit and making first movements with the motor.

3.1.1 Connecting the Module

For first steps you will need a power supply and a communication between PC and one of the serial interfaces of the module (RS485 or USB). If you are interested in detailed pin assignments, please refer to the TMC-1110 Hardware Manual.

Please note: later on it is perfectly possible to operate the unit as standalone device, using the available inputs and outputs for control.

3.1.1.1 Communication

Choose your communication interface out of the interfaces: RS485 or USB.

3.1.1.1.1 RS485

Connect the RS485 interface with the appropriate connector (see Figure 3.1)

RS485 as field bus interface normally requires an adapter. From TRINAMIC the USB-2-485 converter between USB and RS485 is available.

Label	Connector type	Mating connector type
RS485	Low profile box header without locking bar, type 8380, 10 pol., DIN 41651, 2.54mm pitch	Low profile IDC socket connector, 10pol., DIN41651, 2.54mm pitch

3.1.1.1.2 USB

Before using the USB interface the device driver has to be installed (available on www.trinamic.com).

Label	Connector type	Mating connector type
Mini-USB connector	Molex 500075-1517 Mini USB Type B vertical receptacle	Any standard mini-USB plug

3.1.1.2 Motor

The TMC-1110 controls one 2-phase stepper motor. Connect one coil of the motor to the terminal marked A0 and A1 and the other coil to the connector marked B0 and B1.

Before connecting a motor please make sure which cable belongs to which coil. Wrong connections may lead to damage of the driver chips or the motor!

Label	Connector type	Mating connector type
Motor	RIA 183-04, 4 pol., 3.5mm pitch, shrouded header	RIA 169-04, screw type terminal block, pluggable, centerline 3.5mm pitch




Figure 3.2: Motor connection

3.1.1.3 Power Supply

Connect the power supply with the power supply connector (see Figure 3.1), but start with power supply OFF.

Take care of the polarity, wrong polarity can destroy the board!

Do not exceed the maximum power supply of +30V DC!

Label	Connector type	Mating connector type
Power	RIA 220-02, 2 pol., 5.08mm pitch, shrouded header	RIA 249-02, screw type terminal block, pluggable, centerline 5.08mm pitch

3.1.1.4 Reference / Home Switches

Connect the switches with the appropriate connectors if needed.

Please refer to the Hardware Manual for more information about the reference switch connectors.

Label	Connector type	Mating connector type
Ref. switches	Multi-pin-connector, 7 pol., 2.54mm pitch	Female connector with 2.54mm pitch

3.1.1.5 I/Os

Connect inputs and outputs with the appropriate connectors (see Figure 3.1), if you want to use them.

Please refer to the Hardware Manual for more information about the I/O connectors.

Label	Connector type	Mating connector type
GPIO	Multi-pin-connector, 14 pol., 2.54mm pitch	Female connector with 2.54mm pitch

3.1.2 Start the TMCL-IDE Software Development Environment


The TMCL-IDE is available on www.trinamic.com.

Installing the TMCL-IDE:


Make sure the COM port you intend to use is not blocked by another program.

Open TMCL-IDE by clicking **TMCL.exe**.

Choose **Setup** and **Options** and thereafter the **Connection tab**.




For RS485 choose **COM port** and **Type** with the parameters shown below (baud rate 9600). Click **OK**.



Please refer to the *TMCL-IDE User Manual* for more information about connecting the other interfaces (www.TRINAMIC.com).

3.1.3 Using TMCL™ Direct Mode

Start TMCL™ *Direct Mode*.



If the communication is established the TMCM-1110 is automatically detected.

If the module is not detected, please check cables, interface, power supply, COM port, and baud rate.

Issue a command by choosing **Instruction**, **Type** (if necessary), **Motor**, and **Value** and click **Execute** to send it to the module.

ATTENTION

As the TMCM-1110 stepRocker is able to control up to three motors the motor numbers for the three motors are 0, 1, and 2. If only one motor is connected the motor number is always 0.

Address	Instruction	Type	Motor/Bank	Value	Datagram:
1	1	0	0	2040	01 01 00 00 00 00 07 F8 01

Host	Target	Status	Instr.	Value	Datagram:
2	1	100	1	2040	02 01 64 01 00 00 07 F8 67

Examples:

- ROR rotate right, motor 0, value 500 -> Click *Execute*. The first motor is rotating now.
- MST motor stop, motor 0 -> Click *Execute*. The first motor stops now.

Top right of the *TMCL Direct Mode* window is the button *Copy to editor*. Click here to copy the chosen command and create your own TMCL™ program. The command will be shown immediately on the editor.

3.1.4 Important Motor Settings

There are some axis parameters which have to be adjusted right in the beginning after installing your module. Please set the upper limiting values for the speed (axis parameter 4), the acceleration (axis parameter 5), and the current (axis parameter 6). Further set the standby current (axis parameter 7) and choose your microstep resolution with axis parameter 140.

Use the *SAP (Set Axis Parameter)* command for adjusting these values. The SAP command is described in paragraph 4.5.5. You can use the TMC-IDE direct mode for easily configuring your module.

ATTENTION

The most important motor setting is the *absolute maximum motor current* setting, since too high values might cause motor damage!

IMPORTANT AXIS PARAMETERS FOR MOTOR SETTING

Number	Axis Parameter	Description	Range [Unit]																																								
4	maximum positioning speed	Should not exceed the physically highest possible value. Adjust the pulse divisor (axis parameter 154), if the speed value is very low (<50) or above the upper limit. See TMC 429 datasheet for calculation of physical units or use the TMCL-IDE calculation tool.	0... 2047 $\left[\frac{16\text{MHz}}{65536} \cdot 2^{\text{PD}} \frac{\mu\text{steps}}{\text{sec}} \right]$																																								
5	maximum acceleration	The limit for acceleration and deceleration. Changing this parameter requires re-calculation of the acceleration factor and the acceleration divisor. Therefore adjust the ramp divisor (axis parameter 153) carefully in steps of one. See TMC 429 datasheet for calculation of physical units or use the TMCL-IDE calculation tool.	0... 2047* ¹																																								
6	absolute max. current (CS / Current Scale)	<p>The maximum value is 255. This value means 100% of the maximum current of the module. The current adjustment is within the range 0... 255 and can be adjusted in 32 steps.</p> <table border="1"> <tr><td>0... 7</td><td>79... 87</td><td>160... 167</td><td>240... 247</td></tr> <tr><td>8... 15</td><td>88... 95</td><td>168... 175</td><td>248... 255</td></tr> <tr><td>16... 23</td><td>96... 103</td><td>176... 183</td><td></td></tr> <tr><td>24... 31</td><td>104... 111</td><td>184... 191</td><td></td></tr> <tr><td>32... 39</td><td>112... 119</td><td>192... 199</td><td></td></tr> <tr><td>40... 47</td><td>120... 127</td><td>200... 207</td><td></td></tr> <tr><td>48... 55</td><td>128... 135</td><td>208... 215</td><td></td></tr> <tr><td>56... 63</td><td>136... 143</td><td>216... 223</td><td></td></tr> <tr><td>64... 71</td><td>144... 151</td><td>224... 231</td><td></td></tr> <tr><td>72... 79</td><td>152... 159</td><td>232... 239</td><td></td></tr> </table> <p>The unit of the current is adequate to the chosen motor current (with or without jumper). <i>The most important motor setting, since too high values might cause motor damage!</i></p>	0... 7	79... 87	160... 167	240... 247	8... 15	88... 95	168... 175	248... 255	16... 23	96... 103	176... 183		24... 31	104... 111	184... 191		32... 39	112... 119	192... 199		40... 47	120... 127	200... 207		48... 55	128... 135	208... 215		56... 63	136... 143	216... 223		64... 71	144... 151	224... 231		72... 79	152... 159	232... 239		0... 255 <i>Without jumpers:</i> $I_{\text{peak}} = < \text{value} > \times \frac{1.5\text{A}}{255}$ $I_{\text{RMS}} = < \text{value} > \times \frac{1\text{A}}{255}$ <i>Jumpers set:</i> $I_{\text{peak}} = < \text{value} > \times \frac{4\text{A}}{255}$ $I_{\text{RMS}} = < \text{value} > \times \frac{2.8\text{A}}{255}$
0... 7	79... 87	160... 167	240... 247																																								
8... 15	88... 95	168... 175	248... 255																																								
16... 23	96... 103	176... 183																																									
24... 31	104... 111	184... 191																																									
32... 39	112... 119	192... 199																																									
40... 47	120... 127	200... 207																																									
48... 55	128... 135	208... 215																																									
56... 63	136... 143	216... 223																																									
64... 71	144... 151	224... 231																																									
72... 79	152... 159	232... 239																																									
7	standby current	<p>The current limit two seconds after the motor has stopped.</p> <p>The unit of the current is adequate to the chosen motor current (with or without jumper).</p>	0... 255 <i>Without jumpers:</i> $I_{\text{peak}} = < \text{value} > \times \frac{1.5\text{A}}{255}$ $I_{\text{RMS}} = < \text{value} > \times \frac{1\text{A}}{255}$ <i>Jumpers set:</i> $I_{\text{peak}} = < \text{value} > \times \frac{4\text{A}}{255}$ $I_{\text{RMS}} = < \text{value} > \times \frac{2.8\text{A}}{255}$																																								

Number	Axis Parameter	Description	Range [Unit]
140	microstep resolution	0 full step	0.. 8
		1 half step	
		2 4 microsteps	
		3 8 microsteps	
		4 16 microsteps	
		5 32 microsteps	
		6 64 microsteps	
		7 128 microsteps	
		8 256 microsteps	

*1 Unit of acceleration: $\frac{16\text{MHz}^2}{536870912 \cdot 2^{\text{puls_divisor} + \text{ramp_divisor}}} \frac{\text{microsteps}}{\text{sec}^2}$

4 TMCL™ and TMCL-IDE

The TMC-1110 supports TMCL™ direct mode (binary commands) and standalone TMCL™ program execution. You can store up to 2048 TMCL™ instructions on it.

In direct mode and most cases the TMCL™ communication over RS485 or USB follows a strict master/slave relationship. That is, a host computer (e.g. PC/PLC) acting as the interface bus master will send a command to the TMC-1110. The TMCL™ interpreter on the module will then interpret this command, do the initialization of the motion controller, read inputs and write outputs or whatever is necessary according to the specified command. As soon as this step has been done, the module will send a reply back over RS485/USB to the bus master. Only then should the master transfer the next command. Normally, the module will just switch to transmission and occupy the bus for a reply, otherwise it will stay in receive mode. It will not send any data over the interface without receiving a command first. This way, any collision on the bus will be avoided when there are more than two nodes connected to a single bus.

The Trinamic Motion Control Language [TMCL™] provides a set of structured motion control commands. Every motion control command can be given by a host computer or can be stored in an EEPROM on the TMC module to form programs that run standalone on the module. For this purpose there are not only motion control commands but also commands to control the program structure (like conditional jumps, compare and calculating).

Every command has a binary representation and a mnemonic. The binary format is used to send commands from the host to a module in direct mode, whereas the mnemonic format is used for easy usage of the commands when developing standalone TMCL™ applications using the TMCL-IDE (IDE means *Integrated Development Environment*).

There is also a set of configuration variables for the axis and for global parameters which allow individual configuration of nearly every function of a module. This manual gives a detailed description of all TMCL™ commands and their usage.

4.1 Binary Command Format

When commands are sent from a host to a module, the binary format has to be used. Every command consists of a one-byte command field, a one-byte type field, a one-byte motor/bank field and a four-byte value field. So the binary representation of a command always has seven bytes. When a command is to be sent via RS485 or USB interface, it has to be enclosed by an address byte at the beginning and a checksum byte at the end. In this case it consists of nine bytes.

This is different when communicating is via the CAN bus. Address and checksum are included in the CAN standard and do not have to be supplied by the user.

The binary command format for RS485/USB is as follows:

Bytes	Meaning
1	Module address
1	Command number
1	Type number
1	Motor or Bank number
4	Value (MSB first!)
1	Checksum

- The checksum is calculated by adding up all the other bytes using an 8-bit addition.
- When using CAN bus, just leave out the first byte (module address) and the last byte (checksum).

Checksum calculation

As mentioned above, the checksum is calculated by adding up all bytes (including the module address byte) using 8-bit addition. Here are two examples to show how to do this:

in C:

```
unsigned char i, Checksum;
unsigned char Command[9];

//Set the "Command" array to the desired command
Checksum = Command[0];
for(i=1; i<8; i++)
    Checksum+=Command[i];

Command[8]=Checksum; //insert checksum as last byte of the command
//Now, send it to the module
```

4.2 Reply Format

Every time a command has been sent to a module, the module sends a reply.

The reply format for RS485/USB is as follows:

Bytes	Meaning
1	Reply address
1	Module address
1	Status (e.g. 100 means "no error")
1	Command number
4	Value (MSB first!)
1	Checksum

- The checksum is also calculated by adding up all the other bytes using an 8-bit addition.
- When using CAN bus, the first byte (reply address) and the last byte (checksum) are left out.
- Do not send the next command before you have received the reply!

4.2.1 Status Codes

The reply contains a status code. The status code can have one of the following values:

Code	Meaning
100	Successfully executed, no error
101	Command loaded into TMCL™ program EEPROM
1	Wrong checksum
2	Invalid command
3	Wrong type
4	Invalid value
5	Configuration EEPROM locked
6	Command not available

4.3 Standalone Applications

The module is equipped with an EEPROM for storing TMCL™ applications. You can use the TMCL-IDE for developing standalone TMCL™ applications. You can load them down into the EEPROM and then it will run on the module. The TMCL-IDE contains an editor and the TMCL™ assembler where the commands can be entered using their mnemonic format. They will be assembled automatically into their binary representations. Afterwards this code can be downloaded into the module to be executed there.

4.3.1 Testing with a Simple TMCL™ Program


Open the file test2.tmc of the TMCL-IDE. The test program is written for three motors. Change the motor numbers into 0, if only one motor is connected.

Now, the test program looks as follows:

```
//A simple example for using TMCL™ and TMCL-IDE

ROL 0, 500           //Rotate motor 0 with speed 500
WAIT TICKS, 0, 500
MST 0
ROR 0, 250           //Rotate motor 0 with 250
WAIT TICKS, 0, 500
MST 0

SAP 4, 0, 500        //Set max. Velocity
SAP 5, 0, 50         //Set max. Acceleration
Loop: MVP ABS, 0, 10000 //Move to Position 10000
      WAIT POS, 0, 0    //Wait until position reached
      MVP ABS, 0, -10000 //Move to Position -10000
      WAIT POS, 0, 0    //Wait until position reached
      JA Loop           //Infinite Loop
```



1. Click on Icon **Assemble** to convert the TMCL™ into machine code.
2. Then download the program to the TMC-1110 module via the icon **Download**.
3. Press icon **Run**. The desired program will be executed.
4. Click **Stop** button to stop the program.

4.4 TMCL™ Command Overview

In this section a short overview of the TMCL™ commands is given.

4.4.1 TMCL™ Commands

Command	Number	Parameter	Description
ROR	1	<motor number>, <velocity>	Rotate right with specified velocity
ROL	2	<motor number>, <velocity>	Rotate left with specified velocity
MST	3	<motor number>	Stop motor movement
MVP	4	ABS REL COORD, <motor number>, <position offset>	Move to position (absolute or relative)
SAP	5	<parameter>, <motor number>, <value>	Set axis parameter (motion control specific settings)
GAP	6	<parameter>, <motor number>	Get axis parameter (read out motion control specific settings)
STAP	7	<parameter>, <motor number>	Store axis parameter permanently (non volatile)
RSAP	8	<parameter>, <motor number>	Restore axis parameter
SGP	9	<parameter>, <bank number>, value	Set global parameter (module specific settings e.g. communication settings or TMCL™ user variables)

Command	Number	Parameter	Description
GGP	10	<parameter>, <bank number>	Get global parameter (read out module specific settings e.g. communication settings or TMCL™ user variables)
STGP	11	<parameter>, <bank number>	Store global parameter (TMCL™ user variables only)
RS GP	12	<parameter>, <bank number>	Restore global parameter (TMCL™ user variable only)
RFS	13	START STOP STATUS, <motor number>	Reference search
SIO	14	<port number>, <bank number>, <value>	Set digital output to specified value
GIO	15	<port number>, <bank number>	Get value of analogue/digital input
CALC	19	<operation>, <value>	Process accumulator & value
COMP	20	<value>	Compare accumulator <-> value
JC	21	<condition>, <jump address>	Jump conditional
JA	22	<jump address>	Jump absolute
CSUB	23	<subroutine address>	Call subroutine
RSUB	24		Return from subroutine
EI	25	<interrupt number>	Enable interrupt
DI	26	<interrupt number>	Disable interrupt
WAIT	27	<condition>, <motor number>, <ticks>	Wait with further program execution
STOP	28		Stop program execution
SCO	30	<coordinate number>, <motor number>, <position>	Set coordinate
GCO	31	<coordinate number>, <motor number>	Get coordinate
CCO	32	<coordinate number>, <motor number>	Capture coordinate
CALCX	33	<operation>	Process accumulator & X-register
AAP	34	<parameter>, <motor number>	Accumulator to axis parameter
AGP	35	<parameter>, <bank number>	Accumulator to global parameter
VECT	37	<interrupt number>, <label>	Set interrupt vector
RETI	38		Return from interrupt
ACO	39	<coordinate number>, <motor number>	Accu to coordinate

4.4.2 Commands Listed According to Subject Area

4.4.2.1 Motion Commands

These commands control the motion of the motor. They are the most important commands and can be used in direct mode or in standalone mode.

Mnemonic	Command number	Meaning
ROL	2	Rotate left
ROR	1	Rotate right
MVP	4	Move to position
MST	3	Motor stop
RFS	13	Reference search
SCO	30	Store coordinate
CCO	32	Capture coordinate
GCO	31	Get coordinate

4.4.2.2 Parameter Commands

These commands are used to set, read and store axis parameters or global parameters. Axis parameters can be set independently for the axis, whereas global parameters control the behavior of the module itself. These commands can also be used in direct mode and in standalone mode.

Mnemonic	Command number	Meaning
SAP	5	Set axis parameter
GAP	6	Get axis parameter
STAP	7	Store axis parameter into EEPROM
RSAP	8	Restore axis parameter from EEPROM
SGP	9	Set global parameter
GGP	10	Get global parameter
STGP	11	Store global parameter into EEPROM
RSGP	12	Restore global parameter from EEPROM

4.4.2.3 Control Commands

These commands are used to control the program flow (loops, conditions, jumps etc.). It does not make sense to use them in direct mode. They are intended for standalone mode only.

Mnemonic	Command number	Meaning
JA	22	Jump always
JC	21	Jump conditional
COMP	20	Compare accumulator with constant value
CSUB	23	Call subroutine
RSUB	24	Return from subroutine
WAIT	27	Wait for a specified event
STOP	28	End of a TMCL™ program

4.4.2.4 I/O Port Commands

These commands control the external I/O ports and can be used in direct mode and in standalone mode.

Mnemonic	Command number	Meaning
SIO	14	Set output
GIO	15	Get input

4.4.2.5 Calculation Commands

These commands are intended to be used for calculations within TMCL™ applications. Although they could also be used in direct mode it does not make much sense to do so.

Mnemonic	Command number	Meaning
CALC	19	Calculate using the accumulator and a constant value
CALCX	33	Calculate using the accumulator and the X register
AAP	34	Copy accumulator to an axis parameter
AGP	35	Copy accumulator to a global parameter
ACO	39	Copy accu to coordinate

For calculating purposes there is an accumulator (or accu or A register) and an X register. When executed in a TMCL™ program (in standalone mode), all TMCL™ commands that read a value store the result in the accumulator. The X register can be used as an additional memory when doing calculations. It can be loaded from the accumulator.

When a command that reads a value is executed in direct mode the accumulator will not be affected. This means that while a TMCL™ program is running on the module (standalone mode), a host can still send commands like GAP and GGP to the module (e.g. to query the actual position of the motor) without affecting the flow of the TMCL™ program running on the module.

4.4.2.6 Interrupt Commands

Due to some customer requests, interrupt processing has been introduced in the TMCL™ firmware for ARM based modules.

Mnemonic	Command number	Meaning
EI	25	Enable interrupt
DI	26	Disable interrupt
VECT	37	Set interrupt vector
RETI	38	Return from interrupt

4.4.2.6.1 Interrupt Types:

There are many different interrupts in TMCL™, like timer interrupts, stop switch interrupts, position reached interrupts, and input pin change interrupts. Each of these interrupts has its own interrupt vector. Each interrupt vector is identified by its interrupt number. Please use the TMCL™ included file *Interrupts.inc* for symbolic constants of the interrupt numbers.

4.4.2.6.2 Interrupt Processing:

When an interrupt occurs and this interrupt is enabled and a valid interrupt vector has been defined for that interrupt, the normal TMCL™ program flow will be interrupted and the interrupt handling routine will be called. Before an interrupt handling routine gets called, the context of the normal program will be saved automatically (i.e. accumulator register, X register, TMCL™ flags).

There is no interrupt nesting, i.e. all other interrupts are disabled while an interrupt handling routine is being executed.

On return from an interrupt handling routine, the context of the normal program will automatically be restored and the execution of the normal program will be continued.

4.4.2.6.3 Interrupt Vectors:

The following table shows all interrupt vectors that can be used.

Interrupt number	Interrupt type
0	Timer 0
1	Timer 1
2	Timer 2
3	Target position reached 0
4	Target position reached 1
5	Target position reached 2
15	stallGuard™ axis 0
21	Deviation axis 0
27	Left stop switch 0
28	Right stop switch 0
29	Left stop switch 1
30	Right stop switch 1
31	Left stop switch 2
32	Right stop switch 2
39	Input change 0
40	Input change 1
41	Input change 2
42	Input change 3
255	Global interrupts

4.4.2.6.4 Further Configuration of Interrupts

Some interrupts need further configuration (e.g. the timer interval of a timer interrupt). This can be done using SGP commands with parameter bank 3 (SGP <type>, 3, <value>). Please refer to the SGP command (paragraph 4.5.9) for further information about that.

4.4.2.6.5 Using Interrupts in TMCL™

To use an interrupt the following things have to be done:

- Define an interrupt handling routine using the VECT command.
- If necessary, configure the interrupt using an SGP <type>, 3, <value> command.
- Enable the interrupt using an EI <interrupt> command.
- Globally enable interrupts using an EI 255 command.
- An interrupt handling routine must always end with a RETI command

The following example shows the use of a timer interrupt:

```

    VECT 0, TimeroIrq //define the interrupt vector
    SGP 0, 3, 1000    //configure the interrupt: set its period to 1000ms
    EI 0              //enable this interrupt
    EI 255            //globally switch on interrupt processing

//Main program: toggles output 3, using a WAIT command for the delay
Loop:
    SIO 3, 2, 1
    WAIT TICKS, 0, 50
    SIO 3, 2, 0
    WAIT TICKS, 0, 50
    JA Loop

//Here is the interrupt handling routine
TimeroIrq:
    GIO 0, 2          //check if OUTo is high
    JC NZ, OutoOff    //jump if not
    SIO 0, 2, 1        //switch OUTo high
    RETI              //end of interrupt
OutoOff:
    SIO 0, 2, 0        //switch OUTo low
    RETI              //end of interrupt

```

In the example above, the interrupt numbers are used directly. To make the program better readable use the provided include file *Interrupts.inc*. This file defines symbolic constants for all interrupt numbers which can be used in all interrupt commands. The beginning of the program above then looks like the following:

```

#include Interrupts.inc
    VECT TI_TIMERo, TimeroIrq
    SGP TI_TIMERo, 3, 1000
    EI TI_TIMERo
    EI TI_GLOBAL

```

Please also take a look at the other example programs.

4.5 Commands

The module specific commands are explained in more detail on the following pages. They are listed according to their command number.

4.5.1 ROR (rotate right)

The motor will be instructed to rotate with a specified velocity in *right* direction (increasing the position counter).

Internal function: first, velocity mode is selected. Then, the velocity value is transferred to axis parameter #2 (*target velocity*).

The module is based on the TMC429 stepper motor controller and the TMC262 power driver. This makes possible choosing a velocity between 0 and 2047.

Related commands: ROL, MST, SAP, GAP

Mnemonic: ROR <motor number>, <velocity>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
1	don't care	<motor number> 0... 2	<velocity> 0... 2047

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

Example:

Rotate right motor 0, velocity = 350

Mnemonic: ROR 0, 350

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$01	\$00	\$00	\$00	\$00	\$01	\$5e

4.5.2 ROL (rotate left)

With this command the motor will be instructed to rotate with a specified velocity (opposite direction compared to ROR, decreasing the position counter).

Internal function: first, velocity mode is selected. Then, the velocity value is transferred to axis parameter #2 (*target velocity*).

The module is based on the TMC429 stepper motor controller and the TMC262 power driver. This makes possible choosing a velocity between 0 and 2047.

Related commands: ROR, MST, SAP, GAP

Mnemonic: ROL <motor number>, <velocity>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
2	don't care	<motor number> 0... 2	<velocity> 0... 2047

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

Example:

Rotate left motor 0, velocity = 1200

Mnemonic: ROL 0, 1200

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$02	\$00	\$00	\$00	\$00	\$04	\$b0

4.5.3 MST (motor stop)

The motor will be instructed to stop.

Internal function: the axis parameter *target velocity* is set to zero.

Related commands: ROL, ROR, SAP, GAP

Mnemonic: MST <motor number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
3	don't care	<motor number> 0... 2	don't care

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

Example:

Stop motor 0

Mnemonic: MST 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$03	\$00	\$00	\$00	\$00	\$00	\$00

4.5.4 MVP (move to position)

The motor will be instructed to move to a specified relative or absolute position or a pre-programmed coordinate. It will use the acceleration/deceleration ramp and the positioning speed programmed into the unit. This command is non-blocking – that is, a reply will be sent immediately after command interpretation and initialization of the motion controller. Further commands may follow without waiting for the motor reaching its end position. The maximum velocity and acceleration are defined by axis parameters #4 and #5.

The range of the MVP command is 32 bit signed ($-2.147.483.648... +2.147.483.647$). Positioning can be interrupted using MST, ROL or ROR commands.

Attention:

- Please note, that the distance between the actual position and the new one should not be more than $2.147.483.647 (2^{31}-1)$ microsteps. Otherwise the motor will run in the opposite direction in order to take the shorter distance.

Two operation types are available:

- Moving to an absolute position in the range from $-2.147.483.648... +2.147.483.647 (-2^{31}... 2^{31}-1)$.
- Starting a relative movement by means of an offset to the actual position. In this case, the new resulting position value must not exceed the above mentioned limits, too.

Internal function: A new position value is transferred to the axis parameter #0 *target position*.

Related commands: SAP, GAP, SCO, CCO, GCO, MST

Mnemonic: MVP <ABS|REL|COORD>, <motor number>, <position|offset|coordinate number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
4	0 ABS – absolute	<motor number> 0... 2	<position>
	1 REL – relative		<offset>
	2 COORD – coordinate		<coordinate number> 0... 20

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

Example:

Move motor 0 to (absolute) position 90000

Mnemonic: MVP ABS, 0, 9000

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$04	\$00	\$00	\$00	\$01	\$5f	\$90

Example:

Move motor 0 from current position 1000 steps backward (move relative -1000)

Mnemonic: MVP REL, 0, -1000

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$04	\$01	\$00	\$ff	\$ff	\$fc	\$18

Example:

Move motor 0 to previously stored coordinate #8

Mnemonic: MVP COORD, 0, 8

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$04	\$02	\$00	\$00	\$00	\$00	\$08

When moving to a coordinate, the coordinate has to be set properly in advance with the help of the SCO, CCO or ACO command.

4.5.5 SAP (set axis parameter)

Most of the motion control parameters of the module can be specified with the SAP command. The settings will be stored in SRAM and therefore are volatile. That is, information will be lost after power off. **Please use command STAP (store axis parameter) in order to store any setting permanently.**

Internal function: the parameter format is converted ignoring leading zeros (or ones for negative values). The parameter is transferred to the correct position in the appropriate device.

Related commands: GAP, STAP, RSAP, AAP

Mnemonic: SAP <parameter number>, <motor number>, <value>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
5	<parameter number>	<motor number> 0... 2	<value>

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

For a table with parameters and values which can be used together with this command please refer to chapter 5.

Example:

Set the absolute maximum current of motor to 200mA

Because of the current unit $I_{RMS} = \langle \text{value} \rangle \times \frac{1A}{255}$ *) the 200mA setting has the <value> 51 (value range for current setting: 0... 255). The value for current setting has to be calculated before using this special SAP command.

Mnemonic: SAP 6, 0, 47

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$05	\$06	\$00	\$00	\$00	\$00	\$2f

*) Other current units are possible because the motor current can be chosen by jumper. Please refer to chapter 5 for further information about the current unit and to the Hardware Manual for information about using jumpers.

4.5.6 GAP (get axis parameter)

Most parameters of the TMC1110 can be adjusted individually for the axis. With this parameter they can be read out. In standalone mode the requested value is also transferred to the accumulator register for further processing purposes (such as conditioned jumps). In direct mode the value read is only output in the *value* field of the reply (without affecting the accumulator).

Internal function: the parameter is read out of the correct position in the appropriate device. The parameter format is converted adding leading zeros (or ones for negative values).

Related commands: SAP, STAP, AAP, RSAP

Mnemonic: GAP <parameter number>, <motor number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
6	<parameter number>	<motor number> 0... 2	don't care

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

For a table with parameters and values which can be used together with this command please refer to chapter 5.

Example:

Get the maximum current of motor

Mnemonic: GAP 6, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$06	\$06	\$00	\$00	\$00	\$00	\$00

Reply:

Byte Index	0	1	2	3	4	5	6	7
Function	Host-address	Target-address	Status	Instruction	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$02	\$01	\$64	\$06	\$00	\$00	\$02	\$80

⇒ **Status = no error, value = 128**

4.5.7 STAP (store axis parameter)

An axis parameter previously set with a *Set Axis Parameter* command (SAP) will be stored permanent. Most parameters are automatically restored after power up.

Internal function: an axis parameter value stored in SRAM will be transferred to EEPROM and loaded from EEPROM after next power up.

Related commands: SAP, RSAP, GAP, AAP

Mnemonic: STAP <parameter number>, <motor number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
7	<parameter number>	<motor number> 0... 2	don't care*

* the value operand of this function has no effect. Instead, the currently used value (e.g. selected by SAP) is saved

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

For a table with parameters and values which can be used together with this command please refer to chapter 5.

Example:

Store the maximum speed of motor

Mnemonic: STAP 4, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$07	\$04	\$00	\$00	\$00	\$00	\$00

Note: The STAP command will not have any effect when the configuration EEPROM is locked (refer to 6.1). In direct mode, the error code 5 (configuration EEPROM locked, see also section 0) will be returned in this case.

4.5.8 RSAP (restore axis parameter)

For all configuration-related axis parameters non-volatile memory locations are provided. By default, most parameters are automatically restored after power up. A single parameter that has been changed before can be reset by this instruction also.

Internal function: the specified parameter is copied from the configuration EEPROM memory to its RAM location.

Relate commands: SAP, STAP, GAP, and AAP

Mnemonic: RSAP <parameter number>, <motor number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
8	<parameter number>	<motor number> 0... 2	don't care

Reply structure in direct mode:

STATUS	VALUE
100 – OK	don't care

For a table with parameters and values which can be used together with this command please refer to chapter 5.

Example:

Restore the maximum current of motor

Mnemonic: RSAP 6, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$08	\$06	\$00	\$00	\$00	\$00	\$00

4.5.9 SGP (set global parameter)

Most of the module specific parameters not directly related to motion control can be specified and the TMCL™ user variables can be changed. Global parameters are related to the host interface, peripherals or other application specific variables. The different groups of these parameters are organized in *banks* to allow a larger total number for future products. Currently, bank 0 and bank 1 are used for global parameters. Bank 2 is used for user variables and bank 3 is used for interrupt configuration.

All module settings will automatically be stored non-volatile (internal EEPROM of the processor). The TMCL™ user variables will not be stored in the EEPROM automatically, but this can be done by using STGP commands.

Internal function: the parameter format is converted ignoring leading zeros (or ones for negative values). The parameter is transferred to the correct position in the appropriate (on board) device.

Related commands: GGP, STGP, RSGP, AGP

Mnemonic: SGP <parameter number>, <bank number>, <value>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
9	<parameter number>	<bank number>	<value>

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

For a table with parameters and bank numbers which can be used together with this command please refer to chapter 0.

Example:

Set the serial address of the target device to 3

Mnemonic: SGP 66, 0, 3

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$09	\$42	\$00	\$00	\$00	\$00	\$03

4.5.10 GGP (get global parameter)

All global parameters can be read with this function. Global parameters are related to the host interface, peripherals or application specific variables. The different groups of these parameters are organized in *banks* to allow a larger total number for future products. Currently, bank 0 and bank 1 are used for global parameters. Bank 2 is used for user variables and bank 3 is used for interrupt configuration.

Internal function: the parameter is read out of the correct position in the appropriate device. The parameter format is converted adding leading zeros (or ones for negative values).

Related commands: SGP, STGP, RSGP, AGP

Mnemonic: GGP <parameter number>, <bank number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
10	<parameter number>	<bank number>	don't care

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

For a table with parameters and bank numbers which can be used together with this command please refer to chapter 0.

Example:

Get the serial address of the target device

Mnemonic: GGP 66, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$0a	\$42	\$00	\$00	\$00	\$00	\$00

Reply:

Byte Index	0	1	2	3	4	5	6	7
Function	Host-address	Target-address	Status	Instruction	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$02	\$01	\$64	\$0a	\$00	\$00	\$00	\$01

⇒ **Status = no error, value = 1**

4.5.11 STGP (store global parameter)

This command is used to store TMCL™ user variables permanently in the EEPROM of the module. Some global parameters are located in RAM memory, so without storing modifications are lost at power down. This instruction enables enduring storing. Most parameters are automatically restored after power up.

Internal function: the specified parameter is copied from its RAM location to the configuration EEPROM.

Related commands: SGP, GGP, RSGP, AGP

Mnemonic: STGP <parameter number>, <bank number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
11	<parameter number>	<bank number>	don't care

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

For a table with parameters and bank numbers which can be used together with this command please refer to chapter 0.

Example:

Store the user variable #42

Mnemonic: STGP 42, 2

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$0b	\$2a	\$02	\$00	\$00	\$00	\$00

4.5.12 RSGP (restore global parameter)

With this command the contents of a TMCL™ user variable can be restored from the EEPROM. For all configuration-related axis parameters, non-volatile memory locations are provided. By default, most parameters are automatically restored after power up. A single parameter that has been changed before can be reset by this instruction.

Internal function: The specified parameter is copied from the configuration EEPROM memory to its RAM location.

Relate commands: SGP, STGP, GGP, and AGP

Mnemonic: RSGP <parameter number>, <bank number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
12	<parameter number>	<bank number>	don't care

Reply structure in direct mode:

STATUS	VALUE
100 – OK	don't care

For a table with parameters and bank numbers which can be used together with this command please refer to chapter 0.

Example:

Restore the user variable #42

Mnemonic: RSGP 42, 2

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$0c	\$2a	\$02	\$00	\$00	\$00	\$00

4.5.13 RFS (reference search)

The TMC-1110 has a built-in reference search algorithm which can be used. The reference search algorithm provides switching point calibration and three switch modes. The status of the reference search can also be queried to see if it has already finished. (In a TMCL™ program it is better to use the WAIT command to wait for the end of a reference search.) Please see the appropriate parameters in the axis parameter table to configure the reference search algorithm to meet your needs (chapter 5). The reference search can be started, stopped, and the actual status of the reference search can be checked.

Internal function: the reference search is implemented as a state machine, so interaction is possible during execution.

Related commands: WAIT

Mnemonic: RFS <START|STOP|STATUS>, <motor number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
13	0 START – start ref. search 1 STOP – abort ref. search 2 STATUS – get status	<motor number> 0... 2	see below

Reply in direct mode:

When using type 0 (START) or 1 (STOP):

STATUS	VALUE
100 – OK	don't care

When using type 2 (STATUS):

STATUS	VALUE	
100 – OK	0	ref. search active
	other values	no ref. search active

Example:

Start reference search of motor 0

Mnemonic: RFS START, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$0d	\$00	\$00	\$00	\$00	\$00	\$00

With this module it is possible to use stall detection instead of a reference search. Please refer to section 0 for details.

4.5.14 SIO (set output)

This command sets the status of the general digital output either to low (0) or to high (1).

Internal function: the passed value is transferred to the specified output line.

Related commands: GIO, WAIT

Mnemonic: SIO <port number>, <bank number>, <value>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
14	<port number>	<bank number> 2	<value> 0/1

Reply structure:

STATUS	VALUE
100 – OK	don't care

Example:

Set OUT_1 to high (bank 2, output 1)

Mnemonic: SIO 1, 2, 1

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$0e	\$01	\$02	\$00	\$00	\$00	\$01

GPIO




Figure 4.1: connectors of TMCM-1110

Bank 2 is used for setting the status of the general digital output either to low (0) or to high (1).

I/O PORTS USED FOR SIO AND COMMAND

Pin	I/O port	Command	Range
11	OpenDrain_1	SIO 0, 2, <n>	1/0
13	OpenDrain_2	SIO 1, 2, <n>	1/0
4	PWMU0	SIO 2, 2, <n>	1/0
6	PWMU1	SIO 3, 2, <n>	1/0
8	PWMU2	SIO 4, 2, <n>	1/0

4.5.15 GIO (get input/output)

With this command the status of the two available general purpose inputs of the module can be read out. The function reads a digital or analogue input port. Digital lines will read 0 and 1, while the ADC channels deliver their 12 bit result in the range of 0... 4095.

In *standalone mode* the requested value is copied to the *accumulator* (accu) for further processing purposes such as conditioned jumps.

In *direct mode* the value is only output in the *value* field of the reply, without affecting the accumulator. The actual status of a digital output line can also be read.

Internal function: the specified line is read.

Related commands: SIO, WAIT

Mnemonic: GIO <port number>, <bank number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
15	<port number>	<bank number>	don't care

Reply in direct mode:

STATUS	VALUE
100 – OK	<status of the port>

Example:

Get the analogue value of ADC channel 0

Mnemonic: GIO 0, 1

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$0f	\$00	\$01	\$00	\$00	\$00	\$00

Reply:

Byte Index	0	1	2	3	4	5	6	7
Function	Host-address	Target-address	Status	Instruction	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$02	\$01	\$64	\$0f	\$00	\$00	\$01	\$2e

Status = no error, value = 46

GPIO




Figure 4.2: connectors of TCM-1110

4.5.15.1 I/O bank 0 – digital inputs

The ADIN lines can be read as digital or analogue inputs at the same time. The analogue values can be accessed in bank 1.

Pin	I/O port	Command	Range
9	AIN_0	GIO 0, 0	0/1
3	PWMD0	GIO 1, 0	0/1
5	PWMD1	GIO 2, 0	0/1
7	PWMD2	GIO 3, 0	0/1

4.5.15.2 I/O bank 1 – analogue inputs

The ADIN lines can be read back as digital or analogue inputs at the same time. The digital states can be accessed in bank 0.

Pin	I/O port	Command	Range
9	AIN_0	GIO 0, 1	0... 4095
-	ADC7 (connected to +VS)	GIO 1, 1	0... 4095
-	ADC6 (connected to +5V)	GIO 2, 1	0... 4095

4.5.15.3 I/O bank 2 – the states of digital outputs

The states of the OUT lines (that have been set by SIO commands) can be read back using bank 2.

Pin	I/O port	Command	Range
11	OpenDrain_1	GIO 0, 2	1/0
13	OpenDrain_2	GIO 1, 2	1/0
4	PWMU0	GIO 2, 2	1/0
6	PWMU1	GIO 3, 2	1/0
8	PWMU2	GIO 4, 2	1/0

4.5.16 CALC (calculate)

A value in the accumulator variable, previously read by a function such as GAP (get axis parameter) can be modified with this instruction. Nine different arithmetic functions can be chosen and one constant operand value must be specified. The result is written back to the accumulator, for further processing like comparisons or data transfer.

Related commands: CALCX, COMP, JC, AAP, AGP, GAP, GGP, GIO

Mnemonic: CALC <operation>, <operand>

Binary representation:

INSTRUCTION NO.	TYPE <operation>	MOT/BANK	VALUE
19	0 ADD – add to accu 1 SUB – subtract from accu 2 MUL – multiply accu by 3 DIV – divide accu by 4 MOD – modulo divide by 5 AND – logical and accu with 6 OR – logical or accu with 7 XOR – logical exor accu with 8 NOT – logical invert accu 9 LOAD – load operand to accu	don't care	<operand>

Example:

Multiply accu by -5000

Mnemonic: CALC MUL, -5000

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$13	\$02	\$00	\$FF	\$FF	\$EC	\$78

Reply:

Byte Index	0	1	2	3	4	5	6	7
Function	Host-address	Target-address	Status	Instruction	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$02	\$01	\$64	\$13	\$ff	\$ff	\$ec	\$78

Status = no error, value = -5000

4.5.17 COMP (compare)

The specified number is compared to the value in the accumulator register. The result of the comparison can for example be used by the conditional jump (JC) instruction. *This command is intended for use in standalone operation only.*

The host address and the reply are used only to take the instruction to the TMCL™ program memory while the program downloads.

Internal function: the specified value is compared to the internal *accumulator*, which holds the value of a preceding *get* or *calculate* instruction (see GAP/GGP/GIO/CALC/CALCX). The internal arithmetic status flags are set according to the comparison result.

Related commands: JC (jump conditional), GAP, GGP, GIO, CALC, CALCX

Mnemonic: COMP <comparison value>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
20	don't care	don't care	<comparison value>

Example:

Jump to the address given by the label when the position of motor is greater than or equal to 1000.

GAP 1, 2, 0 //get axis parameter, type: no. 1 (actual position), motor: 0, value: 0 don't care

COMP 1000 //compare actual value to 1000

JC GE, Label //jump, type: 5 greater/equal, the label must be defined somewhere else in the program

Binary format of the COMP 1000 command:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$14	\$00	\$00	\$00	\$00	\$03	\$e8

4.5.18 JC (jump conditional)

The JC instruction enables a conditional jump to a fixed address in the TMCL™ program memory, if the specified condition is met. The conditions refer to the result of a preceding comparison. Please refer to COMP instruction for examples. *This function is for standalone operation only.*

The host address and the reply are only used to take the instruction to the TMCL™ program memory while the program downloads.

Internal function: the TMCL™ program counter is set to the passed value if the arithmetic status flags are in the appropriate state(s).

Related commands: JA, COMP, WAIT, CLE

Mnemonic: JC <condition>, <label>

where <condition>=ZE|NZ|EQ|NE|GT|GE|LT|LE|ETO|EAL|EDV|EPO

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
21	0 ZE - zero 1 NZ - not zero 2 EQ - equal 3 NE - not equal 4 GT - greater 5 GE - greater/equal 6 LT - lower 7 LE - lower/equal 8 ETO - time out error 9 EAL - external alarm 10 EDV - deviation error 11 EPO - position error	don't care	<jump address>

Example:

Jump to address given by the label when the position of motor is greater than or equal to 1000.

```
GAP 1, 0, 0    //get axis parameter, type: no. 1 (actual position), motor: 0, value: 0 don't care
COMP 1000     //compare actual value to 1000
JC GE, Label   //jump, type: 5 greater/equal
...
...
Label: ROL 0, 1000
```

Binary format of JC GE, Label when Label is at address 10:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$15	\$05	\$00	\$00	\$00	\$00	\$0a

4.5.19 JA (jump always)

Jump to a fixed address in the TMCL™ program memory. *This command is intended for standalone operation only.*

The host address and the reply are only used to take the instruction to the TMCL™ program memory while the program downloads.

Internal function: the TMCL™ program counter is set to the passed value.

Related commands: JC, WAIT, CSUB

Mnemonic: JA <Label>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
22	don't care	don't care	<jump address>

Example: An infinite loop in TMCL™

```

Loop:  MVP ABS, 0, 10000
        WAIT POS, 0, 0
        MVP ABS, 0, 0
        WAIT POS, 0, 0
        JA Loop      //Jump to the label Loop

```

Binary format of JA Loop assuming that the label Loop is at address 20:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$16	\$00	\$00	\$00	\$00	\$00	\$14

4.5.20 CSUB (call subroutine)

This function calls a subroutine in the TMCL™ program memory. *It is intended for standalone operation only.*

The host address and the reply are only used to take the instruction to the TMCL™ program memory while the program downloads.

Internal function: the actual TMCL™ program counter value is saved to an internal stack, afterwards overwritten with the passed value. The number of entries in the internal stack is limited to 8. This also limits nesting of subroutine calls to 8. The command will be ignored if there is no more stack space left.

Related commands: RSUB, JA

Mnemonic: CSUB <Label>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
23	don't care	don't care	<subroutine address>

Example: Call a subroutine

```

Loop:  MVP ABS, 0, 10000
        CSUB SubW      //Save program counter and jump to label SubW
        MVP ABS, 0, 0
        JA Loop

SubW:   WAIT POS, 0, 0
        WAIT TICKS, 0, 50
        RSUB           //Continue with the command following the CSUB command

```

Binary format of the CSUB SubW command assuming that the label SubW is at address 100:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$17	\$00	\$00	\$00	\$00	\$00	\$64

4.5.21 RSUB (return from subroutine)

Return from a subroutine to the command after the CSUB command. This command is intended for use in standalone mode only.

The host address and the reply are only used to take the instruction to the TMCL™ program memory while the program loads down. This command cannot be used in direct mode.

Internal function: the TMCL™ program counter is set to the last value of the stack. The command will be ignored if the stack is empty.

Related command: CSUB

Mnemonic: RSUB

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
24	don't care	don't care	don't care

Example: please see the CSUB example (section 4.5.20).

Binary format of RSUB:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$18	\$00	\$00	\$00	\$00	\$00	\$00

4.5.22 WAIT (wait for an event to occur)

This instruction interrupts the execution of the TMCL™ program until the specified condition is met. This command is intended for standalone operation only.

The host address and the reply are only used to take the instruction to the TMCL™ program memory while the program loads down. This command cannot be used in direct mode.

There are five different wait conditions that can be used:

- TICKS: Wait until the number of timer ticks specified by the <ticks> parameter has been reached.
- POS: Wait until the target position of the motor specified by the <motor> parameter has been reached. An optional timeout value (0 for no timeout) must be specified by the <ticks> parameter.
- REFSW: Wait until the reference switch of the motor specified by the <motor> parameter has been triggered. An optional timeout value (0 for no timeout) must be specified by the <ticks> parameter.
- LIMSW: Wait until a limit switch of the motor specified by the <motor> parameter has been triggered. An optional timeout value (0 for no timeout) must be specified by the <ticks> parameter.
- RFS: Wait until the reference search of the motor specified by the <motor> field has been reached. An optional timeout value (0 for no timeout) must be specified by the <ticks> parameter.

The timeout flag (ETO) will be set after a timeout limit has been reached. You can then use a JC ETO command to check for such errors or clear the error using the CLE command.

Internal function: the TMCL™ program counter is held until the specified condition is met.

Related commands: JC, CLE

Mnemonic: WAIT <condition>, <motor number>, <ticks>

Binary representation:

INSTRUCTION NO.	TYPE <condition>	MOT/BANK	VALUE
27	0 TICKS - timer ticks* ¹	don't care	<no. of ticks*>
	1 POS - target position reached	<motor number> 0... 2	<no. of ticks* for timeout>, 0 for no timeout
	2 REFSW – reference switch	<motor number> 0... 2	<no. of ticks* for timeout>, 0 for no timeout
	3 LIMSW – limit switch	<motor number> 0... 2	<no. of ticks* for timeout>, 0 for no timeout
	4 RFS – reference search completed	<motor number> 0... 2	<no. of ticks* for timeout>, 0 for no timeout

*¹ one tick is 10 milliseconds

Example:

Wait for motor 0 to reach its target position, without timeout

Mnemonic: WAIT POS, 0, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7	8
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0	Checksum
Value (hex)	\$01	\$1b	\$01	\$00	\$00	\$00	\$00	\$00	\$1d

4.5.23 STOP (stop TMCL™ program execution)

This function stops executing a TMCL™ program. The host address and the reply are only used to transfer the instruction to the TMCL™ program memory.

End standalone TMCL™ programs with the STOP command. It is not to be used in direct mode.

Internal function: TMCL™ instruction fetching is stopped.

Related commands: none

Mnemonic: STOP

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
28	don't care	don't care	don't care

Example:

Mnemonic: STOP

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$1c	\$00	\$00	\$00	\$00	\$00	\$00

4.5.24 SCO (set coordinate)

Up to 20 position values (coordinates) can be stored for every axis for use with the MVP COORD command. This command sets a coordinate to a specified value. Depending on the global parameter 84, the coordinates are only stored in RAM or also stored in the EEPROM and copied back on startup (with the default setting the coordinates are stored in RAM only).

Please note that the coordinate number 0 is always stored in RAM only.

Internal function: the passed value is stored in the internal position array.

Related commands: GCO, CCO, MVP

Mnemonic: SCO <coordinate number>, <motor number>, <position>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
30	<coordinate number> 0... 20	<motor number> 0... 2	<position> -2 ²³ ... +2 ²³

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

Example:

Set coordinate #1 of motor to 1000

Mnemonic: SCO 1, 0, 1000

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$1e	\$01	\$00	\$00	\$00	\$03	\$e8

Two special functions of this command have been introduced that make it possible to copy all coordinates or one selected coordinate to the EEPROM.

These functions can be accessed using the following special forms of the SCO command:

SCO 0, 255, 0

copies all coordinates (except coordinate number 0) from RAM to the EEPROM.

SCO <coordinate number>, 255, 0

copies the coordinate selected by <coordinate number> to the EEPROM. The coordinate number must be a value between 1 and 20.

4.5.25 GCO (get coordinate)

This command makes possible to read out a previously stored coordinate. In standalone mode the requested value is copied to the accumulator register for further processing purposes such as conditioned jumps. In direct mode, the value is only output in the value field of the reply, without affecting the accumulator. Depending on the global parameter 84, the coordinates are only stored in RAM or also stored in the EEPROM and copied back on startup (with the default setting the coordinates are stored in RAM, only).

Please note that the coordinate number 0 is always stored in RAM, only.

Internal function: the desired value is read out of the internal coordinate array, copied to the accumulator register and – in direct mode – returned in the *value* field of the reply.

Related commands: SCO, CCO, MVP

Mnemonic: GCO <coordinate number>, <motor number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
31	<coordinate number> 0... 20	<motor number> 0... 2	don't care

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

Example:

Get motor value of coordinate 1

Mnemonic: GCO 1, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$1f	\$01	\$00	\$00	\$00	\$00	\$00

Reply:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Target-address	Status	Instruction	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$02	\$01	\$64	\$0a	\$00	\$00	\$00	\$00

⇒ **Value: 0**

Two special functions of this command have been introduced that make it possible to copy all coordinates or one selected coordinate from the EEPROM to the RAM.

These functions can be accessed using the following special forms of the GCO command:

GCO 0, 255, 0	copies all coordinates (except coordinate number 0) from the EEPROM to the RAM.
GCO <coordinate number>, 255, 0	copies the coordinate selected by <coordinate number> from the EEPROM to the RAM. The coordinate number must be a value between 1 and 20.

4.5.26 CCO (capture coordinate)

The actual position of the axis is copied to the selected coordinate variable. Depending on the global parameter 84, the coordinates are only stored in RAM or also stored in the EEPROM and copied back on startup (with the default setting the coordinates are stored in RAM only). Please see the SCO and GCO commands on how to copy coordinates between RAM and EEPROM.

Note, that the coordinate number 0 is always stored in RAM only.

Internal function: the selected (24 bit) position values are written to the 20 by 3 bytes wide coordinate array.

Related commands: SCO, GCO, MVP

Mnemonic: CCO <coordinate number>, <motor number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
32	<coordinate number> 0... 20	<motor number> 0... 2	don't care

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

Example:

Store current position of the axis 0 to coordinate 3

Mnemonic: CCO 3, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$20	\$03	\$00	\$00	\$00	\$00	\$00

4.5.27 ACO (accu to coordinate)

With the ACO command the actual value of the accumulator is copied to a selected coordinate of the motor. Depending on the global parameter 84, the coordinates are only stored in RAM or also stored in the EEPROM and copied back on startup (with the default setting the coordinates are stored in RAM only).

Please note also that the coordinate number 0 is always stored in RAM only. For Information about storing coordinates refer to the SCO command.

Internal function: the actual value of the accumulator is stored in the internal position array.

Related commands: GCO, CCO, MVP COORD, SCO

Mnemonic: ACO <coordinate number>, <motor number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
39	<coordinate number> 0... 20	<motor number> 0... 2	don't care

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

Example:

Copy the actual value of the accumulator to coordinate 1 of motor 0

Mnemonic: ACO 1, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$27	\$01	\$00	\$00	\$00	\$00	\$00

4.5.28 CALCX (calculate using the X register)

This instruction is very similar to CALC, but the second operand comes from the X register. The X register can be loaded with the LOAD or the SWAP type of this instruction. The result is written back to the accumulator for further processing like comparisons or data transfer.

Related commands: CALC, COMP, JC, AAP, AGP

Mnemonic: CALCX <operation>

Binary representation:

INSTRUCTION NO.	TYPE <operation>	MOT/BANK	VALUE
33	0 ADD – add X register to accu 1 SUB – subtract X register from accu 2 MUL – multiply accu by X register 3 DIV – divide accu by X-register 4 MOD – modulo divide accu by x-register 5 AND – logical and accu with X-register 6 OR – logical or accu with X-register 7 XOR – logical exor accu with X-register 8 NOT – logical invert X-register 9 LOAD – load accu to X-register 10 SWAP – swap accu with X-register	don't care	don't care

Example:

Multiply accu by X-register

Mnemonic: CALCX MUL

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$21	\$02	\$00	\$00	\$00	\$00	\$00

4.5.29 AAP (accumulator to axis parameter)

The content of the accumulator register is transferred to the specified axis parameter. For practical usage, the accumulator has to be loaded e.g. by a preceding GAP instruction. The accumulator may have been modified by the CALC or CALCX (calculate) instruction.

Related commands: AGP, SAP, GAP, SGP, GGP, GIO, GCO, CALC, CALCX

Mnemonic: AAP <parameter number>, <motor number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
34	<parameter number>	<motor number> 0... 2	<don't care>

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

For a table with parameters and values which can be used together with this command please refer to chapter 5.

Example:

Positioning motor by a potentiometer connected to the analogue input #0:

```

Start:  GIO 0,1      // get value of analogue input line 0
        CALC MUL, 4  // multiply by 4
        AAP 0,0      // transfer result to target position of motor 0
        JA Start     // jump back to start

```

Binary format of the AAP 0,0 command:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$22	\$00	\$00	\$00	\$00	\$00	\$00

4.5.30 AGP (accumulator to global parameter)

The content of the accumulator register is transferred to the specified global parameter. For practical usage, the accumulator has to be loaded e.g. by a preceding GAP instruction. The accumulator may have been modified by the CALC or CALCX (calculate) instruction. **Note, that the global parameters in bank 0 are EEPROM-only and thus should not be modified automatically by a standalone application.**

Related commands: AAP, SGP, GGP, SAP, GAP, GIO

Mnemonic: AGP <parameter number>, <bank number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
35	<parameter number>	<bank number>	don't care

Reply in direct mode:

STATUS	VALUE
100 – OK	don't care

For a table with parameters and bank numbers which can be used together with this command please refer to chapter 0.

Example:

Copy accumulator to TMCL™ user variable #3

Mnemonic: AGP 3, 2

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$23	\$03	\$02	\$00	\$00	\$00	\$00

4.5.31 CLE (clear error flags)

This command clears the internal error flags. *It is intended for use in standalone mode only and must not be used in direct mode.*

The following error flags can be cleared by this command (determined by the <flag> parameter):

- ALL: clear all error flags.
- ETO: clear the timeout flag.
- EAL: clear the external alarm flag
- EDV: clear the deviation flag
- EPO: clear the position error flag

Related commands: JC

Mnemonic: CLE <flags>

Binary representation:

INSTRUCTION NO.	TYPE <flags>	MOT/BANK	VALUE
36	0 – (ALL) all flags 1 – (ETO) timeout flag 2 – (EAL) alarm flag 3 – (EDV) deviation flag 4 – (EPO) position flag 5 – (ESD) shutdown flag	don't care	don't care

Example:

Reset the timeout flag

Mnemonic: CLE ETO

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$24	\$01	\$00	\$00	\$00	\$00	\$00

4.5.32 VECT (set interrupt vector)

The VECT command defines an interrupt vector. It needs an interrupt number and a label as parameter (like in JA, JC and CSUB commands).

This label must be the entry point of the interrupt handling routine.

Related commands: EI, DI, RETI

Mnemonic: VECT <interrupt number>, <label>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
37	<interrupt number>	don't care	<label>

The following table shows all interrupt vectors that can be used:

Interrupt number	Interrupt type
0	Timer 0
1	Timer 1
2	Timer 2
3	Target position reached 0
4	Target position reached 1
5	Target position reached 2
15	stallGuard™ axis 0
21	Deviation axis 0
27	Left stop switch 0
28	Right stop switch 0
29	Left stop switch 1
30	Right stop switch 1
31	Left stop switch 2
32	Right stop switch 2
39	Input change 0
40	Input change 1
41	Input change 2
42	Input change 3
255	Global interrupts

Example: Define interrupt vector at target position 500
VECT 3, 500

Binary format of VECT:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$25	\$03	\$00	\$00	\$00	\$01	\$F4

4.5.33 EI (enable interrupt)

The EI command enables an interrupt. It needs the interrupt number as parameter. Interrupt number 255 globally enables interrupts.

Related command: DI, VECT, RETI

Mnemonic: EI <interrupt number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
25	<interrupt number>	don't care	don't care

The following table shows all interrupt vectors that can be used:

Interrupt number	Interrupt type
0	Timer 0
1	Timer 1
2	Timer 2
3	Target position reached 0
4	Target position reached 1
5	Target position reached 2
15	stallGuard™ axis 0
21	Deviation axis 0
27	Left stop switch 0
28	Right stop switch 0
29	Left stop switch 1
30	Right stop switch 1
31	Left stop switch 2
32	Right stop switch 2
39	Input change 0
40	Input change 1
41	Input change 2
42	Input change 3
255	Global interrupts

Examples:

Enable interrupts globally
EI, 255

Binary format of EI:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$19	\$FF	\$00	\$00	\$00	\$00	\$00

Enable interrupt when target position reached
EI, 3

Binary format of EI:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$19	\$03	\$00	\$00	\$00	\$00	\$00

4.5.34 DI (disable interrupt)

The DI command disables an interrupt. It needs the interrupt number as parameter. Interrupt number 255 globally disables interrupts.

Related command: EI, VECT, RETI

Mnemonic: DI <interrupt number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
26	<interrupt number>	don't care	don't care

The following table shows all interrupt vectors that can be used:

Interrupt number	Interrupt type
0	Timer 0
1	Timer 1
2	Timer 2
3	Target position reached 0
4	Target position reached 1
5	Target position reached 2
15	stallGuard™ axis 0
21	Deviation axis 0
27	Left stop switch 0
28	Right stop switch 0
29	Left stop switch 1
30	Right stop switch 1
31	Left stop switch 2
32	Right stop switch 2
39	Input change 0
40	Input change 1
41	Input change 2
42	Input change 3
255	Global interrupts

Examples:

Disable interrupts globally
DI, 255

Binary format of DI:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$1A	\$FF	\$00	\$00	\$00	\$00	\$00

Disable interrupt when target position reached
DI, 3

Binary format of DI:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$1A	\$03	\$00	\$00	\$00	\$00	\$00

4.5.35 RETI (return from interrupt)

This command terminates the interrupt handling routine, and the normal program execution continues.

At the end of an interrupt handling routine the RETI command must be executed.

Internal function: the saved registers (A register, X register, flags) are copied back. Normal program execution continues.

Related commands: EI, DI, VECT

Mnemonic: RETI

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
38	don't care	don't care	don't care

Example: Terminate interrupt handling and continue with normal program execution
RETI

Binary format of RETI:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Instruction Number	Type	Motor/Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$26	\$00	\$00	\$00	\$00	\$01	\$00

4.5.36 Customer Specific TMCL™ Command Extension (UF0... UF7 - User Function)

The user definable functions UF0... UF7 are predefined functions without topic for user specific purposes. A user function (UF) command uses three parameters. Please contact TRINAMIC for a customer specific programming.

Internal function: Call user specific functions implemented in C by TRINAMIC.

Related commands: none

Mnemonic: UF0... UF7 <parameter number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
64... 71	user defined	user defined	user defined

Reply in direct mode:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Target-address	Status	Instruction	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$02	\$01	user defined	64... 71	user defined	user defined	user defined	user defined

4.5.37 Request Target Position Reached Event

This command is the only exception to the TMCL™ protocol, as it sends two replies: One immediately after the command has been executed (like all other commands also), and one additional reply that will be sent when the motor has reached its target position. ***This instruction can only be used in direct mode (in standalone mode, it is covered by the WAIT command) and hence does not have a mnemonic.***

Internal function: send an additional reply when the motor has reached its target position

Mnemonic: ---

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
138	0/1	(don't care)	motor bit mask

With command 138 the value field is a bit vector. It shows for which motors one would like to have a position reached message. The *value* field contains a bit mask where every bit stands for one motor.

MOTOR BIT MASK

Bit	Selected motor
0	0
1	1
2	2

VALUES FOR TYPE

Value	Description
0	Position reached messages only for the next MVP command.
1	Position reached event message for every MVP command.

Reply in direct mode (right after execution of this command):

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Target-address	Status	Instruction	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$02	\$01	100	138	\$00	\$00	\$00	Motor bit mask

The additional reply will be sent when at least the first motor has reached its target position. The TMCM-1110 can control up to three motors.

Additional reply in direct mode (after a motor has reached its target position):

Byte Index	0	1	2	3	4	5	6	7
Function	Target-address	Target-address	Status	Instruction	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$02	\$01	128	138	\$00	\$00	\$00	Motor bit mask

4.5.38 TMCL™ Control Functions

There are several TMCL™ control functions, but for the user are only 136 and 137 interesting. Other control functions can be used with axis parameters.

Instruction number	Type	Command	Description
136	0 – string 1 – binary	Firmware version	Get the module type and firmware revision as a string or in binary format. (<i>Motor/Bank</i> and <i>Value</i> are ignored.)
137	don't care	Reset to factory defaults	Reset all settings stored in the EEPROM to their factory defaults This command does not send back a reply. <i>Value must be 1234</i>

Further information about command 136

- **Type set to 0 - reply as a string:**

Byte index	Contents
1	Host Address
2... 9	Version string (8 characters, e.g. 6110V100)

There is no checksum in this reply format!

- **Type set to 1 - version number in binary format:**

Please use the normal reply format. The version number is output in the *value* field of the reply in the following way:

Byte index in value field	Contents
1	Version number, low byte
2	Version number, high byte
3	Type number, low byte (currently not used)
4	Type number, high byte (currently not used)

5 Axis Parameters

The following sections describe all axis parameters that can be used with the SAP, GAP, AAP, STAP and RSAP commands.


ATTENTION


The following axis parameters are only available for axis 0, because the module has only one driver IC:

#6, #7
#140
#160... #184
#204... #254

Meaning of the letters in column Access:

Access type	Related command(s)	Description
R	GAP	Parameter readable
W	SAP, AAP	Parameter writable
E	STAP, RSAP	Parameter automatically restored from EEPROM after reset or power-on. These parameters can be stored permanently in EEPROM using STAP command and also explicitly restored (copied back from EEPROM into RAM) using RSAP.

 Basic parameters should be adjusted to motor / application for proper module operation.

 Parameters for the more experienced user – please do not change unless you are absolutely sure.

Number	Axis Parameter	Description	Range [Unit]	Acc.
0	target (next) position	The desired position in position mode (see ramp mode, no. 138).	-2.147.483.648... +2.147.483.647 [μsteps]	RW
1	actual position	The current position of the motor. Should only be overwritten for reference point setting.	-2.147.483.648... +2.147.483.647 [μsteps]	RW
2	target (next) speed	The desired speed in velocity mode (see ramp mode, no. 138). In position mode, this parameter is set by hardware: to the maximum speed during acceleration, and to zero during deceleration and rest.	±2047 $\left\lceil \frac{16\text{MHz}}{65536} \cdot 2^{\text{PD}} \frac{\mu\text{steps}}{\text{sec}} \right\rceil$	RW
3	actual speed	The current rotation speed.	±2047 $\left\lceil \frac{16\text{MHz}}{65536} \cdot 2^{\text{PD}} \frac{\mu\text{steps}}{\text{sec}} \right\rceil$	RW
4	maximum positioning speed	Should not exceed the physically highest possible value. Adjust the pulse divisor (axis parameter 154), if the speed value is very low (<50) or above the upper limit. See TMC 429 datasheet for calculation of physical units or use the TMCL-IDE calculation tool.	0... 2047 $\left\lceil \frac{16\text{MHz}}{65536} \cdot 2^{\text{PD}} \frac{\mu\text{steps}}{\text{sec}} \right\rceil$	RWE
5	maximum acceleration	The limit for acceleration and deceleration. Changing this parameter requires re-calculation of the acceleration factor and the acceleration divisor. Therefore adjust the ramp divisor (axis parameter 153) carefully in steps of one. See TMC 429 datasheet for calculation of physical units or use the TMCL-IDE calculation tool.	0... 2047* ¹	RWE

Number	Axis Parameter	Description	Range [Unit]	Acc.																																								
6	absolute max. current (CS / Current Scale)	<p>The maximum value is 255. This value means 100% of the maximum current of the module. The current adjustment is within the range 0... 255 and can be adjusted in 32 steps.</p> <table><tr><td>0... 7</td><td>79... 87</td><td>160... 167</td><td>240... 247</td></tr><tr><td>8... 15</td><td>88... 95</td><td>168... 175</td><td>248... 255</td></tr><tr><td>16... 23</td><td>96... 103</td><td>176... 183</td><td></td></tr><tr><td>24... 31</td><td>104... 111</td><td>184... 191</td><td></td></tr><tr><td>32... 39</td><td>112... 119</td><td>192... 199</td><td></td></tr><tr><td>40... 47</td><td>120... 127</td><td>200... 207</td><td></td></tr><tr><td>48... 55</td><td>128... 135</td><td>208... 215</td><td></td></tr><tr><td>56... 63</td><td>136... 143</td><td>216... 223</td><td></td></tr><tr><td>64... 71</td><td>144... 151</td><td>224... 231</td><td></td></tr><tr><td>72... 79</td><td>152... 159</td><td>232... 239</td><td></td></tr></table> <p>The unit of the current is adequate to the chosen motor current (with or without jumper). <i>The most important motor setting, since too high values might cause motor damage!</i></p>	0... 7	79... 87	160... 167	240... 247	8... 15	88... 95	168... 175	248... 255	16... 23	96... 103	176... 183		24... 31	104... 111	184... 191		32... 39	112... 119	192... 199		40... 47	120... 127	200... 207		48... 55	128... 135	208... 215		56... 63	136... 143	216... 223		64... 71	144... 151	224... 231		72... 79	152... 159	232... 239		<p>0... 255</p> <p><i>Without jumpers:</i> $I_{peak} = < value > \times \frac{1.5A}{255}$</p> <p>$I_{RMS} = < value > \times \frac{1A}{255}$</p> <p><i>Jumpers set:</i> $I_{peak} = < value > \times \frac{4A}{255}$</p> <p>$I_{RMS} = < value > \times \frac{2.8A}{255}$</p>	RWE
0... 7	79... 87	160... 167	240... 247																																									
8... 15	88... 95	168... 175	248... 255																																									
16... 23	96... 103	176... 183																																										
24... 31	104... 111	184... 191																																										
32... 39	112... 119	192... 199																																										
40... 47	120... 127	200... 207																																										
48... 55	128... 135	208... 215																																										
56... 63	136... 143	216... 223																																										
64... 71	144... 151	224... 231																																										
72... 79	152... 159	232... 239																																										
7	standby current	<p>The current limit two seconds after the motor has stopped.</p> <p>The unit of the current is adequate to the chosen motor current (with or without jumper).</p>	<p>0... 255</p> <p><i>Without jumpers:</i> $I_{peak} = < value > \times \frac{1.5A}{255}$</p> <p>$I_{RMS} = < value > \times \frac{1A}{255}$</p> <p><i>Jumpers set:</i> $I_{peak} = < value > \times \frac{4A}{255}$</p> <p>$I_{RMS} = < value > \times \frac{2.8A}{255}$</p>	RWE																																								
8	target pos. reached	Indicates that the actual position equals the target position.	0/1	R																																								
9	ref. switch status	The logical state of the reference (left) switch. See the TMC 429 data sheet for the different switch modes. The default has two switch modes: the left switch as the reference switch, the right switch as a limit (stop) switch.	0/1	R																																								
10	right limit switch status	The logical state of the (right) limit switch.	0/1	R																																								
11	left limit switch status	The logical state of the left limit switch (in three switch mode)	0/1	R																																								
130	minimum speed	Should always be set 1 to ensure exact reaching of the target position. Do not change!	<p>0... 2047</p> $\left[\frac{16MHz}{65536} \cdot 2^{PD} \frac{\mu steps}{sec} \right]$	RWE																																								
135	actual acceleration	The current acceleration (read only).	0... 2047*1	R																																								

Number	Axis Parameter	Description	Range [Unit]	Acc.																		
138	ramp mode	Automatically set when using ROR, ROL, MST and MVP. 0: position mode. Steps are generated, when the parameters actual position and target position differ. Trapezoidal speed ramps are provided. 2: velocity mode. The motor will run continuously and the speed will be changed with constant (maximum) acceleration, if the parameter target speed is changed. For special purposes, the soft mode (value 1) with exponential decrease of speed can be selected.	0/1/2	RWE																		
140	microstep resolution	<table><tr><td>0</td><td>full step</td></tr><tr><td>1</td><td>half step</td></tr><tr><td>2</td><td>4 microsteps</td></tr><tr><td>3</td><td>8 microsteps</td></tr><tr><td>4</td><td>16 microsteps</td></tr><tr><td>5</td><td>32 microsteps</td></tr><tr><td>6</td><td>64 microsteps</td></tr><tr><td>7</td><td>128 microsteps</td></tr><tr><td>8</td><td>256 microsteps</td></tr></table>	0	full step	1	half step	2	4 microsteps	3	8 microsteps	4	16 microsteps	5	32 microsteps	6	64 microsteps	7	128 microsteps	8	256 microsteps	0... 8	RWE
0	full step																					
1	half step																					
2	4 microsteps																					
3	8 microsteps																					
4	16 microsteps																					
5	32 microsteps																					
6	64 microsteps																					
7	128 microsteps																					
8	256 microsteps																					
153	ramp divisor	The exponent of the scaling factor for the ramp generator - should be de/incremented carefully (in steps of one).	0... 13	RWE																		
154	pulse divisor	The exponent of the scaling factor for the pulse (step) generator – should be de/incremented carefully (in steps of one).	0... 13	RWE																		
160	step interpolation enable	Step interpolation is supported with a 16 microstep setting only. In this setting, each step impulse at the input causes the execution of 16 times 1/256 microsteps. This way, a smooth motor movement like in 256 microstep resolution is achieved. 0 – step interpolation off 1 – step interpolation on	0/1	RW																		
161	double step enable	Every edge of the cycle releases a step/microstep. <i>It does not make sense to activate this parameter for internal use.</i> Double step enable can be used with Step/Dir interface. 0 – double step off 1 – double step on	0/1	RW																		
162	chopper blank time	Selects the comparator <i>blank time</i> . This time needs to safely cover the switching event and the duration of the ringing on the sense resistor. For low current drivers, a setting of 1 or 2 is good. For higher current applications like the TCM-1110 a setting of 2 or 3 will be required.	0... 3	RW																		
163	chopper mode	Selection of the chopper mode: 0 – spread cycle 1 – classic const. off time	0/1	RW																		

Number	Axis Parameter	Description	Range [Unit]	Acc.
164	chopper hysteresis decrement	Hysteresis decrement setting. This setting determines the slope of the hysteresis during on time and during fast decay time. 0 – fast decrement 3 – very slow decrement	0... 3	RW
165	chopper hysteresis end	Hysteresis end setting. Sets the hysteresis end value after a number of decrements. Decrement interval time is controlled by axis parameter 164. -3... -1 negative hysteresis end setting 0 zero hysteresis end setting 1... 12 positive hysteresis end setting	-3... 12	RW
166	chopper hysteresis start	Hysteresis start setting. Please remark, that this value is an offset to the hysteresis end value.	0... 8	RW
167	chopper off time	The off time setting controls the minimum chopper frequency. An off time within the range of 5µs to 20µs will fit. Off time setting for constant t_{off} chopper: $N_{CLK} = 12 + 32 \cdot t_{OFF}$ (Minimum is 64 clocks) Setting this parameter to zero completely disables all driver transistors and the motor can free-wheel.	0 / 2... 15	RW
168	smartEnergy current minimum (SEIMIN)	Sets the lower motor current limit for coolStep™ operation by scaling the CS (Current Scale, see axis parameter 6) value. minimum motor current: 0 – 1/2 of CS 1 – 1/4 of CS	0/1	RW
169	smartEnergy current down step	Sets the number of stallGuard2™ readings above the upper threshold necessary for each current decrement of the motor current. Number of stallGuard2™ measurements per decrement: Scaling: 0... 3: 32, 8, 2, 1 0: slow decrement 3: fast decrement	0... 3	RW
170	smartEnergy hysteresis	Sets the distance between the lower and the upper threshold for stallGuard2™ reading. Above the upper threshold the motor current becomes decreased. Hysteresis: (smartEnergy hysteresis value + 1) * 32 Upper stallGuard2™ threshold: (smartEnergy hysteresis start + smartEnergy hysteresis + 1) * 32	0... 15	RW

Number	Axis Parameter	Description	Range [Unit]	Acc.						
171	smartEnergy current up step	Sets the current increment step. The current becomes incremented for each measured stallGuard2™ value below the lower threshold (see smartEnergy hysteresis start). current increment step size: Scaling: 0... 3: 1, 2, 4, 8 0: slow increment 3: fast increment / fast reaction to rising load	1... 3	RW						
172	smartEnergy hysteresis start	The lower threshold for the stallGuard2™ value (see smart Energy current up step).	0... 15	RW						
173	stallGuard2™ filter enable	Enables the stallGuard2™ filter for more precision of the measurement. If set, reduces the measurement frequency to one measurement per four fullsteps. <i>In most cases it is expedient to set the filtered mode before using coolStep™.</i> <i>Use the standard mode for step loss detection.</i> 0 – standard mode 1 – filtered mode	0/1	RW						
174	stallGuard2™ threshold	This signed value controls stallGuard2™ threshold level for stall output and sets the optimum measurement range for readout. A lower value gives a higher sensitivity. Zero is the starting value. A higher value makes stallGuard2™ less sensitive and requires more torque to indicate a stall. <table><tr><td>0</td><td>Indifferent value</td></tr><tr><td>1... 63</td><td>less sensitivity</td></tr><tr><td>-10 - 64</td><td>higher sensitivity</td></tr></table>	0	Indifferent value	1... 63	less sensitivity	-10 - 64	higher sensitivity	-64... 63	RW
0	Indifferent value									
1... 63	less sensitivity									
-10 - 64	higher sensitivity									
175	slope control high side	Determines the slope of the motor driver outputs. <i>Set to 2 or 3 for this module or rather use the default value.</i> 0: lowest slope 3: fastest slope	0... 3	RW						
176	slope control low side	Determines the slope of the motor driver outputs. <i>Set identical to slope control high side.</i>	0... 3	RW						
177	short protection disable	0: Short to GND protection is on 1: Short to GND protection is disabled <i>Use default value!</i>	0/1	RW						
178	short detection timer	0: 3.2µs 1: 1.6µs 2: 1.2µs 3: 0.8µs <i>Use default value!</i>	0... 3	RW						
179	Vsense	sense resistor voltage based current scaling 0: Full scale sense resistor voltage is 1/18 VDD 1: Full scale sense resistor voltage is 1/36 VDD (refers to a current setting of 31 and DAC value 255) <i>Use default value. Do not change!</i>	0/1	RW						

Number	Axis Parameter	Description	Range [Unit]	Acc.
180	smartEnergy actual current	This status value provides the <i>actual motor current</i> setting as controlled by coolStep™. The value goes up to the CS value and down to the portion of CS as specified by SEIMIN. <u>actual motor current scaling factor:</u> 0 ... 31: 1/32, 2/32, ... 32/32	0... 31	RW
181	stop on stall	Below this speed motor will not be stopped. Above this speed motor will stop in case stallGuard2™ load value reaches zero.	0... 2047 $\left\lceil \frac{16\text{MHz}}{65536} \cdot 2^{\text{PD}} \frac{\mu\text{steps}}{\text{sec}} \right\rceil$	RW
182	smartEnergy threshold speed	Above this speed coolStep™ becomes enabled.	0... 2047 $\left\lceil \frac{16\text{MHz}}{65536} \cdot 2^{\text{PD}} \frac{\mu\text{steps}}{\text{sec}} \right\rceil$	RW
183	smartEnergy slow run current	Sets the motor current which is used below the threshold speed. The unit of the current is adequate to the chosen motor current (with or without jumper).	0... 255 <i>Without jumpers:</i> $I_{\text{peak}} = < \text{value} > \times \frac{1.5\text{A}}{255}$ $I_{\text{RMS}} = < \text{value} > \times \frac{1\text{A}}{255}$ <i>Jumpers set:</i> $I_{\text{peak}} = < \text{value} > \times \frac{4\text{A}}{255}$ $I_{\text{RMS}} = < \text{value} > \times \frac{2.8\text{A}}{255}$	RW
193	ref. search mode	<div> <div>1</div> <div>search left stop switch only</div> </div> <div> <div>2</div> <div>search right stop switch, then search left stop switch</div> </div> <div> <div>3</div> <div>search right stop switch, then search left stop switch from both sides</div> </div> <div> <div>4</div> <div>search left stop switch from both sides</div> </div> <div> <div>5</div> <div>search home switch in negative direction, reverse the direction when left stop switch reached</div> </div> <div> <div>6</div> <div>search home switch in positive direction, reverse the direction when right stop switch reached</div> </div> <div> <div>7</div> <div>search home switch in positive direction, ignore end switches</div> </div> <div> <div>8</div> <div>search home switch in negative direction, ignore end switches</div> </div> <i>Adding 128 to these values reverses the polarity of the home switch input.</i>	1... 8	RWE
194	referencing search speed	For the reference search this value directly specifies the search speed.	0... 2047	RWE
195	referencing switch speed	Similar to parameter no. 194, the speed for the switching point calibration can be selected.	0... 2047	RWE
196	distance end switches	This parameter provides the distance between the end switches after executing the RFS command (mode 2 or 3).	0... 2147483647	R
204	freewheeling	Time after which the power to the motor will be cut when its velocity has reached zero.	0... 65535 0 = never [msec]	RWE

Number	Axis Parameter	Description	Range [Unit]	Acc.
206	actual load value	Readout of the actual load value used for stall detection (stallGuard2™).	0... 1023	R
208	TMC262 driver error flags	<div> <div>Bit 0</div> <div>stallGuard2™ status (1: threshold reached)</div> </div> <hr/> <div> <div>Bit 1</div> <div>Overtemperature (1: driver is shut down due to overtemperature)</div> </div> <hr/> <div> <div>Bit 2</div> <div>Pre-warning overtemperature (1: threshold is exceeded)</div> </div> <hr/> <div> <div>Bit 3</div> <div>Short to ground A (1: short condition detected, driver currently shut down)</div> </div> <hr/> <div> <div>Bit 4</div> <div>Short to ground B (1: short condition detected, driver currently shut down)</div> </div> <hr/> <div> <div>Bit 5</div> <div>Open load A (1: no chopper event has happened during the last period with constant coil polarity)</div> </div> <hr/> <div> <div>Bit 6</div> <div>Open load B (1: no chopper event has happened during the last period with constant coil polarity)</div> </div> <hr/> <div> <div>Bit 7</div> <div>Stand still (1: no step impulse occurred on the step input during the last 2^20 clock cycles)</div> </div> <div>Please refer to the TMC262 Datasheet for more information.</div>	0... 255	R
209	encoder position	The value of an encoder register can be read out or written.	[encoder steps]	RW
210	Encoder prescaler	Prescaler for the encoder.	See paragraph 5.4.1.	RWE
212	maximum encoder deviation	When the actual position (parameter 1) and the encoder position (parameter 209) differ more than set here the motor will be stopped. This function is switched off when the maximum deviation is set to zero.	0... 65535 [encoder steps]	RWE
214	power down delay	Standstill period before the current is changed down to standby current. The standard value is 200 (value equates 2000msec).	1... 65535 [10msec]	RWE
254	Step/dir mode	<div>0</div> <div>Normal mode. Step/dir mode off.</div> <hr/> <div>1</div> <div>Step/dir mode with automatic current reduction in case of standstill. If current reduction in standstill is not desired, choose the same value for the axis parameters #6 and #7.</div>	0/1	RWE

*1 Unit of acceleration: $\frac{16MHz^2}{536870912 \cdot 2^{puls_divisor + ramp_divisor}} \frac{microsteps}{sec^2}$

5.1 stallGuard2™ Related Parameters

The module is equipped with TMC262 motor driver chip. The TMC262 features load measurement that can be used for stall detection. stallGuard2™ delivers a sensorless load measurement of the motor as well as a stall detection signal. The measured value changes linear with the load on the motor in a wide range of load, velocity and current settings. At maximum motor load the stallGuard2™ value goes to zero. This corresponds to a load angle of 90° between the magnetic field of the stator and magnets in the rotor. This also is the most energy efficient point of operation for the motor.




Figure 5.1: Principle function of stallGuard2

Stall detection means that the motor will be stopped when the load gets too high. This level is set using axis parameter #174 (stallGuard2™ threshold). In order to exclude e.g. resonances during motor acceleration and deceleration phases it is also possible to set a minimum speed for motor being stopped due to stall detection using axis parameter #181. Stall detection can also be used for finding the reference point. **Do not use RFS in this case.**

PARAMETERS NEEDED FOR ADJUSTING THE STALLGUARD2™ FEATURE

PARAMETERS NEEDED FOR ADJUSTING THE STALLGUARD2™ FEATURE

Number	Axis Parameter	Description																																								
6	absolute max. current (CS / Current Scale)	<div><div>The maximum value is 255. This value means 100% of the maximum current of the module. The current adjustment is within the range 0... 255 and can be adjusted in 32 steps.</div><table><tr><td>0... 7</td><td>79... 87</td><td>160... 167</td><td>240... 247</td></tr><tr><td>8... 15</td><td>88... 95</td><td>168... 175</td><td>248... 255</td></tr><tr><td>16... 23</td><td>96... 103</td><td>176... 183</td><td></td></tr><tr><td>24... 31</td><td>104... 111</td><td>184... 191</td><td></td></tr><tr><td>32... 39</td><td>112... 119</td><td>192... 199</td><td></td></tr><tr><td>40... 47</td><td>120... 127</td><td>200... 207</td><td></td></tr><tr><td>48... 55</td><td>128... 135</td><td>208... 215</td><td></td></tr><tr><td>56... 63</td><td>136... 143</td><td>216... 223</td><td></td></tr><tr><td>64... 71</td><td>144... 151</td><td>224... 231</td><td></td></tr><tr><td>72... 79</td><td>152... 159</td><td>232... 239</td><td></td></tr></table><div>The most important motor setting, since too high values might cause motor damage!</div></div>	0... 7	79... 87	160... 167	240... 247	8... 15	88... 95	168... 175	248... 255	16... 23	96... 103	176... 183		24... 31	104... 111	184... 191		32... 39	112... 119	192... 199		40... 47	120... 127	200... 207		48... 55	128... 135	208... 215		56... 63	136... 143	216... 223		64... 71	144... 151	224... 231		72... 79	152... 159	232... 239	
0... 7	79... 87	160... 167	240... 247																																							
8... 15	88... 95	168... 175	248... 255																																							
16... 23	96... 103	176... 183																																								
24... 31	104... 111	184... 191																																								
32... 39	112... 119	192... 199																																								
40... 47	120... 127	200... 207																																								
48... 55	128... 135	208... 215																																								
56... 63	136... 143	216... 223																																								
64... 71	144... 151	224... 231																																								
72... 79	152... 159	232... 239																																								
173	stallGuard2™ filter enable	<div><div>Enables the stallGuard2™ filter for more precision of the measurement. If set, reduces the measurement frequency to one measurement per four fullsteps. <i>In most cases it is expedient to set the filtered mode before using coolStep™. Use the standard mode for step loss detection.</i></div><div>0 – standard mode 1 – filtered mode</div></div>																																								
174	stallGuard2™ threshold	<div><div>This signed value controls stallGuard2™ <i>threshold</i> level for stall output and sets the optimum measurement range for readout. A lower value gives a higher sensitivity. Zero is the starting value. A higher value makes stallGuard2™ less sensitive and requires more torque to indicate a stall.</div><table><tr><td>0</td><td>Indifferent value</td></tr><tr><td>1... 63</td><td>less sensitivity</td></tr><tr><td>-1... -64</td><td>higher sensitivity</td></tr></table></div>	0	Indifferent value	1... 63	less sensitivity	-1... -64	higher sensitivity																																		
0	Indifferent value																																									
1... 63	less sensitivity																																									
-1... -64	higher sensitivity																																									
181	stop on stall	<div><div>Below this speed motor will not be stopped. Above this speed motor will stop in case stallGuard2™ load value reaches zero.</div></div>																																								
206	actual load value	<div><div>Readout of the actual load value used for stall detection (stallGuard2™).</div></div>																																								

In this chapter only basic axis parameters are mentioned which concern stallGuard2™. The complete list of axis parameters in chapter 5 contains further parameters which offer more configuration possibilities.


5.2 coolStep™ Related Parameters

The figure below gives an overview of the coolStep™ related parameters. Please have in mind that the figure shows only one example for a drive. There are parameters which concern the configuration of the current. Other parameters are for velocity regulation and for time adjustment.

It is necessary to identify and configure the thresholds for current (I_6 , I_7 and I_{183}) and velocity (V_{182}). Furthermore the stallGuard2™ feature has to be adjusted and enabled (SG_{170} and SG_{181}).

The reduction or increasing of the current in the coolStep™ area (depending on the load) has to be configured with parameters I_{169} and I_{171} .

In this chapter only basic axis parameters are mentioned which concern coolStep™ and stallGuard2™. The complete list of axis parameters in chapter 5 contains further parameters which offer more configuration possibilities.



* The lower threshold of the coolStep™ current can be adjusted up to $I_6/4$. Refer to parameter 168.

Figure 5.2: coolStep™ adjustment points and thresholds

PARAMETERS NEEDED FOR ADJUSTING THE COOLSTEP™ FEATURE

Number	Axis parameter	Description
6	absolute max. current (CS / Current Scale)	The maximum value is 255. This value means 100% of the maximum current of the module. The current adjustment is within the range 0... 255 and can be adjusted in 32 steps.
		0... 7 79...87 160... 167 240... 247
		8... 15 88... 95 168... 175 248... 255
		16... 23 96... 103 176... 183
		24... 31 104... 111 184... 191
		32... 39 112... 119 192... 199
		40... 47 120... 127 200... 207
		48... 55 128... 135 208... 215
		56... 63 136... 143 216... 223
		64... 71 144... 151 224... 231
72... 79 152... 159 232... 239		
<i>The most important motor setting, since too high values might cause motor damage!</i>		
7	standby current	The current limit two seconds after the motor has stopped.
168	smartEnergy current minimum (SEIMIN)	Sets the lower motor current limit for coolStep™ operation by scaling the CS (Current Scale, see axis parameter 6) value. Minimum motor current: 0 – 1/2 of CS 1 – 1/4 of CS
169	smartEnergy current down step	Sets the number of stallGuard2™ readings above the upper threshold necessary for each current decrement of the motor current. Number of stallGuard2™ measurements per decrement: Scaling: 0... 3: 32, 8, 2, 1 0: slow decrement 3: fast decrement
171	smartEnergy current up step	Sets the current increment step. The current becomes incremented for each measured stallGuard2™ value below the lower threshold (see smartEnergy hysteresis start). current increment step size: Scaling: 0... 3: 1, 2, 4, 8 0: slow increment 3: fast increment / fast reaction to rising load
183	smartEnergy slow run current	Sets the motor current which is used below the threshold speed. Please adjust the threshold speed with axis parameter 182.
170	smartEnergy hysteresis	Sets the distance between the lower and the upper threshold for stallGuard2™ reading. Above the upper threshold the motor current becomes decreased.
181	stop on stall	Below this speed motor will not be stopped. Above this speed motor will stop in case stallGuard2™ load value reaches zero.
182	smartEnergy threshold speed	Above this speed coolStep™ becomes enabled.
214	power down delay	Standstill period before the current is changed down to standby current. The standard value is 200 (value equates 2000msec).

For further information about the coolStep™ feature please refer to the TMC262 Datasheet.

5.3 Reference Search

The built-in reference search features switching point calibration and support of one or two reference switches. The internal operation is based on a state machine that can be started, stopped and monitored (instruction RFS, no. 13). The reference switch is connected in series with the left limit switch. The differentiation between the left limit switch and the home switch is made through software. Switches with open contacts (normally closed) are used. The analogue input AIN_0 of the module can be used as home switch.

Hints for reference search:


- The settings of the automatic stop functions corresponding to the switches (axis parameters 12 and 13) have no influence on the reference search.
- Until the reference switch is found for the first time, the searching speed is identical to the maximum positioning speed (axis parameter 4), unless reduced by axis parameter 194.
- After hitting the reference switch, the motor slowly moves until the switch is released. Finally the switch is re-entered in the other direction, setting the reference point to the center of the two switching points. This low calibrating speed is a quarter of the maximum positioning speed by default (axis parameter 195).
- Set one of the values for axis parameter 193 for selecting the reference search mode.

PARAMETERS NEEDED FOR REFERENCE SEARCH


Number	Axis Parameter	Description																
9	ref. switch status	The logical state of the reference (left) switch. See the TMC 429 data sheet for the different switch modes. The default has two switch modes: the left switch as the reference switch, the right switch as a limit (stop) switch.																
10	right limit switch status	The logical state of the (right) limit switch.																
11	left limit switch status	The logical state of the left limit switch (in three switch mode)																
12	right limit switch disable	If set, deactivates the stop function of the right switch																
13	left limit switch disable	Deactivates the stop function of the left switch resp. reference switch if set.																
141	ref. switch tolerance	For three-switch mode: a position range, where an additional switch (connected to the REFL input) won't cause motor stop.																
149	soft stop flag	If cleared, the motor will stop immediately (disregarding motor limits), when the reference or limit switch is hit.																
193	ref. search mode	<table><tr><td>1</td><td>search left stop switch only</td></tr><tr><td>2</td><td>search right stop switch, then search left stop switch</td></tr><tr><td>3</td><td>search right stop switch, then search left stop switch from both sides</td></tr><tr><td>4</td><td>search left stop switch from both sides</td></tr><tr><td>5</td><td>search home switch in negative direction, reverse the direction when left stop switch reached</td></tr><tr><td>6</td><td>search home switch in positive direction, reverse the direction when right stop switch reached</td></tr><tr><td>7</td><td>search home switch in positive direction, ignore end switches</td></tr><tr><td>8</td><td>search home switch in negative direction, ignore end switches</td></tr></table> <i>Adding 128 to these values reverses the polarity of the home switch input.</i>	1	search left stop switch only	2	search right stop switch, then search left stop switch	3	search right stop switch, then search left stop switch from both sides	4	search left stop switch from both sides	5	search home switch in negative direction, reverse the direction when left stop switch reached	6	search home switch in positive direction, reverse the direction when right stop switch reached	7	search home switch in positive direction, ignore end switches	8	search home switch in negative direction, ignore end switches
1	search left stop switch only																	
2	search right stop switch, then search left stop switch																	
3	search right stop switch, then search left stop switch from both sides																	
4	search left stop switch from both sides																	
5	search home switch in negative direction, reverse the direction when left stop switch reached																	
6	search home switch in positive direction, reverse the direction when right stop switch reached																	
7	search home switch in positive direction, ignore end switches																	
8	search home switch in negative direction, ignore end switches																	
194	referencing search speed	For the reference search this value directly specifies the search speed.																
195	referencing switch speed	Similar to parameter no. 194, the speed for the switching point calibration can be selected.																
196	distance end switches	This parameter provides the distance between the end switches after executing the RFS command (mode 2 or 3).																

5.3.1 Reference Search Modes (Axis Parameter 193)


SAP 193, 0, 1



SAP 193, 0, 2



SAP 193, 0, 3



SAP 193, 0, 4








Figure 5.3: Reference search modes 1-4

SAP 193, 0, 5**SAP 193, 0, 6****SAP 193, 0, 7****SAP 193, 0, 8****Figure 5.4: Reference search modes 5-8**

5.4 Encoder

The TMC1110 provides an interface for single ended incremental encoders with TTL (5V) outputs. For the operation with encoder please consider the following:

- The encoder counter can be read by software and can be used to monitor the exact position of the motor. This also makes closed loop operation possible.
- The Encoder channel PHASE_Z is for zeroing the encoder counter. It can be selected as high or as low active, and it is automatically checked in parallel to the Encoder channel A and B inputs for referencing exactly.
- To read out or to change the position value of the encoder, axis parameter 209 is used. To read out the position of your encoder 0 use GAP 209, 0. The position values can also be changed using command SAP 209, 0, <n>, with n = -2.147.483.648... +2.147.483.647
- To change the encoder settings, axis parameter 210 is used. For changing the prescaler of encoder 0 use SAP 210, 0, <p>.
- Automatic motor stop on deviation error is also usable. This can be set using axis parameter 212 (maximum deviation). This function is turned off when the maximum deviation is set to 0.

PARAMETERS NEEDED FOR USING THE ENCODER

Number	Axis Parameter	Description	
209	encoder position	The value of an encoder register can be read out or written.	[encoder steps]
210	Encoder prescaler	Prescaler for the encoder.	See paragraph 5.4.1
212	maximum encoder deviation	When the actual position (parameter 1) and the encoder position (parameter 209) differ more than set here the motor will be stopped. This function is switched off when the maximum deviation is set to zero.	0... 65535 [encoder steps]

5.4.1 Changing the Prescaler Value of an Encoder

The table below shows a prescaler subset which can be selected. Other values between those in the table can be used. The bits 2... 4 must not be used for the prescaler because they are needed to select special encoder functions.

TO SELECT A PRESCALER, THE FOLLOWING VALUES CAN BE USED FOR <P>:

Value for <p>	Resulting prescaler	SAP command for motor 0 SAP 210, M0, <p>	Resulting steps per rotation for a 400 line (1600 quadrate count) encoder
64	0.125	SAP 210, 0, 64	200
128	0.25	SAP 210, 0, 128	400
256	0.5	SAP 210, 0, 256	800
512	1	SAP 210, 0, 512	1600
1024	2	SAP 210, 0, 1024	3200
2048	4	SAP 210, 0, 2048	6400
4096	8	SAP 210, 0, 4096	12800
8192	16	SAP 210, 0, 8192	25600
16384	32	SAP 210, 0, 16384	51200
32768	64	SAP 210, 0, 32768	102400

Formula for resulting steps per rotation:

StepsPerRotation = LinesOfEncoder * 4 * Prescaler

Consider the following formula for your calculation: Prescaler = $\frac{p}{512}$

Example: <p> = 6400
6400/512 = 12.5 (prescaler)

There are some special functions that can also be configured using these values. To select these functions just add the following values to <p>:

Bit	Adder for <p>	Command: SAP 210, <motor number>, <p>
2	4	If set the encoder will be zeroed with next null channel event.
3	8	If set in combination with bit 2: Encoder will be zeroed with each null channel event.
4	16	Channel Z polarity for encoder clearing: 0 - low 1 - high

**Add up both <p> values from these tables to get the required value for the SAP 210 command.
The resulting prescaler is value/512.**

5.5 Calculation: Velocity and Acceleration vs. Microstep- and Fullstep-Frequency

The values of the axis parameters, sent to the TMC429 do not have typical motor values, like rotations per second as velocity. But these values can be calculated from the TMC429 parameters, as shown in this document.

TMC429 VELOCITY PARAMETERS

TMC429 velocity parameters	Related TMC429 axis parameters	Range (TMC429 and TMC429-1110)
Velocity	Axis parameter 2 target (next) speed Axis parameter 3 actual speed Axis parameter 4 maximum positioning speed Axis parameter 13 minimum speed Axis parameter 194 referencing search speed Axis parameter 195 referencing switch speed	0... 2047
a_max / maximum acceleration	Axis parameter 5	0... 2047
μsrs / microstep resolution <i>microsteps per fullstep = 2^{μsrs}</i>	Axis parameter 140 offers the following settings: 0 full step 1 half step 2 4 microsteps 3 8 microsteps 4 16 microsteps 5 32 microsteps 6 64 microsteps 7 128 microsteps 8 256 microsteps	0... 8
ramp_div / ramp divisor	Axis parameter 153: divider for the acceleration. The higher the value is, the less is the maximum acceleration Default: 0	0... 13
pulse_div / pulse divisor	Axis parameter 153: divider for the velocity. Increasing the value by one divides the acceleration into halves, decreasing the value by one doubles the acceleration. Default: 0	0... 13
f_{clk} / clock frequency	---	16MHz

5.5.1 Microstep Frequency

The microstep frequency of the stepper motor is calculated with

$$\mu sf[Hz] = \frac{f_{CLK}[Hz] \cdot velocity}{2^{pulse_div} \cdot 2048 \cdot 32} \quad \mu sf: \text{microstep-frequency}$$

5.5.2 Fullstep Frequency

To calculate the fullstep frequency from the microstep frequency, the microstep frequency must be divided by the number of microsteps per fullstep.

$$fsf[Hz] = \frac{\mu sf[Hz]}{2^{\mu srs}} \quad fsf: \text{fullstep-frequency}$$

The change in the pulse rate per time unit (a : pulse frequency change per second) is given by

$$a = \frac{f_{CLK}^2 \cdot a_{\max}}{2^{pulse_div + ramp_div + 29}}$$

This results in acceleration in fullsteps of:

$$af = \frac{a}{2^{\mu srs}} \quad af: \text{acceleration in fullsteps}$$

Example:

Signal	Value
f_{CLK}	16 MHz
velocity	1000
a_{\max}	1000
pulse_div	1
ramp_div	1
μsrs	6

$$\mu sf = \frac{16MHz \cdot 1000}{2^1 \cdot 2048 \cdot 32} = \underline{\underline{12207031Hz}}$$

$$fsf[Hz] = \frac{12207031}{2^6} = \underline{\underline{1907.34Hz}}$$

$$a = \frac{(16MHz)^2 \cdot 1000}{2^{1+1+29}} = \underline{\underline{119.21 \frac{MHz}{s}}}$$

$$af = \frac{119.21 \frac{MHz}{s}}{2^6} = \underline{\underline{1.863 \frac{MHz}{s}}}$$

5.5.2.1 Calculation of Number of Rotations:

A stepper motor has e.g. 72 fullsteps per rotation.

$$RPS = \frac{fsf}{fullstepsper\ rotation} = \frac{1907.34}{72} = 26.49$$

$$RPM = \frac{fsf \cdot 60}{fullstepsper\ rotation} = \frac{1907.34 \cdot 60}{72} = 1589.46$$

6 Global Parameters

Global parameters are grouped into 4 banks:

- bank 0 (global configuration of the module)
- bank 1 (user C variables)
- bank 2 (user TMCL™ variables)
- bank 3 (interrupt configuration)

Please use SGP and GGP commands to write and read global parameters.

6.1 Bank 0

Parameters 0... 38

The first parameters 0... 38 are only mentioned here for completeness. They are used for the internal handling of the TMCL-IDE and serve for loading microstep and driver tables. Normally these parameters remain untouched. ***If you want to use them for loading your specific values with your PC software please contact TRINAMIC and ask how to do this. Otherwise you might cause damage on the motor driver!***

Number	Parameter
0	datagram low word (read only)
1	datagram high word (read only)
2	cover datagram position
3	cover datagram length
4	cover datagram contents
5	reference switch states (read only)
6	TMC429 SMGP register
7... 22	driver chain configuration long words 0... 15
23... 38	microstep table long word 0... 15

Parameters 64... 132

Parameters with numbers from 64 on configure stuff like the serial address of the module RS485 baud rate. Change these parameters to meet your needs. The best and easiest way to do this is to use the appropriate functions of the TMCL-IDE. The parameters with numbers between 64 and 128 are stored in EEPROM only.

An SGP command on such a parameter will always store it permanently and no extra STGP command is needed. Take care when changing these parameters, and use the appropriate functions of the TMCL-IDE to do it in an interactive way.

Meaning of the letters in column Access:

Access type	Related command	Description
R	GGP	Parameter readable
W	SGP, AGP	Parameter writable
E	SGP, AGP	Parameter stored permanently in EEPROM

Number	Global parameter	Description	Range	Access																																				
64	EEPROM magic	Setting this parameter to a different value as \$E4 will cause re-initialization of the axis and global parameters (to factory defaults) after the next power up. This is useful in case of miss-configuration.	0... 255	RWE																																				
65	RS485 baud rate*)	<table><tr><td>0</td><td>9600 baud</td><td>Default</td></tr><tr><td>1</td><td>14400 baud</td><td></td></tr><tr><td>2</td><td>19200 baud</td><td></td></tr><tr><td>3</td><td>28800 baud</td><td></td></tr><tr><td>4</td><td>38400 baud</td><td></td></tr><tr><td>5</td><td>57600 baud</td><td></td></tr><tr><td>6</td><td>76800 baud</td><td>Not supported by Windows!</td></tr><tr><td>7</td><td>115200 baud</td><td></td></tr><tr><td>8</td><td>230400 baud</td><td></td></tr><tr><td>9</td><td>250000 baud</td><td>Not supported by Windows!</td></tr><tr><td>10</td><td>500000 baud</td><td>Not supported by Windows!</td></tr><tr><td>11</td><td>1000000 baud</td><td>Not supported by Windows!</td></tr></table>	0	9600 baud	Default	1	14400 baud		2	19200 baud		3	28800 baud		4	38400 baud		5	57600 baud		6	76800 baud	Not supported by Windows!	7	115200 baud		8	230400 baud		9	250000 baud	Not supported by Windows!	10	500000 baud	Not supported by Windows!	11	1000000 baud	Not supported by Windows!	0... 11	RWE
0	9600 baud	Default																																						
1	14400 baud																																							
2	19200 baud																																							
3	28800 baud																																							
4	38400 baud																																							
5	57600 baud																																							
6	76800 baud	Not supported by Windows!																																						
7	115200 baud																																							
8	230400 baud																																							
9	250000 baud	Not supported by Windows!																																						
10	500000 baud	Not supported by Windows!																																						
11	1000000 baud	Not supported by Windows!																																						
66	serial address	The module (target) address for RS485.	0... 255	RWE																																				
68	serial heartbeat	Serial heartbeat for RS485 and USB interface. If this time limit is up and no further command is noticed the motor will be stopped. 0 – parameter is disabled	[ms]	RWE																																				
69	CAN bit rate	<table><tr><td>2</td><td>20kBit/s</td><td></td></tr><tr><td>3</td><td>50kBit/s</td><td></td></tr><tr><td>4</td><td>100kBit/s</td><td></td></tr><tr><td>5</td><td>125kBit/s</td><td></td></tr><tr><td>6</td><td>250kBit/s</td><td></td></tr><tr><td>7</td><td>500kBit/s</td><td></td></tr><tr><td>8</td><td>1000kBit/s</td><td>Default</td></tr></table>	2	20kBit/s		3	50kBit/s		4	100kBit/s		5	125kBit/s		6	250kBit/s		7	500kBit/s		8	1000kBit/s	Default	2... 8	RWE															
2	20kBit/s																																							
3	50kBit/s																																							
4	100kBit/s																																							
5	125kBit/s																																							
6	250kBit/s																																							
7	500kBit/s																																							
8	1000kBit/s	Default																																						
70	CAN reply ID	The CAN ID for replies from the board (default: 2)	0... 7ff	RWE																																				
71	CAN ID	The module (target) address for CAN (default: 1)	0... 7ff	RWE																																				
73	configuration EEPROM lock flag	Write: 1234 to lock the EEPROM, 4321 to unlock it. Read: 1=EEPROM locked, 0=EEPROM unlocked.	0/1	RWE																																				
75	telegram pause time	Pause time before the reply via RS485 is sent. For RS485 it is often necessary to set it to 15 (for RS485 adapters controlled by the RTS pin).	0... 255	RWE																																				
76	serial host address	Host address used in the reply telegrams sent back via RS485.	0... 255	RWE																																				
77	auto start mode	0: Do not start TMCL™ application after power up (default). 1: Start TMCL™ application automatically after power up.	0/1	RWE																																				
81	TMCL™ code protection	Protect a TMCL™ program against disassembling or overwriting. 0 – no protection 1 – protection against disassembling 2 – protection against overwriting 3 – protection against disassembling and overwriting If you switch off the protection against disassembling, the program will be erased first! Changing this value from 1 or 3 to 0 or 2, the TMCL™ program will be wiped off.	0,1,2,3	RWE																																				
82	CAN heartbeat	Heartbeat for CAN interface. If this time limit is up and no further command is noticed the motor will be stopped. 0 – parameter is disabled	[ms]	RWE																																				
83	CAN secondary address	Second CAN ID for the module. Switched off when set to zero.	0... 7ff	RWE																																				

Number	Global parameter	Description	Range	Access
84	coordinate storage	0 – coordinates are stored in the RAM only (but can be copied explicitly between RAM and EEPROM) 1 – coordinates are always stored in the EEPROM only	0 or 1	RWE
85	do not restore user variables	0 – user variables are restored (<i>default</i>) 1 – user variables are not restored	0/1	RWE
86	step pulse length	Length of step pulse (for Step/Dir interface): $(1 + x) \mu s$ Default setting: 0 (1 μs) <i>This setting is valid for all three motor axes.</i>	0... 15	RWE
128	TMCL™ application status	0 – stop 1 – run 2 – step 3 – reset	0... 3	R
129	download mode	0 – normal mode 1 – download mode	0/1	R
130	TMCL™ program counter	The index of the currently executed TMCL™ instruction.		R
132	tick timer	A 32 bit counter that gets incremented by one every millisecond. It can also be reset to any start value.		RW
133	random number	Choose a random number.	0... 2147483 647	R

*) With most RS485 converters that can be attached to the COM port of a PC the data direction is controlled by the RTS pin of the COM port. Please note that this will only work with Windows 2000, Windows XP or Windows NT4, not with Windows 95, Windows 98 or Windows ME (due to a bug in these operating systems). Another problem is that Windows 2000/XP/NT4 switches the direction back to *receive* too late. To overcome this problem, set the *telegram pause time* (global parameter #75) of the module to 15 (or more if needed) by issuing an *SGP 75, 0, 15* command in direct mode. The parameter will automatically be stored in the configuration EEPROM.

6.2 Bank 1

The global parameter bank 1 is normally not available. It may be used for customer specific extensions of the firmware. Together with user definable commands (see section 6.3) these variables form the interface between extensions of the firmware (written in C) and TMCL™ applications.

6.3 Bank 2

Bank 2 contains general purpose 32 bit variables for the use in TMCL™ applications. They are located in RAM and can be stored to EEPROM. After booting, their values are automatically restored to the RAM.

Up to 56 user variables are available.

Meaning of the letters in column Access:

Access type	Related command	Description
R	GGP	Parameter readable
W	SGP, AGP	Parameter writable
E	SGP, AGP	Parameter stored permanently in EEPROM

Number	Global parameter	Description	Range	Access
0... 55	general purpose variable #0... 55	for use in TMCL™ applications	$-2^{31} \dots +2^{31}$	RWE
56... 255	general purpose variables #56... #255	for use in TMCL™ applications	$-2^{31} \dots +2^{31}$	RW

6.4 Bank 3

Bank 3 contains interrupt parameters. Some interrupts need configuration (e.g. the timer interval of a timer interrupt). This can be done using the SGP commands with parameter bank 3 (SGP <type>, 3, <value>). **The priority of an interrupt depends on its number. Interrupts with a lower number have a higher priority.**

The following table shows all interrupt parameters that can be set.

Meaning of the letters in column Access:

Access type	Related command	Description
R	GGP	Parameter readable
W	SGP, AGP	Parameter writable
E	SGP, AGP	Parameter stored permanently in EEPROM

Number	Global parameter	Description	Range	Access
0	Timer 0 period (ms)	Time between two interrupts (ms)	32 bit unsigned [ms]	RWE
1	Timer 1 period (ms)	Time between two interrupts (ms)	32 bit unsigned [ms]	RWE
2	Timer 2 period (ms)	Time between two interrupts (ms)	32 bit unsigned [ms]	RWE
27	Left stop switch 0 edge type	0=off, 1=low-high, 2=high-low, 3=both	0... 3	RWE
28	Right stop switch 0 edge type	0=off, 1=low-high, 2=high-low, 3=both	0... 3	RWE
29	Left stop switch 1 edge type	0=off, 1=low-high, 2=high-low, 3=both	0... 3	RWE
30	Right stop switch 1 edge type	0=off, 1=low-high, 2=high-low, 3=both	0... 3	RWE
31	Left stop switch 2 edge type	0=off, 1=low-high, 2=high-low, 3=both	0... 3	RWE
32	Right stop switch 2 edge type	0=off, 1=low-high, 2=high-low, 3=both	0... 3	RWE
39	Input 0 edge type	0=off, 1=low-high, 2=high-low, 3=both	0... 3	RWE
40	Input 1 edge type	0=off, 1=low-high, 2=high-low, 3=both	0... 3	RWE
41	Input 2 edge type	0=off, 1=low-high, 2=high-low, 3=both	0... 3	RWE
42	Input 3 edge type	0=off, 1=low-high, 2=high-low, 3=both	0... 3	RWE

7 TMCL™ Programming Techniques and Structure

7.1 Initialization

The first task in a TMCL™ program (like in other programs also) is to initialize all parameters where different values than the default values are necessary. For this purpose, SAP and SGP commands are used.

7.2 Main Loop

Embedded systems normally use a main loop that runs infinitely. This is also the case in a TMCL™ application that is running standalone. Normally the auto start mode of the module should be turned on. After power up, the module then starts the TMCL™ program, which first does all necessary initializations and then enters the main loop, which does all necessary tasks end never ends (only when the module is powered off or reset).

There are exceptions, e.g. when TMCL™ routines are called from a host in direct mode.

So most (but not all) standalone TMCL™ programs look like this:

```
//Initialization
    SAP 4, 0, 500 //define max. positioning speed
    SAP 5, 0, 100 //define max. acceleration

MainLoop:
    //do something, in this example just running between two positions
    MVP ABS, 0, 5000
    WAIT POS, 0, 0
    MVP ABS, 0, 0
    WAIT POS, 0, 0
    JA MainLoop //end of the main loop => run infinitely
```

7.3 Using Symbolic Constants

To make your program better readable and understandable, symbolic constants should be taken for all important numerical values that are used in the program. The TMCL-IDE provides an include file with symbolic names for all important axis parameters and global parameters.

Example:

```
//Define some constants
#include TMCLParam.tmc
MaxSpeed = 500
MaxAcc = 100
Position0 = 0
Position1 = 5000

//Initialization
    SAP APMaxPositioningSpeed, Motor0, MaxSpeed
    SAP APMaxAcceleration, Motor0, MaxAcc

MainLoop:
    MVP ABS, Motor0, Position1
    WAIT POS, Motor0, 0
    MVP ABS, Motor0, Position0
    WAIT POS, Motor0, 0
    JA MainLoop
```


Just have a look at the file *TMCLParam.tmc* provided with the TMCL-IDE. It contains symbolic constants that define all important parameter numbers.

Using constants for other values makes it easier to change them when they are used more than once in a program. You can change the definition of the constant and do not have to change all occurrences of it in your program.

7.4 Using Variables

The *User Variables* can be used if variables are needed in your program. They can store temporary values. The commands SGP, GGP and AGP are used to work with user variables:

SGP is used to set a variable to a constant value (e.g. during initialization phase).

GGP is used to read the contents of a user variable and to copy it to the accumulator register for further usage.

AGP can be used to copy the contents of the accumulator register to a user variable, e.g. to store the result of a calculation.

Example:

```
MyVariable = 42
    //Use a symbolic name for the user variable
    //(This makes the program better readable and understandable.)

SGP MyVariable, 2, 1234    //Initialize the variable with the value 1234
...
...
GGP MyVariable, 2          //Copy the contents of the variable to the accumulator
register
CALC MUL, 2                //Multiply accumulator register with two
AAP MyVariable, 2          //Store contents of the accumulator register to the
variable
...
...
```

Furthermore, these variables can provide a powerful way of communication between a TMCL™ program running on a module and a host. The host can change a variable by issuing a direct mode SGP command (remember that while a TMCL™ program is running direct mode commands can still be executed, without interfering with the running program). If the TMCL™ program polls this variable regularly it can react on such changes of its contents.

The host can also poll a variable using GGP in direct mode and see if it has been changed by the TMCL™ program.

7.5 Using Subroutines

The *CSUB* and *RSUB* commands provide a mechanism for using subroutines. The *CSUB* command branches to the given label. When an *RSUB* command is executed the control goes back to the command that follows the *CSUB* command that called the subroutine.

This mechanism can also be nested. From a subroutine called by a *CSUB* command other subroutines can be called. In the current version of TMCL™ eight levels of nested subroutine calls are allowed.

7.6 Mixing Direct Mode and Standalone Mode

Direct mode and standalone mode can also be mixed. When a TMCL™ program is being executed in standalone mode, direct mode commands are also processed (and they do not disturb the flow of the program running in standalone mode). So, it is also possible to query e.g. the actual position of the motor in direct mode while a TMCL™ program is running.

Communication between a program running in standalone mode and a host can be done using the TMCL™ user variables. The host can then change the value of a user variable (using a direct mode SGP command) which is regularly polled by the TMCL™ program (e.g. in its main loop) and so the TMCL™ program can react on such changes. Vice versa, a TMCL™ program can change a user variable that is polled by the host (using a direct mode GGP command).

A TMCL™ program can be started by the host using the run command in direct mode. This way, also a set of TMCL™ routines can be defined that are called by a host. In this case it is recommended to place JA commands at the beginning of the TMCL™ program that jump to the specific routines. This assures that the entry addresses of the routines will not change even when the TMCL™ routines are changed (so when changing the TMCL™ routines the host program does not have to be changed).

Example:

```
//Jump commands to the TMCL™ routines
Func1:      JA Func1Start
Func2:      JA Func2Start
Func3:      JA Func3Start

Func1Start: MVP ABS, 0, 1000
            WAIT POS, 0, 0
            MVP ABS, 0, 0
            WAIT POS, 0, 0
            STOP

Func2Start: ROL 0, 500
            WAIT TICKS, 0, 100
            MST 0
            STOP

Func3Start: ROR 0, 1000
            WAIT TICKS, 0, 700
            MST 0
            STOP
```

This example provides three very simple TMCL™ routines. They can be called from a host by issuing a run command with address 0 to call the first function, or a run command with address 1 to call the second function, or a run command with address 2 to call the third function. You can see the addresses of the TMCL™ labels (that are needed for the run commands) by using the *Generate symbol file* function of the TMCL-IDE.

Please refer to the TMCL-IDE User Manual for further information about the TMCL-IDE.

8 Life Support Policy

TRINAMIC Motion Control GmbH & Co. KG does not authorize or warrant any of its products for use in life support systems, without the specific written consent of TRINAMIC Motion Control GmbH & Co. KG.

Life support systems are equipment intended to support or sustain life, and whose failure to perform, when properly used in accordance with instructions provided, can be reasonably expected to result in personal injury or death.

© TRINAMIC Motion Control GmbH & Co. KG 2012

Information given in this data sheet is believed to be accurate and reliable. However neither responsibility is assumed for the consequences of its use nor for any infringement of patents or other rights of third parties, which may result from its use.

Specifications are subject to change without notice.



9 Revision History

9.1 Firmware Revision

Version	Date	Author OK - Olav Kahlbaum	Description
1.00	2011-OCT-18	OK	First version
1.01	2011-DEC-20	OK	<ul style="list-style-type: none"> - USB interface integration - Encoder parameter integrated - TMCL commands GIO and SIO
1.03	2012-APR-03	OK	<ul style="list-style-type: none"> - New interrupts for axis 1 and 2 - Ready for using CAN interface - Extended value range for positioning - Global parameter 86 for setting step pulse length (for Step/Dir interface) added

9.2 Document Revision

Version	Date	Author SD - Sonja Dwersteg	Description
1.00	2011-OCT-30	SD	Initial version
1.01	2011-NOV-03	SD	Minor changes
1.02	2011-NOV-10	SD	TMCL™ control function 137 added (reset to factory default, 4.5.38)
1.03	2011-DEC-22	SD	<ul style="list-style-type: none"> - Example program: Motor numbers changed from three motors to only one motor (4.3.1). - Chapter 3.1.1.2 (USB interface) updated. - Minor changes - Encoder information (chapter 5.4) - TMCL commands GIO and SIO integrated
1.04	2012-JAN-03	SD	Minor changes
1.05	2012-JAN-11	SD	Command 138 corrected
1.06	2012-APR-04	SD	Ref. 1.6 (firmware manual) corresponds to firmware version 1.03. <ul style="list-style-type: none"> - Interrupts 41 and 42 new - Interrupts 29... 32 new - Interrupts 4 and 5 new - Chapter 6: global parameters 68, 69, 70, 71, 82, 83, 85, and 86 new - Chapter 4.1 and 4.2 updated (information about CAN interface) - Chapter 5: axis parameters 6, 7, 140, 160... 184, 204... 254 for axis 0 only - Range for positioning extended to 32 bit - Axis parameters 12, 13, 141, and 149 deleted
1.07	2012-APR-11	SD	Axis parameter #254 (step/dir mode; chapter 5) corrected.

10 References

[TMC262]	TMC262 Datasheet
[TMC429]	TMC429 Datasheet
[TMCL-IDE]	TMCL-IDE User Manual
[USB-2-485]	USB-2-485 Manual

Please refer to www.trinamic.com.