

Operating Instruction Manual

Generic Slave DTM for YOKOGAWA PROFIBUS DP Slave Devices

Configuration of PROFIBUS DP Slave Devices




Table of Contents

1	INTRODUCTION.....	4
1.1	About this Manual	4
1.1.1	Descriptions of the Dialog Panes	4
1.1.2	List of Revisions	4
1.1.3	Conventions in this Manual	5
1.2	Documentation Overview.....	6
1.3	Legal Notes.....	7
1.3.1	Copyright	7
1.3.2	Important Notes	7
1.3.3	Exclusion of Liability	8
1.3.4	Warranty	8
1.3.5	Export Regulations	8
1.3.6	Software License Agreement	8
1.3.7	Registered Trademarks.....	9
1.4	About YOKOGAWA PROFIBUS DP generic Slave DTM	10
1.4.1	Requirements	10
1.5	Dialog Structure of the YOKOGAWA PROFIBUS DP generic Slave DTM.....	11
1.5.1	General Device Information.....	12
1.5.2	Navigation Area	12
1.5.3	Dialog Panes	13
1.5.4	OK, Cancel, Apply and Help.....	14
1.5.5	Status Bar	14
2	GETTING STARTED AND INSTRUCTIONS STEP BY STEP	15
2.1	Configuration Steps	15
2.2	Configuring Slave Parameters	16
3	CONFIGURATION	17
3.1	Overview Configuration	17
3.2	General	18
3.3	Modules	19
3.3.1	Configuration of the Modules of a Slave	21
3.3.2	Select Available Modules	22
3.3.3	Delete Configured Modules.....	22
3.4	Parameter	23
3.5	Groups	24
3.6	Extensions	25
3.7	DPV1	27
3.8	DPV2	29
3.9	Redundancy.....	31

4	DEVICE DESCRIPTION	33
4.1	About Device Description	33
4.2	Device	34
4.3	GSD	34
5	LISTS	35
5.1	List of Figures	35
5.2	List of Tables	35
6	GLOSSARY	37
7	APPENDIX	38
7.1.1	Station Status of the Slave Diagnosis	38
7.1.2	Extended Slave Device Diagnosis	41
7.2	Identifier Bytes	45
7.2.1	Identifier Bytes (General Identifier Format GIF)	45
7.2.2	Special Identifier Byte Format (SIF)	48
7.3	User Rights	50
7.4	References	50

1 Introduction

1.1 About this Manual

This manual describes how to configure PROFIBUS DP Slave devices (PROFIBUS DPV0 and DPV1), which are described with GSD files. These devices can be configured by use of the YOKOGAWA PROFIBUS DP generic Slave DTM within a FDT Framework.

“YOKOGAWA” means Yokogawa Electric Corporation.

1.1.1 Descriptions of the Dialog Panes

The table below gives an overview for the individual dialog panes descriptions:

Section	Subsection	Manual Page
<i>Configuration</i>	<i>General</i>	<i>18</i>
	<i>Modules</i>	<i>19</i>
	<i>Parameter</i>	<i>23</i>
	<i>Groups</i>	<i>24</i>
	<i>Extensions</i>	<i>25</i>
	<i>DPV1</i>	<i>27</i>
	<i>DPV2</i>	<i>29</i>
	<i>Redundancy</i>	<i>31</i>
<i>Device Description</i>	<i>Device</i>	<i>34</i>
	<i>GSD</i>	<i>34</i>

Table 1: Descriptions Dialog Panes

1.1.2 List of Revisions

Index	Date	Version	Component	Chapter	Revision
1	2012-04-05	2.11	YoPBGenSlaveDTM.dll YoPBGenSlaveGUI.ocx	All	Created.

Table 2: List of Revisions

1.1.3 Conventions in this Manual

Operation instructions, a result of an operation step or notes are marked as follows:

Operation Instructions:

➤ <instruction>

Or

1. <instruction>

2. <instruction>

Results:

↪ <result>

Notes:



Important: <important note>



Note: <note>



<note, where to find further information>

1.2 Documentation Overview

The following table lists the documents for SYCON.net/YOKO:

Content	Document Name
General description of netFrame: Description of the output window, menus and toolbars.	SYCONnet netFrame YOKOGAWA xx OI 01 EN.pdf
General description of netDevice. Grafical network view, device catalog and the project tree. Description of <ul style="list-style-type: none"> ▪ menus, ▪ context menus, ▪ insert device, cut/copy/paste device, additional functions (print), delete device, ▪ symbolic name, ▪ network menu, ▪ network toolbar. Getting started/Configuration steps. How to add a device description. Working with bus lines.	SYCONnet netDevice YOKOGAWA xx OI 01 EN.pdf
Description of the configuration dialogs to configure the PROFIBUS DP master. Getting started/Configuration steps. Configuration of the master <ul style="list-style-type: none"> ▪ bus parameters, ▪ DPM management (DPM Settings and DPM Layout), ▪ station table, ▪ master settings, ▪ time sync. 	PROFIBUS DP Master YOKOGAWA xx DTM OI 01 EN.pdf
Description of the configuration dialogs to configure the PROFIBUS DP slave. Getting started/Configuration steps. Configuration of the slave <ul style="list-style-type: none"> ▪ general, ▪ modules, ▪ parameter, ▪ groups, ▪ extension, ▪ DPV1, ▪ DPV2, ▪ redundancy. 	PROFIBUS DP Generic Slave DTM YOKOGAWA OI 01 EN.pdf

Table 3: Documentation Overview

1.3 Legal Notes

1.3.1 Copyright

© Hilscher, 2012, Hilscher Gesellschaft für Systemautomation mbH

All rights reserved.

The images, photographs and texts in the accompanying material (user manual, accompanying texts, documentation, etc.) are protected by German and international copyright law as well as international trade and protection provisions. You are not authorized to duplicate these in whole or in part using technical or mechanical methods (printing, photocopying or other methods), to manipulate or transfer using electronic systems without prior written consent. You are not permitted to make changes to copyright notices, markings, trademarks or ownership declarations. The included diagrams do not take the patent situation into account. The company names and product descriptions included in this document may be trademarks or brands of the respective owners and may be trademarked or patented. Any form of further use requires the explicit consent of the respective rights owner.

1.3.2 Important Notes

The user manual, accompanying texts and the documentation were created for the use of the products by qualified experts, however, errors cannot be ruled out. For this reason, no guarantee can be made and neither juristic responsibility for erroneous information nor any liability can be assumed. Descriptions, accompanying texts and documentation included in the user manual do not present a guarantee nor any information about proper use as stipulated in the contract or a warranted feature. It cannot be ruled out that the user manual, the accompanying texts and the documentation do not correspond exactly to the described features, standards or other data of the delivered product. No warranty or guarantee regarding the correctness or accuracy of the information is assumed.

We reserve the right to change our products and their specification as well as related user manuals, accompanying texts and documentation at all times and without advance notice, without obligation to report the change. Changes will be included in future manuals and do not constitute any obligations. There is no entitlement to revisions of delivered documents. The manual delivered with the product applies.

Hilscher Gesellschaft für Systemautomation mbH is not liable under any circumstances for direct, indirect, incidental or follow-on damage or loss of earnings resulting from the use of the information contained in this publication.

1.3.3 Exclusion of Liability

The software was produced and tested with utmost care by Hilscher Gesellschaft für Systemautomation mbH and is made available as is. No warranty can be assumed for the performance and flawlessness of the software for all usage conditions and cases and for the results produced when utilized by the user. Liability for any damages that may result from the use of the hardware or software or related documents, is limited to cases of intent or grossly negligent violation of significant contractual obligations. Indemnity claims for the violation of significant contractual obligations are limited to damages that are foreseeable and typical for this type of contract.

It is strictly prohibited to use the software in the following areas:

- for military purposes or in weapon systems;
- for the design, construction, maintenance or operation of nuclear facilities;
- in air traffic control systems, air traffic or air traffic communication systems;
- in life support systems;
- in systems in which failures in the software could lead to personal injury or injuries leading to death.

We inform you that the software was not developed for use in dangerous environments requiring fail-proof control mechanisms. Use of the software in such an environment occurs at your own risk. No liability is assumed for damages or losses due to unauthorized use.

1.3.4 Warranty

Please refer to the **Hilscher Software License Agreement** provided in printed form!

1.3.5 Export Regulations

The delivered product (including the technical data) is subject to export or import laws as well as the associated regulations of different countries, in particular those of Germany and the USA. The software may not be exported to countries where this is prohibited by the United States Export Administration Act and its additional provisions. You are obligated to comply with the regulations at your personal responsibility. We wish to inform you that you may require permission from state authorities to export, re-export or import the product.

1.3.6 Software License Agreement

Please refer to the **Hilscher Software License Agreement** provided in printed form!

1.3.7 Registered Trademarks

Windows Vista, Windows 7 and Windows Server 2008 are registered trademarks of Microsoft Corporation.

PROFIBUS is a trademark of PROFIBUS International, Karlsruhe.

All other mentioned trademarks are property of their respective legal owners.

1.4 About YOKOGAWA PROFIBUS DP generic Slave DTM

You can use the YOKOGAWA PROFIBUS DP generic Slave DTM to configure PROFIBUS DP Slave described with GSD files within a FDT Framework.

The information necessary for the configuration of the PROFIBUS DP Slave devices is stored within the PROFIBUS DP Master device when using the PROFIBUS Generic Slave DTM and thus the Master is configured.

1.4.1 Requirements

Requirements YOKOGAWA PROFIBUS DP generic Slave DTM

Requirements for working with a generic PROFIBUS Device DTM are:

- Installed FDT/DTM V 1.2 compliant frame application
- Installed PROFIBUS DP Master DTM
- GSD files of the devices to be configured
- The DTM must be loaded to the device catalog.

Loading GSD Files

To add devices to the **netDevice** device catalog, the GSD file of the used device must be imported via **netDevice** menu **Network > Import Device Descriptions** into the GSD folder of the DTM. This folder is located in the application data directory (All Users) of the configuration software.



For further information refer to section *Configuration Steps* on page 15, under step 1 and 2.



Note: Files and folders added by the user will not be deleted by SYCON.net/YOKO uninstall procedure.

1.5 Dialog Structure of the YOKOGAWA PROFIBUS DP generic Slave DTM

The graphical user interface of the DTM is composed of different areas and elements listed hereafter:

1. A header area containing the **General Device Information**,
2. The **Navigation Area** (area on the left side),
3. The **Dialog Pane** (main area on the right side),
4. The general buttons **OK**, **Cancel**, **Apply**, **Help**,
5. The **Status Line** containing information e. g. the online-state of the utility.




Figure 1: Dialog Structure of the YOKOGAWA PROFIBUS DP generic Slave DTM

1.5.1 General Device Information

Parameter	Meaning
IO Device	Name of the device
Vendor	Vendor name of the device
Device ID	Identification number of the device
Vendor ID	Identification number of the vendor

Table 4: General Device Information

1.5.2 Navigation Area

The **Navigation Area** contains folders and subfolders to open the dialog panes of the DTM.



Figure 2: Navigation Area

- Select the required folder and subfolder.
- The corresponding Dialog pane is displayed.

Hide / display Navigation

	Hiding the navigation area (above right side).
Show navigation area	Opening the navigation area (below left side).

1.5.3 Dialog Panes

Configuration	
General	At the pane General the actual Station Address of the Slave device is displayed and can be changed if necessary. Further information to this you find in section <i>General</i> on page 18.
Modules	At the Modules pane modules can be selected or assigned and configured. Further information to this you find in section <i>Modules</i> on page 19.
Parameters	The Parameter pane allows it to change the parameter settings of the modules. A detailed description you find in section <i>Parameter</i> on page 23.
Groups	At the pane Groups the single Slaves devices can be assigned to up to eight different, after a Master was arranged. Further information to this you find in section <i>Groups</i> on page 24.
Extensions	The Extensions pane contains adjustment possibilities for the extension parameters: Auto Clear, Fail Safe Behavior, Configuration Data Convention, Error on Cyclic Data Exchange and Diagnosis update delay. Further information to this you find in section <i>Extensions</i> on page 25.
DPV1	The DPV1 pane gives access to the DPV1 functions for an acyclic data exchange and to the functions read write and alarm handling. Further information to this you find in section <i>DPV1</i> on page 27.
DPV2	The DPV2 pane allows Time Sync configuration for the Slave. Further information to this you find in section <i>DPV2</i> on page 29.
Redundancy	The Redundancy pane allows redundancy configuration for the Slave. Further information to this you find in section <i>Redundancy</i> on page 31.
Device Description	
Device	The Device Info pane contains the manufacturer information about the device. Further information to this you find in section <i>Device</i> on page 34.
GSD	By use of the GSD-Viewer a GSD file can be searched through. Further information to this you find in section <i>GSD</i> on page 34.

Table 5: Overview Dialog Panes

1.5.4 OK, Cancel, Apply and Help

OK, Cancel, Apply and Help you can use as described hereafter.

	Meaning
OK	To confirm your latest settings, click OK . All changed values will be applied on the frame application database. <i>The dialog then closes.</i>
Cancel	To cancel your latest changes, click Cancel . Answer to the safety query Configuration data has been changed. Do you want to save the data? by Yes , No or Cancel . Yes: The changes are saved or the changed values are applied on the frame application database. <i>The dialog then closes.</i> No: The changes are <u>not</u> saved or the changed values are not applied on the frame application database. <i>The dialog then closes.</i> Cancel: <i>Back to the DTM.</i>
Apply	To confirm your latest settings, click Apply . All changed values will be applied on the frame application database. <i>The dialog remains opened.</i>
Help	To open the DTM online help, click Help .

Table 6: OK, Cancel, Apply and Help

1.5.5 Status Bar

The **Status Bar** displays information about the current state of the DTM. The current activity, is signaled graphically via icons in the status bar.




Figure 3: Status Bar




Icon / Meaning	
Data Source States	
	Data set: The displayed data are read out from the instance data set (database).
	Device: The displayed data are read out from the device.
States of the instance Date Set	
	Valid Modified: Parameter is changed (not equal to data source).

Table 7: Status Icons [1]

2 Getting started and Instructions Step by Step

2.1 Configuration Steps

The following table describes the steps to configure a PROFIBUS DP Slave device with the YOKOGAWA PROFIBUS DP generic Slave DTM as it is typical for many cases. At this time it is presupposed that the PROFIBUS DP Master DTM installation was already done.

#	Step	Short Description	For detailed information see section	Page
1	Add PROFIBUS DP Slave in the Device Catalog	Add the Slave in the Device Catalog by importing the device description file to the Device Catalog. Depending of the FDT Container. For netDevice: - Network > Import Device Descriptions.	(See Operating Instruction Manual netDevice and netProject)	-
2	Load device catalog	Depending of the FDT Container. For netDevice: - select Network > Device Catalog , - select button Reload Catalog .	(See Operating Instruction Manual netDevice and netProject)	-
3	Create new project / Open existing project	Depending of the frame application. For the configuration software: - select File > New or File > Open .	(See Operating Instruction Manual of the Frame Application)	-
4	Insert Master or Slave into configuration	Depending of the FDT Container: For netDevice: - in the Device Catalog click to the Controller, - and insert the device via drag and drop to the line in the network view, - in the Device Catalog click to the Slave, - and insert the device via drag and drop to the Controller bus line in the network view.	-	-
5	Configure Slave	Configure the Slave device. - Double click to the device icon of the Slave. - The Slave DTM configuration dialog is displayed. In the Slave DTM configuration dialog: - select Configuration > General , - set the Watchdog control and Interval, - select Configuration > Modules , - configure the Modules of the Slave, - select Configuration > Parameter , - set the module Parameters, - Select Configuration > Group , - assign the Slave to a group, - select Configuration > Extensions , - set the Extension parameters, - select Configuration > DPV1 , - configure the DPV1 functions, - select Configuration > DPV2 , - configure the Time Sync for the Slave, - select Configuration > Redundancy , - configure the Redundancy Mode and the Output Hold Time for the Slave, - close the Slave DTM configuration dialog via the button OK .	<i>Configuring Slave Parameter</i> <i>General</i> <i>Modules</i> <i>Parameter</i> <i>Groups</i> <i>Extensions</i> <i>DPV1</i> <i>DPV2</i> <i>Redundancy</i>	16 18 19 23 24 25 27 29 31
6	Configuration Steps Master device	Configure the Master device via PROFIBUS DP Master DTM.	(See Operating Instruction Manual DTM for PROFIBUS DP Master devices)	-

#	Step	Short Description	For detailed information see section	Page
7	Save project	Depending of the frame application. For the configuration software: - select File > Save .	(See <i>Operating Instruction Manual of the Frame Application</i>)	-

Table 8: Getting started - Configuration Steps

2.2 Configuring Slave Parameters

The following steps are needed to set the Slave device parameters using the YOKOGAWA PROFIBUS DP generic Slave DTM:

1. Set the Watchdog control and Interval:
 - Select **Configuration > General** in the navigation area.
2. Configure the **Modules** of the Slave.
 - Select **Configuration > Modules** in the navigation area.
3. Set the module **Parameters**.
 - Select **Configuration > Parameter** in the navigation area.
4. Assign the Slave to a group.
 - Select **Configuration > Group** in the navigation area.
5. Set the **Extension** parameters.
 - Select **Configuration > Extensions** in the navigation area.
6. Configure the **DPV1** functions.
 - Select **Configuration > DPV1** in the navigation area.
7. Configure the Time Sync for the Slave.
 - Select **Configuration > DPV2** in the navigation area.
8. Configure the Redundancy Mode and the Output Hold Time for the Slave.
 - Select **Configuration > Redundancy** in the navigation area.



For more information refer to section *General* on page 18, to section *Modules* on page 19, to section *Parameter* on page 23, to section *Groups* on page 24, to section *Extensions* on page 25 *DPV1* on page 27, *DPV2* on page 29 and to section *Redundancy* on page 31.

3 Configuration

3.1 Overview Configuration

Dialog Panes “Configuration”

The table below gives an overview for the **Configuration** dialog panes descriptions:

Section	Subsection	Page
Configuration	General	18
	Modules	19
	Parameter	23
	Groups	24
	Extensions	25
	DPV1	27
	DPV2	29
	Redundancy	31

Table 9: Descriptions of the Dialog Panes Configuration




Figure 4: Navigation Area - Configuration

3.2 General



The screenshot shows a configuration window with a light beige background. It contains three fields: 'Station Address:' with a text box containing the number '5', 'Watchdog control' with a checked checkbox, and 'Interval:' with a text box containing '200' followed by 'ms'.

Figure 5: Configuration > General

At the pane **Configuration > General** the actual **Station Address** of the Slave device is displayed. The station address is set in the Master configuration.

The setting **Watchdog control** activates or deactivates in the Slave the monitoring of communication errors to the assigned DP Master. If the DP Slave detects an interruption of an already operational communication, defined by the Watchdog time, then the Slave sets the outputs into the secure condition.



Note: When the monitoring by means of the **Watchdog control** has been deactivated, it is possible that the outputs are not set into a safe state by the Slave, even though the communication has been interrupted.

In the field **Interval** the monitoring time of the selected Slave device is set. If the time chosen for this is too short for a low baud rate, then it is possible that the Slave will set its outputs into the safe state. If the time chosen is too long, it is possible that if an interruption occurs, the Slave will take a long time to set its outputs into the safe state.

3.3 Modules

At the **Modules** pane modules can be selected or assigned and configured.

The screenshot shows the 'Modules' configuration window. It has two main sections: 'Available Modules' and 'Configured Modules'.

Available Modules:

	Module	Inputs	Outputs	In/Out	Identifier
▶	1 Byte In	1	0	0	0x90
		1 Byte			0x90
□	1 Byte Out	0	1	0	0xA0
			1 Byte		0xA0
+	1 Word In	2	0	0	0xD0
+	1 Word Out	0	2	0	0xE0
+	2 Bytes In	2	0	0	0x91
+	2 Bytes Out	0	2	0	0xA1
+	2 Words In	4	0	0	0xD1
+	2 Words Out	0	4	0	0xE1

Buttons: **Insert**, **Append**

Configured Modules:

	Slot	Module	Inputs	Outputs	In/Out	Identifier
▶	1	1 Byte Out	0	1	0	0xA0
				1 Byte		0xA0
□	2	1 Byte In	1	0	0	0x90
			1 Byte			0x90

Buttons: **Remove**

Summary:

- Length of input/output data: 2 bytes (max. 488 bytes)
- Length of input data: 1 bytes (max. 244 bytes)
- Length of output data: 1 bytes (max. 244 bytes)
- Number of modules: 2 (max. 24)

Figure 6: Configuration > Modules (CIFX DP/DPS, Example of a simple Slave)

There are two kinds of Slaves. A **simple Slave** has a fixed data length. The data length of a **complex** and **modular Slave** is configurable. The selection list **Available Modules** shows all possible modules of the Slave.

- **Module Configuration of a simple Slave**

In the case of a simple Slave, one module is shown and it is copied automatically into the list **Configured Modules**.

For simple Slaves in the column **Module** a module name is displayed. This one indicates the number of inputs, outputs or inputs/outputs of that module. In the line with the module name in the columns **Inputs**, **Outputs** and **In/Out** the number of inputs, the number of outputs or the number of inputs/outputs of the module will be displayed in Bytes. In the line below the module name, the number and the data type (byte or word) of the inputs, outputs or inputs/outputs of this module are displayed.

- **Module Configuration of a complex modular Slave**

In case of a complex modular Slave, the user has to select the required modules manually.

The screenshot shows the 'Modules' configuration window. It is divided into two main sections: 'Available Modules' and 'Configured Modules'.

Available Modules:

	Module	Inputs	Outputs	In/Out	Identifier
▶	mex_sg	23	17	8	0x03,0x00,0x30,0x01,0x20,0x50,0x60,0x10,0x01,0x20,0x10,0x03,0x00,0x30,0x01
			1 Byte		0x20
		1 Word			0x50
			1 Word		0x60
		1 Byte			0x10
					0x01,0x20
		1 Byte			0x10
			1 Byte		0x20
					0x03,0x00,0x30,0x02

Configured Modules:

	Slot	Module	Inputs	Outputs	In/Out	Identifier
▶	1	mex_sg	23	17	8	0x03,0x00,0x30,0x01,0x20,0x50,0x60,0x10,0x01,0x20,0x03,0x00,0x30,0x01
1.1				1 Byte		0x20
1.2			1 Word			0x50
1.3				1 Word		0x60
1.4			1 Byte			0x10
1.5						0x01,0x20
1.6			1 Byte			0x10
1.7				1 Byte		0x20
1.8						

Buttons: Insert, Append, Remove

Summary:

- Length of input/output data: 56 bytes (max. 176 bytes)
- Length of input data: 31 bytes (max. 176 bytes)
- Length of output data: 25 bytes (max. 176 bytes)
- Number of modules: 1 (max. 128)

Figure 7: Configuration > Modules (XN-mex_sg, Example of a complex modular Slave)

For modules consisting from several submodules, in the column **Module** the module name is displayed. In the line with the module name in the columns **Inputs**, **Outputs** and **In/Out** the number of inputs, the number of outputs or the number of inputs/outputs of the module will be displayed in Bytes. In the line below the module name, the number and the data type (byte or word) of the inputs, outputs or inputs/outputs of this module are displayed. In the columns **Inputs**, **Outputs** and **In/Out** for each submodule the number and the data type (byte or word) of the inputs, outputs or inputs/outputs are displayed.

In the column **Identifier** all identifier of the sub modules are displayed in the same line. A description of the Module Configuration Identifier you find in section *Identifier Bytes* on page 45.

The **Slot** column shows a sequential number for the modules or a sequential subnumber for the submodules of a module.

3.3.1 Configuration of the Modules of a Slave

For configuration of the modules of a Slave (selection of the modules), proceed as follows:

1. Insert all the required modules from the selection list **Available Modules** into the list **Configured Modules**. There are several possibilities to select available modules. This is described in section *Select Available Modules* on page 22.

The sequence of the modules in the list **Configured Modules** is important and must match with the sequence which exists in the Master. Typically, the sequence is the actual physical sequence. There are Slaves to which this rule does not apply and where for example first analogue modules and then digital modules must be entered, independent of their actual sequence.

For further information about the modules of the used Slave see the manual of the device manufacturer.



Note: If the Slave device has only one module, this module is taken over automatically in the table **Configured Modules** and can not be deleted.

2. Click on the **OK** button to confirm your selection. If the selection should not be taken over, click the **Cancel** button.

3.3.2 Select Available Modules

There are several possibilities to select an available module and insert it in the list **Configured Modules**:

Possibility	Procedure
Double Click on available Module	Select a module by clicking on it in the list Available Modules and with a double click on this module it appears as last module in the list Configured Modules .
'Insert' Button	Select a module by clicking on it in the list Available Modules . With a mouse click on the Insert button, this module appears in the list Configured Modules in the actually selected slot.
'Append' Button	Select a module by clicking on it in the list Available Modules . With a mouse click on the Append button, the selected module is appended as <u>last module</u> in the list Configured Modules .

Table 10: Select Available Modules



Note: A multiselection is possible. That means several modules can be selected in the list **Available Modules** by holding the SHIFT key and inserted in the list **Configured Modules**.

3.3.3 Delete Configured Modules

To delete a configured module from the list **Configured Modules**, there is the following possibility:

Button	Procedure
'Delete'	Select a module by clicking on it in the list Configured Modules . With a mouse click on the Delete button the selected module will be deleted from the list Configured Modules .

Table 11: Delete Configured Modules

3.4 Parameter

The pane **Parameter** allows it to change the parameter settings of the modules.

The screenshot shows a software interface titled "Parameters". At the top, there is a "Module:" dropdown menu currently set to "Common", with a list showing "Common", "Module 1", and "Module 2". To the right is a "Display Mode:" dropdown set to "Hexadecimal". Below these is a table of parameters:

Name	Value
Value 1	0x01
Value 2	ON
Value 3	No

Figure 8: Configuration > Parameter

If default parameters are available in the GSD file of the Slave, they are automatically inserted.

Some of the DP Slave devices require further Parameter data, for instance in order to change a measuring limit or a value range. This type of data is manufacturer and slave specific. The meaning of the parameters is determined by the device manufacturer. The explanations can be taken from the manufacturers' manual.

- **Module**

In the Module field the module which should be displayed has to be selected. The modules have to be assigned in the Configuration before (see section *Modules* on page 19).

- **Parameter and Value**

The Values of the Parameters can be changed by making a double click on the parameter.

The meaning of the single Parameters can be found in the manual of the device manufacturer.

This screenshot shows the same "Parameters" pane as Figure 8, but with the "Value" for "Value 3" being edited. A dropdown menu is open, showing the current value "No" and an alternative option "Yes".

Name	Value
Value 1	0x01
Value 2	ON
Value 3	No

Figure 9: Change Parameter Values

The **Representation** of the parameter values is by default in hexadecimal representation. If in the drop down list **Display Mode** the item 'Decimal' is selected, the representation changes into the decimal representation.




Figure 10: Decimal Representation of the Parameter Values

3.5 Groups

After a Master was arranged, the single Slaves devices can be assigned to up to eight different **Groups**.




Figure 11: Configuration > Groups

The assignment of the actual Slave device to one or more groups takes place by enabling the group respectively groups with the desired characteristics.

The selected group membership is transferred to the Slave device during its start-up sequence. The group membership acts as a filter for the Sync and Freeze global commands. These are output as Broadcast telegrams in order to synchronize the input and output data of several Slaves. Only the Slaves in whose group these commands have been assigned react on it.

3.6 Extensions

The **Extensions** pane contains adjustment possibilities for the extension parameters: Auto Clear, Fail Safe Behavior, Configuration Data Convention, Error on Cyclic Data Exchange and Diagnosis update delay.

The screenshot shows the 'Extensions' configuration window. It has a title bar 'Extensions' and a light yellow background. There are five sections, each with a title and two radio button options:

- Auto Clear**: ☒ Process Auto Clear, ☐ Ignore Auto Clear
- Fail-Safe Behavior**: ☐ Slave receives zero data in Clear Mode, ☒ Slave receives no data in Clear Mode
- Configuration Data Convention**: ☐ DPV1 compliant, ☒ EN50170 compliant
- Error on Cyclic Data Exchange**: ☐ Continue connecting to slave on failure, ☒ Do not try to connect to slave on failure
- Diagnosis update delay**: A text box containing '3' followed by 'bus cycles'.

Figure 12: Configuration > Extensions

Setting	Description	Default
Auto Clear	<p>The setting Auto Clear activates or respectively deactivates the Auto Clear Function of the actual Slave. This function can only be used, if the <u>global Auto Clear is activated in the Master</u>. The setting of the global Auto Clear is typically configured in the Bus Parameters of the Master.</p> <p>If no data exchange occurs to at least one Slave (Process Auto Clear) or an existing data exchange takes place after the expiration of a monitoring time, then the Master leaves the data exchange and sets the outputs of all assigned DP Slaves into a secure condition.</p> <p>If the setting Ignore Auto Clear is selected, the Master tries to stay in the data exchange with the other Slaves.</p>	Process Auto Clear
Fail Safe Behavior	<p>This mode indicates to the Master that the affected Slave is working in a so-called Fail_Safe mode.</p> <p>If the Fail Safe mode is activated, in the CLEAR state the Slave will receive output data of the length zero instead of the zero output data.</p> <p>On the basis of this process, the Slave immediately recognizes that the Master is in the CLEAR condition even if a previous CLEAR command was destroyed on the Bus.</p>	Slave receives no data in Clear Mode
Configuration Data Convention	<p>The Configuration Data Convention determines whether the configuration data is interpreted according to EN 50170 (supported) or additional configuration data according to PROFIBUS DPV1 extension is used (not supported). Do not use the setting DPV1 compliant.</p>	EN 50170 compliant
Error on Cyclic Data Exchange	<p>If the option Continue if Slave not responding is selected, the Master remains in the state DATA_EXCHANGE and holds the connection to the Slave.</p> <p>When Abort if Slave not responding is chosen, the Master does not remain in the DATA_EXCHANGE condition for the affected Slave if the Slave has been recognized as incorrect, but breaks off the connection to the Slave.</p> <p>Default: Abort if Slave not responding (do not try to connect to slave on failure)</p>	Do not try to connect to slave on failure

Setting	Description	Default
Diagnosis update delay	<p>Some Slave devices which are newer require more time for the consistency testing for the processing of the SET_PRM parameterizing telegrams.</p> <p>In this case the standard diagnosis cycle is not sufficient after the parameterizing phase, to detect the disposition of the Slave for the DATA_EXCHANGE.</p> <p>With the diagnosis delay, the number of diagnosis cycles is advanced after the parameterizing phase, which is the maximum that the Master waits for this disposition, before it starts a new parameterizing.</p> <p>The value range is 0..255.</p>	3 bus cycles

Table 12: Configuration > Extensions

3.7 DPV1

DPV1 serves for an acyclic data exchange and supports the functions read write and alarm handling.



Note: DPV1 functions can only be used and configured, if the used DP Master supports DPV1 functions.

Enable DPV1

Figure 13: Configuration > DPV1 > Enable DPV1

The option **Enable DPV1** has to be checked, to activate DPV1. All setting possibilities concerning DPV1 are grayed out before activating.



Note: In case of Slave devices which do not support DPV1, the **Enable DPV1** field is grayed out and can not be checked for this Slave.

When Redundancy Mode is activated (see section *Redundancy* on page 31) **Enable DPV1** is enabled and checked.

The **Max. channel data length** determines the maximum length of the DPV1 Alarm telegrams. The Slave will arrange its buffer size for the concerning number of data.

The **Max. alarm PDU length** determines the maximum quantity of active alarms.

Alarms

Figure 14: Configuration > DPV1 > Alarms

The **Alarm mode** defines the maximum number of possible active alarms: 1 alarm of each type respectively 2, 4, 8, 12, 16, 24 or 32 alarms in total.

The following alarms can be activated or deactivated by selecting it or not.

- Pull Plug alarm (module pulled),
- Process alarm,
- Diagnosis alarm,
- Manufacturer specific alarm,
- Status alarm and
- Update alarm.

Extra Alarm SAP




Figure 15: Configuration > DPV1 > Extra Alarm SAP

It the field **Extra Alarm SAP** it is set, if the DPV1 Master acknowledges an alarm to the DPV1 Salve via **SAP 51** or **SAP 50**.

Setting	Description	Default
SAP 51	DPV1-Master acknowledges alarms via SAP 51. The Master uses SAP 51 for DPV1 read/write and for alarm acknowledge to this Slave.	Default
SAP 50	DPV1-Master acknowledges alarms via SAP 50. The Master uses SAP 50 for the alarm acknowledge to this Slave. However. The Master still uses SAP 51 for DPV1 read/write services. This setting may cause a higher performance because SAP 50 is used exclusively for the alarm acknowledge and can not be delayed by a running DPV1 read/write service. To use this feature requires that the slave supports it. This information is part of the GSD file.	-

Table 13: Configuration > DPV1 > Extra Alarm SAP

3.8 DPV2

The **DPV2** pane contains adjustment possibilities for the Time Sync configuration for the Slave.

Activating Time Sync, Clock Sync Interval

For Time Sync configuration the settings **Activating Time Sync** and **Clock Sync Interval** must be used.




Figure 16: Configuration > DPV2 > Activate Time Sync, Clock Sync Interval




Figure 17: Configuration > DPV2 > Activate Time Sync, Clock Sync Interval - grayed out as Time Sync is not supported by the Slave (GSD)

Parameter	Meaning	Range of Value/Value
Activate Time Sync	<p>Activate Time Sync is enabled (checked), if Time Sync is supported by the Slave (GSD).</p> <p>Otherwise the field is grayed out and can not be checked for this Slave.</p> <p>Time Sync of Master DTM: In the Time Sync pane of the Master DTM a global clock sync interval can be set (Overwrite clock sync interval for all slaves with Time Sync support checked). If the global clock sync interval is set, the clock sync interval value for the Slave can not be modified in the YOKOGAWA PROFIBUS DP generic Slave DTM and a warning message will be displayed, if the user tries to check Activate Time Sync in the DPV2 pane in the YOKOGAWA PROFIBUS DP generic Slave DTM.</p>	checked, unchecked, Default: checked (<i>Time_Sync_supp</i> is set to true in GSD)
Clock Sync Interval (Time base 10 ms)	<p>Clock Sync Interval of the Out signal in 10ms steps.</p> <p>Time base 10 ms: e.g. the value 1000 results as 10ms*1000=10s Clock Sync Interval</p>	0 ... $2^{16} - 1$, Default: 1000

Table 14: Activate Time Sync, Clock Sync Interval

- Respectively adjust **Clock Sync Interval**.

If Global Clock Sync Intervall Setting is activated in Master DTM:

The Clock Sync Interval value for all Slaves in the configuration with Time Sync support can be set globally in the Master DTM. In case this global setting is activated, the Clock Sync Interval value for the Slave can not be modified in the YOKOGAWA PROFIBUS DP generic Slave DTM and the following warning message will be displayed:




Figure 18: Configuration > DPV2 > Activate Time Sync, Clock Sync Interval > Warning Message on globally set Clock Sync Intervall

- Click **OK**.

The global Clock Sync Interval value setting is done in the **TimeSync** settings pane in the PROFIBUS DP Master DTM.

3.9 Redundancy

The **Redundancy** pane contains adjustment possibilities for the Redundancy configuration for the Slave.

Figure 19: Configuration > Redundancy

Activating Redundancy Mode, Output Hold Time

For Redundancy configuration the settings **Activating Redundancy Mode**, and **Output Hold Time** must be used.

Figure 20: Configuration > Redundancy > Activating Redundancy Mode, Output Hold Time


Parameter	Meaning	Range of Value/Value
Activating Redundancy Mode	Activating Redundancy Mode is enabled (checked), if Redundancy is supported by the Slave (GSD). Otherwise the field is grayed out and can not be checked for this Slave.  Note: When Redundancy Mode is activated, Station Address Offset will be set to 0 always.	checked, unchecked, Default: checked (<i>Slave_Redundancy_supp</i> and <i>PrmCmd_supp</i> are set to true in GSD)
Output Hold Time (Time base 10 ms)	Hold Time of the Out signal in 10ms steps. Time base 10 ms: e.g. the value 128 (0x0080) results as 10ms*128=1280ms=1,28s Hold Time	$0 \dots 2^{16} - 1$, Default: <i>Slave_Max_Switch_Over_Time</i> +1 (if specified in GSD), otherwise: 128

Table 15: Activating Redundancy Mode, Output Hold Time

- Adjust **Output Hold Time**.

Using Jokerblock



Figure 21: Configuration > Redundancy > Using Jokerblock (enabled)




Figure 22: Configuration > Redundancy > Using Jokerblock (disabled)

Parameter	Meaning	Range of Value/Value
Using Jokerblock	The field is grayed out and can not be checked/unchecked by the user. Using Jokerblock is enabled (checked), if GSD for the Slave specifies <i>Jokerblock_supp = 1 & Jokerblock_Location = 0 or 1 & Jokerblock_Type=129</i> Otherwise this option is disabled (unchecked) for this Slave. Note: Ext-Prm-Telegram is not supported!	checked, unchecked, Default: checked (<i>Jokerblock_supp = 1 & Jokerblock_Location = 0 or 1 & Jokerblock_Type=129</i> are set to true in GSD)

Table 16: Using Jokerblock

4 Device Description

4.1 About Device Description

Dialog Panes “Device Description”

The table below gives an overview for the **Device Description** dialog panes descriptions:

Section	Subsection	Page
Device Description	Device	34
	GSD	34

Table 17: Descriptions of the Dialog Panes Device Description




Figure 23: Navigation Area - Device Description

4.2 Device

The **Device Info** dialog contains manufacturer information about the device, which is defined in the GSD file. The following information is indicated:

Parameter	Meaning
Vendor name	Vendor name of the device
Product name	Name of the device
Ident number	Identification number of the device
Revision	Hardware reference

Table 18: General Device Information

4.3 GSD

The **GSD Viewer** shows the content of the GSD file in a text view.

Under **Filename** the file directory path and the file name of the displayed GSD file is displayed. **Find what** offers a search feature to search for text contents within the text of the GSD file.

In the GSD Viewer window on the left side, the line number is displayed for simple overview, the further entries show the GSD file in text format.

Parameter	Meaning
Filename	File directory path and the file name of the displayed GSD file.
Find what	Search feature to search for text contents within the text of the GSD file.
Match case	Search option
Match whole word	Search option

Table 19: Device Description – GSD Viewer

5 Lists

5.1 List of Figures

Figure 1: Dialog Structure of the YOKOGAWA PROFIBUS DP generic Slave DTM	11
Figure 2: Navigation Area	12
Figure 3: Status Bar	14
Figure 4: Navigation Area - Configuration	17
Figure 5: Configuration > General	18
Figure 6: Configuration > Modules (CIFX DP/DPS, Example of a simple Slave)	19
Figure 7: Configuration > Modules (XN-mex_sg, Example of a complex modulare Slave)	20
Figure 8: Configuration > Parameter	23
Figure 9: Change Parameter Values	23
Figure 10: Decimal Representation of the Parameter Values	24
Figure 11: Configuration > Groups	24
Figure 12: Configuration > Extensions	25
Figure 13: Configuration > DPV1 > Enable DPV1	27
Figure 14: Configuration > DPV1 > Alarms	27
Figure 15: Configuration > DPV1 > Extra Alarm SAP	28
Figure 16: Configuration > DPV2 > Activate Time Sync, Clock Sync Interval	29
Figure 17: Configuration > DPV2 > Activate Time Sync, Clock Sync Interval - grayed out as Time Sync is not supported by the Slave (GSD)	29
Figure 18: Configuration > DPV2 > Activate Time Sync, Clock Sync Interval > Warning Message on globally set Clock Sync Intervall	30
Figure 19: Configuration > Redundancy	31
Figure 20: Configuration > Redundancy > Activating Redundancy Mode, Output Hold Time	31
Figure 21: Configuration > Redundancy > Using Jokerblock (enabled)	32
Figure 22: Configuration > Redundancy > Using Jokerblock (disabled)	32
Figure 23: Navigation Area - Device Description	33

5.2 List of Tables

Table 1: Descriptions Dialog Panes	4
Table 2: List of Revisions	4
Table 3: Documentation Overview	6
Table 4: General Device Information	12
Table 5: Overview Dialog Panes	13
Table 6: OK, Cancel, Apply and Help	14
Table 7: Status Icons [1]	14
Table 8: Getting started - Configuration Steps	16
Table 9: Descriptions of the Dialog Panes Configuration	17
Table 10: Select Available Modules	22
Table 11: Delete Configured Modules	22
Table 12: Configuration > Extensions	26
Table 13: Configuration > DPV1 > Extra Alarm SAP	28
Table 14: Activate Time Sync, Clock Sync Interval	29
Table 15: Activating Redundancy Mode, Output Hold Time	31
Table 16: Using Jokerblock	32
Table 17: Descriptions of the Dialog Panes Device Description	33
Table 18: General Device Information	34
Table 19: Device Description – GSD Viewer	34
Table 19: PROFIBUS DP Diagnosis Station state 1 (Bit 7 to 5)	38

Table 20: PROFIBUS DP Diagnosis Station state 1 (Bit 4 to 0)	39
Table 21: PROFIBUS DP Diagnosis Station State 2	40
Table 22: PROFIBUS DP Diagnosis Station State 3	40
Table 23: Device Related Diagnosis	41
Table 24: Device Related Diagnosis (Headerbyte)	41
Table 25: Identifier Related (Module) Diagnosis	42
Table 26: Identifier Related (Module) Diagnosis (Headerbyte)	42
Table 27: Identifier Related (Module) Diagnosis (Bit structure)	42
Table 28: Channel Related Diagnosis	43
Table 29: Byte 1: Identifier Number	43
Table 30: Byte 2: Channel Number	43
Table 31: Byte 3: Type of Diagnosis	44
Table 32: Error Type	44
Table 33: Identifier bytes (overview)	45
Table 34: Identifier Bytes (General Identifier Byte Format GIF)	45
Table 35: Identifier Bytes 0x10 .. 0x3F, 0x50 .. 0x7F, 0x90 .. 0x9F (GIF)	46
Table 36: Identifier Bytes 0xA0 .. 0xBF, 0xD0 .. 0xFF (GIF)	47
Table 37: Special Identifier Format (SIF)	48
Table 38: Length Byte of the SIF	48
Table 39: Special Identifier bytes 0x01 .. 0x0F, 0x40 .. 0x4F, 0x80 .. 0x8F, 0xC0 .. 0xCF (SIF)	49
Table 40: Length byte of the special identifiers (SIF)	49

6 Glossary

GSD

GSD = General Station Description

The 'General Station Description' describe the characteristics of a device type in a stipulated format. The GSD are created individually for each device type. And they are allocated in form of a GSD file for the user by the manufacturer of the device.

The project system can read in and consider the GSD for any PROFIBUS DP device automatically because of the pegged file format during the configuration of the bus system.

FDT

Field Device Tool

FDT specifies an interface, in order to be able to use DTM (Device Type Manager) in different applications of different manufacturers.

Freeze

After receiving the control command FREEZE, the DP-Slave freezes the actual state of the Inputs and transmits them cyclically to the DP-Master. After each new control command FREEZE, the Slave freezes the state of the Inputs again. The actual Input data are not transmitted cyclically from the DP-Slave to the DP-Master until the DP-Master sends the control command UNFREEZE. The DP-Slave has to be assigned to a group for the control command FREEZE in the configuration.

DPV0

PROFIBUS DP with cyclic communication

DPV1

PROFIBUS DP with acyclic communication

DTM

Device Type Manager

The Device Type Manager (DTM) is a software module with graphical user interface for the configuration and/or for diagnosis of devices.

Sync

With the control command SYNC the DP-Master arranges the DP-Slave, that the DP-Slave freezes the states of the Outputs on the actual value. During the following telegrams the DP-Slave saves the Output data in each case, which it has save as Output data. The Outputs are first updated cyclically until the DP-Master sends the control command UNSYNC. The DP-Slave has to be assigned to a group for the control command SYNC in the configuration.,

7 Appendix

7.1.1 Station Status of the Slave Diagnosis

7.1.1.1 The meaning of Station Status 1

Station-Status 1	Set by	Meaning and Remedy
Master lock (Bit 7)	Master	<p>Meaning: The Slave has already been parameterized by another Master and is locked in its access.</p> <p>Remedy: This is security mechanism of PROFIBUS DP. First clarify which master should have access to this Slave. Then add this Slave to the configuration of the master that should have access to this Slave and remove this Slave from the configuration of the other master.</p>
Parameter fault (Bit 6)	Slave	<p>Meaning: This bit is set by the Slave automatically, when the parameters sent by the Master are containing wrong or insufficient data. On every received parameter telegram the Slave executes a check routine on the whole parameter telegram. If the Slave detects a faulty parameter value or illegal data during its check, it will report the Parameter fault. During the check routine the Slave compares its ident number with the one sent by Master.</p> <p>Remedy: So if the Slave reports this error, first compare the Device internal Number with the GSD Ident Number. If they are different, either a wrong GSD file is used or a wrong device was connected to the bus. If this two Ident numbers are the same, check the parameter data</p>
Invalid Slave response (Bit 5)	Master	<p>Meaning: This bit is set by the Master, when the Master receives an invalid answer from the Slave. So the physical contact to the Slave works principally, but the logical answer was not understood.</p> <p>Remedy: An error at the physical transmission line could have appeared like twisted cable, missing bus termination or missing shield connection.</p> <p>Use standardized DP Slave.</p> <p>This also can happen, for example if a PROFIBUS-FMS Slave is connected to the DP-Master instead of a DP Slave. So the Slave does not understand the DP-Telegram and rejects it. It's handled as 'Invalid Slave Response'.</p>

Table 20: PROFIBUS DP Diagnosis Station state 1 (Bit 7 to 5)

Station-Status 1	Set by	Meaning and Remedy
Function not supported (Bit 4)	Slave	<p>Meaning: This bit is set by the Slave, when a function should be performed which is not supported. Newer releases of Slave stations normally support the Sync and Freeze-Mode for I/O data. This is fixed in the GSD-File and read out by SYCON.net and sent to the Slave in the parameter telegram.</p> <p>Remedy: If this error occurs the GSD-File declares at least one of these commands as supported, but the Slave does not. In this case contact the manufacturer of the Slave device for the right GSD-File for the used Slave.</p>
Extended Diagnosis (Bit 3)	Slave	<p>Meaning: This bit is set by the Slave, if extended diagnosis data are a read out. Extended diagnosis data is optionally and normally used by a Slave to hand out manufacturer specific diagnosis information.</p> <p>Remedy: Click on the button Extended Diagnosis to get a Hex-dump of the diagnosis data and read about their <u>meaning in the manual of the manufacturer</u>. If the GSD-File contains information about the Extended Device Diagnosis it can be analyzed with the DTM.</p>
Configuration fault (Bit 2)	Slave	<p>Meaning: During the PROFIBUS DP startup procedure the Slave compares its internal I/O configuration with the configuration of the Master. If the Slave detects differences it will report a configuration error. That means that the Master has another I/O module constellation as the Slave.</p> <p>Remedy: So first compare visually all configured I/O modules in the configuration data of SYCON.net for this Slave with its real physical constellation. Note that the order of the module has to agree. Some Slaves need virtual I/O modules to be configured first or empty slot modules to get an even number of modules to run. This Slave specific I/O module behavior has to be written down in the Slave documentation because it can not be read out from the GSD file. Please read the configuration notes of the manufacturer.</p>
Station not ready (Bit 1)	Slave	<p>Meaning: The DP Slave is still not ready for the data exchange.</p> <p>Remedy: When or at which event the Slave sets this bit is not defined in the specification. That means it can have several Slave specific reasons. Usually the bit is set in combination with one the other fault bits.</p> <p>Check especially the parameter and the configuration. Often the report Station not ready results in case of parameter fault or configuration faults.</p> <p>It is possible that the supply voltage at the Slave was just first switched on. Wait until the device is initialized.</p>
Station not existent (Bit 0)	Master	<p>Meaning: This bit is set by the Master automatically, if this Slave does not answer or is not reachable on the bus.</p> <p>Remedy: Please check your PROFIBUS cable. Both signal wires need to be connected correctly between all devices. In addition the connectors at the end of the cable need to be provided with termination resistors.</p> <p>Check that the device is connected to the bus cable.</p> <p>Check the power supply at the Slave device.</p> <p>Compare the station address at the Slave with the configuration of the Master.</p> <p>Check, if the Slave supports the configured baud rate. Some Slaves only work with up to 1.5 Mbaud or need to be set for a PROFIBUS DP conform behavior.</p> <p>Check the intermediated LWL (optical) connector's converters and repeaters.</p>

Table 21: PROFIBUS DP Diagnosis Station state 1 (Bit 4 to 0)

7.1.1.2 The meaning of Station State 2

Station-Status 2	Set by DP	Meaning
Slave deactivated (Bit 7)	Master	This bit is set by the Master, if the Slave in its parameter set is marked as inactive, so that it is taken out from the cyclic I/O exchange.
Reserved (Bit 6)	-	-
Sync Mode (Bit 5)	Slave	This bit is set by the Slave, when it has received the Sync control command.
Freeze Mode (Bit 4)	Slave	This bit is set by the Slave, when is has received the Freeze control command.
Watchdog on (Bit 3)	Slave	This bit is set by the DP-Slave, when its Watchdog control is active to supervise its corresponding Master connection.
Slave device (Bit 2)	Slave	This bit is always set by the Slave.
Static Diagnosis (Bit 1)	Slave	The Slave sets this bit to indicate the Master to be not operative because of a general error. Typically the DP Slave is not ready for an I/O data transfer. In a case of a set Static Diagnosis bit the Master has to collect diagnosis information as long as this bit is active. On which events or at what time this bit can be set by a Slave device, is not defined in the norm description and can not be mentioned here.
Parameterization request (Bit 0)	Slave	The Slave sets this bit to force the Master system to do a new parameterization. This bit is set as long as new parameterization must be performed. In case of this error you should compare firstly the Device internal Ident Number with the GSD ident number in this window. This numbers need to be the same. Furthermore you have to check the parameter data.

Table 22: PROFIBUS DP Diagnosis Station State 2

7.1.1.3 The meaning of Station State 3

Station-Status 3	Set by	Meaning
Extended diagnosis overflow (Bit 7)	Master Slave	This bit is set, if there is more extended diagnosis information to report to the Master than can be given to the Master in one diagnosis telegram. The DP-Slave sets this bit for example if there is more diagnosis channel information than the Slave can hold down in its diagnosis buffer.
Reserved (Bit 6 to 0)	-	-

Table 23: PROFIBUS DP Diagnosis Station State 3

7.1.1.4 Master Address

This byte of the standard diagnosis shows the address of the DP Master which has parameterized the DP Slave and which has read and write access to the DP Slave. The value 255 (FFH) displays that the DP Slave was not parameterized or faulty parameterized by the DP Master.

7.1.1.5 Ident Number

The Ident Number is the manufacturer code of the DP Slave device.

7.1.2 Extended Slave Device Diagnosis

7.1.2.1 Device Related Diagnosis

This extended diagnosis is referred to the device. The length of the device related diagnosis comprises min 2 to max 63 bytes.

2 .. 63 Bytes			
Headerbyte	2. Byte	...	63. Byte
	Manufacturer specific		

Table 24: Device Related Diagnosis

The meaning of the Headerbyte is shown in the following table. The meaning of the following 1 to max. 62 diagnosis bytes is fixed by the device manufacturer. For further analysis the ident number and the device description of the manufacturer are necessary.

MSB								LSB	Meaning
7	6	5	4	3	2	1	0		
									Block length in bytes including header byte 2 to header byte 63
									Bit 7, Bit 6 fixed to 00

Table 25: Device Related Diagnosis (Headerbyte)

7.1.2.2 Identifier Related (Module) Diagnosis

This extended diagnosis is referred to the module (identifier byte). The length of the identifier related diagnosis comprises min 2 to max 63 bytes.

2 .. 63 Bytes					
Headerbyte	7 .. 0	15 .. 8	23 .. 16	31 .. 24	...

Table 26: Identifier Related (Module) Diagnosis

For each used identifier byte at the configuration one bit is reserved. It is padded to byte limits. The bits which are not configured are set to zero. A set bit means there is diagnosis for this module (identifier byte).

Header Byte

MSB								LSB	Meaning
7	6	5	4	3	2	1	0		
									Block length in bytes including header byte 2 to header byte 63
									Bit 7, Bit 6 fixed to 00

Table 27: Identifier Related (Module) Diagnosis (Headerbyte)

Bit structure for identifier related diagnosis

MSB								LSB	Meaning
7	6	5	4	3	2	1	0		
									Identifier byte 0 has diagnostic
									Identifier byte 1 has diagnostic
									...
									Identifier byte 7 has diagnostic

Table 28: Identifier Related (Module) Diagnosis (Bit structure)

7.1.2.3 Channel Related Diagnosis

This extended diagnosis is referred to a channel.

Byte 1 Identifier Number	Byte 2 Channel Number	Byte 3 Type of Diagnostic
-----------------------------	--------------------------	------------------------------

Table 29: Channel Related Diagnosis

The length per entry is 3 bytes. In this block the diagnosed channels and the diagnosis reason are entered in turn. Several blocks with channel related diagnosis can appear.

Byte 1: Identifier Number

MSB							LSB	Meaning
7	6	5	4	3	2	1	0	
								Identifier Number 0 to 63
								Bit 7, Bit 6 fixed to 00

Table 30: Byte 1: Identifier Number

Byte 2: Channel Number

MSB							LSB	Meaning
7	6	5	4	3	2	1	0	
								Channel Number 0 to 63
								Input / Output 00 reserved 01 Input 10 Output 11 Input / Output

Table 31: Byte 2: Channel Number

For identifier bytes which contain both input and output, the direction of the diagnosed channel is indicated in bit 7 and bit 6 of the channel number.

Byte 3: Type of Diagnosis

MSB				LSB				Meaning
7	6	5	4	3	2	1	0	
								Error Type (described in the following table)
								Channel Type
								000 reserved
								001 Bit
								010 2 Bit
								011 4 Bit
								100 Byte
								101 Word
								110 2 Words
								111 reserved

Table 32: Byte 3: Type of Diagnosis

Error Type	Description
0	reserved
1	short circuit
2	undervoltage
3	overvoltage
4	overload
5	overtemperature
6	line break
7	upper limit value exceeded
8	lower limit value exceeded
9	error
10	reserved
...	...
15	reserved
16	manufacturer specific
...	...
31	manufacturer specific

Table 33: Error Type

7.2 Identifier Bytes

In the configuration telegram identifier bytes are used. The meaning of them is specified in the PROFIBUS specification.

The following table is an overview.

	Value		Meaning			
GIF/SIF	0x00	00	free place			
	0x01-0x0F	01-15	see SIF			
GIF	0x10-0x1F	16-31	1-16	Byte	Input	Consistency over Byte
GIF	0x20-0x2F	32-47	1-16	Byte	Output	Consistency over Byte
GIF	0x30-0x3F	48-63	1-16	Byte	Input/Output	Consistency over Byte
	0x40-0x4F	64-79	see SIF			
GIF	0x50-0x5F	80-95	1-16	Word	Input	Consistency over Word
GIF	0x60-0x6F	96-111	1-16	Word	Output	Consistency over Word
GIF	0x70-0x7F	112-127	1-16	Word		Consistency over Word
	0x80-0x8F	128-143	see SIF			
GIF	0x90-0x9F	144-159	1-16	Byte	Input	Consistency over whole length
GIF	0xA0-0xAF	160-175	1-16	Byte	Output	Consistency over whole length
GIF	0xB0-0xBF	176-191	1-16	Byte		Consistency over whole length
	0xC0-0xCF	192-207	see SIF			
GIF	0xD0-0xDF	208-223	1-16	Word	Input	Consistency over whole length
GIF	0xE0-0xEF	224-239	1-16	Word	Output	Consistency over whole length
GIF	0xF0-0xFF	240-255	1-16	Word		Consistency over whole length

Table 34: Identifier bytes (overview)

7.2.1 Identifier Bytes (General Identifier Format GIF)

For the identifier bytes in general identifier format the following table shows the meaning.

MSB				LSB				Meaning
7	6	5	4	3	2	1	0	
				Bit 3 to 0: Length 0000 = 1 Byte or 1 Word 0001 = 2 Byte or 2 Word ... 1111 = 16 Byte or 16 Word				
				Bit 5 and 4: Input/Output 00 = special identifier format (SIF) 01 = Input 10 = Output 11 = Input and Output				
				Bit 6: Format 0 = Byte 1 = Word				
				Bit 7: Consistency over 0 = Byte or Word 1 = whole length				

Table 35: Identifier Bytes (General Identifier Byte Format GIF)

	Value		Meaning			
GIF/SIF	0x00	00	Free place			
SIF	0x01 – 0x0F		see SIF			
GIF	0x10	16	1	Byte	Input	Consistency over Byte
GIF	0x11	17	2	Byte	Input	Consistency over Byte
GIF	Byte	Input	Consistency over Byte
GIF	0x1F	31	16	Byte	Input	Consistency over Byte
GIF	0x20	32	1	Byte	Output	Consistency over Byte
GIF	0x21	33	2	Byte	Output	Consistency over Byte
GIF	Byte	Output	Consistency over Byte
GIF	0x2F	47	16	Byte	Output	Consistency over Byte
GIF	0x30	48	1	Byte	Input/Output	Consistency over Byte
GIF	0x31	49	2	Byte	Input/Output	Consistency over Byte
GIF	Byte	Input/Output	Consistency over Byte
GIF	0x3F	63	16	Byte	Input/Output	Consistency over Byte
SIF	0x40 – 0x4F		see SIF			
GIF	0x50	80	1	Word	Input	Consistency over Word
GIF	0x51	81	2	Word	Input	Consistency over Word
GIF	Word	Input	Consistency over Word
GIF	0x5F	95	16	Word	Input	Consistency over Word
GIF	0x60	96	1	Word	Output	Consistency over Word
GIF	0x61	97	2	Word	Output	Consistency over Word
GIF	Word	Output	Consistency over Word
GIF	0x6F	111	16	Word	Output	Consistency over Word
GIF	0x70	112	1	Word	Input/Output	Consistency over Word
GIF	0x71	113	2	Word	Input/Output	Consistency over Word
GIF	Word	Input/Output	Consistency over Word
GIF	0x7F	127	16	Word	Input/Output	Consistency over Word
SIF	0x80 – 0x8F		see SIF			
GIF	0x90	144	1	Byte	Input	Consistency over whole length
GIF	0x91	145	2	Byte	Input	Consistency over whole length
GIF	Byte	Input	Consistency over whole length
GIF	0x9F	159	16	Byte	Input	Consistency over whole length

Table 36: Identifier Bytes 0x10 .. 0x3F, 0x50 .. 0x7F, 0x90 .. 0x9F (GIF)

	Value		Meaning			
GIF	0xA0	160	1	Byte	Output	Consistency over whole length
GIF	0xA1	161	2	Byte	Output	Consistency over whole length
GIF	Byte	Output	Consistency over whole length
GIF	0xAF	175	16	Byte	Output	Consistency over whole length
GIF	0xB0	176	1	Byte	Input/Output	Consistency over whole length
GIF	0xB1	177	2	Byte	Input/Output	Consistency over whole length
GIF	Byte	Input/Output	Consistency over whole length
GIF	0xBF	191	16	Byte	Input/Output	Consistency over whole length
SIF	0xC0 – 0xCF		see SIF			
GIF	0xD0	208	1	Word	Input	Consistency over whole length
GIF	0xD1	209	2	Word	Input	Consistency over whole length
GIF	Word	Input	Consistency over whole length
GIF	0xDF	223	16	Word	Input	Consistency over whole length
GIF	0xE0	224	1	Word	Output	Consistency over whole length
GIF	0xE1	225	2	Word	Output	Consistency over whole length
GIF	Word	Output	Consistency over whole length
GIF	0xEF	239	16	Word	Output	Consistency over whole length
GIF	0xF0	240	1	Word	Input/Output	Consistency over whole length
GIF	0xF1	241	2	Word	Input/Output	Consistency over whole length
GIF	Word	Input/Output	Consistency over whole length
GIF	0xFF	255	16	Word	Input/Output	Consistency over whole length

Table 37: Identifier Bytes 0xA0 .. 0xBF, 0xD0 .. 0xFF (GIF)

7.2.2 Special Identifier Byte Format (SIF)

The special identifier byte format (SIF) is an extension of the general identifier byte format and offers more flexibility. Also manufacturer specific information can be used with it.

MSB				LSB				Meaning
7	6	5	4	3	2	1	0	
				Bit 0 to 3: Length of manufacturer specific data according to the length byte for In- and/or Output In case of DDLM_Chk_Cfg: 0000 = no manufacturer specific data follow 0001 = 1 manufacturer specific data follow ... 1110 = 14 manufacturer specific data follow 1111 = no manufacturer specific data follow In case of DDLM_Get_Cfg: 0000 = no manufacturer specific data follow 0001 = 1 manufacturer specific data follow ... 1110 = 14 manufacturer specific data follow 1111 = not allowed				
				Bit 5 and 4: solid 00 = solid				
				Bit 7 and 6: Input/Output 00 = free place 01 = a length byte for Input follows 10 = a length byte for Output follows 11 = a length byte for Input and Output follows				

Table 38: Special Identifier Format (SIF)

Length Byte

MSB				LSB				Meaning
7	6	5	4	3	2	1	0	
				Bit 0 to 5: Length 000000 = 1 Byte or 1 Word 000001 = 2 Byte or 2 Word ... 111111 = 64 Byte or 64 Word				
				Bit 6: Format 0 = Byte 1 = Word				
				Bit 7: Consistency over 0 = Byte or Word (element) 1 = whole length				

Table 39: Length Byte of the SIF

	Value		Meaning
GIF/SIF	0x00	00	free place
GIF	0x01 – 0x0E	01 – 14	free place and 1-14 manufacturer specific data
GIF	0x0F	15	free place and no manufacturer specific data
GIF	0x40	64	1 length byte Input
GIF	0x41 – 0x4E	65 – 78	1 length byte Input and 1-14 manufacturer specific data
GIF	0x4F	79	1 length byte Input and no manufacturer specific data
GIF	0x80	128	1 length byte Output
GIF	0x81 – 0x8E	129 – 142	1 length byte Output 1 and 1-14 manufacturer specific data
GIF	0x8F	143	1 length byte Output 1 and no manufacturer specific data
GIF	0xC0	192	1 length byte Output and 1 length byte Input
GIF	0xC1 – 0xCE	193 – 206	1 length byte Output, 1 length Input byte and 1-14 manufacturer specific data
GIF	0xCF	207	1 length byte Output, 1 length Input byte and no manufacturer specific data

Table 40: Special Identifier bytes 0x01 .. 0x0F, 0x40 .. 0x4F, 0x80 .. 0x8F, 0xC0 .. 0xCF (SIF)

Length Byte

Value		Meaning		
0x00 – 0x3F	00-63	1-64	Byte	Consistency over Byte
0x40 – 0x7F	64-127	1-64	Word	Consistency over Word
0x80 – 0xBF	129-191	1-64	Byte	Consistency over whole length
0xC0 – 0xFF	193-255	1-64	Word	Consistency over whole length

Table 41: Length byte of the special identifiers (SIF)

7.3 User Rights

User-rights are set within the FDT-container.



Note: Administrator rights are always used.

7.4 References

- [1] Device Type Manager (DTM) Style Guide, Version 1.0 ; FDT-JIG - Order No. <0001-0008-000>
- [2] Specification for PROFIBUS, Device Description and Device Integration, Volume 1: GSD, Version 5.1 July 2008, Order No: 2.122
- [3] Industrial communication networks – Fieldbus specifications – Part 5 3: Application layer service definition – Type 3 elements, INTERNATIONAL STANDARD IEC 61158-5-3, Edition 2.0 2010-08, Reference number IEC 61158-5-3:2010(E)
- [4] Digital data communications for measurement and control – Fieldbus for use in industrial control systems – Part 6: Application layer protocol specification, INTERNATIONAL STANDARD IEC 61158-6, Third edition 2003-05, Reference number IEC 61158-6:2003(E)