



**Operating instruction manual**  
**Topology Editor A2LP131**  
**Configuring device topology and connections as well as**  
**properties of device, port and connection**  
**V1.1010**

**Hilscher Gesellschaft für Systemautomation mbH**  
**[www.hilscher.com](http://www.hilscher.com)**

DOC181201OI01EN | Revision 1 | English | 2018-12 | Released | Public

# Table of contents

<b>1</b>	<b>Introduction .....</b>	<b>4</b>
1.1	About this manual .....	4
1.1.1	Overview .....	4
1.1.2	List of revisions .....	4
1.1.3	Online help .....	4
1.1.4	Conventions in this manual .....	5
1.1.5	Language convention for PROFINET .....	5
1.2	Legal notes .....	6
1.3	Registered trademarks .....	10
<b>2</b>	<b>Installation .....</b>	<b>11</b>
2.1	Requirements .....	11
2.2	Shipment .....	11
2.3	Installing the Topology Editor .....	11
<b>3</b>	<b>Description of the Topology Editor .....</b>	<b>12</b>
3.1	About the Topology Editor .....	12
3.2	Requirements .....	12
3.3	Use case PROFINET .....	13
3.3.1	Media redundancy .....	13
3.4	Starting the Topology Editor .....	15
3.5	Closing the Topology Editor .....	15
3.6	Introduction to the user interface .....	16
3.6.1	Topology Editor view .....	16
3.6.2	Topology view .....	17
3.6.3	Property view .....	21
<b>4</b>	<b>PROFINET configuration .....</b>	<b>23</b>
4.1	Project creation .....	23
4.1.1	Example sequence .....	23
4.1.2	Creating a network project .....	24
4.2	Arranging devices in the topology view .....	25
4.3	Connecting devices .....	27
4.4	Removing a device or connection .....	28
4.5	Properties .....	30
4.5.1	Device properties .....	30
4.5.2	Port properties .....	32
4.5.3	MRP properties .....	34
4.6	Validation of configuration steps .....	36
4.6.1	Incorrect configuration or faulty settings .....	36
4.6.2	Failures during port connection .....	37
<b>5</b>	<b>Annex .....</b>	<b>38</b>
5.1	Name encoding .....	38
5.2	References .....	38
	<b>Glossary .....</b>	<b>41</b>

**Contacts..... 42**

# 1 Introduction

## 1.1 About this manual

This manual describes the YOKOGAWA Topology Editor A2LP131 and how to configure a device topology (network structure), the connections between the devices as well as the properties of the device, port and connection.

### 1.1.1 Overview

For the main descriptions of the Topology Editor, see sections:

- *Installation* [► page 11]
- *About the Topology Editor* [► page 12]
- Start Topology Editor
- *Introduction to the user interface* [► page 16]
- Configuration of PROFINET IO IRT

### 1.1.2 List of revisions

Index	Date	Version	Component	Revisions
1	18-12-18	V1.1010	Yokogawa A2LP131 PROFINET IO Controller DTM	All sections created.

### 1.1.3 Online help

The Topology Editor contains a built-in online help.

- You can access the online help via the **F1** key.

### 1.1.4 Conventions in this manual

Notes, instructions and results of operating steps are marked as follows:

#### Notes



---

**Important:**

<important note you must follow to avoid malfunction>

---



---

**Note:**

<general note>

---



---

<note where to find further information>

---

#### Instructions

1. Operation purpose
2. Operation purpose
  - Instruction

#### Results

↻ Intermediate result

⇒ Final result

#### Safety messages

The labeling of safety messages is explained in the chapter Safety.

### 1.1.5 Language convention for PROFINET

For PROFINET the PROFINET IO specification defines the terms "Controller" instead of "Master" and "Device" instead of "Slave". In this manual "Controller" and "Device" are used with the PROFINET IO device or the DTM. For general questions about master or slave functions, the terms "Master" and "Slave" are used. Examples: "Master bus line" (in the network configuration) or "Master diagnosis" (general diagnostic function) or "Slave DTM" or "Stand-alone slave" (in the device catalog).

## 1.2 Legal notes

### Copyright

© Hilscher Gesellschaft für Systemautomation mbH

All rights reserved.

The images, photographs and texts in the accompanying materials (in the form of a user's manual, operator's manual, Statement of Work document and all other document types, support texts, documentation, etc.) are protected by German and international copyright and by international trade and protective provisions. Without the prior written consent, you do not have permission to duplicate them either in full or in part using technical or mechanical methods (print, photocopy or any other method), to edit them using electronic systems or to transfer them. You are not permitted to make changes to copyright notices, markings, trademarks or ownership declarations. Illustrations are provided without taking the patent situation into account. Any company names and product designations provided in this document may be brands or trademarks by the corresponding owner and may be protected under trademark, brand or patent law. Any form of further use shall require the express consent from the relevant owner of the rights.

### Important notes

Utmost care was/is given in the preparation of the documentation at hand consisting of a user's manual, operating manual and any other document type and accompanying texts. However, errors cannot be ruled out. Therefore, we cannot assume any guarantee or legal responsibility for erroneous information or liability of any kind. You are hereby made aware that descriptions found in the user's manual, the accompanying texts and the documentation neither represent a guarantee nor any indication on proper use as stipulated in the agreement or a promised attribute. It cannot be ruled out that the user's manual, the accompanying texts and the documentation do not completely match the described attributes, standards or any other data for the delivered product. A warranty or guarantee with respect to the correctness or accuracy of the information is not assumed.

We reserve the right to modify our products and the specifications for such as well as the corresponding documentation in the form of a user's manual, operating manual and/or any other document types and accompanying texts at any time and without notice without being required to notify of said modification. Changes shall be taken into account in future manuals and do not represent an obligation of any kind, in particular there shall be no right to have delivered documents revised. The manual delivered with the product shall apply.

Under no circumstances shall Hilscher Gesellschaft für Systemautomation mbH be liable for direct, indirect, ancillary or subsequent damage, or for any loss of income, which may arise after use of the information contained herein.

**Liability disclaimer**

The hardware and/or software was created and tested by Hilscher Gesellschaft für Systemautomation mbH with utmost care and is made available as is. No warranty can be assumed for the performance or flawlessness of the hardware and/or software under all application conditions and scenarios and the work results achieved by the user when using the hardware and/or software. Liability for any damage that may have occurred as a result of using the hardware and/or software or the corresponding documents shall be limited to an event involving willful intent or a grossly negligent violation of a fundamental contractual obligation. However, the right to assert damages due to a violation of a fundamental contractual obligation shall be limited to contract-typical foreseeable damage.

It is hereby expressly agreed upon in particular that any use or utilization of the hardware and/or software in connection with

- Flight control systems in aviation and aerospace;
- Nuclear fusion processes in nuclear power plants;
- Medical devices used for life support and
- Vehicle control systems used in passenger transport

shall be excluded. Use of the hardware and/or software in any of the following areas is strictly prohibited:

- For military purposes or in weaponry;
- For designing, engineering, maintaining or operating nuclear systems;
- In flight safety systems, aviation and flight telecommunications systems;
- In life-support systems;
- In systems in which any malfunction in the hardware and/or software may result in physical injuries or fatalities.

You are hereby made aware that the hardware and/or software was not created for use in hazardous environments, which require fail-safe control mechanisms. Use of the hardware and/or software in this kind of environment shall be at your own risk; any liability for damage or loss due to impermissible use shall be excluded.

## Warranty

Hilscher Gesellschaft für Systemautomation mbH hereby guarantees that the software shall run without errors in accordance with the requirements listed in the specifications and that there were no defects on the date of acceptance. The warranty period shall be 12 months commencing as of the date of acceptance or purchase (with express declaration or implied, by customer's conclusive behavior, e.g. putting into operation permanently).

The warranty obligation for equipment (hardware) we produce is 36 months, calculated as of the date of delivery ex works. The aforementioned provisions shall not apply if longer warranty periods are mandatory by law pursuant to Section 438 (1.2) BGB, Section 479 (1) BGB and Section 634a (1) BGB [Bürgerliches Gesetzbuch; German Civil Code] If, despite of all due care taken, the delivered product should have a defect, which already existed at the time of the transfer of risk, it shall be at our discretion to either repair the product or to deliver a replacement product, subject to timely notification of defect.

The warranty obligation shall not apply if the notification of defect is not asserted promptly, if the purchaser or third party has tampered with the products, if the defect is the result of natural wear, was caused by unfavorable operating conditions or is due to violations against our operating regulations or against rules of good electrical engineering practice, or if our request to return the defective object is not promptly complied with.

## Costs of support, maintenance, customization and product care

Please be advised that any subsequent improvement shall only be free of charge if a defect is found. Any form of technical support, maintenance and customization is not a warranty service, but instead shall be charged extra.

## Additional guarantees

Although the hardware and software was developed and tested in-depth with greatest care, Hilscher Gesellschaft für Systemautomation mbH shall not assume any guarantee for the suitability thereof for any purpose that was not confirmed in writing. No guarantee can be granted whereby the hardware and software satisfies your requirements, or the use of the hardware and/or software is uninterrupted or the hardware and/or software is fault-free.

It cannot be guaranteed that patents and/or ownership privileges have not been infringed upon or violated or that the products are free from third-party influence. No additional guarantees or promises shall be made as to whether the product is market current, free from deficiency in title, or can be integrated or is usable for specific purposes, unless such guarantees or promises are required under existing law and cannot be restricted.



## Confidentiality

The customer hereby expressly acknowledges that this document contains trade secrets, information protected by copyright and other patent and ownership privileges as well as any related rights of Hilscher Gesellschaft für Systemautomation mbH. The customer agrees to treat as confidential all of the information made available to customer by Hilscher Gesellschaft für Systemautomation mbH and rights, which were disclosed by Hilscher Gesellschaft für Systemautomation mbH and that were made accessible as well as the terms and conditions of this agreement itself.

The parties hereby agree to one another that the information that each party receives from the other party respectively is and shall remain the intellectual property of said other party, unless provided for otherwise in a contractual agreement.

The customer must not allow any third party to become knowledgeable of this expertise and shall only provide knowledge thereof to authorized users as appropriate and necessary. Companies associated with the customer shall not be deemed third parties. The customer must obligate authorized users to confidentiality. The customer should only use the confidential information in connection with the performances specified in this agreement.

The customer must not use this confidential information to his own advantage or for his own purposes or rather to the advantage or for the purpose of a third party, nor must it be used for commercial purposes and this confidential information must only be used to the extent provided for in this agreement or otherwise to the extent as expressly authorized by the disclosing party in written form. The customer has the right, subject to the obligation to confidentiality, to disclose the terms and conditions of this agreement directly to his legal and financial consultants as would be required for the customer's normal business operation.

## Export provisions

The delivered product (including technical data) is subject to the legal export and/or import laws as well as any associated regulations of various countries, especially such laws applicable in Germany and in the United States. The products / hardware / software must not be exported into such countries for which export is prohibited under US American export control laws and its supplementary provisions. You hereby agree to strictly follow the regulations and to yourself be responsible for observing them. You are hereby made aware that you may be required to obtain governmental approval to export, reexport or import the product.

## Terms and conditions

Please read the notes about additional legal aspects on our netIOT web site under <http://www.netiot.com/netiot/netiot-edge/terms-and-conditions/>.

## 1.3 Registered trademarks

PROFINET® is a registered trademark of PROFIBUS & PROFINET International (PI), Karlsruhe.

Windows® XP, Windows® Vista, Windows® 7, Windows® 8, Windows® 8.1 and Windows® 10 are registered trade marks of the Microsoft Corporation.

All other mentioned trademarks are property of their respective legal owners.

## 2 Installation

### 2.1 Requirements

#### **Prerequisites for the Topology Editor**

- To install your configuration software with the Topology Editor, Microsoft .NET Framework 4.0 must be installed on your computer.
- Read the installation manual for your configuration software (e.g. SYCON.net) and the operating instruction manual for the DTM you are using (e.g. PROFINET IO-Controller DTM for RT) to find out which general requirements apply for the installation of these components.

### 2.2 Shipment

The Topology Editor is integrated as part of the DTM in each FDT frame application.

#### **SYCON.net**

If you are using the configuration software SYCON.net, you will receive the installation file

- SYCON.net netFrame setup.msi
- SYCON.net FDTContainer setup.msi
- A2LP131PNIOControllerDTMSetup.msi
- PNIOGenericDeviceDTMnoPROFI-safeSetup.msi

which includes the YOKOGAWA A2LP131 PROFINET IO-Controller DTM for RT mode inclusively the plug-in for the Topology Editor A2LP131.

### 2.3 Installing the Topology Editor

Install your configuration software in accordance with the manufacturer's instructions. The Topology Editor is installed along with the master DTM (Example PROFINET IO-Controller DTM for RT mode).

#### **SYCON.net**

Install the configuration software SYCON.net as described in the software installation user manual of your YOKOGAWA device.

## 3 Description of the Topology Editor

### 3.1 About the Topology Editor

The Hilscher **Topology Editor** supports the configuration of a device topology (network structure) including the connections between devices and the related settings of the related device, port and connection. The Topology Editor can be used for the configuration of different Real-Time Ethernet systems.

The Topology Editor is integrated as a plug-in in a DTM of any network system and can be used in any frame application which supports FDT.

In addition to the device configuration in the DTM, additional device and connection data (for the topology) can be displayed or configured in the Topology Editor. Hidden devices such as switches or media converters can be displayed.

In the topology view (graphical view of the editor with the network structure), the IO devices can be connected to each other. Each link is represented as a line that begins at the port of one device and ends at the port of the other device.

In the property views of the device, port and connection, the settings of the devices, ports and connections can be configured. Using this data, the Topology Editor checks the identity of the existing devices and whether a connection has been established.

The configuration data for the network structure, devices, and connections specified in the Topology Editor is transmitted to the master DTM where it is calculated and stored together with the master device configuration.

### 3.2 Requirements

Prior to the configuration you have to install the hardware.

## 3.3 Use case PROFINET

### 3.3.1 Media redundancy

In PROFINET both media redundancy protocols (MRP or MRPD) are optional functionalities to support a highly available communication.

#### 3.3.1.1 MRP rules

Each ring topology with RT devices (and controller) requires an MRP manager device. Only one MRP manager device per ring topology is allowed. All devices of the ring topology must be MRP-capable. The MRP manager is a managed switch. The A2LP131 YOKOGAWA PROFINET IO-Controller does not connect to this MRP network directly.




Figure 1: Example of MRP rules

### 3.3.1.2 PROFINET MRP in the Topology Editor

The data for implementing media redundancy (MRP) can be configured in the Topology Editor.

#### 3.3.1.3 Basic conditions for MRP

Currently, the following basic conditions for a media-redundant communication (MRP) apply for the PROFINET hardware and the PROFINET IO-Controller DTM.

If MRP is set:

- MRP network consists from one ring with one **MRP manager** (this could be a PROFINET device switch which supports the MRP manager role and GSDML file indicates this fact).
- A YOKOGAWA A2LP131 PROFINET IO-Controller device cannot assume the role of an **MRP manager** or of an **MRP client**.
- A PROFINET IO-Device can assume the role of an **MRP manager** (if this role is supported by the device and GSDML file indicates this fact).
- A PROFINET IO-Device assumes the role of an **MRP client**.
- The devices PROFINET IO-Controller, PROFINET IO-Device and PROFINET IO-Controller DTM (for RT) do not support MRPD.



---

**Note:**

- Currently, the Topology Editor supports *one* MRP domain only.
  - The maximum number of allowed devices in a ring is 50.
- 
- Exactly *one* MRP manager switch assumes the role of the MRP manager.

## 3.4 Starting the Topology Editor



### Note:

To open the Topology Editor, you need a network project with a master device. If you use a YOKOGAWA PROFINET IO-Controller device, create a network project in SYCON.net first.

- Open the configuration software.
- In the project view select the master device (e. g. for PROFINET the controller device).
- Open the context menu (in SYCON.net right click on the master device).
- Select **MRP Configuration...**




Figure 2: Open the Topology Editor via the context menu

- The topology editor opens.

## 3.5 Closing the Topology Editor

- To close the Topology Editor view, click the cross icon  (above left).



### Note:

Check configuration and make corrections if a warning appears on invalid settings. Compare section *Validation of configuration steps* [▶ page 36].

## 3.6 Introduction to the user interface

### 3.6.1 Topology Editor view

The Topology Editor view displays

- the **Topology view** (left) and
- the **Property view** (right).




Figure 3: Topology Editor view (structure of the user interface)



3.6.2 Topology view

The **Topology view** serves as editor window to display and configure the devices and their connections. The ports of each device are visible.




Figure 4: Topology view (example)

### 3.6.2.1 Zooming or shifting sections

#### Zooming in (scaling up)

- Commands (keyboard and mouse): **Ctrl + mouse wheel forward**




Figure 5: Result of zooming in

#### Zooming out (scaling down)

- Commands (keyboard and mouse): **Ctrl + mouse wheel back**




Figure 6: Result of zooming out

### Restoring the 100% view

- Commands (keyboard and mouse): **Ctrl + mouse wheel click**




Figure 7: 100% view restored

### Shift section of the window

- Drag the slider to the right/left or up/down to select the required part of the window.




Figure 8: Visible part of the window shifted

### 3.6.2.2 Tooltips

If you move your mouse over an item in the user interface, the item name appears.




Figure 9: Example tooltip 'Symbolic name' (of the device)




Figure 10: Example tooltip 'Device type'




Figure 11: Example tooltip 'Port 1'

### 3.6.3 Property view

The **property view** on the right shows protocol-dependent information on the device or port and allows network-related settings.



#### Note:

The descriptions of properties of devices and ports for the PROFINET IO-Controller DTM used in this manual are only examples for this particular use case. If the Topology Editor is used together with another master DTM, the properties of device and ports show other settings that relate to other networks.

#### 3.6.3.1 Displaying properties, hiding or showing property view

##### Displaying properties

- To display the properties in the topology view, select the device or the port.




Figure 12: Property view (example)

##### Hiding or showing property view

- Click to hide the property view.
- Click to show the property view.

### 3.6.3.2 Setting properties

Some properties can be set by editing the property value.

- Place the cursor in the field with the value of the property box (for example 'Symbolic name').
- Change the 'Symbolic name'.




Figure 13: Example changing 'Symbolic name' entry

Depending by the specific property settings, a property value can also be selectable from a list.

#### Input of faulty values for the device or port properties



#### Note:

In case of faulty entries to a property field, the field is marked in red. The entry cannot be saved.

Device	
Symbolic name	SCALANCE_X208PRO_V5.2
Description	Switch for Industrial Ethernet (PROFINET IO dev
Device type	SCALANCE X208PRO V5.2
Name of station	scalance-x208pro
IP address	192.168.0.2
Synchronization role	Unsynchronized (RT)
MRP role	Ring manager
MRP domain name	default-mrp-domain abc
Ports	

Figure 14: Red marking because of wrong entries

## 4 PROFINET configuration

### 4.1 Project creation

#### 4.1.1 Example sequence

To configure your network and its topology, proceed as follows:

1. Create the network project with the master device.
2. In the network view, insert all devices in the network project.
3. Start the Topology Editor.
4. In the Topology Editor, shift all devices to arrange the required topology.
5. Make settings in the Topology Editor:
  - Connect the devices.
  - Configure properties for devices and ports.



---

For more information on the configuration of master and devices, read the corresponding operating instruction manuals.

---

## 4.1.2 Creating a network project

You first need to create your project configuration in the frame application.

- Create a network project.
- Configure the master device.
- Possibly configure a switch device.
- Configure the slave devices.



### Note:

The maximum number of allowed devices in a ring is 50.

### MRP configuration example




Figure 15: MRP configuration error message - 50 device maximum (example)

If more than 50 devices are configured in a MRP ring configuration, the configuration can not be saved, the MRP configuration not valid message is displayed as well as a message in the DTM output window “Maximum number of 50 configured MRP devices exceeded”.



## 4.2 Arranging devices in the topology view



### Note:

To open the Topology Editor, you need a network project with a master device.

- Start the Topology Editor via context menu **MRP Configuration...**
- All devices of a created network project with a master device, possibly a switch device and the slave devices are displayed in the topology view.

### Arranging or shifting devices

- In the topology editor select the device you wish to shift.




Figure 16: Switch selected in the topology view (example)

- The selected device has a blue frame.
- Keep the left mouse button pressed and drag the device to the desired position in the topology view.
- The device is located at the new position.




Figure 17: Slave device moved in the topology view (example)

- Arrange all devices in the Topology Editor as desired.




Figure 18: Arranged master device, switch device and slave devices in the topology view (example)

## 4.3 Connecting devices

The Topology Editor allows the connection of IO devices. To connect two devices in the configuration, connect their ports.

### Connecting devices



- In your configuration connect the intended port of device 1 with the intended port of device 2.

Via 'port 1' in the topology view, connect 'channel 0' of the Ethernet connector.

Via 'port 2' in the topology view, connect 'channel 1' of the Ethernet connector.

When establishing the connection observe the general rules (for example, for auto-crossover and instructions in the manual for your device).

Deactivated ports cannot be used (see *Port properties* [► page 32] / 'port deactivation').

- Click on the port  of the first device and keep the mouse button pressed.
- To create a connection, move the pointer to the port  of the second device and release the mouse button thereafter.
- The connection is displayed as a green line in the Topology Editor:






Figure 19: Graphical illustration of a connection between two devices in the Topology Editor



### Note:

No connection will be established if you try to connect ports with red marks . These ports can neither be connected nor included within the communication.

No connection will be established if you try to connect a port to a port, the 'Port deactivation' setting of which is checked or 'Not supported'. The symbol of such a port then is marked with a red frame line .

## 4.4 Removing a device or connection

Devices or connections configured in the Topology Editor can be removed from the configuration.



### Note:

Master devices cannot be deleted in the Topology Editor.

### Removing device

- In the Topology Editor select the device you wish to delete.
- Press the 'Delete' key.
- Or right click on the device to open the context menu.
- And click **Remove device**.




Figure 20: Remove device (example of an unconnected device)




Figure 21: Remove device (example of an connected device)

- The request pops up and asks if you want to delete the device.




Figure 22: Request whether you want to delete the device

- Click **Yes**.
- The device will be deleted along with its connections if there are any.

### Deletion of master device impossible

The master device cannot be deleted from the topology.




Figure 23: Deleting the master device is not possible (example of a connected device)

### Remove connection

- In the Topology Editor click on the connection you want to remove.
- ⇒ The connecting line is displayed in blue.
- Press the 'Delete' key.
- Or right click on the connection to open the context menu.
- And click **Remove connection**.




Figure 24: Remove device (example of a not connected device)

- ⇒ The connection is removed.

## 4.5 Properties

The properties of device, port and connection required for the topology of a network configuration are displayed in the property view. Here you can also configure the settings of cable lengths, cable material or switching delays, etc., required for a PROFINET IO-Controller DTM.

### 4.5.1 Device properties

The device property view shows general and bus-specific parameters of the devices and allows their configuration.

When configuring PROFINET IO, correct device identification data is displayed: 'Symbolic name', 'Description' (text info from the GSDML file), 'Device type' (physical device name) and 'Name of station' (network name of the PROFINET IO-Controller station). Additionally the device's 'IP address' is displayed depending from the settings made in the controller DTM.

#### Viewing device properties

- In the topology view select the device whose properties you wish to display.
- In the property view, the properties of this device are displayed. See also Properties view.

#### Device properties

Device	
Symbolic name	A2LP131
Description	A2LP131
Device type	A2LP131
Name of station	controller
IP address	192.168.0.1
Synchronization role	Unsynchronized (RT)
MRP role	Not active
MRP domain name	default-mrp-domain
Ports	

Figure 25: Devices properties (example A2LP131)

Device	
Symbolic name	SCALANCE_X208PRO_V5.2
Description	Switch for Industrial Ethernet (PRO)
Device type	SCALANCE X208PRO V5.2
Name of station	scalance-x208pro
IP address	192.168.0.2
Synchronization role	Unsynchronized (RT)
MRP role	Ring manager
MRP domain name	default-mrp-domain
Ports	

Figure 26: Devices properties (example SCALANCE\_X208PRO\_V5.2)

Meaning	Meaning	Value range/value
<b>Symbolic name</b>	<p>Freely editable name of the PROFINET IO-Controller device or the PROFINET IO-Device which can also be changed in the DTM or via the context menu.</p> <p>In the PROFINET IO-Controller DTM, the setting can be made under 'Controller network settings' or 'Device table' each under 'Description'.</p>	Freely editable
<b>Description</b>	<p>GSDML element module info</p> <p>This element contains human-readable text information about the device.</p>	**
<b>Device type</b>	Name of the physical device (also named as 'Device name'). The name is stored in a non-volatile memory of the device.	**
<b>Name of station</b>	<p><b>Network name of the PROFINET IO-Controller station or network name of the PROFINET IO-Device station</b></p> <p>The name of station is only displayed here.</p> <p>For the PROFINET IO-Controller the name of station is set in the PROFINET IO-Controller DTM (in SYCON.net under 'Controller network settings').</p> <p>For the PROFINET IO-Device, the name of station is set directly in the configuration tool for the PROFINET IO-Device device (for SYCON.net in the PROFINET IO-Controller DTM under 'Device table').</p> <p>Information on the approved marks, see section <i>Name encoding</i> [► page 38].</p>	**
<b>IP address</b>	<p>IP address of the PROFINET IO-Controller station or PROFINET IO-Device station</p> <p>The IP address is only displayed here. It is set in the PROFINET IO-Controller DTM (under 'Controller network settings' or 'IP address table').</p> <p><b>Note:</b> This field may be empty in case the setting 'No DCP SET' is selected in the 'IP address table' in the PROFINET IO-Controller DTM.</p>	**
<b>Synchronization role</b>	The display 'Unsynchronized (RT)' indicates that this device does not support IRT communication and that the data exchange to this device cannot be synchronized.	Unsynchronized (RT)
<b>MRP role</b>	Refer to <i>MRP properties</i> [► page 34].	
<b>MRP domain name</b>	Refer to <i>MRP properties</i> [► page 34].	

Table 1: PROFINET IO device properties

\*\* cannot be edited in the Topology Editor


## 4.5.2 Port properties

The port property view shows general and bus-specific parameters of the ports and allows their configuration.

For each port of the PROFINET network devices, the following parameters are displayed: 'Name' (of the port), 'MAU type', 'Port deactivation' and 'Connected to'. For the parameters MRP support and MRP port, see section *MRP properties* [► page 34].

A single MAU type or media converters must be used within the network for the RT communication.

### Viewing port property

- To display the port properties in the topology view, click on the port.
- Click .
- The port properties are displayed in the property view.

### Port properties




Figure 27: Port properties (example A2LP131 PROFINET IO Controller, without 'Port property')




Figure 28: Port properties (example SCALANCE\_X208PRO\_V5.2, Switch for Industrial Ethernet (PROFINET IO device))

Port properties	Meaning	Value range/value
<b>Name</b>	Name of the device port in the Topology Editor	**
<b>MAU type</b>	MAU type: The specifications for the cable material (media type) are defined in the GSDML file of the specific device or controller. Cable materials can be copper or fiber optic (FO) made from glass or plastic. The setting is made in the PROFINET IO-Controller DTM.	**



Port properties	Meaning	Value range/value
<b>Port deactivation</b>	<p>Setting option to disable or enable the specified port</p> <p>Depending on the settings in the GSDML file, 'Port deactivation' is settable via a checkbox or 'not supported' is displayed.</p> <p>With checkbox:</p> <ul style="list-style-type: none"> <li>'Port deactivation' not checked: The port remains active. A connection can be established via this port.</li> <li>'Port deactivation' checked: The port is disabled. No connection can be established via this port. If you try to establish a connection to this port, the symbol for this port is marked with a red frame line.</li> </ul> <p>Without checkbox: display 'not supported' (i. e., the 'Port deactivation' cannot be configured).</p>	<p>Checkbox: not checked, checked Default: Not checked</p> <p>Display (without checkbox): Not supported</p>
<b>Port monitoring</b>	<p>This option is used to activate or deactivate the port diagnostics.</p> <ul style="list-style-type: none"> <li>'Port monitoring' <i>not</i> checked: The port diagnosis is disabled.</li> <li>'Port monitoring' checked: The port diagnosis is enabled.</li> </ul> <p>Examples:</p> <ul style="list-style-type: none"> <li>Link status is monitored, i.e., a diagnosis is generated if link-down occurs.</li> <li>Attenuation (system reserve) is monitored (only for glass fiber).</li> </ul>	<p>Checkbox: not checked, checked Default: not checked</p>
<b>MRP support*</b>	Refer to section <i>MRP properties</i> [► page 34].	**
<b>MRP port*</b>	Refer to section <i>MRP properties</i> [► page 34].	**
<b>Connected to</b>	Specifying the symbolic name of the connected device as well as the port name of this device.	**

Table 2: PROFINET IO port properties

\*appears only when MRP is supported

\*\*cannot be edited in the topology editor

### 4.5.3 MRP properties

#### Media redundant communication

Certain rules must be observed to set up a redundant ring topology. For information on the rules for media-redundant communication in high-availability networks, refer to the MRP rules section.

#### MRP device properties

The settings required for a media-redundant communication ('MRP role' and 'MRP domain name') can be set for each PROFINET MRP device.

Device property	Meaning	Value range/value
<b>MRP role</b>	<p>Property of the PROFINET interface sub-module format. Specifies the role of the PROFINET interface submodule: 'Manager' or 'Client'.</p> <p>To support a media-redundant communication for highly available networks, select the MRP role 'Ring client' or 'Ring manager'. The settings 'Ring client' or 'Ring manager' effect the 'MRP port' setting 'In ring'.</p> <p>If 'Not active' is selected, the device is not in the ring. For the meaning of the MRP roles, see also section MRP rules.</p> <p>If the device does not support media-redundant communication (MRP), 'Not supported' is displayed.</p> <p><b>Note:</b> For A2LP131 PROFINET IO Controller the MRP role is 'Not active' and is not changeable.</p>	Not active, Ring client, Ring manager
<b>MRP domain name</b>	<p>Property of the PROFINET interface sub-module format.</p> <p>Freely editable name for the MRP domain. The MRP domain includes all devices that are configured as participants in the ring.</p> <p><b>Important!</b> A uniform <b>MRP domain name</b> must be used for all participants in an MRP domain.</p> <p>If the MRP domain name for one participant is changed, the MRP domain names of all other participants of this MRP domain are changed in the same way.</p> <p>The MRP domain name must be written in lowercase.</p> <p>Information on the approved marks, see section <i>Name encoding</i> [► page 38].</p> <p><b>Note:</b> MRP domain name is not listed in the device properties view if MRP role is 'Not supported'.</p>	Freely editable  Identical name for all participants of an MRP domain

Table 3: PROFINET MRP device properties

#### Configure MRP device properties

If media redundancy is supported:

- Assign the role as 'MRP client' to the PROFINET IO-Device device: Select **MRP role** 'Ring client'.
- Select a PROFINET IO-Device that supports the role as 'MRP manager' and assign the role as 'MRP manager' to this device: Select **MRP role** 'Ring manager'.
- If a device is not to be included in the MRP domain, assign the role 'Not active' to this device: Select **MRP role** 'Not active'.
- Specify an **MRP domain name**. This name must be the same for all participants in an MRP domain.

### MRP port properties

The port property view shows whether MRP is supported ('MRP support') and whether the device port is connected ('MRP port').

The parameters 'MRP support' and 'MRP port' are displayed for each port of the PROFINET MRP network devices.

The implementation of high-availability networks using media-redundant communication is only possible via a ring topology. Without a ring topology, there is no protection against connection breakdown. If an error occurs, the error-free part of the ring can be used as a redundant communication path.

Port properties	Meaning	Value range/value
<b>MRP support*</b>	Indicates whether the device supports media redundancy. This is defined in the GSDML file of the device.  Media redundancy (using MRP or MRPD) is an optional functionality in the PROFINET to build a redundant ring topology.	**  Supported
<b>MRP port*</b>	Indicates whether a port (according to the definition of the GSDML file) is suitable for a media-redundant communication and whether the port is connected.  Display 'In ring' (In the ring): MRP is supported, port is connected  Display 'Not in ring' (Not in the ring): MRP is supported, port is not connected  <b>Note:</b> For A2LP131 PROFINET IO Controller the 'MRP port' parameter is not listed in the port property view.	In ring, Not in ring

Table 4: PROFINET IO MRP port properties

\*appears only when MRP is supported

\*\*cannot be edited in the topology editor

## 4.6 Validation of configuration steps

The DTM or Topology Editor will check all your configuration steps. Incorrect configuration of the topology or incorrect settings for the device or port properties will trigger warnings.

- **Incorrect configuration of the topology:** A warning question appears and a warning message appears in the DTM output window.
- **Input of faulty values for the device or port properties:** In the property view of the Topology Editor the faulty value is marked in red and cannot be saved.
- **Failures during port connection:** Ports of devices that have a different MAU type cannot be connected to each other. The port symbols appear in red. Deactivated or not supported ports cannot be connected to other ports. The port symbol appears with a red frame line.

### 4.6.1 Incorrect configuration or faulty settings

Incorrect configuration of the topology or incorrect settings for the device or port properties will trigger a warning 'Question' and a warning message in the DTM output window, when you try to close the Topology Editor window.




Figure 29: MRP configuration not valid warning (example)

Additional examples for warnings in the DTM output window:

- MRP port configuration of device [*device name*] is not valid: Connected MRP port(s) of device is not in ring. -> *device name*
- Inconsistent MRP configuration for device [*device name*]. For a MRP client/manager, its 2 MRP ports exactly must be configured as [In ring] and connected to an MRP ring. -> *device name*



#### Note:

You cannot save an invalid configuration in the project! If you close the MRP configuration not valid warning with 'Yes' and you try to save the project, the error message 'Due to the errors in the configuration, the project can not be saved!'.






Figure 30: Error message 'Due to the errors in the configuration, the project can not be saved!' (example)

## 4.6.2 Failures during port connection

- Ports the symbol of which are marked in red  are excluded from the communication, because it is impossible to combine or connect devices of different MAU types, e. g. copper and fiber optic material (FO).
- If you try to connect a port to a port, the 'Port deactivation' setting of which is checked or 'Not supported', the port symbol is marked with a red frame line  and no connection can be established to this port.

## 5 Annex

### 5.1 Name encoding

The name is an OctetString with 1 to 240 octets. A name can contain one or more labels separated by a dot [.].

The definition of IETF RFC 5890 and the following syntax applies:

- 1 or more labels, separated by [.]
- Total length is 1 to 240
- Label length is 1 to 63
- Labels consist of [a-z0-9-]
- Labels do not start with [-]
- Labels do not end with [-]
- Labels do not use multiple concatenated [-] except for IETF RFC 5890
- The first label does not have the form “port-xyz” or “port-xyz-abcde” with a, b, c, d, e, x, y, z = 0..9, to avoid wrong similarity with the field AliasNameValue
- Station names do not have the form a.b.c.d with a, b, c, d = 0...999

### 5.2 References

[1] Application Layer protocol for decentralized periphery and distributed automation, Technical Specification for PROFINET, Version 2.3Ed2MU2, February 2015, Order No: 2.722, PROFIBUS Nutzerorganisation e.V., Karlsruhe

[2] Operating instruction manual, DTM for PROFINET IO-Controller/Master devices, Doc-ID: DOC060302OIXXEN, PROFINET IO Controller DTM OI XX EN.pdf

[3] Operating instruction manual, Generic DTM for PROFINET IO-Device devices, Doc-ID: DOC060305OIXXEN, PROFINET IO-Generic Device DTM XX EN.pdf

## List of figures

Figure 1:	Example of MRP rules.....	13
Figure 2:	Open the Topology Editor via the context menu .....	15
Figure 3:	Topology Editor view (structure of the user interface) .....	16
Figure 4:	Topology view (example).....	17
Figure 5:	Result of zooming in .....	18
Figure 6:	Result of zooming out.....	18
Figure 7:	100% view restored .....	19
Figure 8:	Visible part of the window shifted .....	19
Figure 9:	Example tooltip 'Symbolic name' (of the device) .....	20
Figure 10:	Example tooltip 'Device type' .....	20
Figure 11:	Example tooltip 'Port 1' .....	20
Figure 12:	Property view (example).....	21
Figure 13:	Example changing 'Symbolic name' entry .....	22
Figure 14:	Red marking because of wrong entries .....	22
Figure 15:	MRP configuration error message - 50 device maximum (example).....	24
Figure 16:	Switch selected in the topology view (example) .....	25
Figure 17:	Slave device moved in the topology view (example).....	25
Figure 18:	Arranged master device, switch device and slave devices in the topology view (example).....	26
Figure 19:	Graphical illustration of a connection between two devices in the Topology Editor .....	27
Figure 20:	Remove device (example of an unconnected device).....	28
Figure 21:	Remove device (example of an connected device).....	28
Figure 22:	Request whether you want to delete the device .....	28
Figure 23:	Deleting the master device is not possible (example of a connected device) .....	29
Figure 24:	Remove device (example of a not connected device).....	29
Figure 25:	Devices properties (example A2LP131) .....	30
Figure 26:	Devices properties (example SCALANCE_X208PRO_V5.2).....	30
Figure 27:	Port properties (example A2LP131 PROFINET IO Controller, without 'Port property') .....	32
Figure 28:	Port properties (example SCALANCE_X208PRO_V5.2, Switch for Industrial Ethernet (PROFINET IO device) .....	32
Figure 29:	MRP configuration not valid warning (example) .....	36
Figure 30:	Error message 'Due to the errors in the configuration, the project can not be saved!' (example) .....	37

List of tables

Table 1: PROFINET IO device properties ..... 31

Table 2: PROFINET IO port properties..... 32

Table 3: PROFINET MRP device properties ..... 34

Table 4: PROFINET IO MRP port properties..... 35



## Glossary

<b>DTM</b>	Device Type Manager: Software module with graphical user interface for the configuration and/or for diagnosis of devices
<b>FDT</b>	Field Device Tool: FDT specifies an interface, in order to be able to use DTM (Device Type Manager) in different applications of different manufacturers
<b>IP address</b>	Identifies a device or a computer within an IP-based network and is defined in the Internet Protocol Version 4 (IPv4) as a 32-bit number. For ease of notation the address is usually divided into four 8-bit numbers represented in decimal notation and separated by points: a.b.c.d. Each letter stands for an integer value between 0 and 255, e.g. 192.168.30.16. However, not all combinations are allowed, some are reserved for special purposes. The IP address 0.0.0.0 is defined as invalid.
<b>MAU</b>	Medium Access Unit: Transmitting and receiving device for signals (for feeding signals into and extracting them from the media). On the side of the network medium (cable), the device is the interface for connecting network stations.
<b>MRP</b>	Media Redundancy Protocol: Data network protocol for high-availability networks. The protocol is defined in standard IEC 62439 and suitable for most Industrial Ethernet applications.
<b>MRPD</b>	Media Redundancy for Planned Duplication: is a method for the bumpless changeover of the IRT telegrams (high-availability). The bumpless changeover is ensured, as the cyclic IRT data is sent via both ways of communication in the ring, i. e. if there is no failure in the network, the receiver will get the same IRT telegram twice. The first telegram will be used; the second one will be discarded.
<b>PROFINET</b>	Communication system for Industrial Ethernet designed and developed by PROFIBUS & PROFINET International (PI) which uses some mechanisms similar to those of the PROFIBUS field bus

# Contacts

**YOKOGAWA ELECTRIC CORPORATION World****Headquarters**

9-32, Nakacho 2-chome, Musashino-shi  
Tokyo 180-8750  
Japan

[www.yokogawa.com](http://www.yokogawa.com)

**YOKOGAWA CORPORATION OF AMERICA**

2 Dart Road  
Newnan GA 30265  
USA

[www.yokogawa.com/us](http://www.yokogawa.com/us)

**YOKOGAWA EUROPE BV**

Euroweg 2  
3825 HD AMERSFOORT  
The Netherlands

<http://www.yokogawa.com/eu>

**YOKOGAWA ELECTRIC ASIA Pte. LTD.**

5 Bedok South Road  
Singapore 469270  
Singapore

<http://www.yokogawa.com/sg>

**YOKOGAWA CHINA CO. LTD.**

3F Tower D Cartelo Crocodile Building  
No.568 West Tianshan Road Changing District  
Shanghai, China

<http://www.yokogawa.com/cn>

**YOKOGAWA MIDDLE EAST B.S.C.(c)**

P.O. Box 10070, Manama  
Building 577, Road 2516, Busaiteen 225  
Muharraq, Bahrain

<http://www.yokogawa.com/bh>

Yokogawa has an extensive sales and distribution network.

Please refer to the European website (<http://www.yokogawa.com/eu>) to contact your nearest representative.