



ARDUINO

Node-Red

Farouk MEDDAH



PLAN


➡ **NODE RED**

- ➡ Présentation
 - ➡ Circuits d'exemple
- 



NODE RED

NODE RED (1)



```
node-red
Microsoft Windows [Version 6.1.7601]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.


C:\Windows\system32>node-red
27 Apr 00:44:21 - [info]

Welcome to Node-RED
=====


27 Apr 00:44:21 - [info] Node-RED version: v0.16.2
27 Apr 00:44:21 - [info] Node.js version: v6.9.5
27 Apr 00:44:21 - [info] Windows_NT 6.1.7601 x64 LE
27 Apr 00:44:28 - [info] Loading palette nodes
27 Apr 00:44:56 - [warn] -----
27 Apr 00:44:56 - [warn] [rpi-gpio] Info : Ignoring Raspberry Pi specific node
27 Apr 00:44:56 - [warn] [tail] Not currently supported on Windows.
27 Apr 00:44:56 - [warn] -----
27 Apr 00:44:56 - [info] Settings file : \Users\Farouk\.node-red\settings.js
27 Apr 00:44:56 - [info] User directory : \Users\Farouk\.node-red
27 Apr 00:44:56 - [info] Flows file : \Users\Farouk\.node-red\flows_Farouk-U
AIO.json
27 Apr 00:44:56 - [info] Starting flows
27 Apr 00:44:56 - [info] Started flows
27 Apr 00:44:56 - [info] Server now running at http://127.0.0.1:1880/
```

- 1- Télécharger et installer Node.js
- 2- Installer node-red par la commande:
`npm install -g node-red`

NODE RED (2)



NODE RED (3)



Uploader Firmata vers l'Arduino



MERCI