

Aurora Application Program Interface Guide

Revision 9
December 2019

Revision Status

Revision Number	Date	Description
1	April 2007	Initial release.
2	November 2007	Added GET command, added dome volume and metal resistance to SFLIST command
3	July 2010	Added RESET command
4	October 2011	Added TTFG volume to SFLIST command. Deprecated DSTART and DSTOP commands
5	March 2013	Added DFLT, GETINFO, SAVE and SET commands; added User Parameters chapter.
6	September 2013	PHINF command changes: deprecated reply option 0020; added reply option 0080. Added new user parameters relating to physical port locations. Deprecated VER 8.
7	November 2016	Added VSIU chapter, VSIU command, and Param.Tracking parameters
8	July 2018	Changes for combined revision 18. BEEP, Bit definition of BX/TX reply, TSTART option
9	December 2019	Changes for Trigger-Mode

Part Number: 010466

Copyright 2019 NDI Europe GmbH. All Rights Reserved.

Published by:

NDI Europe GmbH
Güttinger Str. 37
78315 Radolfzell, Germany

Telephone: + 49 7732 8234-0
Global: + (800) 634 634 00
Facsimile: + 49 7732 8234-199
Website: www.ndigital.com

Copyright 2019, NDI Europe GmbH

All rights reserved. No part of this document may be reproduced, transcribed, transmitted, distributed, modified, merged or translated into any language in any form by any means - graphic, electronic, or mechanical, including but not limited to photocopying, recording, taping or information storage and retrieval systems - without the prior written consent of NDI Europe GmbH. Certain copying of the software included herein is unlawful. Refer to your software license agreement for information respecting permitted copying.

DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITIES

NDI Europe GmbH has taken due care in preparing this document and the programs and data on the electronic media accompanying this document including research, development, and testing.

This document describes the state of NDI Europe GmbH's knowledge respecting the subject matter herein at the time of its publication, and may not reflect its state of knowledge at all times in the future. NDI Europe GmbH has carefully reviewed this document for technical accuracy. If errors are suspected, the user should consult with NDI Europe GmbH prior to proceeding. NDI Europe GmbH makes no expressed or implied warranty of any kind with regard to this document or the programs and data on the electronic media accompanying this document.

NDI Europe GmbH makes no representation, condition or warranty to the user or any other party with respect to the adequacy of this document or accompanying media for any particular purpose or with respect to its adequacy to produce a particular result. The user's right to recover damages caused by fault or negligence on the part of NDI Europe GmbH shall be limited to the amount paid by the user to NDI Europe GmbH for the provision of this document. In no event shall NDI Europe GmbH be liable for special, collateral, incidental, direct, indirect or consequential damages, losses, costs, charges, claims, demands, or claim for lost profits, data, fees or expenses of any nature or kind.

Product names listed are trademarks of their respective manufacturers. Company names listed are trademarks or trade names of their respective companies.

Table of Contents

Read Me First!	iii
Warnings	iii
Disclaimers	iii
Contact Information	iv
 1 List of Commands	 1
 2 Communicating with an Aurora System	 3
2.1 Communication Overview	3
2.2 Operating Modes	3
2.3 General Syntax	4
2.4 Receiving System Replies	5
2.5 Best Practices	5
2.6 Port Handles	6
 3 Virtual Sensor Interface Unit	 9
3.1 Aurora Packet Protocol	9
3.2 Packet Routing	11
3.3 Synchronization	11
 4 User Parameters	 12
4.1 About User Parameters	12
4.2 User Parameter Commands	12
4.3 Device Names	12
4.4 Alerts User Parameters	14
4.5 Complete List of User Parameters	17
 5 Commands	 20
 6 Error Code Definitions	 91
 Appendix A For Polaris Users	 94

Appendix B Sample C Routines	104
Abbreviations and Acronyms	111

Read Me First!

This guide describes revision D.002.007 of the Aurora Application Program Interface (API). The [APIREV \(page 22\)](#) command returns the revision of the API that is compatible with the firmware in your Aurora System. If the APIREV command is not supported by your system, [contact NDI technical support](#).

For information on changes in implementation from previous versions of the API, please refer to the “Aurora Firmware Guide.”

Before sending any commands to the system, read the manual that accompanied your system to ensure that you have a full understanding of the functionality.

Warnings



In all NDI documentation, warnings are marked by this symbol. Follow the information in the accompanying paragraph to avoid personal injury.

When using reply option 0800 with the [BX \(page 24\)](#) or [TX \(page 83\)](#) command, you must take appropriate action to detect when a tool is out of volume, and determine whether this situation is detrimental to your application. If a tool is out of volume, reply option 0800 enables the system to return data that may lead to inaccurate conclusions and may cause personal injury.

Disclaimers

Due to the nature of the mathematical model that the Aurora System uses to produce transformations, there is a very infrequent occurrence where the system may randomly return a single frame of significantly inaccurate or misleading data. To reduce the impact of this single frame on a measuring task, be aware of the possibility of this occurrence, and take such data into consideration when collecting transformations.

A complete list of the warnings, classifications, and approvals that apply to the Aurora System is included in the user guide shipped with the system.

Contact Information

If you have any questions regarding the content of this guide or the operation of this product, please contact us:



Head Office
Waterloo, ON Canada

☎ +1 (877) 634-6340
✉ info@ndigital.com
🌐 www.ndigital.com

Shelburne, VT USA

☎ +1 (802) 985-1114
✉ info@ndigital.com
🌐 www.ndigital.com

Radolfzell, Germany

☎ +49 7732 8234 0
✉ info@ndieurope.com
🌐 www.ndieurope.com

Hong Kong, China

☎ + (852) 2802-2205
✉ apinfo@ndigital.com
🌐 www.ndigital.cn

Updates

NDI is committed to continuous improvements in the quality and versatility of its software and hardware. To obtain the best results with your NDI system, check the NDI Support Site regularly for update information:

<https://support.ndigital.com>.

1 List of Commands

Command	Page	Description
APIREV	22	Returns the API revision number that functions with your system.
BEEP	23	Sounds the system beeper.
BX	24	Returns the latest tool transformations and system status in binary format.
COMM	29	Sets the serial communication settings of the system.
DFLT	31	Restores the user parameters to factory default values.
DSTART	32	Deprecated. Use TSTART .
DSTOP	33	Deprecated. Use TSTOP .
ECHO	34	Returns exactly what is sent with the command.
GET	35	Returns the values of user parameters.
GETINFO	36	Returns descriptive information about the user parameters.
INIT	38	Initializes the system.
LED	39	Changes the state of visible LEDs on a tool.
PDIS	41	Disables the reporting of transformations for a particular port handle.
PENA	42	Enables reporting of transformations for a particular port handle.
PHF	43	Releases system resources from an unused port handle.
PHINF	44	Returns information about the tool associated with the port handle.
PHSR	50	Returns the number of assigned port handles and the port status for each one. Assigns a port handle to a tool.
PINIT	53	Initializes a port handle.
PPRD	55	Reads data from the SROM device in a tool.
PPWR	57	Writes data to the SROM device in a tool.
PSEL	59	Selects a tool SROM device as the target for reading or writing with PPRD or PPWR .
PSOUT	60	Sets the status of the GPIO in the Aurora System.
PSRCH	62	Returns a list of valid SROM device IDs for a tool.
PURD	63	Reads data from the user section of the SROM device in a tool.
PUWR	65	Writes data to the user section of the SROM device in a tool.
PVWR	67	Overrides a tool definition file in a tool, and can be used to test a tool definition file before permanently recording the tool definition file onto the SROM device.
RESET	69	Resets the system
SAVE	71	Saves all non-volatile user parameters that have been changed.
Serial break	20	Resets the system.
SET	72	Sets user parameter values.
SFLIST	73	Returns information about the supported features of the system.
TSTART	78	Starts Tracking mode.
TSTOP	80	Stops Tracking mode.

Command	Page	Description
TTCFG	81	Sets up a configuration for a tool, so that you can test the tool without using a tool definition file.
TX	83	Returns the latest tool transformations and system status in text format.
VER	87	Returns the firmware revision number of critical processors installed in the system.
VSEL	89	Selects a characterized measurement volume.

2 Communicating with an Aurora System

This chapter describes various aspects of communicating with an Aurora System. It contains the following sections:

- [“Communication Overview” on page 3](#)
- [“Operating Modes” on page 3](#)
- [“General Syntax” on page 4](#)
- [“Receiving System Replies” on page 5](#)
- [“Best Practices” on page 5](#)
- [“Port Handles” on page 6](#)

2.1 Communication Overview

From the application perspective, the Aurora System is a serial device, which is listening for incoming commands. Upon receiving a command, the system performs some action and returns the status of this action. The system never initiates communication with the application except on power up or reset, when it returns `RESET<CRC16><CR>`.

Immediately after sending a command, the application can begin to poll the serial buffer for a reply. Most commands reply almost instantaneously. After reaching the end of the reply, the application can send another command. There may be some delay in the response of certain commands; see [“Receiving System Replies” on page 5](#) for details.

Note The application must read the complete response from the system before sending another command. Failure to do so may result in an error or in unpredictable system behaviour.

2.2 Operating Modes

The Aurora System has two modes of operation: Setup and Tracking. Some commands will only work if they are sent while the system is in a specific mode of operation. If a command is sent when the system is in a mode not valid for that command, the system returns `ERROR0C`.

Setup

Setup mode allows you to configure the system and tools. Typical Setup mode tasks may include initializing the system, writing to the SROM device on a tool, or checking the system firmware revisions.

The order of the commands sent while in Setup mode is important. For example, a port handle must be initialized ([PINIT](#)) before it can be enabled ([PENAB](#)). Refer to the command documentation in [Chapter 5](#) to see the prerequisites for each command.

The system enters the Setup mode either on successful power up, on sending a reset, or on exiting from Tracking mode.

Tracking

In Tracking mode, the system measures the positions and orientations of tools in real time and returns the information to the host computer when requested. The **BX** and **TX** commands are the most commonly used commands in Tracking mode.

The system enters Tracking mode on successful **TSTART** command and exits Tracking mode on **TSTOP** command.

2.3 General Syntax

Commands must be sent from the host computer to the system in one of the two following formats.

Note To ensure the integrity of data transmission, NDI recommends using format 1, as well as verifying the returned Cyclic Redundancy Check (CRC) on the host computer.

Format 1

`<Command><:><Parameter1><Parameter2>...<ParameterN><CRC16><CR>`

A `<:>` must be sent with every command even if no parameters are required. There are no characters or spaces separating the parameters or the individual parts of the commands. Commands and parameters are not case-sensitive.

This format requires a 16-bit CRC value and therefore may be more useful in application software. The application software can incorporate a CRC calculation and add it to the command each time a command is sent to the system. Including a CRC provides a communications check to ensure that there are no communication problems between the system and the host computer. The CRC is used in both the commands and replies. It is based on all the characters in the command, up to the CRC itself. It is calculated using the polynomial $x^{16} + x^{15} + x^2 + 1$. See [“Sample C Routines” on page 104](#) for sample code to calculate the CRC.

Format 2

`<Command><SPACE><Parameter1><Parameter2>...<ParameterN><CR>`

A `<SPACE>` must be sent with every command even if no parameters are required. There are no characters or spaces separating the parameters or the individual parts of the commands. Commands and parameters are not case-sensitive.

It is not necessary to calculate a CRC value when using this format, so this format is useful for sending commands to the system in an application such as troubleshooting.

To ensure the integrity of data transmission, NDI recommends using format 1, as well as verifying the returned CRC on the host computer.

2.4 Receiving System Replies

Note The Aurora System may take longer to send a response for some commands than for other commands. For example, PINIT and TSTART may take up to five seconds. A reset may take as long as 12 seconds under special circumstances (for example, when a Field Generator is connected for the first time). If a timeout is detected, sending a serial break to the system should return the system to normal operation.

Binary Replies

The **BX** command returns binary replies. All other commands return ASCII replies.

If a complete command is received by the system, replies are sent back in the format:

```
<Reply><CRC16>
```

The system always returns <CRC16> in the reply regardless of whether the command was sent in [format 1](#) or [format 2](#). The <Reply> will be either the requested data, or ERROR<error code>. The <error code> is a two-digit hexadecimal error number. See [“Error Code Definitions” on page 91](#) for a listing of all the error messages associated with error numbers.

Binary replies are returned in little endian format. For example, a 32-bit reply is returned in the format:

Bits	7 - 0	15 - 8	23 - 16	31 - 24
Reply byte	n	n + 1	n + 2	n + 3

ASCII Replies

All commands return ASCII replies except **BX**, which returns binary replies.

If a complete command is received by the system, replies are sent back in the format:

```
<Reply><CRC16><CR>
```

The system always returns <CRC16> in the reply regardless of whether the command was sent in [format 1](#) or [format 2](#). The <Reply> will be either the requested data, OKAY, or ERROR<error code>. The <error code> is a two-digit hexadecimal error number. See [“Error Code Definitions” on page 91](#) for a listing of all the error messages associated with error numbers.

2.5 Best Practices

This section provides guidelines on how to write an application in order to minimize updates required when there are changes to the API. If your application is written correctly, it will still work when additions are made to the API; you will only need to update your application if you wish to take advantage of the new features.

- Ignore the value of any returned field that is listed as “reserved” in the API guide. The values of reserved fields may change in future API releases.
- Program the application to allow all possible values of a returned field, not only the values that are currently defined. This allows for future expansion. For example, if a field returns one character, but currently only characters 0 and 1 are defined, do not write your

application such that 0 and 1 are the only acceptable values; more values may be defined in the future.

- Use the frame number, and not the host computer clock, to identify when data was collected. The frame number is incremented by 8 at a constant rate of 40 Hz. Associating a time from the host computer clock to replies from the system assumes that the duration of time between raw data collection and when the reply is received by the host computer is constant. This is not necessarily the case. The frame number is returned with the command [BX \(page 24\)](#) or [TX \(page 83\)](#).
- Use both the shape type and the shape parameters to represent the characterized measurement volume graphically. There may be multiple volumes with the same shape type. All volumes of the same shape type use the shape parameters the same way. The shape type and shape parameters are returned with the command [SFLIST \(page 73\)](#).
- When checking the firmware revision, check only the combined firmware revision, not the firmware revision of the individual components. The combined firmware revision ensures that all components in a system have compatible firmware. To check the combined firmware revision, use the command [VER 5 \(page 87\)](#).
- When checking for protocol compatibility, check for the API revision instead of the combined firmware revision. An application written for a particular API revision will function with any system that supports that API revision. See the command [APIREV \(page 22\)](#) for details.

2.6 Port Handles

About Port Handles

The system assigns each tool a port handle. Port handles are two characters in hexadecimal format, 0x0A to 0x31. Port handles can be assigned to tools only while the system is in [Setup](#) mode.

Port Handle Commands

The following commands are used for port handles:

Command	Description
PHSR (page 50)	Returns the number of assigned port handles and the port status for each one. Assigns a port handle to a tool.
PVWR (page 67)	Overrides a tool definition file in a tool, and can be used to test a tool definition file before permanently recording the tool definition file onto the SROM device.
PINIT (page 53)	Initializes a port handle.
PHINF (page 44)	Returns port handle status, and information about the tool associated with the port handle, including physical port location.

Command	Description
PHF (page 43)	Releases system resources from an unused port handle. This is required if a tool is disconnected. If a tool is disconnected and then reconnected, the system assigns a new port handle to the tool. The old handle is reported as disabled and should be freed using PHF.
PENA (page 42)	Enables reporting of transformations for a particular port handle.
PDIS (page 41)	Disables the reporting of transformations for a particular port handle.

The order in which these commands are used is detailed in [Figure 2-1 on page 8](#).

Disabled Transformations

A transformation may be reported as DISABLED if:

- the port handle was not enabled with [PENA \(page 42\)](#),
- the port handle has been disabled with [PDIS \(page 41\)](#), or
- a tool has been disconnected and the port handle has not been freed.

Unoccupied Port Handle

A port handle may be reported as UNOCCUPIED if the tool has been disconnected and port handle information is requested using [PHINF \(page 44\)](#).

Flow Chart for Port Handle Usage

[Figure 2-1 on page 8](#) details the logic for using port handles.




Figure 2-1 Flow Chart for Port Handle Usage

Note For a split port on a dual 5DOF tool, the first PHSR sent will report only one port handle. After the port handle is initialized, it is assigned to channel 0. You must then use PHSR again to assign a port handle to channel 1. The port handle for channel 1 is initialized automatically.

3 Virtual Sensor Interface Unit

This chapter describes communication with a Virtual Sensor Interface Unit (VSIU). A VSIU is not a component in the standard Aurora system; it is a custom piece of hardware. VSIUs are usually application- and customer-specific devices with special means of system synchronization.

Care must be taken with the communication to the Aurora, since the VSIUs mean a high strain on the communication bandwidth. The typical amount of transferred measurement data for a single port (2 sensors) using a standard Field Generator is 8kB/s.

3.1 Aurora Packet Protocol

The communication channel between the SCU and the VSIU is multiplexed with the normal command communication to the SCU. To ease this interleaved communication the new packet communication protocol has been introduced.

A packet is an atomic block of data. It must not be interrupted during communication.

Packet Structure

A packet is made of 3 parts:

1. Header: The header contains all information necessary to route the packet from its origin to its destination. It also includes checksums and other means to protect the communication in case of transmission errors.
2. Payload: The payload follows immediately to the header. It might be empty.
3. Endmark (CR (carriage return)): The endmark follows the payload section even if the payload is empty.

Packet Header

```
struct SVSIUHeader
{
    /* always 0xa7c4 */
    unsigned short m_Preamble;

    /* device identification (for routing purposes, etc.) */
    unsigned char m_Id;

    /* packet type: see enum EPacketType
     * 0 - direct communication
     * 1 - VSIU command protocol (command and reply)
     * 2 - VSIU raw data protocol
     * -1 - error answer (the error is a 2byte body (okay: 3bytes with CR
     at end))
     * Errors: see enum EErrorAnswer */
    unsigned char m_Type;
```

```
/* incremented for each new command; repeated in the answer to the
 * command */
unsigned short m_Sequence;

/* length of payload (including the CR at the end!) */
unsigned short m_PayloadLength;

/* crc of payload (including the CR at the end!) */
unsigned short m_PayloadCrc;

/* crc of this header */
unsigned short m_HeaderCrc;
};
```

Note All information in the header is in little endian format.

```
/* EPacketType specifies the content of the m_Type member of the
SVSIUHeader */
enum EPacketType
{
    EPTErrror = 0xff,

    /* direct communication with VSIU */
    EPTDirect = 0,

    /* control communication between SCU and VSIU */
    EPTVSIUCommand = 1,

    /* data sent from VSIU to SCU */
    EPTVSIURaw = 2
};

/* EErrorAnswer specifies the 2byte payload in case m_Type is EPTErrror */
enum EErrorAnswer
{
    EEUnknownType = 0,

    /* if waiting for new data times out while a packet is still incomplete
    */
    EETimeout = 1,
```

```
/* if the packet is addressing another target id. Usually this will be
 * checked only for VSIU control commands from the SCU */
EEInvalidId = 2,

/* an error in the header crc was detected */
EEHeaderCrc = 3,

/* an error in the payload crc was detected */
EEPayloadCrc = 4

};
```

The packet communication uses a simple error handling. The most recent command packet can be repeated arbitrarily often. The receiver must only execute this command once, but needs to report the same answer. So in case of a transmission error (checksum, missing character, etc.) a simple repetition will correct it without the risk that the command is executed twice.

3.2 Packet Routing

There are 4 distinct data channels in a typical VSIU system:

- Aurora API commands between the client software and the Aurora SCU (Aurora API protocol, bidirectional). Each API command is acknowledged by the Aurora. With active packet communication (e.g. when a VSIU is in the system) it is possible that the Aurora may send out packets before the textual or binary answer to the command is sent. This is normal and the client software must be able to work with it.
- Direct commands to the VSIU (Aurora packet protocol, bidirectional). These packets will be always acknowledged with an answer.
- Control commands between the VSIU and the Aurora SCU (Aurora packet protocol, bidirectional). These packets originate in the SCU. These packets will be always acknowledged by the VSIU with an answer.
- Measurement data from the VSIU to the Aurora SCU (Aurora packet protocol, unidirectional). These packets transport the measurement data from the VSIU to the SCU and they will not be repeated. The SCU does not send an acknowledgement after reception. Damaged packets should be dropped. The effect of missing packets are missing transformations for the sensors connected to the VSIU.

3.3 Synchronization

For a normal SIU, all synchronization and communication signals are sent via the direct hardware link to the SCU. Since the VSIU does not have this direct link, it must be synchronized by other means. A VSIU is a custom piece of hardware, so there are no general specifications for how to synchronize it to the SCU. Normally synchronization is achieved by the customer's system being the timing master for the SCU and for the VSIU. For more information on synchronization with the Aurora system, see the "*Aurora V3 User Guide*."

4 User Parameters

This chapter contains the following sections about user parameters:

- “About User Parameters” on page 12
- “User Parameter Commands” on page 12
- “Device Names” on page 12
- “Alerts User Parameters” on page 14
- “Complete List of User Parameters” on page 17

4.1 About User Parameters

The user parameters store values for different aspects of the Aurora System. Some user parameters store values for the full system configuration; others store values pertaining to a particular hardware device in the system. Some user parameters are read-only parameters that store useful information about the system; some user parameter values can be changed, to allow you to configure the system.

For a full list of user parameters, see [page 17](#).

4.2 User Parameter Commands

The following commands are used with the user parameters:

Command	Description
DFLT (page 31)	Restores the user parameters to factory default values.
GET (page 35)	Returns user parameter values.
GETINFO (page 36)	Returns user parameter values and descriptive information about the user parameters, including use details, possible values, and access rules.
SET (page 72)	Sets user parameter values.
SAVE (page 71)	Saves all non-volatile user parameters that have been changed.

See the individual commands for more details.

4.3 Device Names

Note Device names are supported in API revisions D.001.008 and later.

Each hardware device (each System Control Unit, Field Generator and Sensor Interface Unit) in the system configuration has a unique device name.

Determining the Devices in the System Configuration

Use the **GET** command to determine which hardware devices are in your system. To ensure future compatibility if more devices are integrated into your system, your application should read the list of devices every time you connect to a system, or whenever a component is connected or disconnected.

The most general method of reading the list of devices to ensure consistent behaviour in the future is as follows:

Command:

```
GET Device.*
```

Reply:

```
Device.Type.0=SCU
Device.Instance.0=0
Device.Type.1=FG
Device.Instance.1=0
Device.Type.2=SIU
Device.Instance.2=1
Device.Type.3=SIU
Device.Instance.3=4
```

The reply gives information about every device in the system configuration. For each device, there are two parameters:

- **Device.Type.X** describes the type of connected device. Device types are as follows:

Device.Type Parameter	Hardware Device
SCU	System Control Unit
FG	Field Generator
SIU	Sensor Interface Unit or Integrated Sensor Interface Unit

- **Device.Instance.X** describes the instance of that type of device in the configuration.

Parameters with the same X index value (for example, Device.Type.0 and Device.Instance.0) describe the same device. The X values are not necessarily consecutive numbers.

Instance numbers for the SIUs correspond to the port number on the SCU to which they are connected. In the example above, the reply is for an Aurora System with a System Control Unit, a Field Generator, and two SIUs connected to ports 1 and 4 of the System Control Unit.

Constructing Device Names

User parameters for a particular device can always be accessed using the full device name. To construct the device name for a particular device, use the following syntax:

```
<Device.Type.X>-<Device.Instance.X>
```

For the configuration in the example above, the device names are SCU-0, FG-0, SIU-1 and SIU-4.

Accessing User Parameters Using Device Names

Each device has its own set of user parameters. To ensure that the user parameters for the correct device are accessed, prefix the parameter with the device name. All references to user parameters for a device can be made using the device name. To access the user parameters for a particular device, use the following syntax:

```
<Device.Type.X>-<Device.Instance.X>.<User Parameter>
```

For example, use `GET SIU-4.Info.Status.New Alerts` to check the alerts for the SIU connected to port 4.

To view information about the parameters supported by the device, use the following commands:

```
GET FG-0.*
GETINFO FG-0.*
```

Note See the [GET \(page 35\)](#) and [GETINFO \(page 36\)](#) commands for details.

For compatibility reasons the device name can be omitted for the SCU. The default device name is SCU-0.

For example, `GET Param.System Beeper` will return the reply `Param.System Beeper=141B7` while `GET SCU-0.Param.System Beeper` will return the reply `SCU-0.Param.System Beeper=1B6A0`.

The wild card (*) is not allowed in device names. There is one exception: `GET *` will report all user parameters from all available devices.

There are a few user parameters which do not belong to a device but are system parameters, e.g. `Device.Type.*`. These parameters are not prefixed by a device name.

4.4 Alerts User Parameters

The alerts user parameters describe the status of a particular hardware device in the system. To access the user parameters for a particular device, prefix the parameter with the [device name](#) as described in “[Device Names](#)” on [page 12](#).

Alerts User Parameters

[Table 4-1](#) describes the alerts user parameters.

Table 4-1 Alerts User Parameters

User Parameter	Description
Info.Status. Alerts	<p>This user parameter describes the current state of the hardware device by reporting the alerts listed in Table 4-2 (for the System Control Unit), Table 4-3 (for the Field Generator), or Table 4-4 (for the SIUs).</p> <p>The bit corresponding to a particular alert is set when the system first detects the condition. This is accompanied by the system response detailed in Table 4-2, Table 4-3, or Table 4-4. The bit is cleared when the condition no longer exists.</p>

Table 4-1 Alerts User Parameters (Continued)

User Parameter	Description
Info.Status. New Alerts	Read this user parameter when the diagnostic pending bit is set (bit 8 in the BX or TX system status). This user parameter lists the current alerts status whenever an alert is set or cleared. The act of reading this parameter clears both this parameter and the diagnostic pending bit. If no other device has a new alert, the diagnostic pending bit (bit 8 in the BX or TX system status) is also cleared.
Info.Status. Alerts Overflow	Read this user parameter if the overflow bit is set in the user parameter Info.Status.Alerts or Info.Status.New Alerts for a particular hardware device. No bits are currently defined in this parameter.
Param. Simulated Alerts	<p>Simulates the Info.Status.Alerts parameter for the hardware device specified, for testing purposes. To test the response of a particular alert, set the value of this parameter to the value of the alert (see Table 4-2, Table 4-3, or Table 4-4).</p> <p>Simulated alerts can be cleared by “SET Param.Simulated Alerts=0” and reading the Info.Status.New Alerts parameter.</p> <p>The overflow bit can be set with simulated alerts, but no bit will be set in the Info.Status.Alerts Overflow parameter.</p>

The command **RESET** will reset all alert parameters. The command **INIT** does not reset alert parameters.

If a device is disconnected, the alerts for that device will not be available. This may change the diagnostic pending bit.

System Control Unit Alerts

[Table 4-2](#) describes the System Control Unit alerts that are returned by the **Info.Status.Alerts** and **Info.Status.New Alerts** user parameters. The returned value is an integer, which you must convert to an 8-character hexadecimal number. The hexadecimal number is made up of the following individual alert values OR'd together:

Table 4-2 System Control Unit Alerts

Device	Hexadecimal Value	Alert	System Response
SCU	00000001	Processing unit fault	INIT returns ERROR15
SCU	00000002	Processor periphery fault	INIT returns ERROR15
SCU	00000004	Field Generator driver fault Note: Not supported on V1 SCUs.	INIT returns ERROR15 TSTART returns ERROR12
SCU	00000008	Processor or logic voltage fault. Note: Not supported on V1 or V2 SCUs.	INIT returns ERROR15
SCU	80000000	Overflow. Read the value of the user parameter Info.Status.Alerts Overflow .	

Field Generator Alerts

Table 4-3 describes the Field Generator alerts that are returned by the **Info.Status.Alerts** and **Info.Status.New Alerts** user parameters. The returned value is an integer, which you must convert to an 8-character hexadecimal number. The hexadecimal number is made up of the following individual alert values OR'd together:

Table 4-3 Field Generator Alerts

Device	Hexadecimal Value	Alert	System Response
FG	00000001	Communication fault	TSTART returns ERROR14
FG	00000002	Defective coil. This can only be detected when tracking. Note: Not supported when using a V1 SCU.	Sets diagnostic pending bit (bit 8) in TX or BX system status.
FG	00000004	No measurement volume compatible with the SCU firmware. This can happen, for example, when a V2 Field Generator is connected to a V1 SCU.	TSTART returns ERROR14 VSEL returns ERROR24
FG	80000000	Overflow. Read the value of the user parameter Info.Status.Alerts Overflow .	

Sensor Interface Unit Alerts

Table 4-4 describes the Sensor Interface Unit alerts that are returned by the **Info.Status.Alerts** and **Info.Status.New Alerts** user parameters. The returned value is an integer, which you must convert to an 8-character hexadecimal number. The hexadecimal number is made up of the following individual alert values OR'd together:

Table 4-4 Sensor Interface Unit Alerts

Device	Hexadecimal Value	Alert	System Response
SIU	00000001	Processing unit fault. (V3 SIU only)	Sets diagnostic pending bit (bit 8) in TX or BX system status.
SIU	00000002	Communication fault. (V1 SIU only)	Sets diagnostic pending bit (bit 8) in TX or BX system status.
SIU	00000004	Analog module fault (V3 SIU only)	Sets diagnostic pending bit (bit 8) in TX or BX system status.
SIU	00000008	SIU hardware/firmware configuration incompatibility. (V3 SIU only)	Sets diagnostic pending bit (bit 8) in TX or BX system status. System functionality limited.
SIU	80000000	Overflow. Read the value of the user parameter Info.Status.Alerts Overflow .	

4.5 Complete List of User Parameters

Table 4-5 lists the user parameters for the Aurora Systems. To view a complete list of user parameters for your system, use the command [GET *](#) (for parameter names and values) or [GETINFO *](#) (for parameter names, values, and usage details).

Table 4-5 Complete List of User Parameters

User Parameter Name	Description	Access Rules	Device
Device.Instance.X	Instance of this type of device in the system configuration	Read, write	SCU
Device.Type.X	Type of device in the system configuration	Read	SCU
Features.Firmware.Version	Firmware version programmed into the device	Read	SCU, SIU
Features.Hardware.Characterization Date	Date of most recent FG characterization	Read	FG
Features.Hardware.Manufacturing Date	Manufacturing date of the device	Read	SIU
Features.Hardware.Max Ports	Number of physical SIU ports on the SCU	Read	SCU
Features.Hardware.Max Tool Ports	Number of physical tool ports on the SIU	Read	SIU
Features.Hardware.Model	Device model string	Read	All devices
Features.Hardware.Serial Number	Device serial number	Read	All devices
Features.Hardware.Version	Hardware version string	Read	SCU
Info.Path	Physical location of the SIU in the format X.N, where X is the SCU device instance and N is the physical port at the SCU. Possible values: X=0, N ranges from 0 to the value of Features.Hardware.Max Ports	Read	SIU
Info.Port Handles.i	Reports a list of port handles assigned to physical tool port i at the SIU, for i = 0 to value of Features.Hardware.Max Tool Ports. Returns 2 hexadecimal characters for each assigned port handle; returns an empty string if no port handles are assigned.	Read	SIU
Info.Status.Alerts	System hardware and operating status flags ; see “Alerts User Parameters” on page 14 for details.	Read	All devices
Info.Status.Alerts Overflow	System hardware and operating status flags overflow; see “Alerts User Parameters” on page 14 for details.	Read	All devices
Info.Status.New Alerts	System hardware and operating status flags ; see “Alerts User Parameters” on page 14 for details.	Read	All devices

Table 4-5 Complete List of User Parameters (Continued)

Info.Status.Port.i	Reports the device instance of the connected SIU at physical port i at the SCU, for i = 0 to value of Features.Hardware.Max Ports. Returns an empty string if no SIUs are connected.	Read	SCU
Info.Timeout.<command>	Timeout for the specified command (s)	Read	SCU
Param.Page.Rev	Revision describing which parameters are saveable	Read	SCU
Param.System Beeper	Enables/disables the beeper sequence on system reset	Read, write, save	SCU
Param.Tracking.Frame Sync Source	Sets the frame synchronization source. Valid values: 0: Auto Mode (default) If the HF signal is available on the sync port, mode 2 (External Mode) is used. If the HF signal is not available on the sync port, mode 4 (Internal Mode) is used. 1: Reserved 2: External Mode HF and FR must be stable and continuous before issuing the TSTART command. 3: Slave Mode TSTART returns OKAY even when no sync signals are available on the sync port. Tracking mode starts with the first FR pulse on the sync port. After that the FR pulse is required to run continuously. If tracking has not yet started, sending TX and BX commands will result in ERROR05. 4: Internal Mode HF and FR signals from sync port are ignored. 5: Trigger Mode See the “ <i>Aurora User Guide</i> ” for information on the Trigger Mode.	Read, write	SCU
Param.Tracking.Trigger Invert	Invert polarity of signal FR_IN. See the “ <i>Aurora User Guide</i> ” for information on the sync port signals.	Read, write	SCU
Param.Tracking.Ext Sync Available	Reports whether an HF signal can be detected on the sync port. 1: The HF signal is detected on the sync port. 0: The HF signal is not detected on the sync port. See the “ <i>Aurora User Guide</i> ” for information on the sync port signals.	Read	SCU

Table 4-5 Complete List of User Parameters (Continued)

Param.Tracking.Track Frequency	Reports the tracking frame rate. Only valid when in tracking mode.	Read	SCU
Param.Tracking.Frame Frequency	Reports the time stamp increase per second. Only valid when in tracking mode.	Read	SCU
Param.Simulated Alerts	Simulates the 'Info.Status.Alerts' parameter, for testing purposes	Read, write	All devices
Param.User.String	User-defined string (up to 63 chars)	Read, write, save	SCU

5 Commands

Before sending any commands to the system, read the user guide that accompanied your system to ensure that you have a full understanding of the system functionality. The user guide is available on the NDI Support Site at <https://support.ndigital.com>.

Resetting the System with a Serial Break

Resets the system.

Operating Mode

All modes

Syntax

The method depends on the host computer.

Reply

```
RESET<CRC16><CR>
```

Usage Notes

1. The serial break is a special condition, and is specific to the host computer operating system. Refer to your computer manuals to determine how to generate a serial break.
2. The serial break is a good recovery method in the following situations:
 - System warm boot: the system is powered up, but you don't know the communication setup, or which mode the system is in.
 - Synchronization error: while in the [Tracking](#) mode, the [BX](#) or [TX](#) reply status returns that synchronization errors have occurred.
 - Loss of communication: the host computer and the system can no longer communicate.

Note Under normal operation, the Aurora System will return a response to any given command in under 10 seconds. If a timeout is detected, sending a serial break to the system should resolve the problem and return the system to normal operation.

3. After a serial break:
 - All processors receive a hard reset.
 - The system serial communication settings return to the default values: 9600 baud, 8 data bits, no parity, 1 stop bit, and no hardware handshaking.
 - A distinctive 2-beep sequence sounds to indicate that the system is re-initialized.

Example

Command:

N/A

Reply:

RESETBE6F<CR>

APIREV

Returns the API revision number.

Operating Mode

All modes

Syntax

APIREV<SPACE><CR>

Replies

Upon Success:

<Family>.<Major Revision Number>.<Minor Revision Number><CRC16><CR>

On Error:

ERROR<Error Code><CRC16><CR>

See [page 91](#) for error code definitions.

Reply Component	Description
Family	1 ASCII character For the Aurora System, this character is always D. (Other types of NDI measurement systems use other characters.)
Major Revision Number	3 ASCII characters The major revision number is incremented whenever there is an incompatible change in the API. (Whenever a command is deprecated or when its response is changed in a way that may break an application.)
Minor Revision Number	3 ASCII characters The minor revision number is incremented whenever there is an addition to the API that is compatible with all existing applications and usage. (Compatible changes are additions to the API command or option set that will not affect any existing applications.)

Example

Command:

APIREV

Reply:

D.001.00855D4

BEEP

Sounds the system beeper.

Operating Mode

All modes

Syntax

BEEP<SPACE><Number of Beeps><CR>

Parameter	Description
Number of Beeps	Valid Values: 1 to 9

Replies

Upon Success:

<Beep Status><CRC16><CR>

On Error:

ERROR<Error Code><CRC16><CR>

See [page 91](#) for error code definitions.

Reply Component	Description
Beep Status	Possible Values:
	0 The system is busy beeping.
	1 Beeping has started.

Example

Command:

BEEP 1

Reply:

1D4C1

BX

Returns the latest tool transformations and system status information in binary format.

Operating Mode

Tracking

Syntax

BX<SPACE><Reply Option><CR>

Parameter	Description				
Reply Option	<p>Optional. Specifies which information will be returned. If no reply option is specified, the system returns information for reply option 0001.</p> <p>The reply options are hexadecimal numbers that can be OR'd. Reply option 0800 is not reported separately from reply option 0001.</p> <p>Valid Values:</p> <table><tr><td>0001</td><td>Transformation data (default)</td></tr><tr><td>0800</td><td>Out-of-volume transformations</td></tr></table>	0001	Transformation data (default)	0800	Out-of-volume transformations
0001	Transformation data (default)				
0800	Out-of-volume transformations				

Replies

Upon Success:

```
<Start Sequence><Reply Length><Header CRC><Number of Handles>  
<Handle 1><Handle 1 Status><Reply Option 0001 Data>  
...  
<Handle n><Handle n Status><Reply Option 0001 Data>  
<System Status><CRC16>
```

Note The reply for the BX command is binary data.

Note If a handle status is “disabled,” the system will not return any of the <Reply Option 0001 Data> for that port handle.

On Error:

ERROR<Error Code><CRC16><CR>

See [page 91](#) for error code definitions.

Reply Component	Description
Start Sequence	<p>2 bytes: A5C4</p> <p>Indicates the start of the BX reply.</p>

Reply Component	Description	
Reply Length	2 bytes Indicates the number of bytes in the reply body between the <Header CRC> and the <CRC16>, exclusive.	
Header CRC	16 bits CRC of <Start Sequence> and <Reply Length>	
Number of Handles	1 byte The number of port handles for which transformations are returned.	
Handle n	1 byte The port handle whose transformation follows.	
Handle Status	1 byte Possible Values:	
	01	Valid
	02	Missing
	04	Disabled
Reply Option m Data	The data specific to the requested reply option. See the reply option information below for details:	
	Reply option 0001 (transformation data) (default)	
	Reply option 0800 (reporting all transformations)	
System Status	2 bytes	
	Bit field:	
	bits 0 to 4	Reserved
	bit 5	Hardware change. This bit is set if the Field Generator is disconnected from the System Control Unit.
	bit 6	Some port handle has become occupied
	bit 7	Some port handle has become unoccupied
	bit 8	Diagnostic pending. This bit is set whenever an alert is detected or cleared. To view the alerts status and clear the diagnostic pending bit, use GET (page 35) to check the Info.Status.New Alerts user parameter for every hardware device in the system. See “ Usage Notes ” on page 27 for more details.
	bit 9	Reserved
	bit 10	Configuration change. This bit is set when an SIU is added or removed. Currently this bit is only related to the SIU, but other components may be added in the future. This bit is cleared by the commands PHSR (page 50) and INIT (page 38) .
	bits 11 to 15	Reserved

Reply Option 0001 - Transformation Data

<Reply Option 0001 Data> = <Q₀><Q_x><Q_y><Q_z><T_x><T_y><T_z><Indicator Value>
 <Port Handle Status><Frame Number>

or

<Reply Option 0001 Data> = <Port Handle Status><Frame Number>

Reply Component	Description		
Q ₀ , Q _x , Q _y , Q _z	4 bytes each Rotational components of the transformation, quaternion, unitless, reported as IEEE 32-bit, single precision, floating point numbers.		
T _x , T _y , T _z	4 bytes each Translational components of the transformation, in mm, reported as IEEE 32-bit, single precision, floating point numbers.		
Indicator Value	4 bytes An estimate of how well the Aurora System calculated the transformation. Value range is ≥ 0 . For 6DOF tools, the indicator value compares sensor measurements to the tool's design (as described by its SROM device or tool definition file). For 5DOF tools, the indicator value is always zero. Unitless, reported as IEEE 32-bit, single precision, floating point number		
Port Handle Status	4 bytes		
	Bit field:		
	bit 0	Occupied	Bits 0 to 3 are shared for dual, 5DOF tools.
	bit 1	GPIO line 1 closed	
	bit 2	GPIO line 2 closed	
	bit 3	GPIO line 3 closed	
	bit 4	Initialized	
	bit 5	Enabled	
	bit 6	Out of volume	
	bit 7	Partially out of volume. This bit is set only for 6DOF tools, when one sensor is inside the measurement volume and the other sensor is outside the measurement volume.	
	bit 8	A sensor is broken. This bit is set when a sensor lead wire breaks, either along the lead wire length or at its connection points.	
	bit 9	Reserved	
	bit 10	Shorted sensor detected	
	bit 11	Signal too large. Occurs when sensor is too close to Field Generator	
	bit 12	Processing exception	
	bits 13 to 31	Reserved	

Reply Component	Description
Frame Number	<p>4 byte unsigned number</p> <p>The frame number is an internal counter related to data acquisition. The counter starts at power up and does not reset until the system is reset, the system is powered up again, or reply option 80 is sent with the TSTART command. The frame rate is 40 Hz. The frame number corresponds to the frame in which the raw data, used to calculate the accompanying transformation, was collected. The frame number is incremented by 8.</p>

Note If the handle status is “missing,” the system returns only the port handle status and the frame number.

Reply Option 0800 - Reporting All Transformations

This option enables the reporting of transformations when the tool is out of volume. This reply option must be OR'd with [reply option 0001](#).



Warning!

When using reply option 0800 with the BX command, you must take appropriate action to detect when a tool is out of volume, and determine whether this situation is detrimental to your application. If a tool is out of volume, reply option 0800 enables the system to return data that may lead to inaccurate conclusions and may cause personal injury.

Usage Notes

1. The BX reply format requires fewer characters than the text format; this allows transformations to be reported more quickly. For replies in text format, use [TX \(page 83\)](#).
2. To use the BX command, the data bits parameter must be set to 0 (8 bits) using [COMM \(page 29\)](#).
3. Replies are returned in little endian format.
4. See the user guide for detailed descriptions of the port handle status and system status bits.
5. By default, transformations will not be reported if the tool is either partially or wholly out of the characterized measurement volume. To report these transformations, you must use [reply option 0800](#) OR'd with [reply option 0001](#). The accuracy of these transformations is unknown.
6. When the “diagnostic pending” bit is set in the [system status](#), use [GET \(page 35\)](#) to read the [Info.Status.New Alerts](#) user parameter for every hardware device in the system. The act of reading these parameters clears the parameters and the “diagnostic pending” bit. For more information on alerts and their associated user parameters, see “[Alerts User Parameters](#)” on [page 14](#).
7. Bit 8 in the <Port Handle Status> section of [reply option 0001](#) may not always indicate when a lead wire is broken. Broken sensors that result in a short will not be detected.

Example

Command:

BX 0801

Reply:

A5C4005723130201013F3AF3CABE5B7209BF1C07713E635592C39E831F43332973C500511
33DA5BD9F00000031000002CC02013EA1B5D03D137D21BD787C673F72394A4286B6CB4360
6EF4C50468C13ED4E74100000031000002CD000059C9

This is the hexadecimal representation of the binary data being returned. This example returns data for two tools.

COMM

Sets the serial communication settings for the system.

Operating Mode

All modes

Syntax

COMM<SPACE><Baud Rate><Data Bits><Parity><Stop Bits><Hardware Handshaking><CR>

Parameter	Description	
Baud Rate	The data transmission rate between the Aurora System and the host computer, in bits per second.	
	Valid Values:	
	0	9600 Bd (default)
	1	14 400 Bd
	2	19 200 Bd, see usage note 5 .
	3	38 400 Bd
	4	57 600 Bd
	5	115 200 Bd
	6	921 600 Bd, see usage note 6 .
	A	230 400 Bd, see usage note 7 .
Data Bits	The data bits parameter must be set to 8 bits in order to use the BX command.	
	Valid Values:	
	0	8 bits (default)
Parity	1	7 bits
	Valid Values:	
	0	None (default)
	1	Odd
Stop Bits	2	Even
	Valid Values:	
	0	1 bit (default)
Hardware Handshaking	1	2 bits
	Valid Values:	
	0	Off (default)
	1	On

Replies

Upon Success:

OKAY<CRC16><CR>

On Error:

ERROR<Error Code><CRC16><CR>

See [page 91](#) for error code definitions.

Usage Notes

1. The system serial communication parameters have a default setting of 00000 (i.e. 9600 baud, 8 data bits, no parity, 1 stop bit, hardware handshaking off).
2. To use the [BX](#) command you must set the data bits parameter to 0 (8 bits).
3. If you change the baud rate using the COMM command, you must also change your host computer baud rate; otherwise, a system reset or other unexpected communication behaviour will occur. The host application should wait approximately 100 ms after receiving the OKAY reply from the system before changing its own communication parameters.
4. NDI strongly recommends using hardware handshaking when using the higher baud rates.
5. 19200 baud does not work using the "NDI Aurora SCU" USB serial driver.
6. 921600 baud is only available via USB and with combined firmware revision 009 (API Revision D.001.006) or later. A USB port is available on Aurora V2 and V3 systems.
7. Baud rate parameter "A" is available with combined firmware revision 009 (API Revision D.001.006) or later.

Example

Command:

COMM 30001

Reply:

OKAYA896

This changes the serial communication parameters to 38400 baud, 8 data bits, no parity, 1 stop bit, hardware handshaking on.

DFLT

Restores the user parameters to factory default values.

Operating Mode

All modes

Syntax

DFLT<SPACE><User Parameter Name><CR>

Parameter	Description
User Parameter Name	A string, identifying the name of the user parameter. May include a trailing wild card character (*) Use DFLT * to restore all user parameters to default values. User parameter names are case-sensitive.

Replies

Upon Success:

OKAY<CRC16><CR>

On Error:

ERROR<Error Code><CRC16><CR>

See [page 91](#) for error code definitions.

Usage Notes

1. The user parameter name may include a trailing wild card character (*).
2. The user parameter values set using the DFLT command persist until the system is reset or initialized. To save the user parameters at their factory default values, use [SAVE \(page 71\)](#) after using the DFLT command.
3. To view a list of user parameters and their current values, use **GET ***.
4. Parameters of type “string” and the alert parameters have no default values.
5. For more information on user parameters, see [“User Parameters” on page 12](#).

Example

Command:

DFLT *

Reply:

OKAYA896

DSTART

This command is deprecated. Use [TSTART \(page 78\)](#) instead.

DSTOP

This command is deprecated. Use [TSTOP \(page 80\)](#) instead.

ECHO

Returns exactly what is sent with the command.

Operating Mode

All modes

Syntax

ECHO<SPACE><Four or more ASCII characters><CR>

Replies

Upon Success:

Exactly what is sent with the command, with <CRC16><CR>.

On Error:

ERROR<Error Code><CRC16><CR>

See [page 91](#) for error code definitions.

Example

Command:

ECHO Testing!

Reply:

Testing!A81C

GET

Returns the values of user parameters.

Operating Mode

All modes

Syntax

GET<SPACE><User Parameter Name><CR>

Parameter	Description
User Parameter Name	A string, identifying the name of the user parameter. May include a trailing wild card character (*). Use GET * to return all user parameter values. User parameter names are case-sensitive.

Replies

Upon Success:

<User Parameter Name>=<Value><LF>(repeated for each user parameter name)<CRC16><CR>

On Error:

ERROR<Error Code><CRC16><CR>

See [page 91](#) for error code definitions.

Example

Command:

GET Info.Timeout.PINIT

Reply:

Info.Timeout.PINIT=5A6C2

GETINFO

Returns descriptive information about the user parameters.

Operating Mode

All modes

Syntax

```
GETINFO<SPACE><User Parameter Name><CR>
```

Parameter	Description
User Parameter Name	A string, identifying the name of the user parameter. May include a trailing wild card character (*). Use GETINFO * to return information for all user parameters. User parameter names are case-sensitive.

Replies

Upon Success:

```
<User Parameter Name>=<Value>;<Type>;<Attribute>;<Minimum>;<Maximum>;  
<Enumeration>;<Description><LF>(repeated for each user parameter, but no  
line feed after last parameter)<CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Reply Component	Description								
User Parameter Name	Variable size Full name of the user parameter								
Value	Variable size Value of the user parameter								
Type	1 hexadecimal character Describes the data type. Possible Values: <table><tr><td>0</td><td>Boolean</td></tr><tr><td>1</td><td>Integer</td></tr><tr><td>2</td><td>Float</td></tr><tr><td>3</td><td>String</td></tr></table>	0	Boolean	1	Integer	2	Float	3	String
0	Boolean								
1	Integer								
2	Float								
3	String								

Reply Component	Description
Attribute	1 to 4 hexadecimal characters Describes the access rules.
	Bit field:
	bit 0 Read
	bit 1 Write
	bit 2 Save
	bit 3 Volatile
	bits 4 to 15 Reserved (may not all be set to 0)
Minimum	Minimum allowed value of the user parameter. For a string, the minimum number of characters allowed. If minimum = maximum = 0, no range check is performed.
Maximum	Maximum allowed value of the user parameter. For a string, the maximum number of characters allowed. If minimum = maximum = 0, no range check is performed.
Enumeration	Comma-separated enumeration list. This is a list of possible values that the user parameter can take, and corresponds to the values in the <Value> field (the first item in the list corresponds to value 0, the second item corresponds to value 1, etc.).
Description	Describes the user parameter's function.

Usage Notes

1. The user parameter name may include a trailing wild card character (*).
2. Use **GETINFO *** to return information for all user parameters.
3. Numeric user parameter values are returned as decimal strings.
4. User parameter names are case-sensitive.
5. For a list of user parameters and values without descriptive information, use the **GET** command.
6. For more information on user parameters, see [“User Parameters” on page 12](#).

Example

Command:

```
GETINFO Param.User.String
```

Reply:

```
Param.User.String=;3;7;0;64;;User defined string (up to 63 chars)8BFC
```

INIT

Initializes the system.

Operating Mode

All modes

Syntax

```
INIT<SPACE><CR>
```

Replies

Upon Success:

```
OKAY<CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Usage Notes

1. During power up or system reset, the system configuration is determined. The configuration includes firmware revisions and the characterized measurement volume for which the Field Generator has been calibrated. The INIT command ensures that the system configuration was determined successfully.
2. The system will automatically return to [Setup](#) mode after using the INIT command.

Example

Command:

```
INIT
```

Reply:

```
OKAYA896
```

LED

Changes the state of visible LEDs on a tool.

Operating Mode

All modes

Prerequisite Command

[PINIT \(page 53\)](#)

Syntax

```
LED<SPACE><Port Handle><LED Number><State><CR>
```

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF
LED Number	Specifies the LED. The LED number does not correspond to the GPIO line number. For example, LED 1 corresponds to the first LED on the tool, which may not be on GPIO line 1. Valid Values: 1 to 3
State	Sets the state of the specified LED. Valid Values:
	B Blank (not on)
	F Flash
	S Solid on

Replies

Upon Success:

```
OKAY<CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Usage Notes

The GPIO line must be defined as “visible LED” in the tool’s tool definition file for the LED command to function.

Example

Command:

LED 0A1S

Reply:

OKAYA896

This turns on solid the first LED on the tool associated with port handle 0A.

PDIS

Disables the reporting of transformations for a particular port handle.

Operating Mode

Setup

Prerequisite Command

[PENA \(page 42\)](#)

Syntax

PDIS<SPACE><Port Handle><CR>

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF

Replies

Upon Success:

OKAY<CRC16><CR>

On Error:

ERROR<[Error Code](#)><CRC16><CR>

See [page 91](#) for error code definitions.

Example

Command:

PDIS 0A

Reply:

OKAYA896

PENA

Enables the reporting of transformations for a particular port handle.

Operating Mode

Setup

Prerequisite Command

[PINIT \(page 53\)](#)

Syntax

PENA<SPACE><Port Handle><Tool Tracking Priority><CR>

Parameter	Description						
Port Handle	2 hexadecimal characters Valid Values: 0A to FF						
Tool Tracking Priority	Describes the type of tool. Valid Values: <table><tr><td>S</td><td>Static: a static tool is considered to be relatively immobile, e.g. a reference tool.</td></tr><tr><td>D</td><td>Dynamic: a dynamic tool is considered to be in motion, e.g. a probe.</td></tr><tr><td>B</td><td>Button box: a button box can have switches and LEDs, but no sensors. No transformations are returned for a button box tool, but switch status is returned.</td></tr></table>	S	Static: a static tool is considered to be relatively immobile, e.g. a reference tool.	D	Dynamic: a dynamic tool is considered to be in motion, e.g. a probe.	B	Button box: a button box can have switches and LEDs, but no sensors. No transformations are returned for a button box tool, but switch status is returned.
S	Static: a static tool is considered to be relatively immobile, e.g. a reference tool.						
D	Dynamic: a dynamic tool is considered to be in motion, e.g. a probe.						
B	Button box: a button box can have switches and LEDs, but no sensors. No transformations are returned for a button box tool, but switch status is returned.						

Replies

Upon Success:

OKAY<CRC16><CR>

On Error:

ERROR<[Error Code](#)><CRC16><CR>

See [page 91](#) for error code definitions.

Usage Notes

The tool tracking priority selected does not currently affect tracking behaviour.

Example

Command:

PENA 0AD

Reply:

OKAYA896

PHF

Releases system resources from an unused port handle.

Operating Mode

Setup

Prerequisite Command

[PHSR \(page 50\)](#)

Syntax

PHF<SPACE><Port Handle><CR>

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF

Replies

Upon Success:

OKAY<CRC16><CR>

On Error:

ERROR<[Error Code](#)><CRC16><CR>

See [page 91](#) for error code definitions.

Usage Notes

1. The PHF command should be used whenever a tool is disconnected. This optimizes the use of system resources. If PHF is not used, the system will be unable to assign a port handle after the maximum number of port handles has been reached.
2. If a tool is disconnected then reconnected, it is assigned a new port handle. The old port handle is no longer in use and should be freed using PHF.

Example

Command:

PHF 0A

Reply:

OKAYA896

This frees port handle 0A, so it is no longer assigned to a tool.

PHINF

Returns information about the tool associated with the port handle.

Operating Mode

Setup

Prerequisite Command

[PHSR \(page 50\)](#)

Syntax

PHINF<SPACE><Port Handle><Reply Option><CR>

Parameter	Description												
Port Handle	2 hexadecimal characters Valid Values: 0A to FF												
Reply Option	Optional. Specifies which information will be returned. If no reply option is specified, the system returns information for reply option 0001. The reply options are hexadecimal numbers that can be OR'd. If multiple reply options are used, the replies are returned in order of increasing option value. Valid Values: <table><tr><td>0001</td><td>Tool information (default)</td></tr><tr><td>0004</td><td>Tool part number</td></tr><tr><td>0008</td><td>Switch and visible LED information</td></tr><tr><td>0020</td><td>Physical port location</td></tr><tr><td>0040</td><td>GPIO line definitions</td></tr><tr><td>0080</td><td>Sensor configuration and physical port location</td></tr></table>	0001	Tool information (default)	0004	Tool part number	0008	Switch and visible LED information	0020	Physical port location	0040	GPIO line definitions	0080	Sensor configuration and physical port location
0001	Tool information (default)												
0004	Tool part number												
0008	Switch and visible LED information												
0020	Physical port location												
0040	GPIO line definitions												
0080	Sensor configuration and physical port location												

Replies

Upon Success:

If the port handle has been initialized:

<Reply Option 0001 Data><Reply Option 0004 Data>...<Reply Option 0080 Data><CRC16><CR>

If the tool has been disconnected since the port handle was assigned:

UNOCCUPIED<CRC16><CR>

On Error:

ERROR<Error Code><CRC16><CR>

See [page 91](#) for error code definitions.

Reply Option 0001 - Tool Information

<Reply Option 0001 Data> = <Tool Type><Manufacturer's ID><Tool Revision><Serial Number><Port Handle Status>

Reply Component	Description	
Tool Type	8 characters	
	<Tool Type> = <Main Type><Number of Switches><Number of Visible LEDs><Reserved><Subtype>	
	Main Type	2 hexadecimal characters
		Possible Values:
		01 Reference
		02 Probe
		03 Button box or foot switch
		04 Software-defined
		05 and 06 Reserved
		07 Calibration device
		08 to 0A Reserved
		0B Catheter
		0C to FF Reserved
	Number of Switches	1 character
	Number of Visible LEDs	1 character
	Reserved	2 characters
	Subtype	2 characters
Manufacturer's ID	12 characters	
Tool Revision	3 characters	
Serial Number	8 hexadecimal characters (32 bits)	
	Bit field:	
	bits 0 to 9	Sequence number (one-based)
	bits 10 to 18	Day of year (zero-based, e.g. Jan 1 is day 0 and Dec 31 is day 364)
	bits 19 to 22	Month (zero-based)
	bits 23 to 31	Year (year is <current year> - 1900,e.g. the year 2005 is 105)

Reply Component	Description
Port Handle Status	2 hexadecimal characters (8 bits)
	Bit field:
	bit 0 Occupied
	bit 1 GPIO line 1 closed
	bit 2 GPIO line 2 closed
	bit 3 GPIO line 3 closed
	bit 4 Port handle initialized
	bit 5 Port handle enabled
	bits 6 and 7 Reserved

Reply Option 0004 - Tool Part Number

Reply Component	Description
Reply Option 0004 Data	20 characters
	The part number of the tool.

Reply Option 0008 - Switch and Visible LED Information

Reply Component	Description
Reply Option 0008 Data	2 hexadecimal characters (8 bits)
	This option reports the information found in the tool definition file. It is not information sensed by the hardware.
	Bit field:
	bit 0 Reserved
	bit 1 Input supported on GPIO line 1
	bit 2 Input supported on GPIO line 2
	bit 3 Input supported on GPIO line 3
	bit 4 Tool tracking LED supported
	bit 5 Visible LED supported on GPIO line 1
	bit 6 Visible LED supported on GPIO line 2
	bit 7 Visible LED supported on GPIO line 3

Reply Option 0020 - Physical Port Location

<Reply Option 0020 Data> = <System Control Unit Serial Number><Reserved>
<Port Number><Channel Number>

Reply Component	Description
System Control Unit Serial Number	8 characters
Reserved	2 characters
Port Number	2 ASCII characters Possible Values: depends on the configuration of SIUs.
Channel Number	2 characters For a dual, 5DOF tool. Possible Values: 00 or 01

Note Reply option 0020 is deprecated. Use [PHINF reply option 0080](#) instead.

Reply Option 0040 - GPIO Line Definitions

<Reply Option 0040 Data> = <GPIO Line 1><GPIO Line 2><GPIO Line 3>
<Reserved>

Reply Component	Description
GPIO Line n	1 hexadecimal character Definition of the n th general purpose input/output line. Possible Values:
	0 Not available, or defined as a tool tracking LED
	1 Input
	2 Output
	3 Visible LED
	4 Always high
Reserved	1 character

Reply Option 0080 - Sensor configuration and physical port location

```
<Reply Option 0080 Data> = <DOF><Number of Sensors>
<Physical Port Information Sensor 1>
<Physical Port Information Sensor 2 (if present)>
```

Reply Component	Description	
Degrees of Freedom (DOF)	2 characters	
	Possible Values:	
	05	5DOF Sensor(s)
	06	6DOF Sensor
Number of Sensors	00	No Sensors
	2 characters	
	Possible Values: 00 to 02	
Physical Port Information	SCU Instance	2 characters: 00
	Port at SCU	2 characters
		Possible values: 00 to value of user parameter Features.Hardware.Max Ports (see page 17 for details).
	Tool Port at SIU	2 characters
		Possible values: 00 to value of user parameter Features.Hardware.Max Tool Ports (see page 17 for details).
	Channel	2 hexadecimal digits
		Possible Values: 00 or 01

Usage Notes


1. With the exception of reply option 0020, reply option 0080 (physical port information) and the port handle status, all of the information returned with this command is read from the tool's SROM device or from a tool definition file assigned to the port handle with [PVWR \(page 67\)](#).
2. If the port handle has not been initialized, the system will correctly report only the SCU serial number and port number (in reply option 0020), the port handle status (in reply option 0020) and the physical port information (in reply option 0080).
3. Reply option 0020 is deprecated. Use [PHINF reply option 0080](#) instead.
4. [Reply Option 0040](#): If a GPIO line is defined as a visible LED, it will also be reported in reply option [0008](#). The tracking LED will be reported as available and is also reported in reply option [0008](#).

Example

Command:

PHINF 0A006D

Reply:



PHSR

Returns the number of assigned port handles and the port handle status for each one. Assigns a port handle to a tool.

Operating Mode

Setup

Prerequisite Command

[INIT \(page 38\)](#)

Syntax

PHSR<SPACE><Reply Option><CR>

Parameter	Description
Reply Option	Specifies which information will be returned. If no reply option is specified, the system returns information for reply option 00.
	The reply options cannot be OR'd.
	Valid Values:
	00 Reports all allocated port handles (default)
	01 Reports port handles that need to be freed
	02 Reports port handles that are occupied, but not initialized or enabled
	03 Reports port handles that are occupied and initialized, but not enabled
	04 Reports enabled port handles

Replies

Upon Success:

```
<Number of Port Handles>
<1st Port Handle><1st Port Handle Status>
<2nd Port Handle><2nd Port Handle Status>
...
<nth Port Handle><nth Port Handle Status>
<CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Reply Component	Description														
Number of Port Handles	2 hexadecimal characters The number of allocated port handles of the type specified in the reply option. If no reply option is specified, the number returned is the total number of allocated port handles.														
n^{th} Port Handle	2 hexadecimal characters Specifies the port handle whose status follows.														
n^{th} Port Handle Status	3 hexadecimal characters (12 bits) Bit field: <table> <tr> <td>bit 0</td><td>Occupied</td></tr> <tr> <td>bit 1</td><td>GPIO line 1 closed</td></tr> <tr> <td>bit 2</td><td>GPIO line 2 closed</td></tr> <tr> <td>bit 3</td><td>GPIO line 3 closed</td></tr> <tr> <td>bit 4</td><td>Initialized</td></tr> <tr> <td>bit 5</td><td>Enabled</td></tr> <tr> <td>bit 6 to 11</td><td>Reserved</td></tr> </table>	bit 0	Occupied	bit 1	GPIO line 1 closed	bit 2	GPIO line 2 closed	bit 3	GPIO line 3 closed	bit 4	Initialized	bit 5	Enabled	bit 6 to 11	Reserved
bit 0	Occupied														
bit 1	GPIO line 1 closed														
bit 2	GPIO line 2 closed														
bit 3	GPIO line 3 closed														
bit 4	Initialized														
bit 5	Enabled														
bit 6 to 11	Reserved														

Usage Notes

1. When you send the PHSR command, the system will detect and assign port handles to any tools that do not already have a port handle assigned (i.e. any tools that were connected after the last PHSR call). It will then return the requested port handle information.
2. For a split port on a dual 5DOF tool, the first PHSR sent will report only one port handle. After the port handle is initialized, it is assigned to channel 0. You must then use PHSR again to assign a port handle to channel 1. The port handle for channel 1 is initialized automatically. See [“Flow Chart for Port Handle Usage” on page 8](#).
3. If you disconnect a tool while the system is in [Tracking](#) mode, the port handle will be reported as “disabled” in the replies to the [BX](#) and [TX](#) commands. If you reconnect the tool, it will need a new port handle.
4. If you connect a tool to the system while the system is in [Tracking](#) mode (either reconnecting a tool that was just disconnected, or connecting a new tool), you will have to take the following steps before the system will report the tool:
 - a) Exit [Tracking](#) mode ([TSTOP](#)).
 - b) Assign, initialize, and enable a port handle for the tool, as outlined in [Figure 2-1 on page 8](#).
 - c) Re-enter [Tracking](#) mode ([TSTART](#)).

Example 1

Command:

PHSR

Reply:

001414

In this case, there are no tools connected to the system.

Example 2

Command:

PHSR

Reply:

010A001C1B5

In this case, one tool is connected to the system and it has been assigned port handle 0A. This port handle is not initialized or enabled.

Example 3

Command:

PHSR 03

Reply:

040A01F0B01F0C01F0D01F2DDB

In this case, four tools are connected to the system and have been assigned port handles 0A, 0B, 0C, and 0D. All four port handles are initialized but not enabled.

PINIT

Initializes a port handle.

Operating Mode

Setup

Prerequisite Command

[PHSR \(page 50\)](#)

Syntax

```
PINIT<SPACE><Port Handle><CR>
```

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF

Replies

Upon Success:

```
OKAY<CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Usage Notes

1. Use PINIT to initialize a port handle for a tool after you have assigned a port handle using [PHSR](#). If you are using [PVWR](#) to override the SROM device in a tool, use PINIT after PVWR.
2. For a split port on a dual 5DOF tool, the first PHSR sent will report only one port handle. After the port handle is initialized using PINIT, it is assigned to channel 0. You must then use PHSR again to assign a port handle to channel 1. The port handle for channel 1 is initialized automatically. See “[Flow Chart for Port Handle Usage](#)” on [page 8](#).
3. If the tool description is read from a tool definition file that has been loaded using [PVWR \(page 67\)](#), initialization involves unpacking and verifying the tool definition file. This process is almost instantaneous.
4. If the tool description is read from an SROM device, initialization involves reading, unpacking, and verifying the tool definition file contents. This process takes approximately two seconds if successful, or several seconds longer if a problem is encountered and retries are attempted by the system.

5. When the PINIT command is issued, all previous settings for that port handle (e.g. set using TTCFG or PVWR) are reset, and related port handles (e.g. for a dual 5DOF configuration) are invalidated.

Example

Command:

```
PINIT 0A
```

Reply:

```
OKAYA896
```

This initializes port handle 0A.

PPRD

Reads data from the SROM device of a tool.

Operating Mode

Setup

Prerequisite Command

[PSEL \(page 59\)](#)

Syntax

```
PPRD<SPACE><Port Handle><SROM Device Address><CR>
```

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF
SROM Device Address	4 hexadecimal characters Valid Values: 0000 to 07C0

Replies

Upon Success:

```
<SROM Device Data><CRC16><CR>
```

(The SROM device data is 64 bytes (128 hexadecimal characters) of data.)

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Usage Notes

1. The SROM device is a 2-KB write-once device that must be read in 64-byte chunks. An SROM device is considered blank if its contents are all 0xFFs.
2. PPRD reads 64 bytes of data from the SROM device starting at a specified SROM device address.
3. You must select the SROM device as the reading target with [PSEL \(page 59\)](#) before sending the PPRD command.

Example

Command:

PPRD 0A0000

Reply:

```
010041010000000200000000053CDD33020000000200000000000000000000000000  
0000000000000000000000000000008000000780B6D3D9E0F73BE7DE9
```


PPWR

Writes data to the SROM device in a tool.

Operating Mode

Setup

Prerequisite Command

[PSEL \(page 59\)](#)

Syntax

```
PPWR<SPACE><Port Handle><SROM Device Address><SROM Device Data><CR>
```

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF
SROM Device Address	4 hexadecimal characters Valid Values: 0000 to 07C0
SROM Device Data	64 bytes (128 hexadecimal characters) of data

Replies

Upon Success:

```
OKAY<CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Usage Notes

1. PPWR writes 64 bytes of data to the SROM device starting at a specified SROM device address.
2. You must select the SROM device as the writing target with [PSEL \(page 59\)](#) before sending the PPWR command.
3. The data must be formatted into unsigned ASCII characters. Each byte of binary data can be represented by two hexadecimal characters, which are then sent to the system in ASCII (4 bits per ASCII character).
4. The tool description section of a tool SROM device is a 1 KB, write-once area that must be written in 64-byte chunks. If the information being written to the system is less than 64 bytes,

then the remainder of the chunk must be padded out with 1s to maintain the 64-byte size before being written to the SROM device.

5. An SROM device is considered blank if its contents are all 0xFFs.

Example

Command:

[illegible]

Reply:

OKAYA896

PSEL

Selects an SROM device target for a tool.

Operating Mode

[Setup](#)

Prerequisite Command

[PHSR \(page 50\)](#)

Syntax

PSEL<SPACE><Port Handle><Tool SROM Device ID><CR>

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF
Tool SROM Device ID	16 hexadecimal characters Use PSRCH (page 62) to determine the IDs of the tool's SROM device(s).

Replies

Upon Success:

OKAY<CRC16><CR>

On Error:

ERROR<[Error Code](#)><CRC16><CR>

See [page 91](#) for error code definitions.

Example

Command:

PSEL 0A0B3876530000005B

Reply:

OKAYA896

This selects the SROM device with ID 0B3876530000005B for port handle 0A.

PSOUT

Sets the states of the general purpose input/output (GPIO) lines in a tool.

Operating Mode

All modes

Prerequisite Command

[PINIT \(page 53\)](#)

Syntax

```
PSOUT<SPACE><Port Handle><GPIO Line 1 State><GPIO Line 2 State>  
<GPIO Line 3 State><CR>
```

Parameter	Description								
Port Handle	2 hexadecimal characters Valid Values: 0A to FF								
GPIO Line n State	State of the nth GPIO line Valid Values: <table><tr><td>N</td><td>No change</td></tr><tr><td>S</td><td>Solid on</td></tr><tr><td>P</td><td>Pulse</td></tr><tr><td>O</td><td>Off</td></tr></table>	N	No change	S	Solid on	P	Pulse	O	Off
N	No change								
S	Solid on								
P	Pulse								
O	Off								

Replies

Upon Success:

```
OKAY<CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Usage Notes

You can check the status of an output using [PHINF \(page 44\)](#).

Example**Command:**

PSOUT 0ANSN

Reply:

OKAYA896

This sets the three GPIO lines associated with port handle 0A to no change, solid on, and no change.

PSRCH

Returns a list of valid SROM device ID(s) for a tool.

Operating Mode

Setup

Prerequisite Command

[PHSR \(page 50\)](#)

Syntax

```
PSRCH<SPACE><Port Handle><CR>
```

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF

Replies

Upon Success:

```
<Number of SROM Devices><SROM Device 1 ID><SROM Device 2 ID>...<SROM  
Device 7 ID><CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Reply Component	Description
Number of SROM Devices	1 character
SROM Device n ID	16 characters

Usage Notes

The tool SROM device has an embedded ID, which is a unique, 16-character, alphanumeric identifier. The SROM device ID is used to select an SROM device as a target with [PSEL \(page 59\)](#).

Example

Command:

```
PSRCH 0A
```

Reply:

```
10B3876530000005B7FFF
```

In this case, there is one SROM device, with ID 0B3876530000005B.

PURD

Reads data from the user section of the SROM device in a tool.

Operating Mode

[Setup](#)

Prerequisite Command

[PHSR \(page 50\)](#)

Syntax

PURD<SPACE><Port Handle><User SROM Device Address><CR>

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF
User SROM Device Address	4 hexadecimal characters Valid Values: 0000 to 03C0

Replies

Upon Success:

<SROM Device Data><CRC16><CR>

(The SROM device data is 64 bytes (128 hexadecimal characters) of data.)

On Error:

ERROR<[Error Code](#)><CRC16><CR>

See [page 91](#) for error code definitions.

Usage Notes

1. The SROM device is automatically selected as the reading target when this command is issued, so you do not need to find and specify the SROM device ID. The SROM device address has an implied offset in the command which reads the user information from the correct SROM device address.
2. The PURD command returns 64 bytes of data at a time.

Example

Command:

PURD 0A0000

Reply:

0022446688AACCEE0022446688AACCEE0022446688AACCEE0022446688AACCEE002244668
8AACCEE0022446688AACCEE0022446688AACCEE0022446688AACCEE3CC0

PUWR

Writes data to the user section of the SROM device in a tool.

Operating Mode

Setup

Prerequisite Command

[PHSR \(page 50\)](#)

Syntax

```
PUWR<SPACE><Port Handle><User SROM Device Address><User SROM Device Data><CR>
```

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF
User SROM Device Address	4 hexadecimal characters Valid Values: 0000 to 03C0
User SROM Device Data	64 bytes of data to write (128 hexadecimal characters)

Replies

Upon Success:

```
OKAY<CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Usage Notes

1. The SROM device is automatically selected as the writing target when this command is issued, so you do not need to find and specify the SROM device ID. The SROM device address has an implied offset in the command which places the user information at the correct SROM device address.
2. The data must be formatted into unsigned ASCII characters. Each byte of binary data can be represented by two hexadecimal characters, which are then sent to the system in ASCII (4 bits per ASCII character).
3. The user section of a tool SROM device is a 1-KB, write-once area that must be written in 64-byte chunks. If the information being written to the system is less than 64 bytes, then the

remainder of the chunk must be padded out with 1s to maintain the 64-byte size before being written to the system.

- Unused portions of the SROM device can be written to by setting the SROM device address appropriately. To determine which portions of the SROM device are unused, read the contents of the SROM device using [PURD \(page 63\)](#).

Example

Command:

[illegible]

Reply:

OKAYA896

PVWR

Allows you to upload a tool definition file for a tool. The Aurora System will use the data in the uploaded tool definition file instead of the data in the tool's SROM device.

Operating Mode

Setup

Prerequisite Command

[PHSR \(page 50\)](#)

Syntax

```
PVWR<SPACE><Port Handle><Start Address><Tool Definition Data><CR>
```

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF
Start Address	4 hexadecimal characters Increment the start address by 64 bytes with each chunk of data sent for a particular port handle. Valid Values: 0000 to 03C0
Tool Definition Data	128 hexadecimal characters

Replies

Upon Success:

```
OKAY<CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Usage Notes

1. Use PVWR in the following cases:
 - To assign a tool definition file to a tool, to override the SROM device in the tool.
 - To assign a tool definition file to a tool, to test the tool definition file before permanently recording the tool definition file onto the SROM device.

2. The data must be formatted into unsigned ASCII characters. Each byte of binary data can be represented by two hexadecimal characters, which are then sent to the system in ASCII (4 bits per ASCII character).
3. Data is sent to the system in 64-byte chunks (128 hexadecimal characters). The last chunk must be padded out with zeroes to maintain the 64-byte size before being written to the system.
4. After using PVWR, initialize ([PINIT](#)) and enable ([PENAB](#)) the port handle in order to track the tool.
5. If the tool needs to be re-initialized with the tool definition file, the PVWR sequence must be run again before PINIT is used.
6. To permanently write a tool definition file to an SROM device, use [PPWR](#) ([page 57](#)).

Example

Command:

```
PVWR 0B00004E444900551C0000001000000000000000101000000001A419335A0000000030000  
0003000000000000004000000000000000000000000000000000000000000000000000000000
```

Reply:

OKAYA896

RESET

Resets the system.

Operating Mode

All modes

Syntax

RESET<SPACE><Reset Option><CR>

Parameter	Description			
Reset Option	Optional. Specifies the type of reset. If no reset option is specified, the system performs a RESET 1.			
	Valid Values:			
	<table><tr><td>0</td><td>Generates a “soft” reset and resets the baud rate to 9600. System will not beep</td></tr><tr><td>1</td><td>Same behaviour as resetting the system with a serial break. See page 20</td></tr></table>	0	Generates a “soft” reset and resets the baud rate to 9600. System will not beep	1
0	Generates a “soft” reset and resets the baud rate to 9600. System will not beep			
1	Same behaviour as resetting the system with a serial break. See page 20			

Replies

Upon Success:

RESET 0

OKAY<CRC16><CR>

RESET 1

RESET<CRC16><CR>

On Error:

ERROR<[Error Code](#)><CRC16><CR>

See [page 91](#) for error code definitions.

Usage Notes

1. RESET can only be used when the host computer and the Aurora System are at the same baud rate. To reset the system when the baud rates do not match or when the system is in an unknown state use a serial break, see [page 20](#).
2. Reset option 1 (hard reset) is only valid with the Aurora V2 and V3 systems. It is not supported on older Aurora Systems.
3. If the command is successful, the reply will be sent at the default communications setting; 9600 baud, 8 data bits, no parity, 1 stop bit, hardware handshaking off.
4. Errors will be sent with the previous baud rate settings.
5. Successful commands will wait for 100ms before executing the reset. This gives enough time to wait for an error message and to switch to 9600baud to receive the reply.

Example

Command:

RESET 1

Reply:

RESETBE6F

SAVE

Saves all non-volatile user parameters that have been changed (on all connected devices).

Operating Mode

All modes

Syntax

SAVE<SPACE><CR>

Replies

Upon Success:

OKAY<CRC16><CR>

On Error:

ERROR<Error Code><CRC16><CR>

See [page 91](#) for error code definitions.

Usage Notes

1. To restore the user parameters to factory default values, use the [DFLT \(page 31\)](#) command. To save the user parameters at their factory default values, use the SAVE command after using the DFLT command.
2. To set user parameter values, use the [SET \(page 72\)](#) command.
3. For more information on user parameters, see “User Parameters” on [page 12](#).

Example

Command:

SAVE

Reply:

OKAYA896

SET

Sets user parameter values.

Operating Mode

All modes

Syntax

```
SET<SPACE><User Parameter Name>=<Value><CR>
```

Parameter	Description
User Parameter Name	A case-sensitive string, identifying the name of the user parameter.
Value	The value to set. Numerical values are decimal. For boolean values, 1 is true and 0 is false.

Replies

Upon Success:

```
OKAY<CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Usage Notes

1. To view a list of user parameters and their current values, use **GET ***. For a description of the user parameters, use **GETINFO ***.
2. The user parameter values set using the SET command persist until the system is reset or initialized. To save the user parameter values, use [SAVE \(page 71\)](#). To reset user parameters to their default values, use [DFLT \(page 31\)](#).
3. User parameter names are case-sensitive.
4. For more information on user parameters, see [“User Parameters” on page 12](#)

Example

Command:

```
SET SCU-0.Param.System Beeper=0
```

Reply:

```
OKAYA896
```

This turns off the system beeper on system reset. Note that this example must be followed by the command [SAVE](#) in order to take effect.

SFLIST

Returns information about the supported features of the system.

Operating Mode

Setup

Syntax

```
SFLIST<SPACE><Reply Option><CR>
```

Parameter	Description					
Reply Option	Specifies which information will be returned.					
	The reply options cannot be OR'd.					
	Valid Values:					
	<table><tr><td>00</td><td>Summary of supported features</td></tr><tr><td>03</td><td>Number of volumes and volume shapes</td></tr><tr><td>10</td><td>Number of ports</td></tr></table>	00	Summary of supported features	03	Number of volumes and volume shapes	10
00	Summary of supported features					
03	Number of volumes and volume shapes					
10	Number of ports					

Replies

Upon Success:

```
<Reply Option n Data>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Reply Component	Description
Reply Option n Data	The data specific to the requested reply option. See the reply option information below for details: Reply Option 00 (Supported Features Summary) Reply Option 03 (Measurement Volumes) Reply Option 10 (Number of ports)

Reply Option 00 - Supported Features Summary

Reply Component	Description
Reply Option 00 Data	8 hexadecimal characters (32 bits)
	Bit field:
bits 0 and 1	Reserved
bit 2	Multiple volume characterization parameters supported
bits 3 to 15	Reserved
bit 16	Magnetic ports available
bits 17 and 18	Reserved
bit 19	Field Generator available
bits 20 to 31	Reserved

Reply Option 03 - Measurement Volumes

```

<Reply Option 03 Data> =
<Number of Volumes><1st Shape Type><1st Shape Parameters><Reserved><Metal
Resistant><LF>
...
<nth Shape Type><nth Shape Parameters><Reserved><Metal
Resistant><LF><CRC16><CR>

```

Reply Component	Description
Number of Volumes	1 hexadecimal character
n th Shape Type	1 hexadecimal character
	Possible Values:
9	Cube volume
A	Dome volume
n th Shape Parameters	10 parameters, 7 characters each (a sign, and six digits with an implied decimal in the position XXXX.XX) See the shape parameters below.
Reserved	1 hexadecimal character
Metal Resistant	1 hexadecimal character
	Possible Values:
0	no information
1	metal resistant
2	not metal resistant
3 to F	reserved


Shape Parameters

<nth Shape Parameters> in [reply option 03](#) returns the following values (illustrated in [Figure 5-1](#) and [Figure 5-2](#))

Cube Volume:

Shape Parameter	Description	Value
D1	Minimum x value	-250 mm
D2	Maximum x value	+250 mm
D3	Minimum y value	-250 mm
D4	Maximum y value	+250 mm
D5	Minimum z value	-550 mm
D6	Maximum z value	-50 mm
D7 to D10	Reserved	

Top View



Side View




Figure 5-1 Cube Volume Parameters

Dome Volume:

There are currently two Field Generators that support the dome volume, the Planar Field Generator (PFG) and the Tabletop Field Generator (TTFG). The following table details values for both FGs.

Shape Parameter	Description	Value PFG (mm)	Value TTFG (mm)
D1	Offset from Field Generator	+50	+120
D2	Cylinder radius along x-axis	+480	+210
D3	Minimum dome radius	+50	+120
D4	Maximum dome radius	+660	+600
D5	Cylinder radius along y-axis Note: If D5 is equal to 0, the y-axis radius is equal to the x-axis radius (circular cylinder)	0(+480)	+300
D6	Maximum offset from Field Generator Note: If D6 is equal to 0, the maximum offset is equal to D4 (the maximum dome radius)	0(+660)	+600
D7 to D10	Reserved	—	—




Figure 5-2 Dome Volume Parameters

Reply Option 10 - Number of Ports Available

Reply Component	Description
Reply Option 10 Data	2 hexadecimal characters This option is deprecated. Use the GET command and the user parameter Features.Hardware.Max Tool Ports instead.

Usage Notes

Reply Option 03 Use both the shape type and the shape parameters to graphically represent the characterized measurement volume. There may be multiple volumes with the same shape type. All volumes of the same shape type use the shape parameters the same way.

Example**Command:**

SFLIST 03

Reply:

29-025000+025000-025000+025000-055000-005000+000000+000000+000000
+00000011
A+005000+048000+005000+066000+000000+000000+000000+000000+00000011
D3BB

TSTART

Starts [Tracking](#) mode.

Operating Mode

[Setup](#)

Prerequisite Command

[INIT \(page 38\)](#)

Syntax

TSTART<SPACE><Reply Option><CR>

Parameter	Description
Reply Option	00 (Optional, default) 40 (Optional, starts tracking in faster acquisition mode) 80 (Optional, resets the frame counter to zero) The reply options are hexadecimal numbers that can be OR'd (C0).

Replies

Upon Success:

OKAY<CRC16><CR>

On Error:

ERROR<[Error Code](#)><CRC16><CR>

See [page 91](#) for error code definitions.

Usage Notes

If reply option 80 is not used, only resetting the system resets the counter for the frame number. The frame number is reported in reply option 0001 of the [TX \(page 83\)](#) and [BX \(page 24\)](#) commands.

Using reply option 40 will result in the following:

- A data acquisition rate of 66 Hz. (It may be lower when serial interface limits the speed.)
- A shorter frame length of 15 ms.
- Precision uncertainty increases by a factor of 2.

Example**Command:**

TSTART

Reply:

OKAYA896

TSTOP

Stops [Tracking](#) mode.

Operating Mode

[Tracking](#)

Prerequisite Command

[TSTART](#) ([page 78](#))

Syntax

TSTOP<SPACE><CR>

Replies

Upon Success:

OKAY<CRC16><CR>

On Error:

ERROR<[Error Code](#)><CRC16><CR>

See [page 91](#) for error code definitions.

Example

Command:

TSTOP

Reply:

OKAYA896

TTCFG

Sets up a configuration for a tool, so that you can test the tool without using a tool definition file.

Operating Mode

Setup

Prerequisite Command

[PHSR \(page 50\)](#)

Syntax

```
TTCFG<SPACE><Port Handle><CR>
```

Parameter	Description
Port Handle	2 hexadecimal characters Valid Values: 0A to FF

Replies

Upon Success:

```
OKAY<CRC16><CR>
```

On Error:

```
ERROR<Error Code><CRC16><CR>
```

See [page 91](#) for error code definitions.

Usage Notes

1. TTCFG internally sets up a test configuration for a tool, so that it can be tested without having a tool definition file. This is useful for testing the wiring in the tool before characterizing the tool.
2. After sending the TTCFG command, you will need to initialize ([PINIT](#)) and enable ([PENA](#)) the port handle before using any other commands that list these as prerequisites.
3. TTCFG configures the tool as dual, 5DOF. After initializing the port handle, a second port handle will be automatically generated. This second port handle will be already initialized but not enabled.
4. If the tool needs to be re-initialized with the test configuration, the TTCFG sequence must be run again before PINIT is used.

Example

Command:

TTCFG 0A

Reply:

OKAYA896

TX

Returns the latest tool transformations and system status information in text format.

Operating Mode

Tracking

Syntax

TX<SPACE><Reply Option><CR>

Parameter	Description				
Reply Option	<p>Optional. Specifies which information will be returned. If no reply option is specified, the system returns information for reply option 0001.</p> <p>The reply options are hexadecimal numbers that can be OR'd. Reply option 0800 is not reported separately from reply option 0001.</p> <p>Valid Values:</p> <table><tr><td>0001</td><td>Transformation data (default)</td></tr><tr><td>0800</td><td>Out-of-volume transformations</td></tr></table>	0001	Transformation data (default)	0800	Out-of-volume transformations
0001	Transformation data (default)				
0800	Out-of-volume transformations				

Replies

Upon Success:

```
<Number of Handles><Handle 1><Reply Option 0001 Data><LF>
...
<Handle n><Reply Option 0001 Data><LF>
<System Status><CRC16><CR>
```

Note If the port handle is disabled, the system returns the string DISABLED instead of <Reply Option 0001 Data>.

On Error:

ERROR<Error Code><CRC16><CR>

See [page 91](#) for error code definitions.

Reply Component	Description
Number of Handles	<p>2 hexadecimal characters</p> <p>The number of port handles for which transformations are returned.</p>
Handle n	<p>2 hexadecimal characters</p> <p>The port handle whose transformation follows.</p>

Reply Component	Description
Reply Option Data	The data specific to the requested reply option. See the reply option information below for details:
	Reply option 0001 (transformation data) (default)
	Reply option 0800 (reporting all transformations)
System Status	4 hexadecimal characters (16 bits)
	The status of the system.
	Bit field:
	bits 0 to 4 Reserved
	bit 5 Hardware change. This bit is set if the Field Generator is disconnected from the System Control Unit.
	bit 6 Some port handle has become occupied
	bit 7 Some port handle has become unoccupied
	bit 8 Diagnostic pending. This bit is set whenever an alert is detected or cleared. To view the alerts status and clear the diagnostic pending bit, use GET (page 35) to check the Info.Status.New Alerts user parameter for every hardware device in the system. See “Usage Notes” on page 86 for more details.
	bit 9 Reserved
	bit 10 Configuration change. This bit is set when an SIU is added or removed. Currently this bit is only related to the SIU, but other components may be added in the future. This bit is cleared by the commands PHSR (page 50) and INIT (page 38) .
	bits 11 to 15 Reserved

Reply Option 0001 - Transformation Data

<Reply Option 0001 Data> = <Q₀><Q_x><Q_y><Q_z><T_x><T_y><T_z><Indicator Value>
 <Port Handle Status><Frame Number>

or

<Reply Option 0001 Data> = MISSING<Port Handle Status><Frame Number>

Reply Component	Description
Q ₀ , Q _x , Q _y , Q _z	6 characters each (a sign, and 5 decimal digits with an implied decimal in the position X . XXXX) Rotational component of the transformation, quaternion, unitless.
T _x , T _y , T _z	7 characters each (a sign, and 6 decimal digits with an implied decimal in the position XXXX . XX) Translational components of the transformation, in mm.

Reply Component	Description		
Indicator Value	<p>6 characters (a sign, and 5 decimal digits with an implied decimal in the position X . XXXX)</p> <p>An estimate of how well the Aurora System calculated the transformation. Values range from 0 to 9.9. A higher value indicates a higher error.</p> <p>For 6DOF tools, the indicator value compares sensor measurements to the tool’s design (as described by its SROM device or tool definition file).</p> <p>For 5DOF tools, the indicator value is always zero.</p>		
Port Handle Status	8 hexadecimal characters (32 bits)		
	Bit field:		
	bit 0	Occupied	Bits 0 to 3 are shared for dual, 5DOF tools.
	bit 1	GPIO line 1 closed	
	bit 2	GPIO line 2 closed	
	bit 3	GPIO line 3 closed	
	bit 4	Initialized	
	bit 5	Enabled	
	bit 6	Out of volume	
	bit 7	Partially out of volume. This bit is set only for 6DOF tools, when one sensor is inside the measurement volume and the other sensor is outside the measurement volume.	
	bit 8	A sensor is broken. This bit is set when a sensor lead wire breaks, either along the lead wire length or at its connection points.	
	bit 9	Reserved	
	bit 10	Shorted sensor detected	
	bit 11	Signal too large. Occurs when sensor is too close to Field Generator.	
bit 12	Processing exception		
bits 13 to 31	Reserved		
Frame Number	<p>8 hexadecimal characters</p> <p>The frame number is an internal counter related to data acquisition. The counter starts at power up and does not reset until the system is reset, the system is powered up again, or reply option 80 is sent with the TSTART command. The frame number corresponds to the frame in which the raw data, used to calculate the accompanying transformation, was collected. The frame number is incremented by 8.</p>		

Note If a transformation cannot be determined, the system returns the string **MISSING**, followed by the port handle status and frame number.

Reply Option 0800 - Reporting All Transformations

This option enables the reporting of transformations or translations when the tool is out of volume. This reply option must be OR'd with [reply option 0001](#).



When using reply option 0800 with the TX command, you must take appropriate action to detect when a tool is out of volume, and determine whether this situation is detrimental to your application. If a tool is out of volume, reply option 0800 enables the system to return data that may lead to inaccurate conclusions and may cause personal injury.

Usage Notes


- 1. The TX format is easier to parse than the binary format; it is useful when troubleshooting, or observing data as it is collected. For replies in binary format, use [BX \(page 24\)](#).
- 2. See the user guide for detailed descriptions of the port handle status and system status bits.
- 3. By default, transformations will not be reported if the tool is either partially or wholly out of the characterized measurement volume. To report these transformations, you must use [reply option 0800](#) OR'd with [reply option 0001](#). The accuracy of these transformations is unknown.
- 4. When the “diagnostic pending” bit is set in the [system status](#), use [GET \(page 35\)](#) to read the [Info.Status.New Alerts](#) user parameter for every hardware device in the system. The act of reading these parameters clears the parameters and the “diagnostic pending” bit. For more information on alerts and their associated user parameters, see “[Alerts User Parameters](#)” on [page 14](#).
- 5. Bit 8 in the <Port Handle Status> section of [reply option 0001](#) may not always indicate when a lead wire is broken. Broken sensors that result in a short will not be detected.

Example

Command:

TX

Reply:



The system returned transformation data for one tool.

VER

Returns the firmware revision number of critical processors installed in the system.

Operating Mode

Setup

Syntax

VER<SPACE><Reply Option><CR>

Parameter	Description
Reply Option	Specifies which information will be returned.
	The reply options cannot be OR'd.
	Valid Values:
	0 System Control Processor
	4 System Control Processor, with enhanced revision numbering. The revision numbering is XXX.YYY, where XXX = major revision and YYY = minor revision. The major revision number is always the same as the revision number for reply option 0 .
	5 Combined firmware revision number. The revision numbering format is XXX. Only the number is reported; there is no information about the type of system.
	7 Field Generator information

Replies

Upon Success:

<Reply Option Data><CRC16><CR>

On Error:

ERROR<[Error Code](#)><CRC16><CR>

See [page 91](#) for error code definitions.

Reply Option 0 - System Control Processor

```
<Reply Option 0 Data> =
<Type of Firmware><LF>
<NDI Serial Number><LF>
<Characterization Date><LF>
<Freeze Tag><LF>
<Freeze Date><LF>
<Copyright Information><LF>
```

Reply Option 4 - System Control Processor with Enhanced Revision Numbering

```
<Reply Option 4 Data> =
<Type of Firmware><LF>
```

```
<NDI Serial Number><LF>
<Characterization Date><LF>
<Freeze Tag><LF>
<Freeze Date><LF>
<Copyright Information><LF>
```

Reply Option 5 - Combined Firmware Revision Number

```
<Reply Option 5 Data> = <Combined Firmware Revision>
```

Reply Option 7 - Field Generator Information

```
<Reply Option 7 Data> =
<Field Generator Serial Number><LF>
<Field Generator Model><LF>
<Characterization Date><LF>
```

Reply Option 8 - Sensor Interface Unit Information

This reply option is deprecated. To read the firmware version of the SIU, use [GET \(page 35\)](#) to read the value of the Features.Firmware.Version user parameter. See “[User Parameters](#)” on [page 12](#) for details.

Usage Note

If you send the command VER 5 after the INIT command has replied with ERROR2E, the reply will be “??”, because component versions are incompatible.

Examples

Command:

```
VER 5
```

Reply:

```
0061994
```


VSEL

Selects a characterized measurement volume.

Operating Mode

[Setup](#)

Prerequisite Command

[INIT \(page 38\)](#)

Syntax

VSEL<SPACE><Volume Number><CR>

Parameter	Description
Volume Number	1 hexadecimal character Valid Values: 1 to the maximum returned by SFLIST (page 73)

Replies

Upon Success:

OKAY<CRC16><CR>

On Error:

ERROR<[Error Code](#)><CRC16><CR>

See [page 91](#) for error code definitions.

Usage Notes

Use [SFLIST \(page 73\)](#) to determine which measurement volumes are available.

Example

Command:

VSEL 1

Reply:

OKAYA896

VSIU

Registers or unregisters a VSIU with the Aurora system.

Operating Mode

Setup

Prerequisite Command

[INIT \(page 38\)](#)

Syntax

VSIU<SPACE><Parameter><CR>

Parameter	Description
1	Registers a new VSIU with the Aurora. The reply is the VSIU instance number (X). This instance number is equivalent to the instance number used for the 'SIU-X' user parameters. 'ERROR2A' is returned if the maximum number of VSIUs is exceeded. Currently Aurora systems support up to 4 VSIUs.
0X	Unregister VSIU instance X from the Aurora. On success 'OKAY' is returned. Trying to unregister an unknown instance will return 'ERROR42'.

Replies

Upon Success:

<SIU Instance X><CRC16><CR>

or

OKAY<CRC16><CR>

On Error:

ERROR<Error Code><CRC16><CR>

See [page 91](#) for error code definitions.

Usage Notes

1. Once the VSIU has been successfully registered, the client software must to query the device using `GET Device.*` until 'SIU-X' appears in the list of devices. Once it appears, the device can be checked directly to ensure initialization was successful.
2. The SCU starts the initialization 250 ms after the successful VSIU command. This gives the client application enough time to configure the packet routing.
3. Any problems during the initialization process will be shown in the SIU-X alert information. See [“Alerts User Parameters” on page 14](#) for more information.
4. Upon INIT, RESET or a serial break, all configured VSIUs are automatically unregistered from the Aurora system.

6 Error Code Definitions

If the system receives an invalid command, it responds to the host with the message `ERROR<Error Code><CRC>`. [Table 6-1](#) identifies the error codes and their definitions.

Table 6-1 Error Code Definitions

Error Code	Definition
01	Invalid command.
02	Command too long.
03	Command too short.
04	Invalid CRC calculated for command; calculated CRC does not match the one sent.
05	Time-out on command execution.
06	Unable to set up new communication parameters. This occurs if one of the communication parameters is out of range.
07	Incorrect number of parameters.
08	Invalid port handle selected.
09	Invalid mode selected. Either the tool tracking priority is out of range, or the tool has sensors defined and 'button box' was selected.
0A	Invalid LED selected. The LED selected is out of range.
0B	Invalid LED state selected. The LED state selected is out of range.
0C	Command is invalid while in the current operating mode .
0D	No tool is assigned to the selected port handle.
0E	Selected port handle not initialized. The port handle needs to be initialized before the command is sent.
0F	Selected port handle not enabled. The port handle needs to be enabled before the command is sent.
10	System not initialized. The system must be initialized before the command is sent.
11	Unable to stop tracking. This occurs if there are hardware problems. Please contact NDI.
12	Unable to start tracking. This occurs if there are hardware problems. Please contact NDI.
13	Unable to initialize the port handle.
14	Invalid Field Generator characterization parameters or incompatible hardware.
15	Unable to initialize the system. This occurs if: <ul style="list-style-type: none"> the system could not return to Setup mode there are internal hardware problems. Please contact NDI.
16 to 18	Reserved.

Table 6-1 Error Code Definitions (Continued)

Error Code	Definition
19	Unable to read device's firmware revision information. This occurs if: <ul style="list-style-type: none"> the processor selected is out of range the system is unable to inquire firmware revision information from a processor
1A	Internal system error. This occurs when the system is unable to recover after a system processing exception.
1B to 1C	Reserved.
1D	Unable to search for SROM device IDs.
1E	Unable to read SROM device data. This occurs if the system is: <ul style="list-style-type: none"> unable to auto-select the first SROM device on the given port handle as a target to read from unable to read a page of SROM device data successfully
1F	Unable to write SROM device data. This can occur if: <ul style="list-style-type: none"> the SROM device starting address is out of range the system is unable to auto-select the first SROM device on the given port handle as a target for writing to an SROM device on the given port handle has not previously been selected with the PSEL command as a target to write to the system is unable to write a page of SROM device data successfully
20	Unable to select SROM device for given port handle and SROM device ID.
21 to 22	Reserved.
23	Command parameter is out of range.
24	Unable to select parameters by volume. This occurs if: <ul style="list-style-type: none"> the selected volume is not available there are internal hardware errors. Please contact NDI.
25 to 28	Reserved.
29	Main processor firmware is corrupt.
2A	No memory is available for dynamic allocation (heap is full).
2B	The requested port handle has not been allocated.
2C	The requested port handle has become unoccupied.
2D	All handles have been allocated.
2E to 30	Reserved.
31	Invalid input or output state.
32	Reserved.
33	Feature not available.
34	User parameter does not exist.
35	Invalid value type (e.g. string instead of integer).
36	User parameter value set is out of valid range.

Table 6-1 Error Code Definitions (Continued)

Error Code	Definition
37	User parameter array index is out of valid range.
38	User parameter size is incorrect.
39	Permission denied; file or user parameter is read-only.
3A	Reply buffer too small.
3B to 41	Reserved.
42	Device not present. This occurs when the command is specific to a device that is not connected to the system.
43 to C4	Reserved.
C5	The data bits parameter (set using COMM (page 29)) must be set to 8 bits in order to use the BX command.
C6 to F3	Reserved
F4	Unable to erase Flash SROM device.
F5	Unable to write Flash SROM device.
F6	Unable to read Flash SROM device.
F7 to FF	Reserved.

Appendix A For Polaris Users

The Aurora System shares a large part of its API with the NDI Polaris System. If you have written an application for use with the Polaris System, you can adapt it to function with the Aurora System. The following sections list the differences between the Aurora API and various versions of the Polaris API.

Read the section that corresponds to the type of Polaris System and version of Polaris firmware for which your application is designed:

- [“Differences Between the Aurora System and the Polaris System \(Rev 18\)” on page 95](#)
Read this section if your application is written for use with a Polaris System with combined firmware revision 018.
- [“Differences Between the Aurora System and the Polaris System \(Rev 24\)” on page 98](#)
Read this section if your application is written for use with a Polaris System with combined firmware revision 022 to 024.
- [“Differences Between the Aurora System and the Polaris Vicra or Polaris Spectra System” on page 101](#)
Read this section if your application is written for use with a Polaris Vicra System or a Polaris Spectra System.

To determine the combined firmware revision of your Polaris System, use the command VER 5. If your application is written for a Polaris System that uses a combined firmware revision other than Rev 22-24 or Rev 18, contact [NDI technical support](#) for more information.

A.1 Differences Between the Aurora System and the Polaris System (Rev 18)

Read this section if your application is written for use with a Polaris System with combined firmware revision 018.

Deprecated Commands

- GX, replaced by [BX \(page 24\)](#) and [TX \(page 83\)](#)
- PSTAT, replaced by [PHSR \(page 50\)](#) and [PHINF \(page 44\)](#)
- PVCLR, replaced by [PHF \(page 43\)](#)
- PVTIP, no replacement for the Aurora System

New Commands

- [APIREV \(page 22\)](#) returns the API revision number.
- [DFLT \(page 31\)](#) restores the user parameters to factory default values.
- [ECHO \(page 34\)](#) returns exactly what is sent with the command.
- [GET \(page 35\)](#) returns the user parameter values.
- [GETINFO \(page 36\)](#) returns descriptive information about the user parameters.
- [RESET \(page 69\)](#) resets the system (can specify either a hard reset or a soft reset).
- [SAVE \(page 71\)](#) saves all non-volatile user parameters that have been changed.
- [SET \(page 72\)](#) sets user parameter values.

Changed Command

- [PHINF \(page 44\)](#): in reply option 0001, the size of the <tool type> field increases from 7 to 8 characters.

Polaris-Only Commands

These commands function only with the Polaris System. Sending these commands to the Aurora System will generate an error:

3D	IRINIT
IRATE	PFSEL
IRCHK	PHRQ
IREDD	TCTST

Aurora-Only Command

[PSOUT \(page 60\)](#) functions only with the Aurora System.

Commands with Differences Between Polaris and Aurora

These commands function differently with the Aurora System than with the Polaris System:

PHINF (page 44)

- **Polaris-only option:** As of Aurora combined firmware revision 013, reply option 0020 is deprecated for the Aurora system (use reply option 0080 instead)
- **Aurora-only option:** The following reply option is valid only with the Aurora System: reply option 0080 (Sensor configuration and physical port location)

SFLIST (page 73)

- **Polaris-only options:** The following reply options are valid only for the Polaris System:
reply option 01 (number of wired tool ports)
reply option 02 (number of wireless tool ports)
reply option 04 (number of wired tool ports available which support tool-in-port detection from current sensing)
- **Aurora-only options:** The following reply option is valid only with the Aurora System: reply option 10 (number of ports)

SSTAT

- This command will work with the Aurora System, but won't return any useful data. This command will return the following data:

SSTAT 0001 returns 00
SSTAT 0002 returns 00
SSTAT 0004 returns 00
SSTAT 0100 returns 00000000
SSTAT 0200 returns 00000000

VER (page 87)

- **Polaris-only options:** The following reply options are valid only with the Polaris System:
reply option 1 (left sensor processor)
reply option 2 (right sensor processor)
reply option 3 (Tool Interface Unit processor)
reply option 6 (Tool Docking Station)
- **Aurora-only options:** The following reply option is valid only with the Aurora System: reply option 7 (Field Generator information)

Differences in Concepts

Port handles: Previous versions of the Polaris API distinguished between wired tool ports (corresponding to wired tools that were physically connected to the system) and wireless tool ports (corresponding to passive tools and active wireless tools). Wired tool ports were assigned a port number, and wireless tool ports were assigned a port letter.

The API no longer supports the concept of tool ports, and instead assigns each tool a port handle. Port handles are independent of the physical port numbering. Port handles provide greater flexibility than port numbers and replace port numbers and port letters in most commands. Port handles range from 0x0A to 0xFF with the Aurora System. (With the Polaris System, port handles range from 0x01 to 0xFF.)

For a split port on a dual 5DOF tool, the first [PHSR \(page 50\)](#) sent will report only one port handle. After the port handle is initialized, it is assigned to channel 0. You must then use PHSR again to assign a port handle to channel 1, and then initialize the port handle using [INIT \(page 38\)](#). See [“Flow Chart for Port Handle Usage” on page 8](#).

GPIO: General purpose input/outputs can be used as either an input or an output with the Aurora System. With the Polaris System, GPIOs can only be used as inputs.

API revisions: The API now has a revision number. If you upgrade the firmware, you can check the API revision to determine whether your application software may need to be updated. In the event of a firmware change that does not affect the API, the API revision number will remain the same, and any application software written using that API revision will continue to function with the new firmware revision. To determine the API revision programmed into your system, use the command [APIREV \(page 22\)](#).

A.2 Differences Between the Aurora System and the Polaris System (Rev 24)

Read this section if your application is written for use with a Polaris System with combined firmware revision 022 to 024.

New Commands

- [APIREV \(page 22\)](#) returns the API revision number.
- [DFLT \(page 31\)](#) restores the user parameters to factory default values.
- [ECHO \(page 34\)](#) returns exactly what is sent with the command.
- [GET \(page 35\)](#) returns the user parameter values.
- [GETINFO \(page 36\)](#) returns descriptive information about the user parameters.
- [RESET \(page 69\)](#) resets the system (can specify either a hard reset or a soft reset).
- [SAVE \(page 71\)](#) saves all non-volatile user parameters that have been changed.
- [SET \(page 72\)](#) sets user parameter values.

Polaris-Only Commands

These commands function only with the Polaris System. Sending these commands to the Aurora System will generate an error:

3D	IRINIT
GETIO	PFSEL
IRATE	PHRQ
IRCHK	SETIO
IREDD	TCTST

Aurora-Only Command

[PSOUT \(page 60\)](#) functions only with the Aurora System.

Commands with Differences Between Polaris and Aurora

These commands function differently with the Aurora System than with the Polaris System:

[BX \(page 24\)](#) and [TX \(page 83\)](#)

- **Polaris-only options:** The following reply options are valid only with the Polaris System:
 - reply option 0002 (tool and marker information)
 - reply option 0004 (3D position of a single stray active marker)
 - reply option 1000 (3D positions of stray passive markers)
- **Polaris-only bit:** The following bit is valid only with the Polaris System:
 - <system status> bit 1 (too much external IR)

- **Aurora-only bits:** The following bits are valid only with the Aurora System:
<system status> bit 5 (hardware change)
<port handle status> bit 8 (broken sensor)

PHINF (page 44)

- **Polaris-only options:** The following reply options are valid only with the Polaris System:
reply option 0002 (wired tool electrical information)
reply option 0010 (tool marker type and wavelength)
reply option 0020 (physical port location) - as of Aurora combined firmware revision 013, this option is deprecated for Aurora system (use reply option 0080 instead)
- **Aurora-only option:** The following reply option is valid only with the Aurora System:
reply option 0040 (GPIO status)
reply option 0080 (Sensor configuration and physical port location)

PHSR (page 50)

- **Polaris-only bit:** The following bit is valid only with the Polaris System:
<port handle status> bit 7 (tool detected from current sensing)

SFLIST (page 73)

- **Polaris-only options:** The following reply options are valid only for the Polaris System:
reply option 01 (number of wired tool ports)
reply option 02 (number of wireless tool ports)
reply option 04 (number of wired tool ports available which support tool-in-port detection from current sensing)
- **Aurora-only options:** The following reply option is valid only with the Aurora System:
reply option 10 (number of ports)

SSTAT

- This command will work with the Aurora System, but won't return any useful data. This command will return the following data:

SSTAT 0001 returns 00
SSTAT 0002 returns 00
SSTAT 0004 returns 00
SSTAT 0100 returns 00000000
SSTAT 0200 returns 00000000

VER (page 87)

- **Polaris-only options:** The following reply options are valid only with the Polaris System:
reply option 1 (left sensor processor)
reply option 2 (right sensor processor)
reply option 3 (Tool Interface Unit processor)
reply option 6 (Tool Docking Station)

- **Aurora-only options:** The following reply option is valid only with the Aurora System: reply option 7 (Field Generator information)

Differences in Concepts

Port handles: Port handles range from 0x0A to 0xFF with the Aurora System. With the Polaris System, port handles range from 0x01 to 0xFF.

For a split port on a dual 5DOF tool, the first [PHSR \(page 50\)](#) sent will report only one port handle. After the port handle is initialized using PINIT, it is assigned to channel 0. You must then use PHSR again to assign a port handle to channel 1. The port handle for channel 1 is initialized automatically. See [“Flow Chart for Port Handle Usage” on page 8](#)

GPIO: General purpose input/outputs can be used as either an input or an output with the Aurora System. With the Polaris System, GPIOs can only be used as inputs.

API revisions: The API now has a revision number. If you upgrade the firmware, you can check the API revision to determine whether your application software may need to be updated. In the event of a firmware change that does not affect the API, the API revision number will remain the same, and any application software written using that API revision will continue to function with the new firmware revision. To determine the API revision programmed into your system, use the command [APIREV \(page 22\)](#).

A.3 Differences Between the Aurora System and the Polaris Vicra or Polaris Spectra System

Read this section if your application is written for use with a Polaris Vicra System or a Polaris Spectra System.

Polaris-Only Commands

These commands function only with the Polaris Vicra and Polaris Spectra Systems. Sending these commands to the Aurora System will generate an error:

3D	PFSEL
GETIO	PHRQ
GETLOG	SETIO
IRATE	SYSLOG
IRCHK	TCTST
IREDD	VGET
IRINIT	VSNAP

Commands with Differences Between Polaris and Aurora

These commands function differently with the Aurora System than with the Polaris Vicra and Spectra Systems:

[BX \(page 24\)](#) and [TX \(page 83\)](#)

- Polaris-only options:** The following reply options are valid only with the Polaris Vicra and Spectra Systems:
 - reply option 0002 (tool and marker information)
 - reply option 0004 (3D position of a single stray active marker)
 - reply option 0008 (3D positions of markers on tools)
 - reply option 1000 (3D positions of stray passive markers)
- Polaris-only bits:** The following bits are valid only with the Polaris Vicra and Spectra Systems:
 - <system status> bit 8 (diagnostic pending)
 - <system status> bit 9 (temperature)
 - <port handle status> bit 8 (algorithm limitation)
 - <port handle status> bit 9 (IR interference)
 - <port handle status> bit 12 (processing exception)
 - <port handle status> bit 14 (fell behind while processing)
 - <port handle status> bit 15 (data buffer limitation)
- Aurora-only bits:** The following bits are valid only with the Aurora System:
 - <system status> bit 5 (hardware change)
 - <port handle status> bit 8 (broken sensor)

PHINF (page 44)

- **Polaris-only options:** The following reply options are valid only with the Polaris System:
reply option 0002 (wired tool electrical information)
reply option 0010 (tool marker type and wavelength)
reply option 0020 (physical port location) - as of Aurora combined firmware revision 013, this option is deprecated for Aurora system (use reply option 0080 instead)
- **Aurora-only option:** The following reply option is valid only with the Aurora System:
reply option 0040 (GPIO status)
reply option 0080 (Sensor configuration and physical port location)

PHSR (page 50)

- **Polaris-only bit:** The following bit is valid only with the Polaris System:
<port handle status> bit 7 (tool detected from current sensing)

PSOUT (page 60)

- **Aurora-only option:** The GPIO line state “P” (pulse) is only with the Aurora System.

SFLIST (page 73)

- **Polaris-only options:** The following reply options are valid only for the Polaris System:
reply option 01 (number of wired tool ports)
reply option 02 (number of wireless tool ports)
reply option 04 (number of wired tool ports available which support tool-in-port detection from current sensing)
- **Aurora-only options:** The following reply option is valid only with the Aurora System:
reply option 10 (number of ports)

SSTAT

- This command will work with the Aurora System, but won't return any useful data. This command will return the following data:

SSTAT 0001 returns 00
SSTAT 0002 returns 00
SSTAT 0004 returns 00
SSTAT 0100 returns 00000000
SSTAT 0200 returns 00000000

VER (page 87)

- **Polaris-only options:** The following reply options are valid only with the Polaris System:
reply option 1 (left sensor processor)
reply option 2 (right sensor processor)
reply option 3 (Tool Interface Unit processor)
reply option 6 (Tool Docking Station)

- **Aurora-only options:** The following reply option is valid only with the Aurora System: reply option 7 (Field Generator information)

Differences in Concepts

Port handles Port handles range from 0x0A to 0xFF with the Aurora System. With the Polaris System, port handles range from 0x01 to 0xFF.

For a split port on a dual 5DOF tool, the first [PHSR \(page 50\)](#) sent will report only one port handle. After the port handle is initialized using PINIT, it is assigned to channel 0. You must then use PHSR again to assign a port handle to channel 1. The port handle for channel 1 is initialized automatically. See [“Flow Chart for Port Handle Usage” on page 8](#)

GPIO General purpose input/outputs can be used as either an input or an output with the Aurora System. With the Polaris System, GPIOs can only be used as inputs.

Appendix B Sample C Routines

The following sample C routines are included for reference:

Table 6-2 Sample C Routines

Routine	Description
CalcCRC16	Calculates a running CRC16 using the polynomial $X^{16} + X^{15} + X^2 + 1$.
EulerAngleTrig	Determines the sine and cosine of the Euler angles.
DetermineR	Calculates the 3x3 rotation matrix which corresponds to the given Euler angles.
CvtQuatToRotationMatrix	Determines the rotation matrix that corresponds to the given quaternion values.
DetermineEuler	Calculates the Euler angles given the 3x3 rotation matrix.
CvtQuatToEulerRotation	Determines the rotation in Euler angles (degrees) that corresponds to the given quaternion rotation.

The following defines are used by the sample C routines:

```

/*
 * Conversion factors.
 */
#define RAD_TO_DEGREES      (180 / 3.1415926)

/*
 * Defined data types.
 */
typedef float
    RotationMatrix[3][3];

typedef struct Rotation
{
    float
        fRoll, /* rotation about the object's z-axis (Euler angle) */
        fPitch, /* rotation about the object's y-axis (Euler angle) */
        fYaw; /* rotation about the object's x-axis (Euler angle) */
} Rotation;

typedef struct QuatRotation
{
    float
        fQ0,
        fQX,
        fQY,
        fQZ;
} QuatRotation;

```


B.1 CalcCRC16

The following is a sample C routine, for calculating a running 16 bit CRC, as used in communications between the host computer and the Aurora System.

```

/*****
Name:          CalcCRC16

Input Values:
    int
        data :Data value to add to running CRC16.
    unsigned int
        *puCRC16 :Ptr. to running CRC16.

Output Values:
    None.

Returned Value:
    None.

Description:
    This routine calculates a running CRC16 using the polynomial
    X^16 + X^15 + X^2 + 1.

*****/
void CalcCRC16( int data, unsigned int *puCRC16 )
{
    static int
        oddparity[16] = { 0, 1, 1, 0, 1, 0, 0, 1, 1, 0, 0, 1, 0, 1, 1, 0 };

    data = (data ^ (*puCRC16 & 0xff)) & 0xff;
    *puCRC16 >>= 8;

    if ( oddparity[data & 0x0f] ^ oddparity[data >> 4] )
    {
        *puCRC16 ^=0xc001
        /* if */
    }
    data <<= 6;
    *puCRC16 ^= data;
    data <<= 1;
    *puCRC16 ^= data;

} /* CalcCRC16 */

```

B.2 EulerAngleTrig

```

/*****
Name:          EulerAngleTrig

Input Values:
    Rotation
        *pdtRotationAngle :Ptr to struct containing the roll, pitch, yaw
        Euler angles which define the required rotation.

```

Output Values:

Rotation

*pdtSinAngle :Ptr to struct containing the sine of the roll, pitch,
yaw Euler angles.
*pdtCosAngle :Ptr to struct containing the cosine of the roll, pitch,
yaw Euler angles.

Returned Value:

None.

Description:

This routine determines the sine and cosine of the Euler angles.

```

*****/
static void EulerAngleTrig( Rotation *pdtRotationAngle,
                          Rotation *pdtSinAngle,
                          Rotation *pdtCosAngle )
{
    pdtSinAngle->fRoll= sin( pdtRotationAngle->fRoll );
    pdtSinAngle->fPitch= sin( pdtRotationAngle->fPitch );
    pdtSinAngle->fYaw = sin( pdtRotationAngle->fYaw );
    pdtCosAngle->fRoll= cos( pdtRotationAngle->fRoll );
    pdtCosAngle->fPitch= cos( pdtRotationAngle->fPitch );
    pdtCosAngle->fYaw= cos( pdtRotationAngle->fYaw );

} /* EulerAngleTrig */

```

B.3 DetermineR

```

/*****
Name:      DetermineR

```

Input Values:

Rotation

*pdtRotationAngle :Ptr to struct containing the roll, pitch, yaw
Euler angles which define the required rotation.

Output Values:

RotationMatrix

dtRotationMatrix :The 3x3 rotation matrix to be determined.

Returned Value:

None.

Description:

This routine calculates the 3x3 rotation matrix which corresponds to the
given Euler angles.

```

*****/
void DetermineR( Rotation *pdtRotationAngle, RotationMatrix
               dtRotationMatrix )
{
    Rotation
    dtSinAngle, /* the sine of the roll, pitch, and yaw angles */
    dtCosAngle; /* the cosine of the roll, pitch, and yaw angles */

```

```

/*
 * Might as well determine the sine and cosine of the given Euler angles right from
 the start
 */
EulerAngleTrig( pdtRotationAngle, &dtSinAngle, &dtCosAngle );

/*
 * Fill in the rotation matrix.
 */
dtRotationMatrix[0][0] = dtCosAngle.fRoll * dtCosAngle.fPitch;
dtRotationMatrix[0][1] = dtCosAngle.fRoll * dtSinAngle.fPitch *
    dtSinAngle.fYaw - dtSinAngle.fRoll * dtCosAngle.fYaw;
dtRotationMatrix[0][2] = dtCosAngle.fRoll * dtSinAngle.fPitch *
    dtCosAngle.fYaw + dtSinAngle.fRoll * dtSinAngle.fYaw;
dtRotationMatrix[1][0] = dtSinAngle.fRoll * dtCosAngle.fPitch;
dtRotationMatrix[1][1] = dtSinAngle.fRoll * dtSinAngle.fPitch *
    dtSinAngle.fYaw + dtCosAngle.fRoll * dtCosAngle.fYaw;
dtRotationMatrix[1][2] = dtSinAngle.fRoll * dtSinAngle.fPitch *
    dtCosAngle.fYaw - dtCosAngle.fRoll * dtSinAngle.fYaw;
dtRotationMatrix[2][0] = - dtSinAngle.fPitch;
dtRotationMatrix[2][1] = dtCosAngle.fPitch * dtSinAngle.fYaw;
dtRotationMatrix[2][2] = dtCosAngle.fPitch * dtCosAngle.fYaw;

} /* DetermineR */

```

B.4 CvtQuatToRotationMatrix

```

/*****
Name:          CvtQuatToRotationMatrix

```

Input Values:

QuatRotation

*pdtQuatRot :Ptr to the quaternion rotation.

Output Values:

RotationMatrix

dtRotationMatrix :The 3x3 determined rotation matrix.

Returned Value:

None.

Description:

This routine determines the rotation matrix that corresponds to the given quaternion.

Let the quaternion be represented by:

$$Q = \begin{bmatrix} Q_0 \\ Q_x \\ Q_y \\ Q_z \end{bmatrix}$$

and the rotation matrix by:

```

    | M00 M01 M02 |
M = | M10 M11 M12 |
    | M20 M21 M22 |

```

then assuming the quaternion, Q, has been normalized to convert Q to M we use the following equations:

```

M00 = (Q0 * Q0) + (Qx * Qx) - (Qy * Qy) - (Qz * Qz)
M01 = 2 * ((Qx * Qy) - (Q0 * Qz))
M02 = 2 * ((Qx * Qz) + (Q0 * Qy))
M10 = 2 * ((Qx * Qy) + (Q0 * Qz))
M11 = (Q0 * Q0) - (Qx * Qx) + (Qy * Qy) - (Qz * Qz)
M12 = 2 * ((Qy * Qz) - (Q0 * Qx))
M20 = 2 * ((Qx * Qz) - (Q0 * Qy))
M21 = 2 * ((Qy * Qz) + (Q0 * Qx))
M22 = (Q0 * Q0) - (Qx * Qx) - (Qy * Qy) + (Qz * Qz)

```

```

*****/
void CvtQuatToRotationMatrix( QuatRotation *pdtQuatRot,
                             RotationMatrix dtRotMatrix )
{
    float
        fQ0Q0,
        fQxQx,
        fQyQy,
        fQzQz,
        fQ0Qx,
        fQ0Qy,
        fQ0Qz,
        fQxQy,
        fQxQz,
        fQyQz;

    /*
     * Determine some calculations done more than once.
     */
    fQ0Q0 = pdtQuatRot->fQ0 * pdtQuatRot->fQ0;
    fQxQx = pdtQuatRot->fQX * pdtQuatRot->fQX;
    fQyQy = pdtQuatRot->fQY * pdtQuatRot->fQY;
    fQzQz = pdtQuatRot->fQZ * pdtQuatRot->fQZ;
    fQ0Qx = pdtQuatRot->fQ0 * pdtQuatRot->fQX;
    fQ0Qy = pdtQuatRot->fQ0 * pdtQuatRot->fQY;
    fQ0Qz = pdtQuatRot->fQ0 * pdtQuatRot->fQZ;
    fQxQy = pdtQuatRot->fQX * pdtQuatRot->fQY;
    fQxQz = pdtQuatRot->fQX * pdtQuatRot->fQZ;
    fQyQz = pdtQuatRot->fQY * pdtQuatRot->fQZ;

    /*
     * Determine the rotation matrix elements.
     */
    dtRotMatrix[0][0] = fQ0Q0 + fQxQx - fQyQy - fQzQz;
    dtRotMatrix[0][1] = 2.0 * (-fQ0Qz + fQxQy);
    dtRotMatrix[0][2] = 2.0 * (fQ0Qy + fQxQz);
    dtRotMatrix[1][0] = 2.0 * (fQ0Qz + fQxQy);
    dtRotMatrix[1][1] = fQ0Q0 - fQxQx + fQyQy - fQzQz;
    dtRotMatrix[1][2] = 2.0 * (-fQ0Qx + fQyQz);
    dtRotMatrix[2][0] = 2.0 * (-fQ0Qy + fQxQz);

```

```

        dtRotMatrix[2][1] = 2.0 * (fQ0Qx + fQyQz);
        dtRotMatrix[2][2] = fQ0Q0 - fQxQx - fQyQy + fQzQz;

    } /* CvtQuatToRotationMatrix */

```

B.5 DetermineEuler

```

/*****
Name:          DetermineEuler

Input Values:
    RotationMatrix
        dtRotationMatrix :The 3x3 rotation matrix to convert.

Output Values:
    Rotation
        *pdtEulerRot :Rotation is Euler angle format.
        Roll, pitch, yaw Euler angles which define the required rotation.

Returned Value:
    None.

Description:
    This routine calculates the Euler angles given the 3x3 rotation matrix.

*****/
void DetermineEuler( RotationMatrix dtRotMatrix, Rotation *pdtEulerRot )
{
    float
        fRoll,
        fCosRoll,
        fSinRoll;

    fRoll    = atan2( dtRotMatrix[1][0], dtRotMatrix[0][0] );
    fCosRoll = cos( fRoll );
    fSinRoll = sin( fRoll );

    pdtEulerRot->fRoll = fRoll;
    pdtEulerRot->fPitch = atan2( -dtRotMatrix[2][0],
        (fCosRoll * dtRotMatrix[0][0]) + (fSinRoll *
        dtRotMatrix[1][0]) );
    pdtEulerRot->fYaw = atan2(
        (fSinRoll * dtRotMatrix[0][2]) -
        (fCosRoll * dtRotMatrix[1][2]),
        (-fSinRoll * dtRotMatrix[0][1]) +
        (fCosRoll * dtRotMatrix[1][1]) );

} /* DetermineEuler */

```

B.6 CvtQuatToEulerRotation

```

/*****
Name:          CvtQuatToEulerRotation

```

Input Values:

QuatRotation

*pdtQuatRot :Ptr to the quaternion rotation.

Output Values:

Rotation

*pdtEulerRot :Ptr to the determined rotation Euler angles.

Returned Value:

None.

Description:

This routine determines the rotation in Euler angles (degrees) that corresponds to the given quaternion rotation.

```

*****/
void CvtQuatToEulerRotation( QuatRotation *pdtQuatRot, Rotation *pdtEulerRot )
{
    RotationMatrix
    dtRotMatrix;

    CvtQuatToRotationMatrix( pdtQuatRot, dtRotMatrix );

    DetermineEuler( dtRotMatrix, pdtEulerRot );

    pdtEulerRot->fYaw    *= RAD_TO_DEGREES;
    pdtEulerRot->fPitch  *= RAD_TO_DEGREES;
    pdtEulerRot->fRoll   *= RAD_TO_DEGREES;

} /* CvtQuatToEulerRotation */
```

Abbreviations and Acronyms

Abbreviation or Acronym	Definition
API	Application Program Interface
CRC	Cyclic Redundancy Check
FG	Field Generator
GPIO	General Purpose Input/Output
IEEE	Institute of Electrical and Electronic Engineers
ISIU	V3 Sensor Interface Unit
LED	Light Emitting Diode
PFG	Planar Field Generator
RMS	Root Mean Square
SCU	System Control Unit
SIU	Sensor Interface Unit
SRAM	Serial Read Only Memory
TTFG	Tabletop Field Generator
V1	<p>First generation Aurora System.</p> <p>FG: Aurora V1 Field Generators (V1 FG) have serial numbers starting with F4, e.g. F4-xxxxx or with FGb, e.g. FGb0-Sxxxxx.</p> <p>SCU: Aurora V1 System Control Units (V1 SCUs) have serial numbers starting with A3 or A4. e.g. A4-xxxxxx.</p> <p>SIU: Aurora V1 Sensor Interface Units (V1 SIU) have serial numbers starting with S4, e.g. S4-xxxxxx. Some older V1 SIUs have only a lot number.</p>
V2	<p>Second generation Aurora System.</p> <p>FG: Aurora V2 Field Generators (V2 FG) have serial numbers starting with FGc, FGd, or FGe e.g. FGc0-Sxxxxx.</p> <p>SCU: Aurora V2 System Control Units (V2 SCUs) have serial numbers starting with SCb or SCe, e.g. SCb2-Sxxxxx.</p> <p>SIU: Aurora V1 SIUs are used with the V2 system.</p>
V3	<p>Third generation Aurora System.</p> <p>FG: Aurora V2 FGs are used with the V3 system.</p> <p>SCU: Aurora V3 System Control Units (V3 SCU) have serial numbers starting with SCd, e.g. SCd0-Sxxxxx.</p> <p>SIU: Aurora V3 Sensor Interface Units (V3 SIU) have serial numbers starting with SIf or SIg, e.g. SIg0-Sxxxxx.</p>
WFG	Window Field Generator

Index

Numerics

5DOF tool, 47

A

alerts, 14, 17
 simulated, 19
 analog module fault for SIU, 16
 API revision, 22
 APIREV command, 22

B

baud rate, 29
 BEEP command, 23
 beeper, 18
 broken sensor, 26, 85
 button box, 42, 45
 BX command, 24

C

C routine defines, 104
 calibration device, 45
 catheter, 45
 channel number, 47
 characterization date, 17
 characterized measurement volume
 compatibility fault, 16
 number of, 74
 selection, 89
 shape parameters, 74
 shape type, 74
 supported, 74
 combined firmware revision number, 87
 COMM command, 29
 command
 alphabetical listing, 1
 format, 4
 receiving replies, 5
 reply format, 5
 sending, 4
 serial break, 20
 timeouts, 18
 used with user parameters, 12
 communication
 loss, 20

 overview, 3, 9
 parameters, 29
 communication fault
 Field Generator, 16
 SIU, 16
 configuration change, 25, 84
 configuration of a tool, 81
 contact information, iv
 controlling visible LEDs on tools, 39
 CRC, 5, 91
 calculating using a C routine, 105
 cyclic redundancy check *see* CRC

D

data bits, 29
 default user parameter values, 31
 defective coil fault, 16
 defines, 104
 device
 instance, 17
 type, 17
 DFTL command, 31
 diagnostic pending, 25, 84
 disabled port handle, 24, 83
 disabled transformations, 7
 disabling port handles, 41
 disclaimers, iii
 DSTART command, 32
 DSTOP command, 33
 dual, 5DOF tool, 47
 dynamic tracking, 42

E

ECHO command, 34
 email NDI, iv
 enabling port handles, 42
 enumeration list, 37
 error
 codes, 91
 processing exception, 26, 85
 Euler angles
 converting from quaternion, 109
 converting to rotation matrix, 106
 determining from rotation matrix, 109
 determining sine and cosine, 106

F

fault

- communication, 16
- defective coil, 16
- Field Generator driver, 15
- measurement volume compatibility, 16
- SCU processing periphery, 15
- SCU processing unit, 15
- SIU analog module, 16
- SIU communication, 16
- SIU hardware/firmware incompatibility, 16
- SIU processing unit, 16
- features of the system, 73
- Field Generator
 - communication fault, 16
 - defective coil fault, 16
 - driver fault, 15
 - information, 87
 - measurement volume incompatibility fault, 16
- firmware
 - current version, 17
 - versions, 87
- firmware/hardware incompatibility fault for SIU, 16
- foot switch, 45
- frame number, 27, 78, 85
- freeing port handles, 43

G

- general purpose input/output *see* GPIO
- GET command, 35
- GETINFO command, 36
- GPIO, 51
 - setting the status, 60
 - status, 26, 46, 47, 60, 85
 - supported, 46
 - using the LED command, 39

H

- handles *see* port handles
- hard reset, 20
- hardware
 - change, 25, 84
 - handshaking, 29
- hardware model, 17
- hardware/firmware incompatibility fault for SIU, 16

I

- indicator value, 26, 85
- INIT command, 38
- initializing
 - port handles, 53
 - the system, 38
- input status *see* GPIO

- invalid command, 91

L

LED

- command, 39
- visible, 39, 45, 46, 47, 91

M

- manufacturer's ID, 45
- manufacturing date, 17
- measurement volume *see* characterized measurement volume
- missing transformation, 27, 85
- mode
 - Setup, 3, 91
 - Tracking, 4, 91
- model of hardware, 17
- modes of operation, 3

N

- NDI, iv
- number of measurement volumes, 74

O

- operating modes, 3
- out of volume, 26, 27, 85
- output status *see* GPIO

P

- parameters
 - see* user parameters
- parity, 29
- part number of a tool, 46
- partially out of volume, 26, 27, 85
- PDIS command, 41
- PENA command, 42
- PHF command, 43
- PHSR command, 50
- PINIT command, 53
- Polaris, 94
- Polaris Spectra, 94
- Polaris Vicra, 94
- port handle
 - physical port location, 48
- port handles
 - about, 6
 - assigning, 50

- disabled, 83
- disabling, 41
- enabling, 42
- errors, 91
- freeing, 43
- information, 44
- initializing, 53
- physical port location, 44, 47
- reading the SROM device, 55
- searching for SROM device IDs, 62
- selecting an SROM device, 59
- split port, 51, 53
- status, 25, 26, 46, 50, 51, 84, 85
- unoccupied, 7
- usage, 7
- writing to a virtual tool definition file, 67
- writing to an SROM device, 57
- PPRD command, 55
- PPWR command, 57
- probe, 45
- processing exception, 26, 85
- processing periphery fault, 15
- processing unit fault - SCU, 15
- processing unit fault - SIU, 16
- PSEL command, 59
- PSOUT command, 60
- PSRCH command, 62
- PURD command, 63
- PUWR command, 65
- PVWR command, 67

Q

- quaternion, 26, 84
 - converting to Euler angles, 109
 - converting to rotation matrix, 107

R

- reading the SROM device, 55, 63
- receiving replies, 5
- reference tool, 45
- reply format, 5
- RĒSET command, 69
- resetting the system, 20, 69
- revision
 - API, 22
 - combined firmware, 87
 - system control processor, 87
 - tool, 45
- rotation matrix
 - converting from Euler, 106
 - converting from quaternion, 107
 - converting to Euler angles, 109

S

- SAVE command, 71
- saveable user parameters, 18
- SCU
 - Field Generator driver fault, 15
 - processing periphery fault, 15
 - processing unit fault, 15
 - processor or logic fault, 15
- SCU version, 17
- sending commands, 4
- Sensor Interface Unit, 87
- sensor, broken, 26, 85
- serial break, 20
- serial communication parameters, 29
- serial number
 - Position Sensor, 17
 - System Control Unit, 47
 - tool, 45
- SET command, 72
- Setup mode, 3, 91
- SFLIST command, 73
- shape
 - parameters, 74
 - type, 74
- simulated alerts, 19
- SIU
 - analog module fault, 16
 - communication fault, 16
 - hardware/firmware incompatibility fault, 16
 - processing unit fault, 16
- software-defined tool, 45
- sounding the system beeper, 23
- Spectra, 94
- split port, 51, 53
- SROM device
 - error, 92
 - ID, 59, 62
 - overriding, 53, 67
 - padding out, 58, 66
 - reading, 55, 63
 - selecting, 59
 - tool description, 55, 57
 - user section, 63, 65
 - writing to, 57, 65
- SROM Image file *see* tool definition file
- start tracking mode, 78
- static tracking, 42
- stop bits, 29
- stop tracking mode, 80
- strings, user-defined, 19
- Support Site, iv
- supported measurement volumes, 74
- switches, 45, 46
- synchronization error, 20
- syntax, 4
- system alerts, 14, 17
- system beeper, 18
- system control processor version, 87
- System Control Unit serial number, 47

system features, 73

T

test configuration, 81

timeout for commands, 18

tool

- definition file, 53, 67, 81, 91

- description, 55

- part number, 46

- revision, 45

- serial number, 45

- SROM device ID, 59

- test configuration, 81

- tracking priority, 42

- type, 45

Tracking mode, 4, 91

- start, 78

- stop, 80

tracking priority, 42

transformations

- binary, 24

- disabled, 7

- missing, 27, 85

- text, 83

transmission rate, 29

TSTART command, 78

TSTOP command, 80

TTCFG command, 81

TX command, 83

U

unoccupied port handle, 7

user parameters

- about, 12

- alerts parameters, 14

- commands, 12

- enumeration list, 37

- restoring default values, 31

- retrieving descriptive information, 35, 36

- saveable, 18

- saving values, 71

- setting values, 72

user-defined strings, 19

V

VER command, 87

version

- API, 22

- combined firmware, 87

- firmware, 87

- of SCU, 17

- system control processor, 87

version of firmware, 17

Vicra, 94

visible LED, 39, 45, 46, 47

volume *see* characterized measurement volume

VSEL command, 89

W

warm boot, 20

warnings, iii

writing to the SROM device, 57, 65