

JDY-16 Host Configuration

Step 1: Configuration master mode

AT+HOSTEN1 // Configured as master mode, the mode will restart automatically when the general module changes the mode.

Step 2: Send scan slave instructions

AT+SCAN // After sending, it will search the peripheral slave, and output the slave information from the serial port, MAC, RSSI, NAME

Step 3: Send connection instructions

Connection is divided into two ways, both can be chosen alternatively.

AT+CONN1 or AT+CONN112233445566

After the above connection, the master slave communication can be achieved.

Of course, master-slave binding can also be done.

You just need to change the third steps AT+CONN to AT+BAND.