



Programming:
DISCONNECT MAINS POWER!!
Disconnect both I_switch sensors!!
Use a 3v3 set FTDI for programming
Conect Rx and Tx crossed to the module
<Rx from FTDI to Tx of module >
<Tx from FTDI to Rx of module >
Insert FLASH jumper between pin 1 and 2 , JP7,
insert FTDI connector and
get a short to RESET header
Now you can send the software via FTDI
Remove the FLASH jumper and get another short
to RESET header

Use 2 flat telephone cables, straight wired with this plugs:
<https://store.comet.srl.ro/Catalogue/Product/10075/>