

Micro PC VX2 user's manual v1.0

Contents

Chapter1. Getting to know your computer 1

Top View 3

Rear View 4


Front View 4

Bottom view. 5


Chapter 2. Attentions 6

Chapter1.


●Top View



- ①Power Bottom
- ②Power LED


	LED color	meaning
Power 	White	ON-work
	twinkle	S3
	extinguish	S4

● Rear View




①DCIN	Connet Adapter
②HDMI	Connet HDMI
③VGA	Connet VGA
④LAN	Connet LAN
⑤USB2.0	Connet USB
⑥USB3.0	Connec USB
⑦headset	Conct headset

● front View



- ① USB2.0
- ② USB2.0
- ③ TF card
- ④ IR

● Bottom view



① HDD Cover

Chapter 2. Attentions

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party

Responsible for compliance could void the user' s authority to operate this equipment.

(Example- use

only shielded interface cables when connecting to computer or peripheral devices).

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. This equipment should be installed and operated with minimum distance of 20 cm the radiator your body.