

CONTENTS

CONTENTS	1
1 INTRODUCTION	4
2 SAFETY PRECAUTION	5
3 KEYBOARD	7
4 PREPARION	8
4.1 INSTALL SIM CARD	8
4.2 INSTALL SD CARD	8
4.3 INSTALL BATTERY	9
4.4 REMOVE BATTERY	9
4.5 CHARGE BATTERY	9
4.6 SECURITY PASSWORD	10
5 COMMON FUNCTIONS	11
5.1 POWER ON	11
5.2 MAKE A CALL	11
5.3 MAKE A CALL WITH CONTACTS	12
5.4 MAKE A CALL WITH CALL RECORDS	12
5.5 ANSWER A CALL	13
5.6 REFUSE A CALL	13
5.7 END A CALL	13
5.8 VOLUME CONTROL	13
5.9 EMERGENCY SERVICE	13
5.10 INCALL OPTIONS	13
5.11 SD CARD	14
5.12 POWER OFF	14
6 MENU FUNCTION	14
6.1 SMS	14
6.1.1 NEW MESSAGE	14
6.1.2 INBOX	15
6.1.3 DRAFT	15
6.1.4 OUTBOX	15

6.1.5 SENT MESSAGE	15
6.1.6 MESSAGE SETTINGS	15
6.2 SETTINGS	15
6.2.1 CALL CENTER	15
6.2.2 PHONE SETTINGS	16
6.2.3 MODE	17
6.2.4 PROFILES	18
6.2.5 SECURITY	18
6.2.6 RESET	19
6.3 MULTIPLE MEDIA	19
6.3.1 CAMERA	19
6.3.2 PHOTOS	20
6.3.3 VIDEO RECORDER	20
6.3.4 VIDEO PLAYER	20
6.3.5 MUSIC PLAYER	21
6.3.6 VOICE RECORDING	21
6.3.7 FM RADIO	21
6.4 OTHER FUNCTIONS	22
6.4.1 FILE MANAGEMENT	22
6.4.2 WEB SERVICE	22
6.4.3 CALCULATOR	23
6.4.4 ALARM CLOCK	23
6.4.5 CALENDAR	23
6.4.6 BLUETOOTH	23
6.5 SOS	23
6.6 CONTACTS	24
6.6.1 Add contact	24
6.6.2 View	24
6.6.3 Message	24
6.6.4 Edit	24
6.6.5 Delete	25
6.6.6 Copy	25
6.6.7 Contact Setting	25
7 INPUT	26
8 ACCESSORIES	27
9 MAINTENANCE	27
10 SAFTY	28
11 ENVIRONMENTAL PROTECTION	29

1 INTRODUCTION

Thank you very much for choosing our products.

Our mobile phones are up to the standard of communications industry of the People's Republic of China, also European standard, and approved applicable to GSM network. GSM network is a global cellular communications system of international standards. This phone can access a variety of international network. It helps you dial and receive international calls as freely as you're in hometown.

In order to use your mobile phone better, we recommend that you read this manual carefully, in order to use the various functions described in this manual fully.

Some features may not be allowed to use for different mobile phone network configuration and different services provided by the operators, please contact the seller or network operators for confirmation.

2 SAFETY PRECAUTION

Please read these simple rules and obey them to avoid danger and prevent illegal. This manual offer details of safety use.

TRAFFIC SAFETY FIRST

- Do not use the phone when you're driving. Please park first when it's necessary.

POWER OFF NEAR GAS STATION

- Do not use the phone in a gas station or near inflammables.

POWER OFF IN A PLANE

- Do power off your phone in a plane for it's illegal.

POWER OFF IN A HOSPITAL

- Avoid using your phone near medical equipment like pacemakers and hearing AIDS.

DISTRACTION

- All phones may be affected by interference of radio waves and call quality.

FAIR USE

- Only use the phone in a proper position (near you ear). Do not touch the top of the phone avoiding cover the built-in antenna. Call quality will be affected by touch between fingers and antenna shell.

PROFESSIONAL SERVICES

- Only professional maintenance person is allowed to assemble and repair this phone.

CONNECTION

- Please read the user manual to get more specific safety guide when connect with other devices. Do not connect with mismatched devices.

ACCESSORIES

- Only use the specified battery and accessories to avoid phone damage.

CHILDREN SAFETY

- Please keep the phone out of children's reach.

°

3 KEYBOARD

1. LEFT SOFT KEY, RIGHT SOFT KEY

Perform function showed at the left/ right bottom of LCD.

LEFT to main menu, RIGHT to contact list under standby interface.

2. DIAL/ PICK KEY

SIM 1/SIM 2 dials or picks a call from SIM 1/SIM 2.

Press this key to check the recent call records under stand interface.

3. END/ POWER KEY

End a call.

Long press to power on and off.

Return to stand interface.

4. OK KEY

Confirm.

5 NAVI-KEY

Left/Right: Move cursor left and right when edit.

Up/ Down: Scroll and scan the contact list/ number/ messages and all sub menus. Move cursor up and down when edit.

6.NUMBER/ LETTER KEY

Dial and input.

7.*

Different functions under different menus.

Short press inputs * under standby interface. Long press opens FM.

Continuous press * input "+" "P" 和 "W" under dial input interface.

8.#

Different functions under different menus.

Switch input method under text edit interface.

Long press opens and closes VOICE DIAL under standby interface.

Notice: 1) .Short press means press and release at once; Long press means keep pressing for over 3 seconds.

2) . All function menus are for keyboard operating. Please follow the guidance on the LCD for touch operating.

4 PREPARION

4.1 INSTALL SIM CARD

Please put SIM card out of children's reach.

Any scratch and bend may easily damage the SIM card. Please be careful when insert, take out and preserve the SIM card.

Please make sure the phone is power off and battery is free before SIM is taken out.

Take the back cover off and find the SIM card slot. Put SIM card in the slot right. Please make the metal part of the SIM card down and the edge angle match the slot shape.

4.2 INSTALL SD CARD

SD card is supported. Please make sure the SD card is installed properly.

Notice: SD card may slip out of the slot by shaking the phone. Please do not bend or scratch the SD card or make it contact with electrostatic, dust and flooding.

Take out the battery and find the SD card slot. Release the slot cover and make the metal part of the SD card down. Pay attention to the edge angle. Close the slot cover after SD card is totally plugged in the slot properly.

4.3 INSTALL BATTERY

Open the back cover.

Insert the battery into the battery slot.

Close the phone cover.

4.4 REMOVE BATTERY

Power off the phone first and push down the back cover.

Remove the battery from the battery slot.

•Settings and data in the SIM card or phone will be lost after battery removed.

4.5 CHARGE BATTERY

Insert the charger plug in the charging interface, and then connect the other side to the power socket. If the phone is power on and the stripes at the top right of the screen keep rolling, the phone is charging. When the stripe is full of the whole icon and stop scrolling, battery charging is completed; The charging scroll icon will still be rolling when the phone is charging after power off.

Pull out the plug after charging is completed.

•When battery is low, the phone will warn you. While capacity is too low, the phone will automatically power off. Please do not make battery under low power for a long time because it will damage the quality and longevity.

•It is normal that when battery voltage is too low, there will be a pre-charging process without any charging signs.

•Please use the charger we offered to make sure the phone works properly.

•Please do not take off the battery during charging.

·Please keep the phone ventilate under an appropriate environmental temperature around 0℃~+45℃ when it's charging,

4.6 SECURITY PASSWORD

—PIN Code

This is your SIM card personal identification number. PIN and SIM card usually are provided by the network operator. SIM card will be locked if you input the wrong PIN number for three times continuously. You need to enter the PUK code to unlock. Please contact the network operator for details.

—PIN2 Code

PIN2 code is provided along with some SIM card. It's normally needed by some special functions such as FDN (fixed dialing number) and Valuate Unit.

PIN2 code will be locked if you input the wrong PIN2 number for three times continuously. You need to enter the PUK2 code to unlock. Please contact the network operator for details.

—PUK Code

PUK Code is provided by the network operator and needed when PIN Code is locked. If your SIM card is locked, there'll be a sign ask you to input your PUK code. Your phone will be unlocked after you input the right PUK code. Your SIM card may be invalid if you input the wrong PUK code continuously for 10 times. Please contact the network operator for details.

—PUK2 Code

PUK2 Code is provided by the network operator and needed for unlocking the PIN2. Your PIN2 code will be locked forever if you input the wrong PUK2 code continuously for 10 times. There is no influence about other functions that not related with PIN2. Please contact the network operator for details.

—Mobile Phone Password

Password prevents your phone from being used without permission. (Original

password is 1122). Please change your password for safety.

5 COMMON FUNCTIONS

5.1 Power on

Long press End/ Power key to power on your phone. Background light turns on and boot animation flashes.

This phone is dual sim and dual standby with GSM network.

1. There'll be a sign if SIM card is not insert properly or poor contact. Long press the End/ Power key to power off the phone and reinstall your SIM card.
2. You need to input your mobile phone password or PIN Code if you enable them when you install your SIM card and power on.

Network searching is automatic and there'll be signs of the network names and signal strength which depends on SIM card. You can still use the emergency call and other functions not based on network signal when there's no network service.

5.2 MAKE A CALL

5.2.1 MAKE A DOMESTIC CALL

When network provider logo appears on the screen, you can dial or answer the phone. The network signal strength is displayed on the top left corner of the screen. Call quality is affected strongly by obstacles.

Input numbers to make a call under standby interface. Press 'Delete' to correct wrong number. Press 'LEFT' and 'SAVE to Contacts' can save this number in SIM1/ SIM2 or phone.

There's a animation when dialing and status information when call is picked up. Please follow this steps for a domestic call:

Area Code—Number—Dial Key

5.2.2 DIAL A TELEPHONE EXT

Some extension line cannot be connected directly. You need to dial the telephone operator and long press [*] to handover until there's a sign [P] on the LCD and then dial extension line.

Please follow these steps:

Area Code – Operator Number - P – Extension Line – Dial Key

Some extension line must be connected through operator phone. You need to dial the operator number first and [*] to handover until there's a sign [W] on the LCD and then dial extension line.

Please follow these steps:

Area Code – Operator Number - W– Extension Line – Dial Key

5.2.3 MAKE AN INTERNATIONAL CALL

Long press [*] until you get a [+]. Input the country code and the number. Do not forget to delete the [0] before city code when you are making an international call.

Please follow these steps:

+ - Country Code - Number – Dial Key

5.3 MAKE A CALL WITH CONTACTS

You can call anyone in your contacts directly.

Enter the main menu and choose [Contacts] and enter the list. Find out the contact you want and press [Dial] / [Answer].

Please follow the introduction in [Contacts].

5.4 MAKE A CALL WITH CALL RECORDS

All dialed/ received/ missed calls are all saved by type under records menus. Old records will be deleted automatically when records capacity is full. Press [Dial]/ [Answer] key can check recent call. You can dial anyone you want in the list directly.

5.5 ANSWER A CALL

There'll be signs (vibration or ringtone) when you have a call. Name (It depends on whether you save this number in your contacts.) and number will be displayed. You can pick up the call in these ways:

1. [Call Center→Call Settings→Advanced Settings→Answer Mode] choose [Any Key].
2. [Call Center→Call Settings→Advanced Settings→Answer Mode] choose [Automatic Answer Under Headset]
3. Press [Left Function Key]/ [OK] key to choose [Answer].
4. Press [Dial]/[Answer] key.

5.6 REFUSE A CALL

Press [End]/ [Power] key or [Right Function Key] to refuse a call.

5.7 END A CALL

Press [End]/ [Power] key to end a call and cancel a dialing call.

5.8 VOLUME CONTROL

Use the navigation keys to control the volume during a call.

5.9 EMERGENCY SERVICE

You can make emergency service calls without a SIM card. Please check the details with your operator.

5.10 INCALL OPTIONS

Press Right Function Key can enable the hand-free function during a call. Press again can shut down the hand-free function.

Press [LEFT] key can enter call settings menu during a call. The menu depends on the call situation and can only be seen during a call. Call forwarding, call waiting, conference call should be supported by network operator. Please check with your operator for details.

·**Keep/resume phone call:** keep the current call in status, or resume a phone call

·**End phone call:** End the current call.

·**New call:** Enter call dialing interface.

·**Contacts:** Enter contact list

·**Records:** Enter call records

·**Message:** Enter message sending

·**Voice Record:** Enter record interface and record the call

·**Silent:** Turn on or off the local voice.

·**DTMF:** Dual tone multiple frequency

5.11 SD CARD

You can choose SD card with all capacity and read the contents in the card by inserting it properly. All operating concerned about SD card in this manual is under an enabled SD card condition.

5.12 POWER OFF

Press [End]/ [Power] key can power off your phone under standby interface.

6 MENU FUNCTION

6.1 SMS

Short message service is a network needed function. You can send/ receive/ edit a short message. Please check with your operator for details.

6.1.1 NEW MESSAGE

Choose this item and enter the editing interface. Press [#] to switch the input method during edition and choose [Option] to choose what you need to do.

6.1.2 INBOX

There're read or unread messages you received.

Choose any message and press [OK] to read. Press [OK] to reply and edit.

6.1.3 DRAFT

There're unsent messages saved by purpose or accident temporarily. Read a draft and press [Option] key can choose what you need to do.

6.1.4 OUTBOX

Outbox storages and manages the messages being sent and failed being sent. Choose a message and press Left key can choose what you need to do.

6.1.5 SENT MESSAGE

Outbox storages and manages the messages already sent successfully. Choose a message and press Left key can choose what you need to do.

6.1.6 MESSAGE SETTINGS

—**SIM1:** Set the SMS function for SIM1

—**SIM2:** Set the SMS function for SIM2

—**Save sent messages:** Save the sent messages in Sent Message Box

6.2 SETTINGS

6.2.1 CALL CENTER

—**RECENT:**

Check your recent calls based on both SIM 1 and SIM 2. You can call any

numbers under this list. Press [OK] can check the specification about the call. Press [Option] can choose what you need to do. You can delete any records in the recent list.

—**Call Settings:**

—**SIM 1 Call Setting(SIM1 available and enabled)**

Set up SIM1 functions like Call waiting, Call rewarding, Call barring, Line Switching. Call waiting, Call rewarding, Call barring need support from network operator.

—**SIM 2 Call Setting(SIM2 available and enabled)**

Set up SIM2 functions like Call waiting, Call rewarding, Call barring, Line Switching. Call waiting, Call rewarding, Call barring need support from network operator.

—**Advanced Settings**

- Automatic Redial:** Redial unanswered calls when function is enabled.
- Talk Time Prompt:** No prompt tone when function is disenabled.
- Answer Mode:** Any key Answer or Headset Mode Automatic Answer.

6.2.2 PHONE SETTINGS

— **Time and Date**

- Local Setting:** Set the city you are in.
- Time/ Date:** Set the time and date.
- Format Settings:** Set the displayed format of the time and date.

—**Language**

You can choose whatever language the phone provided.

—**Default Input Method**

Set the default input method for editing.

—Standby Menu Display

You can choose the display of LCD under standby interface.

- **Wall paper:** Choose your favorite wall paper.
- **Power on Animation:** Choose animation displayed when power on.
- **Power off Animation:** Choose animation displayed when power off.
- **Display Time and Date:** Press [OK] key to enable and disable this function. When it's enabled, the time and date will be displayed on the screen.

—Specify Function Key

Set the Navi Key shortcuts.

—Airplane Mode

No call, message, signal and no communication when this function is enabled.

Memo: You can use other functions that signal is not needed such as contacts, reading articles on your phone or listening to music saved in your SD card.

Please power off your mobile phone after you get on a plane.

—Other Settings

- **LCD background light:** Set the brightness of the LCD background light and lasting time.

—Voice Number

Enabled Voice Number can make your number dialing be voiced.

6.2.3 MODE

—Dual Sim (2SIM cards)

SIM1 and SIM 2 are enabled.

—Only SIM1

SIM 1 is enabled while SIM 2 is disabled.

—Only SIM2

SIM 2 is enabled while SIM 1 is disabled.

6.2.4 PROFILES

Standard: Common environment

Silent: Silent environment

Meeting: Meeting environment, need to set up in advance

Outdoor: Outdoor environment, need to set up in advance

Choose the profile you want and press [Option]:

—On

Choose the profile

—Personal Settings

Set the profile personally. No such option under silent profile.

—Reset

Reset the profile you choose.

6.2.5 SECURITY

You can set your security options to keep your phone safe.

—SIM 1 Security

Set SIM1 lock or password.

—SIM 2 Security

Set SIM2 lock or password.

—Phone Security

·**Phone Lock:** It can prevent your phone from being used by other people.

Memo: Original phone password is 1122. Please reset it ASAP.

·**Reset Password:** Change your phone password.

—Auto-Lock

Enable or disable the function and set the auto-lock time.

6.2.6 RESET

Input phone password (1122) and confirm. The phone will power off and everything in the phone will be reset.

6.3 MULTIPLE MEDIA

6.3.1 CAMERA

You can take pictures and save them in your phone.

Notice: Please obey the law and respect other people's privacy and legal rights when taking photos and videos.

You can set the camera when it's open:

Adjust the focus by NAVI [Up] and [Down] key.

Press [Option] key:

—**Video Recording:** Switch to video recording function

—**Photos:** You can check the photos in your SD card and choose it as a wall paper or rename them and delete them.

—**Camera Settings:**

Avoid Flashing: Can set "50Hz" or "60Hz" according to your need.

Delay Shooting: 5seconds/10/15 according to your need.

—**Photo Settings:**

Photo Size: 160*120、320*240、240*320

Photo Quality: Low/ middle/ high

—**White Balance:** Auto, Sunlight, Tungsten, Daylight, Cloudy, Glow.

—**Mode:** Auto/ Night shot

—**Storage:** Storage location can be phone and SD card.

—**Reset Default:** Reset all settings to default.

Press [OK] key to take a photo after settings.

6.3.2 PHOTOS

View the photos and press [left] key to choose:

- View:** View the photos
- Send:** Send photos through Bluetooth
- Set:** Use it as wallpaper
- Rename:** Reset its name
- Delete:** Delete the photo
- Information:** View the specification of this photo

6.3.3 VIDEO RECORDER

Press [Option] to get these functions:

- Switch to Camera:** Switch to camera
- Video Recorder Setting:** Avoid flashing
- Video Setting:** set the quality of the video

6.3.4 VIDEO PLAYER

Display and play the videos in the list.

Choose a video and press left key to get these functions:

- Play:** Play the video you choose
- Send:** Send the video through Bluetooth
- Rename:** Rename the video
- Delete:** Delete the video

Press [OK] key can play and suspend the video playing. Long press Navi [Left] and [Right] can speed and backward the video playing. [Up] key switch full screen. [Down] key stop playing.

6.3.5 MUSIC PLAYER

Play the music files saved in corresponding directory. Press [OK] key to play/suspend. Press [Left] and [Right] to get last and next song. Long press [Left] and [Right] to speed and backward.

Press* or # to control the volume

Press [Playlist] to enter play list. Choose a file and press [Option] can get these functions:

- Play:** Play the song
- Details:** View the details of the song
- Update the playlist:** Update the playlist
- Setting:** Set concerned parameter

6.3.6 VOICE RECORDING

Press [Left] key to get options for new record, record list and settings.

6.3.7 FM RADIO

FM Radio is enabled in this phone.

Enable FM and press Navi[Up]/[Down] key to get next/last channel. Press Navi[Left] and [Right] to search automatically. Press [OK] to enable and disable FM radio. Press [Left] key for these options:

- Channel List:** Edit channel name and frequency.
- Manual Input:** Manual input frequency.
- Auto Search:** Search channels automatically and save.
- Setting:** Open or close the background play.

6.4 OTHER FUNCTIONS

6.4.1 FILE MANAGEMENT

Enable and choose [SD Card]. Press [Option] under root directory, you can get these options:

—Open

List the folders and files in the SD card.

Choose a folder and press [Option] you can get:

- Open:** Open this folder
- New folder:** Create a new folder
- Rename:** Change the name of this folder
- Delete:** Choose and confirm to delete this folder

Choose a file and press [Option] you can get: View (Play) , Use, New folder, Rename, Delete, Copy, Remove, Details.

—Format

Format the SD card mean delete all the data in it.

—Details

View the full space and left space of this SD card.

6.4.2WEB SERVICE

—**Bubbling Browser:** For webpage

—**SIM application:** Some value-added service offered by operator.

Notice: These functions need GPRS enabled. Please check with your operator for details.

6.4.3 CALCULATOR

Provide a calculator based on simple arithmetic: add, subtract, multiply and divide.

Notice: This calculator accurate to 12-bit valid number

6.4.4 ALARM CLOCK

Multiple alarms are enabled under power off or silent mode. Choose any alarm and press [Edit] can edit the parameter. Do not forget to press [Save] after you finish setting.

6.4.5 CALENDAR

Enter calendar and press [Option] to jump to appointed day/ today/ view as week.

6.4.6 BLUETOOTH

Enabled BT: Choose if enable BT or not.

Can be Found: Choose if share or hide the BT. Other devices can't find your BT if it's hide.

My Device: Search BT devices around

My name: Name showed to other devices when BT is enabled and can be found.

6.5 SOS

SOS function is available. Finish setting and long press[OK]key to call the emergency contact. A Help Message will be sent if call is not answered.

—Emergency number setting

5 SOS number is available.

—Help message

Set the details of the help message

—Receiver

Set the receiver of the help message

—Call waiting time

Set the time for call waiting. Promptly/ 5s/ 10s

6.6 CONTACTS

You can add a contact under this menu.

Input number and press [Left] key under standby interface to save the number to phone, SIM card contacts.

6.6.1 Add contact

Add a new contact

6.6.2View

View the details of the contact.

6.6.3 Message

Send a message to the contact.

6.6.4 Edit

Edit this contact.

6.6.5 Delete

Delete the contact.

6.6.6 Copy

Copy the contact to phone/ SIM1/SIM2.

6.6.7 Contact Setting

- Other Number:** View and edit the fixed dialing number.
- Storage:** View SIM and phone contacts storage capacity.

7 INPUT

Multiple input methods are offered.

Press [#] key can circularly switch the input methods: SCIM-Chinese, 123, ABC/abc/Stroke.

7.1 ABC/abc

Letter and number key table:

Number Key	Letter and Other Input	Memo
1	symbols	
2	ABC2; abc2	
3	DEF3; def3	
4	GHI4; ghi4	
5	JKL5; jkl5	
6	MNO6; mno6	
7	PQRS7; pqrs7	
8	TUV8; tuv8	
9	WXYZ9; wxyz9	
0	0 and space	
#	Switch input method	

7.2 123

Press [0—9] for relevant numbers.

7.3 SCIM-Chinese

It's based on Chinese Pinyin.

8 ACCESSORIES

You can choose the following accessories from our company and ask the retailer for others. Please pay attention that these accessories are for this phone and only for this phone. It may be dangerous to ignore this warn.

8.1 SPARE BATTERY

You can choose other Li-battery with different capacity from our company.

8.2 CHARGER/ CHARGER WIRE

Plug charger into the power socket and insert the other side to the phone to charge the battery. You can also connect the phone and your PC (power on) to charge. Charging status will be showed on the LCD. The phone will not be power on automatically if you charge it after power off. You can power it on after charging finished.

9 MAINTENANCE

9.1 BATTERY NOTICE

- Please charge when battery is about to be out of power. You'd better use all power out before you charge.
- Please do not leave the charge connected with the power socket when charging finished or charge the battery over a week.
- Please cool or warm the battery before charge because temperature can affect the limits of charging. Please stop charging if environment temperature is over 45℃ for your safety.
- Please use the battery only for this phone to avoid short circuit. Connecting the battery's negative and positive sides with conducting

materials can easily cause short circuit.

- Please do not use a damaged battery.
- Exposing the battery under extremely cold and hot places will short its life and make some functions of the phone not available even it is charged.
- Please do not put the battery in fire and send it to battery recycling center instead of discard it at random.

9.2 MAINTAIN

Please follow these suggestions to maintain your phone:

- Please put the phone and accessories out of children's reach.
- Please keep the phone dry for liquid can cause metal corrosion circuit.
- Please keep the phone away from hot temperature which can short the life of electronic devices, make plastic melt and damage the battery.
- Please do not try to open or disassemble the phone for all non-professional disassembling will cause damage.
- Please do not clean the phone with highly acidic or alkaline cleanser.
- Please use the original accessories only. Any violation of the rules would void the warranty.

10 SAFETY

Please comply with the safety rules of protecting.

10.1 TRAFFIC SAFETY

- Please focus in driving and not use your phone unless car is parked in a safe place. Use your phone hand free ONLY under emergency. Some electronic systems will be affected by the wave from your phone without enough protection.
- Suggest use your phone only in a car with external antenna.

- Never set up your phone in a car without a qualified technician.

10.2 PLAN SAFETY

- Please power off your GSM phone before loading. It's illegal to use a phone on plane for it will badly affect the operating of the plane and cellular network. Any violation of these rules will be charged and refused to serve.

10.3 HOSPITAL SAFETY

- Please power off where phone is forbidden to use or recognized as dangerous. Please comply with all safety rules concerned about the phone.
- Please ask the doctor or the medical equipment supplier for any questions about the effects of phone using.
- Please follow the doctor and manufacture's suggestion about the hearing AIDs and pace make equipment.
- Please power off your phone near dangerous places where using phone may cause explosion such as gas station, chemical factory.
- Please comply with the restricted rules concerned about wireless device.

11 ENVIRONMENTAL PROTECTION

Parts	Hazardous Substance					
	Pb	Hg	Cd	Cr6	PBB	PBDE
Phone	X	0	0	0	0	0

Battery	X	0	0	0	0	0
Accessories	X	0	0	0	0	0

Description:

"0" means that the hazardous substance content is below the standard of SZ/T11363-2006.

"x" means that the hazardous substance content is beyond the standard of SZ/T11363-2006.

Notice: There is a "x" for no optional alternative technology and parts are available nowadays.

INSTRUCTION : No further notice for upgrade version. Our company holds the final right of interpretation about this manual.

WARN: Manufacture accepts no responsibility for the consequence cause by violation of the above suggestion and improper use of the phone.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC rf exposure information and statements

Us (FCC) SAR limit is 1.6 W/kg on average more than a gram of tissue. Device type:

T6 (FCC ID: 2ADBRE1200) has also been on the SAR limit test. the

The highest SAR value report in this standard in the use of product certification

Head is 0.712w/kg, when properly worn on the body is 0.602w/kg. The device tests

For a typical wear on operating the back of the phone kept 15 mm from the body.

Keep in line with the requirements of FCC radiofrequency exposure. Use the maintenance accessories

15 mm separation distance from the user's body and the back of the phone. use

Clips, half and similar accessories does not contain metal component assembly.

Use of accessories may not meet the FCC radiofrequency don't meet these requirements

Should avoid to contact, requirements and tests the equipment for typical wear in the body

Components. Only use the supplied antenna or approval.