



Authorized Antennas and Accessories

WARNING. This is NOT a CONSUMER device. It is designed for installation by FCC LICENSEES and QUALIFIED INSTALLERS. You MUST have an FCC LICENSE or express consent of an FCC Licensee to operate this device. Unauthorized use may result in significant forfeiture penalties, including penalties in excess of \$100,000 for each continuing violation.

Category	Name	Purpose	P/N
Donor Antenna	CubeAnt™	CubeAnt™ Compact Donor Antenna, 4 dB	CBA-50-OHM
Donor Antenna	SleekAnt™	SleekAnt™ Ultra-Compact Donor Antenna, 4 dB	SLA-50-OHM
Donor Antenna	SportsAnt™	SportsAnt™ Vehicle Donor Antenna, 4 dB	SPA-50-OHM
Donor Antenna	AeriaFlex™	AeriaFlex™ Donor Antenna, 5 dB	AFLX-50-OHM
Donor Antenna	AeriaLight-mini™	AeriaLight-mini™ Donor Antenna, 5 dB	AERM-50-OHM
Donor Antenna	DomeAnt-Plus™	DomeAnt-Plus™ Portable/Vehicle Donor Antenna, 6 dB	DMAP-50-OHM
Donor Antenna	BoatAnt-mini™	BoatAnt-mini™ Marine Donor Antenna, 6 dB	BTM-50-OHM
Donor Antenna	OmniAnt™	OmniAnt™ Portable/Vehicle Donor Antenna, 7 dB	OMNT-50-OHM
Donor Antenna	OmniWide™	OmniWide™ Portable/Vehicle Donor Antenna, 7 dB	OMNW-50-OHM
Donor Antenna	RVAnt™	RVAnt™ RV/Vehicle Donor Antenna, 7 dB	RVA-50-OHM
Donor Antenna	Omnirial™	Omnirial™ Donor Antenna, 8 dB	OMNR-50-OHM
Donor Antenna	DomeAnt-Dir™	DomeAnt-Dir™ Directional Dome Donor Antenna, 9 dB	DMDIR-50-OHM
Donor Antenna	AeriaLog-Lite™	AeriaLog-Lite™ Donor Antenna, 9 dB	ALGL-50-OHM
Donor Antenna	Omnirial-Plus™	Omnirial-Plus™ Donor Antenna, 9 dB	OMNP-50-OHM
Donor Antenna	BoatAnt™	BoatAnt™ Marine Donor Antenna, 9 dB	BTA-50-OHM
Donor Antenna	BusAnt™	BusAnt™ Vehicle Donor Antenna, 9 dB	BSA-50-OHM
Donor Antenna	BusAnt™	BusAnt™ Vehicle Donor Antenna with GPS, 9 dB	BSAG-50-OHM
Donor Antenna	WallAnt™	WallAnt™ On-Wall Donor Antenna, 9 dB	WLA-50-OHM
Donor Antenna	AeriaLight™	AeriaLight™ Donor Antenna, 9 dB	AER-50-OHM
Donor Antenna	AeriaWide™	AeriaWide™ Shielded Donor Antenna, 10 dB	AWD-50-OHM
Donor Antenna	FlexAnt™	FlexAnt™ Donor Antenna, 10 dB	FLX-50-OHM
Donor Antenna	AeriaLog™	AeriaLog™ Shielded Donor Antenna, 11 dB	ALG-50-OHM
Donor Antenna	WinAerial™	WinAerial™ On-Window Donor Antenna, 11 dB	WIN-50-OHM
Donor Antenna	YagiRef-Plus™	YagiRef-Plus™ Shielded Donor Antenna, 11 dB	YRFP-50-OHM
Donor Antenna	WideAnt-X™	WideAnt-X™ Donor Antenna, 12 dB	WDAX-50-OHM
Donor Antenna	UniAnt™	UniAnt™ Shielded Donor Antenna, 12 dB	UNI-50-OHM
Donor Antenna	AeriaLight-Plus™	AeriaLight-Plus™ Donor Antenna, 13 dB	AERP-50-OHM
Donor Antenna	WinAerial-Plus™	WinAerial-Plus™ On-Window High Gain Donor Antenna, 13 dB	WNP-50-OHM
Donor Antenna	WideAnt-Lite™	WideAnt-Lite™ Donor Antenna, 13 dB	WDAL-50-OHM
Donor Antenna	WideAnt™	WideAnt™ Shielded Donor Antenna, 15 dB	WDA-50-OHM
Donor Antenna	YagiRef-Lite™	YagiRef-Lite™ Shielded Donor Antenna, 20 dB	YRL-50-OHM

Donor Antenna	YagiRef-QLP™	YagiRef-QLP™ Highly Directional Shielded Donor Antenna, 24 dB	YQLP-50-OHM
Donor Antenna	GiAnt™	GiAnt™ Ultra-Directional Shielded Donor Antenna, 27 dB	GNT-50-OHM
Service Antenna	CubeAnt™	CubeAnt™ Compact Donor Antenna, 4 dB	CBA-50-OHM
Service Antenna	AeriaFlex™	AeriaFlex™ Coverage Antenna, 5 dB	AFLX-50-OHM
Service Antenna	CeilAnt™	CeilAnt™ Coverage Antenna, 9 dB	CLA-50-OHM
Service Antenna	DeskAnt™	DeskAnt™ Desktop Coverage Antenna, 8 dB	DKA-50-OHM
Service Antenna	DomeAnt™	DomeAnt™ Desktop Coverage Antenna, 8 dB	DMA-50-OHM
Service Antenna	DomeAnt-Alpha™	DomeAnt-Alpha™ Ceiling Coverage Antenna, 5 dB	DMAA-50-OHM
Service Antenna	DomeAnt-Delta™	DomeAnt-Delta™ Ceiling Coverage Antenna, 6 dB	DMAD-50-OHM
Service Antenna	DomeAnt-Gamma™	DomeAnt-Gamma™ Ceiling Coverage Antenna, 6 dB	DMAG-50-OHM
Service Antenna	DomeAnt-Dir™	DomeAnt-Gamma™ Directional Ceiling Coverage Antenna, 8 dB	DMDIR-50-OHM
Service Antenna	EMPatch™	EMPatch™ Patch Coverage Antenna, 3 dB	EMPV-50-OHM
Service Antenna	FlexAnt™	FlexAnt™ Coverage Antenna, 10 dB	FLX-50-OHM
Service Antenna	OmniAnt™	OmniAnt™ Portable/Desktop Coverage Antenna, 7 dB	OMNT-50-OHM
Service Antenna	OmniWide™	OmniWide™ Portable/Desktop Donor Antenna, 7 dB	OMNW-50-OHM
Service Antenna	PanAnt™	PanAnt™ Coverage Antenna, 13 dB	PNA-50-OHM
Service Antenna	SleekAnt™	SleekAnt™ Ultra-Compact Coverage Antenna, 4 dB	SLA-50-OHM
Service Antenna	WallAnt™	WallAnt™ Coverage Antenna, 9 dB	WLA-50-OHM
Service Antenna	DeskAnt-Plus™	DeskAnt-Plus™ Desktop/Portable Coverage Antenna, 7 dB	DAP-50-OHM
Service Antenna	AeriaDesk™	AeriaDesk™ High Gain Desktop Antenna, 11 dB	ADK-50-OHM
Service Antenna	DomeAnt-Plus™	DomeAnt-Plus™ Portable/Desktop Donor Antenna, 6 dB	DMAP-50-OHM
Low Loss Coaxial Cable	WIR200™	Connection between devices/antennas/accessories (15 feet, N-Male to N-Male)	WIR200-NM-NM-15FT
Low Loss Coaxial Cable	WIR200™	Connection between devices/antennas/accessories (15 feet, N-Male to SMA-male)	WIR200-NM-NM-15FT
Ultra Low Loss Coaxial Cable	WIR400™	Connection between devices/antennas/accessories (25 feet)	WIR400-NM-NM-25FT
Ultra Low Loss Coaxial Cable	WIR400™	Connection between devices/antennas/accessories (50 feet)	WIR400-NM-NM-50FT
Inline Coupler	Ncoupler™	Allows identical (N-Male) coaxial cables to be connected together	NC-NF-NF
Passthrough Cable	WinCoax™	Very thin coaxial junction to port an external cable through a closed window	WINCX-NM-NF
RF Wall Plate	WallPlate™	Wall plate with N-Female connector for clean and professional installations	WALLPLATE1
Direct-Connect Adapter (for modems, hotspots, m2m, etc.)	ExtAnt™	Allows connection of a specific device, such as a modem, hotspot, router, wireless card, etc. (connects to the sohoBoos™ via DCA™)	EXTANT-BRAND-MODEL
Direct-Connect Adapter (for modems, hotspots, m2m, etc.)	ExtAntPro™	Allows connection of a specific device, such as a modem, hotspot, router, wireless card, etc. (connects to the sohoBoos™ via DCA™) (professional/military version)	EXTANTPRO-BRAND-MODEL
Attenuator for Direct-Connect Adapter	DirConAtt™	Must be inserted between a direct-connect adapter (ExtAnt™ or ExtAntPro™) and the sohoBoost™	DCA-SB1
Microstrip Splitter	EMSPlit™	Distributes signal among antennas (connects directly to the sohoBoos™)	EMS-50-OHM
Microstrip Splitter	EMSPlit3™	Distributes signal among antennas (connects directly to the sohoBoos™)	EMS3-50-OHM
Microstrip Splitter	EMSPlit4™	Distributes signal among antennas (connects directly to the sohoBoos™)	EMS4-50-OHM
Femtocell Adapter	FemtoDir™	Allows connection of a femtocell device with user antenna port (connects directly to the sohoBoos™)	FEMTODIR1
Femtocell Adapter	FemtoPatch™	Allows connection of a femtocell device without user antenna port (connects directly to the sohoBoos™)	FEMTOPATCH1
Signal Attenuator	WBSA-10™	Reduces sohoBoost™ sensitivity to prevent self-amplification in small spaces	SIG-ATT-10DB
Signal Attenuator	WBSA-20™	Reduces sohoBoost™ sensitivity to prevent self-amplification in small	SIG-ATT-20DB

		spaces	
Signal Attenuator	WBSA-30™	Reduces sohoBoost™ sensitivity to prevent self-amplification in small spaces	SIG-ATT-30DB
Lightning Strike Protecort	LightningPro™	Protects persons and equipments from lightning strike discharges (connects directly to the sohoBoost™)	LPRO-50-OHM-NM-NF
Antenna Mount	WallMount™	Allows installation of a donor antenna on a wall instead of a mast/pole	WALLMOUNT1
Antenna Mount	AntMount™	Allows installation of an antenna pole by using a wall	ANTMOUNT1
Antenna Pole, Steel	SteelPole™	Stell antenna pole, stackable, 4 feet long	STLPOL4
Attenuator	ATTCOMB™	Allows direct connection of a cellular device to the sohoBoost™ coverage port (connects directly to the sohoBoost™)	ATTCOMB
Attenuator+Combiner	ATTCOMB2™	Allows direct connection of two cellular devices to the sohoBoost™ coverage port (connects directly to the sohoBoost™)	ATN-CMB-2
Attenuator+Combiner	ATTCOMB4™	Allows direct connection of two cellular devices to the sohoBoost™ coverage port (connects directly to the sohoBoost™)	ATN-CMB-4
Attenuator+Combiner	ATTCOMB8™	Allows direct connection of two cellular devices to the sohoBoost™ coverage port (connects directly to the sohoBoost™)	ATN-CMB-8
Mobile Handset Cradle – Small	sohoCradle1™	Allows direct connection of a mobile handset to the sohoBoost™ coverage port (connects directly to the sohoBoost™ or to a combiner)	SCRDL1
Mobile Handset Cradle – Medium	sohoCradle2™	Allows direct connection of a mobile handset to the sohoBoost™ coverage port (connects directly to the sohoBoost™ or to a combiner)	SCRDL2
Mobile Handset Cradle – Large	sohoCradle3™	Allows direct connection of a mobile handset to the sohoBoost™ coverage port (connects directly to the sohoBoost™ or to a combiner)	SCRDL3
Small Tablet Cradle	TabCradle1™	Allows direct connection of a tablet computer to the sohoBoost™ coverage port (connects directly to the sohoBoost™ or to a combiner)	TABCRDL1
Medium Tablet Cradle	TabCradle2™	Allows direct connection of a tablet computer to the sohoBoost™ coverage port (connects directly to the sohoBoost™ or to a combiner)	TABCRDL2
Large Tablet Cradle	TabCradle3™	Allows direct connection of a tablet computer to the sohoBoost™ coverage port (connects directly to the sohoBoost™ or to a combiner)	TABCRDL3
Modem RF Sleeve	ModSleeve™	Allows direct connection of a hotspot or USB modem (connects directly to the sohoBoost™ or to a combiner)	MODSLV
Wireless-To-Inline Converter	W2I™	Converts the sohoBoost™ from wireless to inline by adjusting all signals on all bands to allowable input and output levels specifications	W2I-SB