





Model: BH60



**LIVALL** Smart Safety Helmet

### I. Introduction

This smart safe-riding helmet (hereinafter referred to as "Bling Helmet") is made of the lightest and safest materials, which makes it more comfortable and safer. Its fine ventilating structure inside enables air to flow smoothly through so as to achieve the best cooling effect. It also has Bluetooth speakers, and warning tail light.




### II. Packing list

- |                         |                   |
|-------------------------|-------------------|
| One helmet              | One hag tag       |
| One USB charging cable  | One warranty card |
| One product instruction |                   |

### III. Wearing instruction

Usage:  
This safety helmet adopts a fixed setting, easy to operate, putting on or taking off the helmet only with the buckle. Flatten the drawstrings on both sides and make them clinging to your face, buckle up it when the helmet is tightly put on. If the drawstrings become loose, please take off the helmet and adjust them properly. When adjusting the drawstrings, please use one hand to fix the buckle and then adjust the drawstrings with proper tightness. If you want to strengthen the rear drawstring, pull it tight from its back, use one hand to fix the helmet and another one to fix the drawstring under the chin and adjust the four drawstrings to a most appropriate position.



#### Proper wearing

The helmet must be worn closely to your head. If you want to lower the front to cover your forehead, you could make the drawstring close to your chin and loose the rear drawstring; if you want to heighten the front of the helmet, loose the drawstring and tighten the rear drawstring.



#### Comfort adjustment:

In order to check the tightness of the helmet, you could put on the helmet and buckle up it, open your mouth to feel whether the drawstrings are closely attached to your chin, and then move your helmet forward and backward, if the helmet becomes loose, then the tightness of the drawstring must be strengthened and make sure that the thickness of the pad is proper. The helmet could not be able to move forth and back much distance; the helmet could not be taken off if the buckle is not opened. Note: It is necessary to reaffirm whether the helmet is in a good condition every time you wear.

#### Checking

Make sure that the helmet must be put on your head correctly and firmly. Readjust the tightness of the drawstrings to a proper position if the helmet still shakes. For the best protection effect, please make sure that the

helmet is suitable for you and could be tightly wore. Check the adjustment again every time you wear to ensure that the helmet could be closely put on your head.

### IV. Operating Instruction

#### Start up:

Long press "□" for 2s till you hear the "power on" sounds, meanwhile the outline light and tail light will flash twice in orange.

#### Power off:

When the device is in a state of working, long press "□" till you hear the "power off" sounds, meanwhile the outline light and tail light would flash once in orange.

#### Connecting to Bluetooth earphone:

Connect the bluetooth with your smart phone when first-use or when change to another smart phone; When the device is power off, long press "□" till you hear the "ready to pair" sounds, means the device starts matching; scan the device with your phone which the Bluetooth is available. and click it to connect when spotting the equipment of "BH60". The speakers on both sides will make the noise of "matching completed" when the connection is completed; The bluetooth will be connected automatically next time.

#### Answer and hang up calls:

When there's an incoming call, the device would give out notification voice, press "□" to answer the call and long press for 1S to reject; during calls, press "□" to hang up.

#### Redial calls:

When the device is powered, quick press "□" twice to dial the last number.

**LIVALL** Smart Safety Helmet



Designed and Assembled in Shenzhen China

#### Music player:

When the device is powered, press "□" to play music (need to open the music player APP in your phone before this operation). Long press "+" to play the previous song and "-" the next song.

#### Volume adjustment:

During music playing or taking calls, press "+" to increase volume while "-" to decrease

#### Notification voice switches of Bluetooth speaker:

The default setting is English. When the product is powered, first hold "-" and then press "+" to cycle switch languages, from English→Chinese→French→Spanish; when the language is selected, loose "-".

#### Charging:

Use the USB cable to connect the USB port beneath the tail light to the charger with USB (DC 5V) port. When it's connected, the two indicator lights in the middle of the tail light would flash red (no such indicator under normal standby state) and green when the charging is done. The electricity of the charger is suggested to be > 1A and the charging time about 3.5h.

#### Factory Reset:

Hold "□" till the outline light shows white, and about 20 seconds later, the white light would automatically fade away and the product is reset.

### V. Precautions

#### Temperature

The safety helmet would be damaged under/over 150 °F (65.6 °C). Under hot weather, if the helmet is put in dark vehicle or storage bag, its temperature would be even higher. Heat would incur irregular misshaping to the surface of the helmet, like bubbling or pits. If this happens, please discard this helmet immediately and replace it with a new one. To insure a proper use of this helmet, please carefully read this Instruction before use so as to get to know the features, performance, wearing, maintenance and other aspects of the product.

#### Safety precautions

This helmet is designed to burden damages and injuries from external impact. Although such injury may seem minor, it could damage the helmet. If the helmet is damaged from falling or other causes, please discard the helmet and replace it with a new one. Some accidents are unavoidable for whatever safety helmet and the damaging degree may differ from the impacting; even at a slow speed, severe head injuries or life threatening damages may occur. So please make sure that you've completely and carefully read this Instruction and have arranged all possible protections before riding the bike, scooter or wearing the roller skates.

#### Speaker usage instructions

This product is equipped with Bluetooth speakers, and taking calls during riding may distract the user's attention, so it is suggested that distracting functions like calls and voices be used after the bike is stopped; listening to music during riding may affect user's attention to surrounding sounds, which may bring potential safety hazards, so it is suggested that the volume be lowered.

#### Warnings

This safety helmet is specially designed for bikes, so please don't use it on other mobile vehicles, like motor cars or motor bikes. No safety helmet could completely avoid all unpredicted impacting, but for the best protection effect, the size of the helmet must be proper and the buckle must be tightly buckled. Unless advised by the manufacturer, please refrain from modify or remove any part of the helmet. Children should refrain from using during climbing or other activities, in case of getting trapped or entangled from wearing this helmet.

#### Water warnings

This product is only resistant to short period rainfall, so to avoid any malfunctions, please try to avoid riding during raining.

### VI. Trouble-shooting of electronic functions

During use or after impact (without misshaping or cracking), if the following functions go wrong, please follow the steps to fix them; If failed, please contact the after-sale service center.

#### Malfunctions

1. Unable to get started up
2. When starting up, only heard the start up notification sound but no indication of flashing outline lights
3. After start up, it automatically powers off after a short period of use (maybe the battery is low)
4. After unplugging the charging cable, the charging light is still on and rebooting could not fix it.

5. Start up is normal, but the speaker has no notification sound or has just single tone or noises.

#### Trouble shooting steps

1. Charging for 1 to 2 hours
2. Check the tail light, main control (within the brim) and the inner side of two speakers to see whether there're clear cracks, if does, please manually push it in.
3. Factory reset, hold "□" till the outline light shows white, and about 20 seconds later, the white light would automatically fade away and the product is reset. And then start it up, if the trouble is not fixed, please contact the after sales center.

### VII. Appendix Technical specifications:

Bluetooth:  
Bluetooth distance: Max 10m  
Speaker: Stereo 2\*0.5W  
Mic: -39dB microphone  
Tail light: 8 +6 color LED  
Buttons: three buttons, start up (play, pause, power off), volume + (next song), volume - (previous song)

Charging port: MicroUSB  
Electricity parameter: DC 5V/0.5A  
Battery capacity: 380mAh (1.4WH)  
Charging time: 1.5h  
Battery life: >10h  
Standby duration: >180 days  
Product size: 285\*230\*150  
Product weight: 279g±5%

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection

against harmful interference in a residential installation. This equipment generates, uses and can radiate

radio frequency energy and, if not installed and used in accordance with the instructions, may cause

harmful interference to radio communications. However, there is no guarantee that interference will not

occur in a particular installation. If this equipment does cause harmful interference to radio or television

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is

connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## After-Sales Service Warranty Card

#### After-Sales Information:

Thank you for purchasing LIVALL product, please read the following instructions for better service

1. The warranty time is 1 year after purchase. Any quality problem can be maintained free or it can be replaced within 3 months after purchase if re-sale is available.

2. Damages caused by the following reasons are not included in the scope of free warranty:

Exceeding the specified warranty period;

Damages caused by unsuitable operation;

Damages caused by user removing or repairing it by themselves as well as other man-made damages.

3. This warranty card is the important certificate for the warranty service provided to the end user, please keep it well. The card should be taken along with the product to the manufacturer when the maintenance is required.

4. Our company reserves the rights to modification and explanation for above terms and conditions.

Please visit [www.livall.com](http://www.livall.com) for more information.

User Name: \_\_\_\_\_

Tel.: \_\_\_\_\_

ID No.: \_\_\_\_\_

Home Address: \_\_\_\_\_

Seller: \_\_\_\_\_

Purchase Date: \_\_\_\_\_

Maintenance Record: \_\_\_\_\_



Note: This form should be completed in real details, otherwise, it would be invalid.