


正面

<div>Journey Bluetooth® Speaker</div> <div><div>FCC ID:2AGR4-3977B</div><div>User Manual</div><div>IC:21530-3977B</div><div>BC</div></div>	<div><div><div>Specification</div><div>Bluetooth Specifications: Bluetooth® version 2.1+EDR Support profile: HSP, HFP, A2DP, AVCTP Transmission distance: up to 10 m (This may vary based on environmental factors or the type of Bluetooth® device being used) Built-in battery: Lithium Battery 2000mAh USB Recharge voltage: 5V</div><div>Frequency Response: 20-2000Hz Signal to Noise Ratio (SNR): ≥80dB</div></div><div><div>General Functions</div><div></div></div></div>	<div><div><div>1. Power Button: Press and hold the power button to control the power of the speaker.</div><div>2. Play/Pause Button: Press the Play/Pause button once to pause the music, press again to play.</div><div>3. Vol + / Next Track: Press and hold the + button to increase the volume. Press once for the next track.</div><div>4. Vol - / Previous Track: Press and hold the – button to reduce the volume. Press once for the previous track.</div><div>5. Light Bulb Icon: Press the light bulb icon repeatedly to cycle through light options. Continue to press until the desired light option is reached or until the light turns off.</div></div><div><div>Bluetooth Operation</div><div><div>1. Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device.</div><div>2. Turn the speaker on by pressing and holding the On/Off button for several seconds. The indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode. The indicator light will go off if no Bluetooth devices are detected within 5 minutes.</div></div></div></div>	<div><div><div>3."GEMLINE SPKR" will appear on the Bluetooth device list, select "GEMLINE SPKR" to establish pairing. If instructed to enter a PIN code, please enter '0000'.</div><div>4. When you want to play audio from another Bluetooth device, disconnect the speaker from the original device and follow steps 1-3 to re-pair the speaker with a new Bluetooth enabled device.</div></div><div><div>Speakerphone Operation</div><div><div>1. If you receive a call during Bluetooth mode, answer the incoming call directly on your paired phone. The audio will transmit through the speaker for hands-free use.</div><div>2. To end the call, simply hang up directly on your paired phone.</div></div></div><div><div>AUX Playback Operation</div><div><div>1. Turn on the speaker.</div><div>2. Connect the speaker to a smartphone, audio device, or laptop with the 3.5mm AUX cable (not included).</div><div>3. The volume, play/pause, and next/previous song button</div></div></div></div>
--	---	---	--

1

2

3

4

反面

can only be adjusted on the device that is connected through the 3.5mm AUX cable.


Charging the Speaker


1. When the battery is low, please charge via the included USB cable. The charging time is approximately 3 hours and provides up to 4-6 hours of continuous operation.


2. The LED indicator light will be red during charging and will turn off once it is fully charged.

3. Make sure to charge the speaker for at least 4 hours before using it for the first time.

Light Function

1. Press the  button once to turn on the multi-color light mode.

2. Press the  button twice to turn on the night light mode.

2. Press the  button three times to turn off the light.

Warning

1. Do not disassemble, repair, or modify the speaker.

2. Do not place product in or near fire to avoid danger, as it uses a lithium battery.

3. Avoid storage at extreme temperatures, this can shorten the battery life and may affect the speaker.

4. Keep the speaker dry and do not store the speaker in damp areas to avoid damage to the speaker.

5. Avoid dropping the speaker as it may damage the speaker.

Kind Reminder

1. To prolong the speaker's life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.

2. When an error occurs with the speaker, please turn off the speaker and restart it to troubleshoot.

3. When the speaker's power is low, the Bluetooth range may be affected. Please charge the speaker to avoid disruptions during use.

Problem	Troubleshooting Method
Unable to pair the speaker with a mobile device	<div><div>1. Inspect whether the speaker is searching for a Bluetooth enabled device to connect to. If not, restart the speaker.</div><div>2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices.</div><div>3. The power of the battery is insufficient, please recharge the speaker.</div></div>
The music stops from time to time	<div><div>1. Inspect the distance between the speaker and the Bluetooth enabled device, it may exceed the Bluetooth transmission range.</div><div>2. Inspect if there is an obstacle between the speaker and the Bluetooth enabled device.</div><div>3. The power of the battery is insufficient, please recharge the speaker.</div></div>

Problem	Troubleshooting Method
The sound is low or distorted	<div><div>1. Inspect the volume of the connected speaker or Bluetooth enabled device and adjust the volume as needed.</div><div>2. The power of the battery is insufficient, please recharge the speaker.</div></div>
The Bluetooth indicator light remains OFF	<div><div>1. The power of the battery is insufficient, please recharge the speaker.</div><div>2. Restart the speaker.</div></div>

Packing List

• Bluetooth® Speaker

• USB Charging Cable

• User Manual

• Gift Box

5

6

7

8

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.