


<div>Craze Sport <i>Bluetooth</i>[®] Ear Buds</div> <div>IC :21530-3774B FCC ID: 2AGR4-3774B</div> <div>BC</div> <div>Instruction Manual</div> <div>Craze Sport BT[®] Ear Buds 3774B</div>	<div>OVERVIEW</div> <div></div> <div>1. Volume +, Previous Track 2. Volume -, Next Track 3. LED Indicator Light 4. Power On/Off, Play/Pause, Hands-Free 5. Micro USB Charging Port 6. Microphone</div>	<div>BLUETOOTH[®] OPERATION</div> <div>1. Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device. 2. Turn the earbuds on by pressing the Power On/Of, Play/Pause, Hands-Free button for approximately 7 seconds until the LED indicator light begins to flash. The LED indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode. The indicator light will go off if no Bluetooth devices are detected within 3 minutes. 3. "GEMLINE EB" will appear on the Bluetooth device list, select "GEMLINE EB" to establish pairing. If instructed to enter a PIN code, please enter '0000'. 4. The LED indicator light will flash slowly to indicate successful pairing. 5. When you want to play audio from another Bluetooth device, disconnect the earbuds from the original device and follow steps 1-3 to re-pair the earbuds with a new Bluetooth enabled device.</div>	<div>BUTTON CONTROL</div> <div><ul style="list-style-type: none">• Power On/Off: Press and hold Power, Play/Pause, Hands-Free button for approximately 4 seconds• Play/Pause: Press the Power, Play/Pause, Hands-Free button once• Volume +, Previous Track (press once to increase volume, press and hold for previous track)• Volume -, Next Track (press once to decrease volume, press and hold for next track)• Hands-free Phone Use: Press On/Off, Play/Pause, Hands-Free button once to answer an incoming call. While on a call, press On/Off, Play/Pause, Hands-Free button once to end the call.• Redial last call: Press On/Off, Play/Pause, Hands-Free button twice to redial last number dialed on the connected mobile device• Reject a call: Press and hold On/Off, Play/Pause, Hands-Free button for 2 seconds to reject an incoming phone call</div>
Front Cover	page 02	page 03	page 04

<div>SPECIFICATION</div> <div>Bluetooth specifications: Bluetooth[®] version 4.0 + EDR, Bluetooth V1.2, V1.6 Support profile: A2DP / HFP / HSP / AVRCP Transmission distance: up to 10 m (This may vary based on environmental factors or the type of Bluetooth[®] device being used) Built-in battery:120mAh Lithium battery x 2 USB Recharge voltage: 5V Output power: 20mW Frequency Response: 2.4-2.48GH</div> <div>PACKING LIST</div> <div><ul style="list-style-type: none">• Bluetooth[®] Earbuds• Silicone Earbud Covers• USB Charging Cable• Travel Case• User Manual</div>	<div>CHARGING THE EARBUDS</div> <div>1. When the battery is low, please charge via the included USB cable. The charging time is approximately 2 hours and provides up to 5 hours of continuous operation. 2. The LED indicator light will be red during charging and the red light will turn off once it is fully charged. NOTE: You cannot use the earbuds while they are charging.</div> <div>WARNING</div> <div>1. Do not disassemble, repair, or modify the earbuds. 2. Do not place product in or near fire to avoid danger, as it uses a lithium battery. 3. Avoid storage at extreme temperatures, this can shorten the battery life and may affect the earbuds. 4. Keep the earbuds dry and do not store the earbuds in damp areas to avoid damage to the earbuds. 5. Avoid dropping the earbuds as it may cause damage the product.</div>	<div>KIND REMINDER</div> <div>1. To prolong the earbuds life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time. 2. When an error occurs with the earbuds, please turn off the earbuds and restart it to troubleshoot. 3. When the earbud power is low, the Bluetooth range may be affected. Please charge the earbuds to avoid disruptions during use.</div> <table><tr><th>PROBLEM</th><th>TROUBLESHOOTING METHOD</th></tr><tr><td>Unable to pair the earbuds with a mobile device</td><td>1. Inspect whether the earbuds are searching for a Bluetooth enabled device to connect to. If not, restart the earbuds. 2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. 3. The power of the battery is insufficient, please recharge the earbuds.</td></tr></table>	PROBLEM	TROUBLESHOOTING METHOD	Unable to pair the earbuds with a mobile device	1. Inspect whether the earbuds are searching for a Bluetooth enabled device to connect to. If not, restart the earbuds. 2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. 3. The power of the battery is insufficient, please recharge the earbuds.	<table><tr><th>PROBLEM</th><th>TROUBLESHOOTING METHOD</th></tr><tr><td>The music stops from time to time</td><td>1. Inspect the distance between the earbuds and the Bluetooth enabled device, it may exceed the Bluetooth transmission range. 2. Inspect if there is an obstacle between the earbuds and the Bluetooth enabled device. 3. The power of the battery is insufficient, please recharge the earbuds.</td></tr><tr><td>The sound is low or distorted</td><td>1. Inspect the volume of the connected earbuds or Bluetooth enabled device and adjust the volume as needed. 2. The power of the battery is insufficient, please recharge the earbuds.</td></tr><tr><td>The Bluetooth indicator light remains OFF</td><td>1. The power of the battery is insufficient, please recharge the earbuds. 2. Restart the earbuds.</td></tr></table> <div>The <i>Bluetooth</i>[®] word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Gem Group is under license. Other trademarks and trade names are those of their respective owners.</div>	PROBLEM	TROUBLESHOOTING METHOD	The music stops from time to time	1. Inspect the distance between the earbuds and the Bluetooth enabled device, it may exceed the Bluetooth transmission range. 2. Inspect if there is an obstacle between the earbuds and the Bluetooth enabled device. 3. The power of the battery is insufficient, please recharge the earbuds.	The sound is low or distorted	1. Inspect the volume of the connected earbuds or Bluetooth enabled device and adjust the volume as needed. 2. The power of the battery is insufficient, please recharge the earbuds.	The Bluetooth indicator light remains OFF	1. The power of the battery is insufficient, please recharge the earbuds. 2. Restart the earbuds.
PROBLEM	TROUBLESHOOTING METHOD														
Unable to pair the earbuds with a mobile device	1. Inspect whether the earbuds are searching for a Bluetooth enabled device to connect to. If not, restart the earbuds. 2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. 3. The power of the battery is insufficient, please recharge the earbuds.														
PROBLEM	TROUBLESHOOTING METHOD														
The music stops from time to time	1. Inspect the distance between the earbuds and the Bluetooth enabled device, it may exceed the Bluetooth transmission range. 2. Inspect if there is an obstacle between the earbuds and the Bluetooth enabled device. 3. The power of the battery is insufficient, please recharge the earbuds.														
The sound is low or distorted	1. Inspect the volume of the connected earbuds or Bluetooth enabled device and adjust the volume as needed. 2. The power of the battery is insufficient, please recharge the earbuds.														
The Bluetooth indicator light remains OFF	1. The power of the battery is insufficient, please recharge the earbuds. 2. Restart the earbuds.														
Back Cover	page 05	page 06	page 07												

#3774_Craze Sport Bluetooth[®] Ear Buds Instructions

Please read the following clearly before you do the printing of all kind of our instruction sheets.

- 1) The folded size should be 3"W x 3"H.
- 2) Please exactly follow all the trim marks and fold marks.
- 3) Please exactly follow the page in proper order.(The page numbers do not need to print.)
- 4) The color of this kind instruction is : 1C(Black)
- 5) Use 90gsm gloss art paper for bulk production.
- 6) 8PP Book Binding with saddle stitching.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.