




## R20A Door Phone User Manual



# About this manual

Thank you for choosing Akuvox's R20A door phone. This manual is intended for end users, who need to use and configure the door phone. It provides an overview of the most essential functions and features of the product, whose firmware version is 20.0.1.102.

## FCC Warning

Any Changes expressly or modifications not approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference,
- and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Contact us

For more information about the product, please visit us at [www.akuvox.com](http://www.akuvox.com) or feel free to contact us by

Sales email: [sales@akuvox.com](mailto:sales@akuvox.com)

Technical support email: [techsupport@akuvox.com](mailto:techsupport@akuvox.com)

Telephone: +86-592-2133061 ext.7694/8162

**We highly appreciate your feedback about our products.**

# Content

<b>1. Product Overview</b>	<b>- 5 -</b>
1.1 Product Description	- 5 -
1.2 Connector Introduction	- 5 -
<b>2. Daily Use</b>	<b>- 6 -</b>
2.1 Making a Call	- 6 -
2.2 Receiving a Call	- 6 -
2.3 Unlock by RF Card	- 6 -
<b>3. Configuration</b>	<b>- 7 -</b>
3.1 Web Login	- 7 -
3.1.1. Obtaining IP Address	- 7 -
3.1.2. Access the Device Website	- 7 -
3.2 Basic Setting	- 8 -
3.2.1 Time/Lang	- 8 -
3.2.2 Voice	- 8 -
3.3 IP Address Setting	- 9 -
3.3.1 DHCP	- 9 -
3.3.2 Static IP	- 9 -
3.4 Call Setting	- 10 -
3.4.1 No Answer Call	- 10 -
3.4.2 Push Button	- 10 -
3.5 Card Setting	- 11 -
3.5.1 Import/Export Card Data	- 11 -
3.5.2 Obtain and Add Card	- 11 -
3.5.3 Door card Management	- 11 -

# 1. Product Overview

## 1.1 Product Description

Akuvox R20A is a SIP-compliant, hands-free one button video outdoor phone. It can be connected with your Akuvox IP Phone for remote unlock control and monitor. Users can operate the indoor phone to communicate with visitors via voice and video, and use RF card to unlock the door. It's applicable in villas, office and so on

## 1.2 Connector Introduction

**Ethernet(POE):** Ethernet(POE) connector which can provide both power and network connection.



**12V/GND:** External power supply terminal if POE is not available.

**RS485A/B:** RS485 terminal.

**DOORA/B:** Trigger signal input terminal.

**RelayA/B (NO/NC):** Relay control terminal.

**Note:** 12V/1A dc from LPS (power cord  $\leq 3m$ ) or POE.



## 2. Daily Use

### 2.1 Making a Call


Press the call button to call out the predefined number or IP address and if LED turns green, it means the call has been answered.

### 2.2 Receiving a Call

User can use IP phone or indoor monitor to call R20A and R20A will answer it automatically by default. If user disable auto answer, pressing button to answer incoming call.

### 2.3 Unlock by RF Card

Place the predefined RF card on the card sensor area. The door phone will announce 'the door is now opened' and open the door 13.56MHz and 125KHz RF card is supported by R20A.



## 3. Configuration

### 3.1 Web Login

#### 3.1.1. Obtaining IP Address


The Akuvox R20A uses DHCP IP address by default. If IP address is unknown, press and hold call button for a short period of time(about 5s) after LED light turns blue, R20A will announce its IP continuously. Press once again to stop.

#### 3.1.2. Access the Device Website

Open a Web Browser, access the corresponding IP address. Then, enter the default user name and password to login. The default administrator User Name and Password are shown below:

User name: **admin**

Password: **admin**



The screenshot shows a web browser window with a title bar that says "Login". The page has a light gray background with a subtle grid pattern. In the center, there are two labels: "User Name" and "Password". To the right of "User Name" is a text input field containing the text "admin". To the right of "Password" is a password input field with ten black dots. Below the password field is a checkbox that is checked, with the text "Remember Username/Password" next to it. At the bottom right of the form is a blue button with the text "Login".

## 3.2 Basic Setting

### 3.2.1 Time/Lang

Go to Phone->Time/Lang to select local Time Zone for NTP server.

### 3.2.2 Voice

Go to Phone->Voice, to configure volume and upload tone file.

(1)**Mic Volume:** To configure Microphone volume.


(2)**Speaker Volume:** To configure Speaker volume.

(3)**Open Door Warning:** Disable it, you will not hear the prompt voice when the door is opened.

(4)**IP Announcement:** To setup the IP Announcement active time. Over the configured value, the phone will not announce its IP address, even you hold the button.

(5)**RingBack Upload:** To upload the ring back tone you need.


(6)**Opendoor Tone Upload:** To upload the Opendoor tone you need.



The screenshot shows the 'Time/Lang' configuration page with the 'NTP' section active. It contains the following fields:

NTP	
Time Zone	0 GMT
Primary Server	0.pool.ntp.org
Secondary Server	1.pool.ntp.org
Update Interval	3600 (>= 3600s)
System Time	08:31:52

At the bottom, there are 'Submit' and 'Cancel' buttons.



The screenshot shows the 'Voice' configuration page with several sections:

- Mic Volume:** A slider for 'Mic Volume' set to 8, with a range of (1~15).
- Speaker Volume:** A slider for 'Speaker Volume' set to 8, with a range of (1~15).
- Open Door Warning:** A dropdown menu for 'Open Door Warning' set to 'Enabled'.
- IP Announcement:** A field for 'IP Announcement active time' set to 0, with a range of (0~180).
- RingBack Upload:** A section with a search bar, 'Upload', and 'Delete' buttons. Below it, it says 'File Format: wav, size: < 200KB, samplerate: 16000, Bits: 16'.
- Opendoor Tone Upload:** A section with a search bar, 'Upload', and 'Delete' buttons.



## 3.3 IP Address Setting


Go to Network->Basic, dynamically or statically to obtain IP address.

### 3.3.1 DHCP

R20A uses DHCP by default, it will get IP address, Subnet Mask, Default Gateway and DNS server address from DHCP server automatically.

### 3.3.2 Static IP

If selected, you could manually set IP address, Subnet Mask, Default Gateway and DNS server.



The image shows a 'Network-Basic' configuration window with a 'LAN Port' tab. Under the 'LAN Port' section, there are two radio buttons: 'DHCP' and 'Static IP'. The 'Static IP' option is selected. Below the radio buttons, there are five text input fields: 'IP Address' (192.168.1.118), 'Subnet Mask' (255.255.255.0), 'Default Gateway' (192.168.1.1), 'LAN DNS1' (192.168.1.1), and 'LAN DNS2' (empty). At the bottom of the window, there are two buttons: 'Submit' and 'Cancel'.

LAN Port	
<input type="radio"/> DHCP	
<input checked="" type="radio"/> Static IP	
IP Address	192.168.1.118
Subnet Mask	255.255.255.0
Default Gateway	192.168.1.1
LAN DNS1	192.168.1.1
LAN DNS2	
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

## 3.4 Call Setting

Go to Intercom->Basic, to configure basic call setting.

### 3.4.1 No Answer Call

Enable it, if there is no answer from push button number over 60s (default value), R20A will call predefined 'No Answer Call' number.

### 3.4.2 Push Button

(1)**Push Button:**To configure the destination number or IP you want to contact with. If you would like to call multiple numbers at same time, divide them by semicolon.

(2)**No Answer Call 1&2:**To setup one or two no answer call number.

The screenshot displays the 'Intercom-Basic' configuration window. It is divided into two main sections: 'Basic' and 'Push Button'.

**Basic Section:**

- Select Account:** A dropdown menu with 'Auto' selected.
- No Answer Call:** A dropdown menu with 'Disabled' selected.

**Push Button Section:**

Key	Number
Push Button	192.168.35.57
No Answer Call1	
No Answer Call2	

## 3.5 Card Setting

Go to Intercom -> Card setting, to manage card access system.

### 3.5.1 Import/Export Card Data

R20A supports import or Export the card data file, which is convenient for administrator to deal with a large number of cards.

### 3.5.2 Obtain and Add Card

- ① Switch card status to 'Card Issuing' and click 'Apply';
- ② Place card on the card reader area and click 'Obtain';
- ③ Name card and choose which door you want to open;
- ④ Click 'Add' to add it into list.

### 3.5.3 Door card Management

Valid card information will be shown in the list. Administrator could delete one card's access permission or empty all the list.

**Card Setting**

**Import/Export Card Data(.xml)**

Search... Import Export

**Card Status**

Card Status Card Issuing Apply

**Card Setting**

IC Key DoorNum 1 ▾

IC Key Name

IC Key Code Obtain Add

**Door Card Management**

Index	Name	Code	Door	
1				<input type="checkbox"/>
2				<input type="checkbox"/>
3				<input type="checkbox"/>
4				<input type="checkbox"/>
5				<input type="checkbox"/>
6				<input type="checkbox"/>
7				<input type="checkbox"/>
8				<input type="checkbox"/>
9				<input type="checkbox"/>
10				<input type="checkbox"/>

Page 1 ▾ Prev Next Delete Delete All