

# Instructions

Open the package, remove the remote control, use the special cross screwdriver to open the remote controller back cover, install the 2\* 1.5V battery, close the cover and turn the screw

First, open the first step of the remote control car cover, open the battery cover with a special cross screwdriver, put 3\* 1.5V batteries in the box, close the lid, turn the screws tightly, turn on the power switch and put the car on the relatively smooth ground

Pick up the remote key according to the forward key when the car forward according to the key, the car to the back. If you need to deal with the vehicles to turn left in the remote control handle to move the handle. At the same time, in the business at the same time, the car can move forward, turn left, if the car needs for rights at the same time pushing the car to the front the handle to the right right, note that the remote control car products to the needs of the normal operation of the corresponding frequency, such as remote 49MHz must be 49MHz, this is equivalent to normal operation.

## **FCC Warning:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.