



- | | |
|--------------------------------------|------------------------------|
| 1.LCD screen | 9.Line input level control |
| 2.MP3 player control | 10.Volume control |
| MODE: USB/SD/FM/BT convertor | 11.Treble control |
| ◀◀ : Previous songs | 12.Bass control |
| ▶▶ : Next songs | 13.XLR microphone input |
| ↺ : Repeat all / Random / Repeat one | 14.6.35 microphone input |
| ▶ : Play/Pause | 15.RCA phone(R+L) line input |
| 3.SD card input | 16.6.35mm line output |
| 4.USB input | 17.XLR line input |
| 5.Clip LED indicator | 18.XLR line output |
| 6.Power LED indicator | 19.Speaker out 8 Ohm |
| 7. Mic 1 input level control | 20.Fused IEC mains inlet |
| 8. Mic 2 input level control | 21.Main power switch |



INSTRUCTION MANUAL

BJS-154BT



OPERATION.....	1
GENERAL USE INSTRUCTIONS.....	2
SPECIFICATIONS.....	2
CONTROLS AND CONNECTIONS.....	3



- **CAUTION, TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK)**
- **THIS PRODUCT MUST BE EARTHED**
- **NO USER-SERVICEABLE PARTS INSIDE, REFER SERVICING TO QUALIFIED SERVICE PERSONNEL**

OPERATION

1. Prior to switching on, turn volume down to minimum.
2. Connect the audio source to the appropriate Input socket.
3. Another Speaker can be connected to the output socket, so that several boxes can be daisy chained.
4. Connect to the mains supply.
5. Switch on the audio source, followed by the active speaker.
6. Set the volume with the applicable control.
7. Adjust the bass + treble.

- Do not overload the box to avoid damage to the speakers.
- Do not place an open fire (candles etc) on top or next to the box - FIRE HAZARD
- Only connect to an **earthed** mains outlet of 110Vac/60Hz.
- For indoor use only. If the box is used outdoors, you need to make sure that no humidity can enter the box.
- When not in use, unplug the unit from the mains.
- Unplug the unit from the mains prior to checking or replacing the fuse.
- Make sure that the box is placed on a stable, strong surface.
- The boxes can be hung. Use only strong and approved mounting material. During the mounting, make sure that nobody is standing below the mounting area.
- Do not place liquids on the box and protect it against humidity. Humidity can shorten the life time considerably.
- Only use suitable means of transportation if you want to move the box - BEWARE OF YOUR BACK !!
- Always unplug the unit during a thunderstorm or when it is not in use.
- If the unit has not been used for a long period of time, condensation can occur inside the housing. Please let the unit reach room temperature prior to use.
- Never try to repair the unit yourself. It does not contain any user serviceable parts.
- Run the mains lead in such a way that nobody can fall over it and nothing can be put in it.
- Set the unit to the lowest volume prior to switching it on.
- Keep the unit out of the reach of children.

SPECIFICATIONS

	BJS-154BT
Woofer	15"
Power	2300 W
Impedance	8 ohm
Frequency Range	40 Hz-18 KHz(-10dB)
Sensitivity	98dB (+/- 2dB)
Connector	XLR/6.35mm/RCA
Mic Input Level	≤15mV
Line Input/Output Level	≥250mV

