

User Manual
RLTP169 -BLACK

1. Your phone

Standby mode, the function of shortcut keys

Up navigation key: direct access to Shortcuts ,you can set its function as following: select Menu→Settings →Phone settings→ Dedicated keys→Up,then press the left navigation key to edit interface to chose the function you want, then press OK.

Down navigation key: direct access to Calculator, you can set its function as following: select Menu→Settings →Phone settings→ Dedicated keys→Down, then press the left navigation key to edit interface to chose the function you want, then press OK.

key: long press changing the mode: general mode / silent mode.

2. Function menu Description

1) Phonebook

The phone offers two memory banks: the SIM card and mobile phone, the phone's storage capacity is 200, the storage capacity of the SIM card is decided by the type of SIM card.

- Enter a number in the standby mode, press the left key to enter the edit save the interface.
- If you saved to the SIM card, the user can edit the name, telephone number. .
- If you are saved to the "mobile phone", the user can edit the name, telephone number.

1.1 Contacts

select any record in the phone book list will have the following options:

- You can press the answer key to call this number
- View: View detailed information on the record.
- Add new contact: add a new record to Phone or SIM card, the user can edit the name and telephone number.
- Send text message: send a message to the record. .
- Edit: Edit the record.
- Delete: delete the record.
- Copy: copy in the same or a different memory and the option to save to the file management.
- Move: move to Phone or SIM card memory.
- Add to Speed Dial: add the number to speed dial list.

1.2 Add new contact

add a new record to Phone or SIM card, the user can edit the name and telephone number.

1.3 Speed dial

the user can chose the Status on or off and in Set numbers user can edit the speed dial number list, the number can add from the phonebook records or direct insert a new telephone number.

1.4 Phonebook settings

It will have the following options after entering:

- 1、Delete all contacts: Delete all contacts from the SIM card or phone;
- 2、Copy contacts: Copy all contacts from the SIM card or phone.
- 3、Move contacts: Move all contacts from the SIM card or phone.
- 4、Memory status: The mobile phone store state.

2 Messaging

The phone supports the sending messages (referred to as SMS). The message is first sent to the network SMS center, and then network to the destination user again to send. If the destination user is not on, or can not receive, the network will temporarily save this messages, retention period is the decision by sending the user's settings and service operators.

If the text messages is not full, it is directly stored in the SIM card or phone (user settings). If the text messages capacity is full, you can not receive new messages, the top there will be a blinking icon in the main screen, and prompts the SMS storage is full, delete some text messages, inbox free space, the phone can continue to receive new SMS.

2.1 Write Message

- In the standby screen, select Menu →message → write message .to enter the edit SMS interface, the following: text editing, press the left soft key "Options", you can choose to send, save, using a template, edit, language, Association options. If you want to delete the contents written by the navigation key to move the cursor to delete the contents of the back, and then press the power button to clear, long press the right soft key to delete all content. When finished, send a message, press the left soft key "OK".
- Send to: sending a number of interface, direct enter the number you want to send from contacts, call history, add a number. Selection is complete, press the left soft key "OK" to send a message. Select a recipient the option to do the following:

- Send: send a message to the corresponding recipient.
- Edit recipient: you can edit the recipient's number.
- Remove recipient: delete the recipient.
- Remove all recipients: delete all the recipients.
- Save: save the message to Drafts.
- Input method: set the language need to edit.
- Advanced: you can chose Insert number or name from phonebook.
- Save: save the message to Drafts.

2.2 Inbox

In standby screen, select Menu → Messaging → Inbox, you can view the SIM card inbox SMS has been received, as the following options:

- View: You can view a received message.
- Reply: You can reply SMS to the sender.
- Call sender: You can call the sender.
- Forward: to forward this message to others.
- Delete: Delete the current SMS.
- Delete All: Delete all SMS in the Inbox.
- Save to phonebook: Add the number in the telephone directory.

2.3 Drafts

Into the Drafts, you can view the message stored in the Drafts, and can conduct the following operations: View, send, edit, delete, delete all.

2.4 Outbox

Into the outbox, you can view all the outbox message here and you also can handle to save SMS, and can do the following:

view, resend, edit, delete, delete all.

2.5 Sent messages

Into the Sent messages, you can view the message stored in the Sent messages, and has the following options:

View, forward, delete, delete all.

2.6 Advance setting

- SMS settings
- Profile settings
 - SMSC address: setting the number of the SMS center
- Common settings
 - Delivery report: setting the switch of SMS report
 - Reply path: setting the switch of reply path
 - Save sent message: setting the switch of the storage of sent messages.
- Memory status: The memory status of SIM card and the phone are visible.
- Voicemail server

Each SIM card can be set two voice mail number in the settings, press the "1" key for a longtime to make available to listen to dial voice mail number voice messages. This function should be supported by the network operator.

3 Call center

3.1 Call history

- Missed call: Enter the missed call, you can view the list of missed

calls.

- Dialed calls: To enter the dialed calls, you can view the dialed calls list.
- Received calls: To enter the received phone, you can view the list of received phone.
- Delete call logs: You can choose to delete all the call records.
- Call timers: You can see last call time, dialled calls time and received calls time.

3.2 Call settings

- Advanced setting:

Blacklist: You can choose to reject the number calls in blacklist or not, and edit the blacklist number.

Auto redial: Able to open or close the function of auto redial. When it's on, the phone shall redial automatically after you failed dialing.

Call time reminder: The call time will display when calling if it's on.

Answer mode: Able to set answer the call by pressing any key.

4 FM radio

This phone has FM radio function, can be used to listen to the radio.

At the FM interface, you can press the up or down button to change the channels.

Press *# to make the voice up or down

Press 5 to switch on or off the FM.

Press the left key, you can find:

- Channel list: Edit the channel name and frequency.
- Manual input: View the list of channels.

- Auto search: the automatic search radio stations and save the search channel to channel list.
- Settings: you can set the recording format and quality.

Note: FM reception quality and quantity depend on the specific location.

5 Multimedia

5.1 Audio player

In the music player interface, the up navigation key or #key (increase volume), the down navigation key or *key(decrease volume), 4key key(foward), 6key (next),5key (stop or play);

Music player interface, press "Options" to enter the list of all the songs interface. Options to play music files in the list, update playlists and more.

In Options, enter the settings menu:

- List auto gen: the switch settings you can make it on or off.
- Repeat: You can set the repeat playback of music:
Off, one or all.
- Shuffle: set the playback order, respectively, can be set to open (Random Play) and off (the current list of the order of play).
- Background play: select on or off, the mobile phone in the other user interface (except for video player, camera or recording menu interface) can also play music.

5.2 Image viewer

You can view all the images which store at the memory card.

5.3 Video player

You can play video which store at the memory card.

5.4 Sound recorder

New record: Start recording.

Play: Play a selected record.

List: Enter the list of recordings.

6 Settings

Main menu, select "Settings", you can set up your phone menu options.

6.1 Profile

This phone provides a General mode, silent Mode, Meeting mode and Outdoor mode.

6.1.1 General mode

For each profile, you can enter the "Active / customize" to operate the following options:

- Alert type: can set to ring, vibrate only or vibrate and ring
- Ring type : can set to repeat or beep once
- Ring tone: Set a ringing tone.
- Ring tone volume: press up or down key to set the ring volume.
- Message: Set the Message tone.
- Message volume: press up or down key to set the ring volume of message
- Keypad: You can select the silent, click, tone, human voice tone.
- Key tone volume: press up or down key to set the ring volume of keytone
- System alert: Set system alert on or off.

6.1.2 silent mode

Activate silent

6.1.3 meeting mode

Like the General model

6.1.4 outdoor mode

Like the General model

6.2 Phone settings

- Time and date: the date and time set corresponding.
- Language: set the phone menu display language.
- Pref.input method: You can set the editing language, Association options, the default input method
- Dedicated keys : you can set shortcuts for up and down keys here.
- Screen auto lock : you can make it off or set 15 seconds or 30 seconds or 1min or 5 mins.
- Wallpaper : you can change the wallpaper via photos stored in the memory card.
- LCD backlight : set the brightness and times

6.3 Security Settings

6.3.1 SIM Security

You can set the phone's menu security options, in order to avoid the illegal use of SIM card. PIN code to prevent the illegal use of your SIM card. If the current PIN code has been closed, select Open to open the PIN code protection, the next boot will ask for your PIN code; if the current PIN code is already open, choose to turn off the PIN code protection can be turned off, select Security Settings -> SIM card lock -> Change

password -> PIN code, you can set up a new PIN code, please follow the prompts in order to enter the old PIN, new PIN code and repeat the new PIN code.

- PIN lock: turn on or turn off the SIM card lock. Need to enter the PIN code.
- Change PIN: Change PIN.
- Change PIN2: Change PIN2.

6.4.2 Phone security

The phone lock can prevent your phone from unauthorized use.

Select the phone lock can open the phone lock password protection, the next boot will ask for your phone lock code; again to enter a password you can turn off the phone lock password protection.

- Change Password: Modify the phone password.

Note: The default phone lock code is 1122, you should change your PIN.

6.5 Restore settings

Use this function to restore factory settings, the preset password is 1122.

7 Organizer

7.1 Fun

You can play games here.

7.2 File manager

Used for a variety of documents and data storage management. The phone memory card can be used for capacity expansion.

- Select the memory card (memory card is inserted), the following options:

- Open: Go to the next level of the folder list interface
- Format: to format the current memory.
- Details: You can view the memory space information.

7.3 Calendar

Press the left soft key to enter the calendar display, the first line shows the year, month, second row shows the week, the middle section shows the specific date of a month. In a calendar interface, press the up navigation key ,date forward one week, press the right navigation key, date forward one day.

- View: see the events on selected day.
- View all:see all the events added in calendar.
- Add event: can be added to the schedule.\
- Delete event:you can chose to delete all events,overdue events or specific period events.
- Jump to date: Enter to find the specified date, it will quickly jump to that date
- Go to today: switch to the current date.

7.4 Alarm

This phone provides five alarm clocks available to users, users may need to be set. Enter the alarm clock editing interface:

- use the 4 or 6 key to select on / off status.
- set the alarm clock time.
- Snooze Time: use 4 or 6 Select the default value or 1-10 minutes.
- Repeat: press the left key to set once, everyday or custom.
- Alarm tone: You can set the alarm tone.

7.5 Calculator

provide users with the calculator function, can add, subtract, multiply, and divide can do the simple calculation.

7.6 Torch

Turn on or off torch.

7.7 Services

See the SIM card service.

8 SOS

- **SOS Switch**

Open or close SOS function here

- **SOS SMS content**

- 1) Edit SOS message of help content.
- 2) Set to send this SOS message or not

- **SOS number**

Can set 5 emergency numbers.

- **Alarm sound**

Turn on or off the alarm sound for help.

9. WARNINGS

9.1 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference

9.2 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

9.3 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of **1.5 cm** must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used

by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.