

编号: Z-PKQG-TC418P-V2

材质: 80g书纸+四色双面印刷+正反印刷

Size: 519 X 445 mm 折后Size: 104 x148 mm



Wireless Audio

Transmitter

Model NO.: BTC-418-P

User Manual	EN
Bedienungsanleitung	DE
Mode d'emploi	FR
Manuale di Istruzioni	IT
Manual de Usuario	ES

IMPORTANT NOTICE

No Sound? Is the indicator on the transmitter a solid/steady **BLUE**? Then it is connected and ready to use. If there's still no sound, please adjust the TV audio output settings as suggested or contact your TV manufacturer for support.

Delay? Ensure your headphone/speaker also supports aptX Low Latency. Non-aptX LL supported headphones/speakers (e.g., Bose, Beats, Sony) will experience a 2-3 second delay. aptX code and will experience a 70-220ms latency (may be noticeable by some users).

Cannot pair? Ensure your Bluetooth headphone/speaker enter pairing mode. (Usually LED on Bluetooth headphones flashes **RED** and **BLUE** alternately or flashes **BLUE** quickly).

Please read this user manual carefully before setting up, and keep this handy for future reference.


Search "Avantree Audikast Plus" on YouTube for step-by-step video guide.



support.avantree.com

What's in the Box?


1. Transmitter - Audikast Plus
2. Micro USB power/data cable
3. Optical audio cable
4. AUX 3.5mm audio cable
5. AUX 3.5mm to RCA audio cable



1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.



1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.




1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.



Any questions? Please visit:
support.avantree.com
(User Manuals, FAQ, Video Tutorials and More)
Email support: support@avantree.com (Response Time: 1 working day)
Live chat: www.avantree.com

Dispose of the packaging and this product in accordance with the latest provisions.




Note: Please make sure that you keep the 3.5mm AUX Jack "vacant" while using the OPTICAL out. (If anything is plugged into the AUX Jack, the transmitter will default to the AUX signal and ignore any OPTICAL input).



English

LED Indication

Status	LED Indicator
Power on	All LED light up for 2 seconds
Pairing	8 flash RED and BLUE alternately
Connected	8 turn solid BLUE
Reconnecting	8 flash BLUE every 2 seconds
Valid optical audio signal	OPT lights up
Invalid optical audio signal	OPT flashes
Valid analogue audio signal	AUX lights up
Invalid analogue audio signal	AUX flashes
Audio Playing on PC	USB lights up



After connecting your audio cable as above, once the VALID audio signal is detected, the "AUX" indicator on the Audikast Plus will light up **SOLID WHITE**, and you should be able to hear your TV/audio source through your headphones. If not:

- 1) Ensure your TV speaker setting is set to "Headset."
- 2) Plug a pair of wired headphones into the headphones jack you're using with the Audikast Plus on TV. See if you can hear anything.
- 3) Turn up the volume and see if it helps.
- 4) Ensure the audio cable is good and fully plugged.

1. Pair and connect to Bluetooth headphone/receiver

Powering up the transmitter
Power on the transmitter using the USB cable provided. Connect 1 to either TV USB port (TV must be ON to provide power) or a 5V/500mA-2A rated USB charger (e.g., your phone charger should work). Then slide the ON/OFF switch to ON. All LED lights will light up for 2 seconds upon powering on.

Enter the transmitter into PAIRING MODE
For first time use, the transmitter will enter pairing mode automatically, the 8 next to 1 will flash **RED** and **BLUE** alternately. For non-first time use, press and hold 2 for 1 second to enter pairing mode.


Enter your headphones/speakers into PAIRING MODE
Please refer to relevant user manual (Usually LED on headphone flash **RED** and **BLUE** alternately or flash **BLUE** quickly).

Connecting
During the pairing process, keep the devices close to each other and wait. Once connected, the 8 next to 2 will turn **SOLID BLUE**.


Reconnect
NO need to manually reconnect the transmitter to your device before each use. The transmitter will automatically reconnect to the last connected device within 5-10 seconds after both devices had been powered on. Alternatively, reboot the transmitter and wait 5-10 seconds for them to reconnect.

If the 8 next to 4 on the transmitter turn solid **BLUE**, it confirms that the connection between the transmitter and headphones is working normally. The next step is to feed the audio from your TV into the transmitter.


After you've connected the transmitter to your TV/audio while following the steps shown in the sections below, if you still cannot hear anything through your headphones, please either adjust your TV audio output setting as suggested or contact your TV manufacturer for support.



1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.




1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.




3.1 TVs with DIGITAL OPTICAL/SPDIF Audio Out

After connecting your optical cable as above, go to your TV audio settings and change your "audio format" to "PCM". Usually, the "OPT" indicator on the Audikast Plus will change to **SOLID WHITE**, and now you should be able to hear your TV/audio source through your headphones. If not:

- 1) Ensure that your TV Speaker is set to "External Speaker."
- 2) Ensure that your TV "DOLBY/DTS" is set to "OFF" (not auto).
- 3) Ensure the audio cable is good and fully plugged.




3.2 TV with DIGITAL OPTICAL/SPDIF Audio Out



Deutsch

LED Indication

Status	LED Indicator
Power on	All LED light up for 2 seconds
Pairing	8 flash RED and BLUE alternately
Connected	8 turn solid BLUE
Reconnecting	8 flash BLUE every 2 seconds
Valid optical audio signal	OPT lights up
Invalid optical audio signal	OPT flashes
Valid analogue audio signal	AUX lights up
Invalid analogue audio signal	AUX flashes
Audio Playing on PC	USB lights up



After connecting your audio cable as above, once the VALID audio signal is detected, the "AUX" indicator on the Audikast Plus will light up **SOLID WHITE**, and you should be able to hear your TV/audio source through your headphones. If not:

- 1) Ensure your TV speaker setting is set to "Headset."
- 2) Plug a pair of wired headphones into the headphones jack you're using with the Audikast Plus on TV. See if you can hear anything.
- 3) Turn up the volume and see if it helps.
- 4) Ensure the audio cable is good and fully plugged.

1. Pair and connect to Bluetooth headphone/receiver

Powering up the transmitter
Power on the transmitter using the USB cable provided. Connect 1 to either TV USB port (TV must be ON to provide power) or a 5V/500mA-2A rated USB charger (e.g., your phone charger should work). Then slide the ON/OFF switch to ON. All LED lights will light up for 2 seconds upon powering on.

Enter the transmitter into PAIRING MODE
For first time use, the transmitter will enter pairing mode automatically, the 8 next to 1 will flash **RED** and **BLUE** alternately. For non-first time use, press and hold 2 for 1 second to enter pairing mode.


Enter your headphones/speakers into PAIRING MODE
Please refer to relevant user manual (Usually LED on headphone flash **RED** and **BLUE** alternately or flash **BLUE** quickly).

Connecting
During the pairing process, keep the devices close to each other and wait. Once connected, the 8 next to 2 will turn **SOLID BLUE**.


Reconnect
NO need to manually reconnect the transmitter to your device before each use. The transmitter will automatically reconnect to the last connected device within 5-10 seconds after both devices had been powered on. Alternatively, reboot the transmitter and wait 5-10 seconds for them to reconnect.

If the 8 next to 4 on the transmitter turn solid **BLUE**, it confirms that the connection between the transmitter and headphones is working normally. The next step is to feed the audio from your TV into the transmitter.


After you've connected the transmitter to your TV/audio while following the steps shown in the sections below, if you still cannot hear anything through your headphones, please either adjust your TV audio output setting as suggested or contact your TV manufacturer for support.



1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.




1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.




3.1 TVs with DIGITAL OPTICAL/SPDIF Audio Out

After connecting your optical cable as above, go to your TV audio settings and change your "audio format" to "PCM". Usually, the "OPT" indicator on the Audikast Plus will change to **SOLID WHITE**, and now you should be able to hear your TV/audio source through your headphones. If not:

- 1) Ensure that your TV Speaker is set to "External Speaker."
- 2) Ensure that your TV "DOLBY/DTS" is set to "OFF" (not auto).
- 3) Ensure the audio cable is good and fully plugged.




3.2 TV with DIGITAL OPTICAL/SPDIF Audio Out



Français

LED Indication

Status	LED Indicator
Power on	All LED light up for 2 seconds
Pairing	8 flash RED and BLUE alternately
Connected	8 turn solid BLUE
Reconnecting	8 flash BLUE every 2 seconds
Valid optical audio signal	OPT lights up
Invalid optical audio signal	OPT flashes
Valid analogue audio signal	AUX lights up
Invalid analogue audio signal	AUX flashes
Audio Playing on PC	USB lights up



After connecting your audio cable as above, once the VALID audio signal is detected, the "AUX" indicator on the Audikast Plus will light up **SOLID WHITE**, and you should be able to hear your TV/audio source through your headphones. If not:

- 1) Ensure your TV speaker setting is set to "Headset."
- 2) Plug a pair of wired headphones into the headphones jack you're using with the Audikast Plus on TV. See if you can hear anything.
- 3) Turn up the volume and see if it helps.
- 4) Ensure the audio cable is good and fully plugged.

1. Pair and connect to Bluetooth headphone/receiver

Powering up the transmitter
Power on the transmitter using the USB cable provided. Connect 1 to either TV USB port (TV must be ON to provide power) or a 5V/500mA-2A rated USB charger (e.g., your phone charger should work). Then slide the ON/OFF switch to ON. All LED lights will light up for 2 seconds upon powering on.

Enter the transmitter into PAIRING MODE
For first time use, the transmitter will enter pairing mode automatically, the 8 next to 1 will flash **RED** and **BLUE** alternately. For non-first time use, press and hold 2 for 1 second to enter pairing mode.


Enter your headphones/speakers into PAIRING MODE
Please refer to relevant user manual (Usually LED on headphone flash **RED** and **BLUE** alternately or flash **BLUE** quickly).

Connecting
During the pairing process, keep the devices close to each other and wait. Once connected, the 8 next to 2 will turn **SOLID BLUE**.


Reconnect
NO need to manually reconnect the transmitter to your device before each use. The transmitter will automatically reconnect to the last connected device within 5-10 seconds after both devices had been powered on. Alternatively, reboot the transmitter and wait 5-10 seconds for them to reconnect.

If the 8 next to 4 on the transmitter turn solid **BLUE**, it confirms that the connection between the transmitter and headphones is working normally. The next step is to feed the audio from your TV into the transmitter.


After you've connected the transmitter to your TV/audio while following the steps shown in the sections below, if you still cannot hear anything through your headphones, please either adjust your TV audio output setting as suggested or contact your TV manufacturer for support.



1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.




1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.





3.1 TVs with DIGITAL OPTICAL/SPDIF Audio Out

After connecting your optical cable as above, go to your TV audio settings and change your "audio format" to "PCM". Usually, the "OPT" indicator on the Audikast Plus will change to **SOLID WHITE**, and now you should be able to hear your TV/audio source through your headphones. If not:

- 1) Ensure that your TV Speaker is set to "External Speaker."
- 2) Ensure that your TV "DOLBY/DTS" is set to "OFF" (not auto).
- 3) Ensure the audio cable is good and fully plugged.




3.2 TV with DIGITAL OPTICAL/SPDIF Audio Out



Italiano

LED Indication

Status	LED Indicator
Power on	All LED light up for 2 seconds
Pairing	8 flash RED and BLUE alternately
Connected	8 turn solid BLUE
Reconnecting	8 flash BLUE every 2 seconds
Valid optical audio signal	OPT lights up
Invalid optical audio signal	OPT flashes
Valid analogue audio signal	AUX lights up
Invalid analogue audio signal	AUX flashes
Audio Playing on PC	USB lights up



After connecting your audio cable as above, once the VALID audio signal is detected, the "AUX" indicator on the Audikast Plus will light up **SOLID WHITE**, and you should be able to hear your TV/audio source through your headphones. If not:

- 1) Ensure your TV speaker setting is set to "Headset."
- 2) Plug a pair of wired headphones into the headphones jack you're using with the Audikast Plus on TV. See if you can hear anything.
- 3) Turn up the volume and see if it helps.
- 4) Ensure the audio cable is good and fully plugged.

1. Pair and connect to Bluetooth headphone/receiver

Powering up the transmitter
Power on the transmitter using the USB cable provided. Connect 1 to either TV USB port (TV must be ON to provide power) or a 5V/500mA-2A rated USB charger (e.g., your phone charger should work). Then slide the ON/OFF switch to ON. All LED lights will light up for 2 seconds upon powering on.

Enter the transmitter into PAIRING MODE
For first time use, the transmitter will enter pairing mode automatically, the 8 next to 1 will flash **RED** and **BLUE** alternately. For non-first time use, press and hold 2 for 1 second to enter pairing mode.


Enter your headphones/speakers into PAIRING MODE
Please refer to relevant user manual (Usually LED on headphone flash **RED** and **BLUE** alternately or flash **BLUE** quickly).

Connecting
During the pairing process, keep the devices close to each other and wait. Once connected, the 8 next to 2 will turn **SOLID BLUE**.


Reconnect
NO need to manually reconnect the transmitter to your device before each use. The transmitter will automatically reconnect to the last connected device within 5-10 seconds after both devices had been powered on. Alternatively, reboot the transmitter and wait 5-10 seconds for them to reconnect.

If the 8 next to 4 on the transmitter turn solid **BLUE**, it confirms that the connection between the transmitter and headphones is working normally. The next step is to feed the audio from your TV into the transmitter.


After you've connected the transmitter to your TV/audio while following the steps shown in the sections below, if you still cannot hear anything through your headphones, please either adjust your TV audio output setting as suggested or contact your TV manufacturer for support.



1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.




1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.




3.1 TVs with DIGITAL OPTICAL/SPDIF Audio Out

After connecting your optical cable as above, go to your TV audio settings and change your "audio format" to "PCM". Usually, the "OPT" indicator on the Audikast Plus will change to **SOLID WHITE**, and now you should be able to hear your TV/audio source through your headphones. If not:

- 1) Ensure that your TV Speaker is set to "External Speaker."
- 2) Ensure that your TV "DOLBY/DTS" is set to "OFF" (not auto).
- 3) Ensure the audio cable is good and fully plugged.




3.2 TV with DIGITAL OPTICAL/SPDIF Audio Out



Spanish

LED Indication

Status	LED Indicator
Power on	All LED light up for 2 seconds
Pairing	8 flash RED and BLUE alternately
Connected	8 turn solid BLUE
Reconnecting	8 flash BLUE every 2 seconds
Valid optical audio signal	OPT lights up
Invalid optical audio signal	OPT flashes
Valid analogue audio signal	AUX lights up
Invalid analogue audio signal	AUX flashes
Audio Playing on PC	USB lights up



After connecting your audio cable as above, once the VALID audio signal is detected, the "AUX" indicator on the Audikast Plus will light up **SOLID WHITE**, and you should be able to hear your TV/audio source through your headphones. If not:

- 1) Ensure your TV speaker setting is set to "Headset."
- 2) Plug a pair of wired headphones into the headphones jack you're using with the Audikast Plus on TV. See if you can hear anything.
- 3) Turn up the volume and see if it helps.
- 4) Ensure the audio cable is good and fully plugged.

1. Pair and connect to Bluetooth headphone/receiver

Powering up the transmitter
Power on the transmitter using the USB cable provided. Connect 1 to either TV USB port (TV must be ON to provide power) or a 5V/500mA-2A rated USB charger (e.g., your phone charger should work). Then slide the ON/OFF switch to ON. All LED lights will light up for 2 seconds upon powering on.

Enter the transmitter into PAIRING MODE
For first time use, the transmitter will enter pairing mode automatically, the 8 next to 1 will flash **RED** and **BLUE** alternately. For non-first time use, press and hold 2 for 1 second to enter pairing mode.


Enter your headphones/speakers into PAIRING MODE
Please refer to relevant user manual (Usually LED on headphone flash **RED** and **BLUE** alternately or flash **BLUE** quickly).

Connecting
During the pairing process, keep the devices close to each other and wait. Once connected, the 8 next to 2 will turn **SOLID BLUE**.


Reconnect
NO need to manually reconnect the transmitter to your device before each use. The transmitter will automatically reconnect to the last connected device within 5-10 seconds after both devices had been powered on. Alternatively, reboot the transmitter and wait 5-10 seconds for them to reconnect.

If the 8 next to 4 on the transmitter turn solid **BLUE**, it confirms that the connection between the transmitter and headphones is working normally. The next step is to feed the audio from your TV into the transmitter.


After you've connected the transmitter to your TV/audio while following the steps shown in the sections below, if you still cannot hear anything through your headphones, please either adjust your TV audio output setting as suggested or contact your TV manufacturer for support.



1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.



1. Ensure that you're using the TV Red/White ports labeled "AUDIO OUT" other Red/White ports will NOT work.
2. Ensure that your TV Speaker setting is set to "External Speaker."
3. Plug a pair of wired headphones into the RCA jack you're using with the Audikast Plus on TV. See if you can hear anything.
4. Turn up the volume and see if it helps.



FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.