

Contents

| | |
|---|----------|
| 1.Basic Information..... | 2 |
| <i>Brief Introduction</i> | <i>2</i> |
| <i>Safety Notice.....</i> | <i>2</i> |
| <i>Cleaning and Maintaining.....</i> | <i>2</i> |
| 2.Before Using | 2 |
| <i>SIM</i> | <i>3</i> |
| <i>Phone Unlock</i> | <i>3</i> |
| <i>SIM Unlock.....</i> | <i>3</i> |
| 3.Function menu Introduction | 3 |
| <i>File manager</i> | <i>3</i> |
| <i>Phonebook.....</i> | <i>4</i> |
| <i>Fun.....</i> | <i>4</i> |
| <i>Call center</i> | <i>4</i> |
| <i>Messaging.....</i> | <i>6</i> |
| Write message | 7 |
| Inbox..... | 7 |
| Drafts | 7 |
| Outbox | 7 |
| Sent messages..... | 7 |
| Message settings..... | 7 |
| <i>Multimedia.....</i> | <i>7</i> |
| Camera | 7 |
| Image viewer | 7 |
| Video recorder..... | 8 |
| Video player | 8 |
| Audio player | 8 |
| Sound recorder | 8 |
| FM radio | 8 |
| <i>Organizer.....</i> | <i>8</i> |
| Calendar | 9 |

| | |
|--------------------------------|-----------|
| Alarm..... | 9 |
| Calculator | 9 |
| Bluetooth | 9 |
| Torch | 9 |
| <i>Settings</i> | 9 |
| User Profiles | 9 |
| Phone settings..... | 10 |
| Security settings | 11 |
| Network settings..... | 11 |
| Dual SIM Settings | 12 |
| Connectivity | 12 |
| Restore factory settings | 12 |
| Shortcuts..... | 12 |
| <i>Services</i> | 12 |
| Internet service | 12 |
| STK | 12 |
| <i>Cherry phone</i> | 12 |
| 4.Safety warning | 13 |
| 5.Appendix | 14 |

1.Basic Information

Brief Introduction

Thank you for choosing **CR-MP3005** mobile phone. It is a flip phone. You can read the manual, a comprehensive understanding of the use of mobile phones and enjoy its perfect functionality and simple method of operation.

CR-MP3005 supports two SIM cards function. In addition to basic call functions, but also to provide you with phone book, personalized ring tones, alarm, camera, image viewer, video recorder, video player, audio player, FM, One Memory Card (T-Flash card), calculator, calendar etc. A variety of practical features to facilitate your work and leisure activities, in addition, **CR-MP3005** interface with personalized mobile phone design, its perfect functionality to meet your needs.

Our Company reserves without any prior notice the contents of this manual under the right to make changes.

Safety Notice

If your phone is lost or stolen, immediately notify the telecommunications sector, or its outlet, to disable the SIM. This will allow you to take phone calls from other economic loss arising. To make you more secure use of mobile phones, please take precautionary measures, such as:

- Set up mobile phone SIM card PIN password, PIN password to prevent your SIM is unauthorized use by others.

Cleaning and Maintaining

Do not use the bathroom where high humidity, cell phone, battery and charger, the same should also avoid the rain. Use a soft, dry cloth to clean the phone, battery and charger. Dirt outlet will lead to poor contact, power-down, which does not charge, regular cleaning.

2.Before Using

SIM

Before using your phone you must insert a valid SIM (Subscriber Identity Module) card. SIM card provide by the network provider.

Warning: Be sure to remove the SIM phone off before. There is absolutely prohibited in the case of an external power supply connected to insert or remove the SIM, or SIM card and mobile phone may be damaged.

Phone Unlock

In order to prevent illegal use, your phone can set the phone lock password protected. Use this function, you must enter the phone lock password so that you can unlock the phone into the normal use state.

Enter the phone lock password, press the LSK to confirm. For example, if the phone lock password is set to 1122, then the following input: 1122.

SIM Unlock

In order to prevent illegal use of your SIM with PIN (Personal Identification Number) password encryption protection. Use this function, if you have set the PIN password protection, every time you must enter the PIN password at boot time, so that you can unlock the SIM card and phone to normal use. Enter the PIN password, press the LSK to confirm. For example, if the PIN is set to 1234, then the following input: 1234. If there consecutive incorrect, your SIM will be network locked, the phone will ask for PUK password.

3.Function menu Introduction

File manager

Into the File manager menu, the menu display **Phone** and **Memory card**. Root directory, select "**Phone**", press the **LSK** to enter "**Options**" can be as follows:

- **Open** Open the root directory lists the directories and files.
- **Format** Format the memory card, this action will remove all current flash memory data.

Root directory, select "**Memory Card**", press the **LSK** to enter "**Options**" can be as follows:

- **Open** Open the root directory lists the directories and files.
- **Format** Format the memory card, this action will remove all current flash memory data.
- **Details** more information you can view, such as Name, Total size, free size.

You can play the music or video files, view Photo, copy/move/delete files, rename files and so on. You can send the file through bluetooth.

Phonebook

You can use the phonebook to store records, can store the following: name and phone number. In the phonebook list, select a record, to make a call when you press the dial keys. Select a record in the phonebook, you can do the following:

- View** View the contact details or edit record.
- Send text message** Send text message to this number.
- Call** Make a call to the number.
- Edit** Can edit and save record.
- Delete** Delete the record.
- Copy** Copy the current record to Phone/SIM.
- Add to Blacklist** Add this number to blacklist.
- Contact settings:**
 - Preferred storage** Select SIM1, SIM2, Phone and All to switch, and phonebook list will change accordingly, such as select SIM1, the phonebook list will only show SIM1 records .
 - Speed dial** Open speed dial. If you long press number keys on the dialing interface, you can call up.
 - Extra numbers** You can set fixed dialing numbers.
 - Memory status** View the usage and total Phonebook capacity information.
 - Copy contacts** You can copy contacts from SIM to phone/SIM and from phone to SIM.
 - Move contacts** You can move contacts from SIM to phone/SIM and from phone to SIM.
 - Delete all contacts** You can delete all contacts in SIM card and phone.

Fun

Games

- Snake You can play snake game and set game level, also can check best grades and help.
- Games settings You can set BGM, sound effect and volume.

Call center

Call logs

Missed calls

Enter the missed calls menu, will display the missed calls list. Select missed call

records, press the Options key:

- **View** View the details.
- **Call** Call the record number.
- **Send text message** Send text message to record number.
- **Save to Contact** Save the number to the phone or SIM card.
- **Add to blacklist** Add the number to blacklist.
- **Delete** Delete the number.

Dialled calls

Enter the dialled calls menu to display the current record of outgoing phone list of phone numbers. Please refer to missed calls for details.

Received calls

Enter the received calls menu to display the current record has been received mobile phone number list. Please refer to missed calls for details.

All calls

Enter the all call menu, will display the all calls list. Please refer to missed calls for details.

Delete call logs

Press the LSK to select "OK" to enter sub-menu to delete call records.

Call timers

You can check call timers of last call, dialled calls and received calls.

Call settings

Call waiting

Open this feature, during the call if the new call, the network will notify you. Specific use with your network provider.

- **Activate** launch the function.
- **Deactivate** Close the function.
- **Query status** Query the function's status.

Call divert

Network Call Transfer service allows you to call a business case in a default transferred to a phone number you specify. The features include: Divert all voice

calls, Divert if unreachable, Divert if no answer, Divert if busy, Divert all data calls.

Call barring

Into the "Call barring" sub-menu, you can set the following call barring any combination to improve security. Some network providers may not provide this service call restrictions, specific use, please contact your network provider. Network provider will provide a four password so that you can enable call restrictions.

Change the password to enter the old call barring password, set new restrictions on the password.

Line switching

You can set line 1 or line 2. If set line 1 you can dial and receive call, if set line 2 you can only receive call, not unable to dial call.

Advanced settings

Blacklist:

You can add blacklist numbers and enable its status.

Auto redial:

Through on / off settings, to activate or disable the feature. Turned on and when your phone call after another failed attempt to connect up to redial 10 times. This feature can save you the trouble of repeated calls.

Call time reminder:

Off Close the function.

Single Enter any numbers between 1-3000 (sec), remind one time.

Periodic Enter any number between 30-60 (sec), from the input time (in seconds), remind for periodic.

Answer mode:

Any key: You can press any key to answer incoming call

Auto answer when headset mode: Incoming call could be auto answered when headset mode.

Messaging

Make sure that the information in writing before the message center number is set correctly. Access to an information menu, you can edit the message.

Write message

Edit text message and multimedia message.

Inbox

Messages which are received.

Drafts

Draft messages.

Outbox

Messages are not sent successfully.

Sent messages

Messages are sent successfully.

Message settings

You can change settings for text/multimedia/service message.

Multimedia

Camera

The phone includes high-definition camera, you can take pictures anytime, anywhere, and to save the photos to your phone or memory card.

State in the preview, press the LSK to enter "Options" you can do this to conduct a more detailed set of parameters.

Photos: Photo album shows the current list of files.

Camera settings: Including flash light, anti-flicker, scene mode, white balance and delay timer.

Image settings: Include the image size and image quality.

Storage: Storage location can be set as Phone, Memory card

Restore default settings: Set all parameters to default settings.

Image viewer

Select an album sub-menu, you can easily view stored in the camera album picture

list, and press the LSK to enter to "Options" to choose the pictures to do the View, Send, Use as, Rename, Delete, change Storage and check Image information operations. View pictures, by pressing on the left and right navigation buttons to switch pictures.

Video recorder

Switch to camera: Switch to the camera.

Camcorder settings: Anti-flicker setting

Video settings: Video quality

Storage: You can select phone or memory card

Video player

Choose video player sub-menu, you can easily view the saved video player in the video list, press the LSK to enter "Options" to select the video files to do the play, send(send the video as multimedia or via bluetooth) ,rename and delete etc .

Audio player

You can play local music in the memory card/phone memory.

Sound recorder

You can set audio quality to record.

FM radio

FM interface, press the OK key to turn on / off FM, press * key and # key to adjust the FM playing volume. Press the left soft key "Options" can show FM options menu, the contents as follow:

Channel list: Shows FM channel list.

Manual input: Can be their own editors to manually enter the channel frequency, the effective value of 87.5 ~ 108.0.

Auto search: Auto search FM channels in the channel list.

Settings: You can set background play,loudspeaker play,audio quality and record storage.

Organizer

Calendar

Enter calendar the screen will show a calendar month with the current date marked. Press the up, down, left, and right navigation keys to change the date, calendar information on the screen will be updated accordingly. Press the left soft key "Options" option to display the calendar menu.

Alarm

Select and edit an alarm clock: You can set the setting of alarm on / off, Time, Repeat and Alarm tone. You can choose to set to repeat:

Once, Everyday, Custom.

Calculator

Your phone provides you with the basic arithmetic operations. Press the left soft key "Clear", Press the right softkey "Back" to exit the calculator.

Bluetooth

Power: Turn on bluetooth or not.

Visibility: You can set it on/off.

My device: You can search for nearby bluetooth devices and pair them.

Search audio device: Search bluetooth audio device only.

My name: Bluetooth device name which can be renamed.

Advanced:

Audio path Leave in phone/Forward to Bluetooth headset.

Storage To receive the file will be automatically transferred to the specified path, the path can be set as phone or memory card.

My address Bluetooth address.

Torch

You can turn on/off the torch.

Settings

User Profiles

Profiles including General、Silent、Meeting、 Outdoor and Headset. First,

based on the current scene, select a different profile, then you only need a personal profile can be set and activated.

General: General environment.

Silent: For Silent environment.

Meeting: Vibrate mode.

Press the left soft key "Options":

Activate: Enable the selected profile.

Customize:

Ring type: You can choose repeat and beep once.

Ringtone According to their own preferences set ringtones, can also be set from the memory card custom ringtones

Ringtone volume In the volume control interface, you can volume up and down navigation keys on the set. Volume level is divided into seven.

Message According to their own preferences set ringtones.

Message volume In the volume control interface, you can volume up and down navigation keys on the set. Volume level is divided into seven.

Keypad You can set keypad as silent,click and tone

Keypad volume You can set keypad volume.

Power on You can set power on ringtone.

Power off You can set power off ringtone.

System alert: Set it on or off.

Phone settings

Into the phone settings sub-menu, you can make the following settings:

Time and date

In this menu, you can change the phone time and date settings.

Auto power on/off

You can set time to power on/off automatically..

Language

Phone supports many kinds of language for you to select. Set the current language type, then menu and interface refresh for the corresponding language.

Pref. input method

The phone supports many kinds of methods, to choose an input method

as the default when the initial input.

Display settings

Wallpaper: Set wallpaper.

Auto Keypad lock: You can set screen auto lock time.

Power on display: You can set power on display.

Power off display: Set screen auto lock time.

Show date and time: You can set On/off.

Dedicated keys

Set up,down,left and right key for shortcuts.

Flight mode

Switch between normal mode and flight mode.

Misc. settings

Display backlight

You can set brightness and time.

Security settings

Into the "Security Settings" menu, you can set the phone's security options, mobile phone or SIM card to avoid unauthorized use.

SIM security

PIN lock: You can set PIN lock on or off by inputting SIM PIN. And you can change PIN and PIN2.

Phone security

Phone lock: You can set it on/off.

Change password:

Change the phone password, enter the old password and then enter a new password. Phone default password is 1122.

Network settings

SIM:

Network selection(Automatic/Manual)

GPRS connection(When needed/Always)
GPRS transfer pref.: Data prefer/Call prefer

Dual SIM Settings

You can choose to open sim1, sim2 or open dual card

Connectivity

Restore factory settings

In this menu, enter the password, once determined, the phone automatically reboot the phone after the relevant parameters can be set to return to default settings. The default password is 1122.

Shortcuts

You can add,edit,delete and change the menus order.

Services

Internet service

Homepage You can login the homepage directly.
Bookmarks There are several default bookmarks.
Search or input URL You can input URL and login it.
Settings You can set the internet service.

STK

Insert the SIM card, will show STK, if not insert the SIM card does not display this menu.

Cherry phone

Specification Dual SIM 2.4 inch QVGA Display
Camera,Bluetooth,Mp3,Mp4,1450mAh Battery Expandable Memory Up to 32GB Bangla Language Support,Torch,FM Radio
Customer Care You can view the after-sales address and telephone
Collection point
Helpline Number

4.Safety warning

4.1 General precautions

- Please use your phone in accordance with rules of area.Do not use the phone when driving.
- Do not put the battery,phone or the charger into a microwave oven or high apparatus;Do not put the phone in areas with high temperature(not higher than 45 degrees Celsius),high humidity or with air that contains dust;otherwise the phone may break down.
- Do not use near fuel or chemicals;do not use the phone in areas with a potentially explosive atmosphere;otherwise the phone may break down or cause fire.
- Keep the phone out of child's reach;otherwise the child may use it as a toy and suffer injury.
- Only professional are allowed to assemble and repair the phone.It may be of great danger and against warranty to assemble and repair the phone without permission.
- Use the phone not more than 2000 metres above sea-level.

4.2 Battery precautions

The battery capacity is 1450mA,the charge current is 500mA.

- Do not dispose your battery or mobile in a fire,otherwise the battery may burst.
- Prevent the battery from humidity otherwise excessive heat,fuming and corrosion may occur.
- If the battery suffers heating up,discoloration or distortion during use,charging or storage,stop using it and change a new one.
- The battery life is limited and will be reduced after long and frequent charging.If it doesn't work after several cycles of charging,it indicates the end of its life.
- Always use the battery and battery charger authorized by the manufacturer.Such products of other bands may cause leakage,excessive heat,bursting and fire.
- Do not dispose off the battery with domestic garbage,instead you should dispose off it in line with the regulations.

5. Appendix

Specific Absorption Rate (SAR) information SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this mobile phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 5mm from the body.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to

which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.