

ESL CF Card / CF-3100

FCC User manual:

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain compliance with FCC RF exposure compliance requirements, please follow operation instruction as documented in this manual.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Index

[\[GENERAL INFORMATION\]](#) [\[PRODUCT INFORMATION\]](#)

[\[TYPICAL OPERATION\]](#)

[\[INFO SERVER ADMINISTRATOR MENU\]](#)

[\[INFO PAD ADMINISTRATOR MENU\]](#) [\[CONTENTS\]](#)

USER MANUAL



Digi Info ESL Tentative 04

Ver. 0.18.080122.1 (Updated on 15/03/08)

ENTRY TO ADMINISTRATOR MENU SCREEN

[Home] [Up]

1. Press **[F2]** button to open **Info Cast application**



2. At **Info Cast Main** Screen, touch  key to enter to **Administrator Menu**



3. Configure the setting as desired

Note: No password required for entry

INFO PAD ADMINISTRATOR MENU

[Home]

Info Pad Administrator Menu is used by store people to do maintenance like e.g. initialize tag item, check tag or item information, update price and etc. To use these operations, it is required for the user to set Info Pad setting, format tag, and etc in the Info Pad Serviceman Menu Screen in advance.

- **ENTRY TO ADMINISTRATOR MENU SCREEN**
- **INITIALIZE MODE**
- **INITIALIZE AND PRINTING MODE**
- **PRINTING MODE**
- **SHOW PAGE 2**
- **ITEM INFORMATION**
- **SHOW TRANSACTION**
- **UPDATE PRICE**

INITIALIZE AND PRINTING MODE

[Home] [Up]

Initialize and Printing Mode is used to initialize a tag, assign an item link (tag id), price, beacon id and etc, to tag and also send sticker for printing to Info Pad, then send to wireless printer from Info Pad. It also update database with item link (tag id) to specific item.

Note: Only formatted tag can be initialized, it is required to format tag in advance and format can be done in Serviceman menu.


Note: Wireless printer and info pad setting for wireless required to set in advance, see "Info pad setting" under operation manual.

Note: Tag ID and Beacon ID is auto generate by server in sequence and apply to initialized tag


Note: Item barcode and data must be programmed in advance before can initialize a tag

Entry to Initialize and Printing Mode:

1. At the **Administrator Menu** Screen



2. Press [INIT AND PRINT] button to go to **Initialize and Printing Mode** screen



Note: Touch **[BACK]** to exit from Initialize and Printing Mode screen

3. Scan barcode for initialize

Note: The barcode must exist and linked to item in database

Note: Also able to enter barcode value by keypad

4. Touch Info Pad Magnet area to Tag Magnetic key area to initialize



Formatted Tag:



5. Wait for connection to server and initialized tag with item data e.g. price and tag symbol or etc

Barcode Scanned:

**Initialize Tag:****Completed Operation:**



6. Then server will send sticker printing command to Info Pad

Note1: Then use wireless printer to print sticker from Info Pad

Note2: When finish initialization, message as "Init and Print Finish" displayed and tag display the value and sticker printed, indicate successful of initializing

INITIALIZE MODE

[Home] [Up]

Initialize Mode is used to initialize a tag and assign an item link (tag id), price, beacon id and etc to tag. It also update database with item link (tag id) to specific item.


Note: Only formatted tag can be initialized, it is required to format tag in advance and format can be done in Serviceman menu.

Note: Tag ID and Beacon ID is auto generate by server in sequence and apply to initialized tag


Note: Item barcode and data must be programmed in advance before can initialize a tag

Entry to Initialize Mode

1. At the **Administrator Menu** Screen



2. Press [INIT] button to go to **Initialize Mode** screen



Note: Touch [BACK] to exit from Initialize Mode screen

3. Scan barcode for initialize


Note1: The barcode must exist and linked to item in database

Note2: Also able to enter barcode value by keypad

4. Touch Info Pad Magnet area to Tag Magnetic key area



Formatted Tag:



5. Wait for connection to server and initialized tag with item data e.g. price and tag symbol or etc

Note: When finish initialization, scanned barcode data cleared and tag display the value, indicate successful of initializing

Loading Initialize Data:



Initialize tag:




ITEM INFORMATION

[Home] [Up]


Item Information is used to check information about tag and item barcode.

Entry to Item Information

1. At the **Administrator Menu** Screen



2. Press [ITEM INFORMATION] button to go to Item Information screen




Note: Touch [BACK] to exit from Item Information screen

3. Scan barcode to display item information


Note: The barcode must exist and linked to item in database

Note: Also able to enter barcode value by keypad



The screenshot shows a software interface titled 'Item Information' with a 'Back' button. Below the title bar, the text 'Please Scan the BarCode:' is displayed above a text input field containing the barcode number '0013256111802'.

4. Wait for the item information display screen



The screenshot shows the 'Item Information' screen with a 'Back' button. Below the title bar, the text 'Please Scan the BarCode:' is displayed above an empty text input field. Below this, the following item details are displayed:

<i>EAN Code:</i>	0013256111802
<i>Item Name:</i>	TONG GARDEN K
<i>Price Data:</i>	33

PRINTING MODE

[Home] [Up]

Printing Mode is used to printing sticker for selected tag item.


Note: Wireless printer and Info Pad setting for wireless required to be set in advance, see “Info Pad setting” under operation manual.

Entry to Printing Mode

1. At the **Administrator Menu** Screen



2. Press **[PRINT]** button to go to **Printing Mode** screen



Note: Touch **[BACK]** to exit from Printing Mode screen

3. Press **[PRESS BUTTON TO START STICK PRINTING]** button to begin sticker printing from Info Pad



4. Touch Info Pad Magnet area to Tag Magnetic key area to send tag data to info server and retrieve information of tag from the info server (will receive in Info Pad)



5. Then send print command from Info Pad to Wireless Printer to print the sticker



SHOW PAGE 2


[Home] [Up]

Show Page 2 is used to view then second page of tag. It is useful for viewing secondary data for the item.

Note: Show page 2 in info pad run only for 8 second.

Entry to Show Page 2:

1. At the **Administrator Menu Screen**



2. Press [SHOW PAGE 2] button to go to **Show Page 2** screen

Note: Touch [BACK] to exit from Show Page 2 screen



3. Press [PRESS BUTTON TO START SHOW PAGE] button to begin show second page of tag

Note: All tag will be displaying in 2nd page for 8 second.




SHOW TRANSACTION

[Home] [Up]

Show Transaction is used to check the transaction data for the scanned barcode.

Entry to Show Transaction

1. At the **Administrator Menu** Screen



2. Press **[SHOW TRANSACTION]** button to go to **Show Transaction** screen

Note: Touch **[BACK]** to exit from Show Transaction screen



3. Scan barcode to check the transaction data

Show Transaction

Back

Please Scan the BarCode:

0013256111802

Last Sales Date	Last Sales Time
Yesterday Sales Qty	Last 7 Days Qty
This Week Sales Qty	
1 Week Sales Qty	2 Week Sales Qty
3 Week Sales Qty	4 Week Sales Qty

Show Transaction

Back

Please Scan the BarCode:

Last Sales Date	Last Sales Time
Yesterday Sales Qty	Last 7 Days Qty
12	84
This Week Sales Qty	0
1 Week Sales Qty	2 Week Sales Qty
0	0
3 Week Sales Qty	4 Week Sales Qty
0	0

Example of Transaction Data

Note1: The barcode must exist and linked to item in database

Note2: Also able to enter barcode value by keypad


UPDATE PRICE

[Home] [Up]

Update Price is used to update (by batch) the displayed tag data for the scanned barcode.


Entry to Update Price

1. At the **Administrator Menu** Screen



2. Press [UPDATE PRICE] button to go to **Update Price** screen

Note: Touch [BACK] to exit from Update Price screen



3. Scan barcode to update the displayed price data for the barcode




Update Price Back

Please Scan the BarCode:

0013256111802

Get the BarCode, Send to the Server

Please Wait ...



Update Price Back

Please Scan the BarCode:

0013256111802

Get the BarCode, Send to the Server

Please Wait ...

Send to the Server Successfully

Note1: The barcode must exist and linked to item in database

Note2: Also able to enter barcode value by keypad

Note3: After scanned barcode, data cleared indicate successful of operation