




Search Device Function is Completed – When no device is

found

③ Device List



Found Devices in the Bluetooth Device List



3) Display Settings



① Brightness



Level 1 : The darkest

Level 9 : The brightest

② Rotation




③ Backlight



- In case 10 Second is set up :

If there is not any Key input, Backlight will be fade out getting darker to Brightness Level1

④ Dim Backlight




- Off : When Backlight Time out turns Backlight Off

- On : When Backlight Time out changes to Backlight Level 1


4) FM



① Preset Add



② Preset Delete



* You can check if currently stored channel is properly operating by moving to the actual frequency after you change Preset channel by Up Down key.

③ Auto Scan



* if you enter Auto Scanning Mode, you will enter FM Mode from Menu Mode.


* Current Frequency status of Frequency Bar is on going and increased Preset channel status is marked.

* Once Scanning is completed, make Preset Channel 1 move to Default Frequency if there is not Preset Channel you are looking for.

④ Stereo




5) Information



6) Recording



① Encoder




② Quality




* WMA
Highest : 44.1KHz, 128Kbps
High : 44.1KHz, 96Kbps
Medium: 44.1KHz, 80Kbps
Low : 44.1KHz, 64Kbps

* PCM
Highest : 48KHz, 1536Kbps
High : 44.1KHz, 1410Kbps
Medium: 32KHz, 1024Kbps
Low : 22KHz, 704Kbps


7) System




① Language



② Erase Internal Memory



③ Erase External Memory




④ Initialize



8)Time




① Auto Power Off




* Auto Power Off : Automatically Power Off when there is no key pressing on Idle(pause) Mode

② Sleep



③ Set Time






Play key : Save & Exit set time menu

Menu Key : Don't save & Exit set time menu


14. Warring & Error Message

(1) USB Connect





(2) Sync Notice

1) Sync Notice



* A-B Repeat

- If you press ▼ Minus Key during music play, A-B Repeat Mode starts.

- 1)  A-B Repeat Start) When you press ▼ key once, icon of side picture will be shown..
- 2)  A-B Repeat Repeat) If you press ▼ key once again, it will repeat playing the section between A and B.
- 3) If you press ▼ key once again, A-B Repeat mode is over and back to Repeat Icon as it was.

(3) Etc

1) Key Lock



2) Booting Logo



3) Charging indicator


- While charging, battery icon is scrolled as white color.



- After completion of charging, battery icon is filled with light green color.






4) Power Off



Next : Pink Spiders / Little Razorblade

Scroll Bar processing time is within 2 seconds.

5) Bluetooth Status Icon

-  : Bluetooth Disable – Power Save & Bluetooth Off
-  : Bluetooth Enable – Bluetooth Device Not Connected
-  : Bluetooth Enable – Bluetooth Device Connected

<<NOTICE>>

Labeling requirements

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Information to user

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

* IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

FCC ID UQ5NSDVBXG

CE0197