





To Replace Battery
1. Depress covers and remove battery cover.
2. Take out CR1450 battery.
3. Press arrow on cover to the NEGATIVE (-) side.
4. Insert battery cover and tighten screws.

**3 Volt Universal
Type CR1450
or CR1471**

CADENT
iTero Wireless Foot Pedal
P/N: MA14731-D

THIS DEVICE COMPLIES WITH PART 15 OF FCC RULES
OPERATION IS SUBJECT TO THE FOLLOWING CONDITIONS:
(1) THIS DEVICE MAY NOT BE USED TO AVOID INTERFERENCE
TO OTHER RADIO COMMUNICATIONS.
(2) THIS DEVICE MAY BE USED TO AVOID INTERFERENCE
TO OTHER RADIO COMMUNICATIONS.
FCC ID: UJZMA4731

Pedal S/N: 0001
System S/N: 1000
Made in Israel