

<div data-bbox="331 329 580 612"></div> <div data-bbox="306 681 584 701"><p>Wireless Speaker Instruction Manual</p></div>	<div data-bbox="730 238 954 296"><p>How to use the Speaker The General Features</p></div> <div data-bbox="835 323 994 450"></div> <div data-bbox="730 462 1113 704"><div>1. On/Off/Play/Pause Button Long press this button to power on/off the device. Short press this button to play/pause the playing music. Short press this button to answer the incoming phone call.</div><div>2. PREV/Volume Down Button Short press the button to play the previous track. Hold in the button to turn down the volume.</div><div>3. NEXT/Volume Up Button Short press the button to play the next track. Hold in the button to turn up the volume.</div></div>
---	--