


Package Contents



Recommended Tools

Drill, Drill bits: 5/32", 1/2"

Approved Credential:

i.e. iCLASS or Prox ID card

Flathead drivers 3/32", 3/16"

Phillips drivers P0, P2

Pencil, Wire Stripper

Optional:

Cam Lock for key override

Specifications

Voltage: 12-24 VDC $\pm 10\%$ (Power Supply not provided)

Power Consumption: <3W peak, 0.5W steady state

Operating Temperature: -10C to 50C

Holding Force: 250 lbs

External Interface Signals Summary:

Lock Signal Name	Lock Signal Direction and Wire Color	Electrical Interface	Logic
Vin	Input, Red/24 AWG	Power to Reader	Input Power
Unlock	Input, Orange/24 AWG	Wetted Relay Contact Closure (0-35 VDC)	Active High
Tamper / Door Position +	Output, Yellow/24 AWG	Dry Contact (0-35 VDC, <100mA)	Open = Unlocked Closed = Locked
Tamper / Door Position -	Output, Blue/24 AWG	Dry Contact (0-35 VDC, <100mA)	Open = Unlocked Closed = Locked
Wiegand Data 0	Output, Green/24 AWG	0-5 VDC	Active Low
Wiegand Data 1	Output, White/24 AWG	0-5 VDC	Active Low
Green LED	Input, Brown/24 AWG	0-5 VDC	Active Low
Red LED	Input, White/Brown/24 AWG	0-5 VDC	Active Low
Ground/Return	Input, Black/24 AWG	-	-

LED Function: LED states are controlled and defined by the User's EAC. Enabling the red and green LEDs on the K200 occurs via an active low (ground) signal.

Output Type: SIAAC-01-1996 Wiegand Output Compliant.


FCC Part 15, Compliant, Industry Canada Compliant

BHMA: A156.3, A156.36, A156.25 Compliant

Credentials Supported: 125kHz Proximity or 13.56MHz iCLASS, iCLASS SEOS, iCLASS SE, ISO 15693 ICLASS, ISO 14443A Mifare, Mifare Plus, Desfire SE, Desfire EV1, and NFC over HCE.

SYSTEM OVERVIEW


The K200-622 wired cabinet lock (K200) extends access control to a cabinet or drawer. The K200 lock is capable of reading radio-frequency identification (RFID) credentials and providing that credential data to an electronic access control (EAC) system via Wiegand data signaling. The EAC is responsible for determining whether user access should be granted or denied. When the EAC provides an active-high unlock signal to the lock in the access granted case, the K200 drives a motor to complete the unlock/lock cycle. EAC indication of user access/denial is provided to the user by way of LED control inputs on each lock. Additional lock monitoring features (e.g., door position, tamper) are monitored within the lock and status of each is provided to the EAC.




TESTING THE LOCK

1. TEST the lock with a known good credential to confirm it will open as desired when installed.

- a. REMOVE the cover from the lock body.




- b. PASS the wire and shaft from the reader through the lock body.




NOTE: The wire connector is keyed.


- c. CONNECT the wire connector from the reader to the socket in the lock compartment.



- d. CONNECT the 10-position Molex Micro-Fit 3.0 cable between the K200 and the EAC, and ENSURE power is ON.




- e. PRESENT a credential known to the EAC.



- f. **WHEN** a green LED indicates access is granted, **THEN** TWIST the knob to retract the latch.
- g. Carefully UNPLUG the cable, and SEPARATE the lock and reader to prepare for installation.


MOUNTING THE LOCK

NOTE: The K200 reader and lock body can be oriented in several ways to accommodate various cabinets and drawers. When selecting an orientation, it should be noted that some reader orientations may prevent use of the key override function. For example, in the door handing shown here, the key override paddle cannot be accessed in orientation "A", but it can be accessed in orientations "B," "C" and "D".



1. ESTABLISH the horizontal centerline of the latch.

- HOLD the lock body to the inside of the door and POSITION it generally where you would like it to mount.
- LOCATE lock centerline notch on the latch, and MARK this point on the inside of the cabinet door using a pencil.
- DRAW the horizontal latch centerline from this mark on the inside of the cabinet door and TRANSFER it to the outside of the cabinet door.
- TRANSFER this centerline to the inside of the cabinet or the second door on a double-door cabinet.




2. TRANSFER the location of the inside wall of the cabinet to the door.

- a. MEASURE the horizontal distance between the inside edge of the cabinet and the door edge.

NOTE: The drawn line depicts the location of the strike mounting surface.

- b. LOCATE the lock centerline notch on the latch and MARK this point on the inside of the cabinet door using a pencil.
- c. DRAW the horizontal latch centerline from this mark on the inside of the cabinet door and TRANSFER it to the outside of the cabinet door.



Cabinet/door front view


3. PLACE and USE the Lock/Reader Template.

NOTE: The orientation will be reversed for a right hand door.

- a. CUT through line to separate the Strike Plate Template.
- b. PEEL OFF the protective layer of the Lock Template, ALIGN it to both the latch centerline and the line depicting the inside wall of cabinet, and PRESS to secure.

NOTE: Two of the holes in the following step are 3/16" [4.76 mm] diameter and two are 1/2" [12.70 mm] diameter. The two pilot holes are 1/16" [1.59 mm].

- c. DRILL four holes and two pilot holes through the cabinet, as shown in the figure below.
- d. DRILL only one 3/16" [4.76 mm] hole, depending on the desired Antenna/Reader orientation.



- e. **IF** the optional key override will be installed, **THEN GO TO** Step 5.

- f. REMOVE the lock template from the door.

4. INSTALL the shaft extension.

- a. **IF** the cabinet door thickness is greater than ½" [12.70 mm] (see Table 1),
THEN INSTALL the Shaft Extension to the Antenna/Reader to ensure proper engagement into the lock.
- b. INSTALL the Shaft Extension to the shaft as shown in the figure, and firmly **TIGHTEN** the screw.





Table 1

Door Thickness	Extension Shaft Used?
1/16" [1.59 mm] – ½" [12.70 mm]	No
> ½" [12.70 mm] – 1 ½" [38.10 mm]	Yes

5. **IF** a Cam Lock key override will be used,
AND the orientation allows for installation,
THEN INSTALL the Key Override Paddle.


- a. INSERT the paddle's arm into the opening shown, and **ALIGN** the rails of the paddle to the ones on the lock.
- b. **SLIDE** the paddle gently until it stops.



6. PREPARE the Key Override Door.

NOTE: The Cam Lock is optional and must be obtained by others.

- a. **IF** a Key Override is used,
THEN MARK and DRILL a hole for a ¾" [19.05 mm] Cam Lock in the door using the template as a guide.
- b. INSTALL the optional Cam Lock with the Cabinet Lock as shown in the figure.



7. INSTALL the Antenna/Reader.


CAUTION

Pinching the wires may prevent the Reader and Lock from properly functioning.

- a. PLACE and HOLD the antenna/reader to the outside of cabinet, routing the wire through the 1/2" [12.70 mm] offset hole, and ENSURE the knob is in the locked position in the vertical.

NOTE: Using the table below will help determine the length of the top mount screw needed, based on the thickness of the cabinet door.

- b. INSTALL the top mount screw to attach the antenna/reader to the outside case.



Door Thickness	Reader Mounting	Approximate Screw Cut Length	Lock Mounting	Approximate Screw Cut Length
1/16" [1.59 mm]	8-32 x 5/16" [4.00 mm x 7.94 mm]	No cut	8-32 x 1 3/4" [4.00 mm x 44.45 mm] Breakaway	1 1/16"
1/4" [6.35 mm]	8-32 x 5/16" [4.00 mm x 7.94 mm]	No cut	8-32 x 1 3/4" [4.00 mm x 44.45 mm] Breakaway	1 3/4"
1/2" [12.70 mm]	8-32 x 1 3/4" [4.00 mm x 44.45 mm] Breakaway	5/8"	8-32 x 1 3/4" [4.00 mm x 44.45 mm] Breakaway	1 7/16"
3/4" [19.05 mm]	8-32 x 1 3/4" [4.00 mm x 44.45 mm] Breakaway	7/8"	8-32 x 1 3/4" [4.00 mm x 44.45 mm] Breakaway	No cut
1" [25.40 mm]	8-32 x 1 3/4" [4.00 mm x 44.45 mm] Breakaway	1 1/8"	8-32 x 2 1/2" [4.00 mm x 63.50 mm]	2"
1 1/4" [31.75 mm]	8-32 x 1 3/4" [4.00 mm x 44.45 mm] Breakaway	1 3/8"	8-32 x 2 1/2" [4.00 mm x 63.50 mm]	No cut
1 1/2" [38.10 mm]	8-32 x 1 3/4" [4.00 mm x 44.45 mm] Breakaway	No cut	8-32 x 2 1/2" [4.00 mm x 63.50 mm]	No cut

8. INSTALL the lock.



- a. REMOVE the cover from lock.
- b. PLACE the lock on the inside of the door, threading the cable through the lock.
- c. ATTACH the lock to the antenna/reader using two 8-32 [4.00 mm] lock mount screws (see Table 2 for length), and TIGHTEN the screws.
- d. INSTALL the two #6 [3.5 mm] self-threading screws, and TIGHTEN.

NOTE: The third #6 [3.5 mm] self-threading screw is important to achieve maximum holding force for doors greater than 5/8" [15.88 mm] thick.

- e. INSTALL the third #6 [3.5 mm] self-threading screw only if the door is greater than 5/8" [15.88 mm] thick, using the lock as a guide, and TIGHTEN.

Cable is threaded through the hole in the lock.

8a and 8b





Used only for doors greater than 5/8" thick.


9. CONNECT the antenna/reader wire to the lock body.

NOTE: The antenna/reader wire connector is engineered to fit only one way.

- INSERT the antenna/reader wire connector, ensuring correct orientation
- TUCK excess cable into the lock body.
- ATTACH the cover.



10. CONNECT the 10-position Molex Micro-Fit Cable between the K200 and the EAC.



11. ENSURE the following power cabling guidelines are followed:


Wire AWG	Supply Voltage	Allowed Cable Length (ft.)*
20 AWG	12	872
	24	6679
22 AWG	12	548
	24	4201
24 AWG	12	345
	24	2641

* Round trip loss. $V = 2 \times I \times R \times \text{xft}$ \longrightarrow $\text{xft} = V / (2 \times I \times R)$

12. POSITION the cable out of the way, as required.

13. PREPARE for the single door strike plate.

- PEEL OFF the protective layer of the Strike Plate Template and ALIGN it to both the latch centerline and the cabinet edge.
- DRILL the two pilot holes shown on the template.
- REMOVE the template.




CAUTION

The Installer must ensure that the lock can be opened before closing the cabinet door.

14. INSTALL the single door strike plate.


- PLACE the strike plate over the pilot holes, and INSERT and TIGHTEN the two screws in the slotted holes.
- CLOSE the door to verify installation, and ADJUST the strike plate if necessary.
- INSERT and TIGHTEN the lock down screw on the strike plate.



15. INSTALL for the double-door strike plate mounting bracket. (OPTIONAL)


NOTE: The double-door strike plate bracket requires that one door can be secured.

- PLACE the bracket on door, making sure it aligns with the mark made in Step 2c and the edge of the door.
- MARK the door.
- REMOVE the bracket and DRILL pilot holes at the two marks.
- INSTALL the bracket using the provided mounting screws.



16. INSTALL the double-door strike plate.

- PLACE the strike plate over the holes on the bracket.
- INSERT and TIGHTEN the three 6-32 x 5/16" (3.5 mm x 7.94 mm) provided screws.



FCC Statement



This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Operation with non-approved equipment is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

IC Statement

This device complies with Industry Canada license-exempt RSS standards(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation.

CE Statement

HES hereby declares that these proximity readers are in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.



Conformité aux normes FCC

Cet équipement a été testé et trouvé conforme aux limites pour un dispositif numérique de classe B, conformément à la Partie 15 des règlements de la FCC. Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement génère, utilise et peut émettre des fréquences radio et, s'il n'est pas installé et utilisé conformément aux instructions du fabricant, peut causer des interférences nuisibles aux communications radio. Rien ne garantit cependant que l'interférence ne se produira pas dans une installation particulière. Si cet équipement provoque des interférences nuisibles à la réception radio ou de télévision, qui peut être déterminé en comparant et en l'éteignant, l'utilisateur est encouragé à essayer de corriger les interférences par une ou plusieurs des mesures suivantes:

- Réorienter ou déplacer l'antenne de réception.
- Augmenter la distance entre l'équipement et le récepteur.
- Branchez l'appareil dans une prise sur un circuit différent de celui auquel le récepteur est connecté.
- Consultez votre revendeur ou un technicien radio / TV pour assistance.

Les changements ou modifications à cet appareil sans expressément approuvée par la partie responsable de conformité pourraient annuler l'autorité de l'utilisateur de faire fonctionner cet équipement.

Conformité aux normes IC

Cet appareil est conforme avec Industrie Canada exempt de licence RSS standard(s). Son fonctionnement est soumis aux deux conditions suivantes:

- (1) cet appareil ne peut causer d'interférences, et

(2) cet appareil doit accepter toute interference, y compris des interférences qui peuvent provoquer un fonctionnement indésirable du périphérique.

Conformité aux normes CE

HES déclare par la présente que ces lecteurs à proximité sont conformes aux exigences essentielles et aux autres stipulations pertinentes de la Directive 1999/5/CE.

For Technical Support please call 1-800-626-7590