

# **KDCSLED-HF**

## **User Manual**

Rev 1.1  
April 2018

## Table of Contents

---

<b>1. INTRODUCTION.....</b>	<b>5</b>
1.1 Specification.....	6
1.2 Package.....	7
1.3 Installation.....	8
<b>2. OPERATING YOUR KDCSLED-HF .....</b>	<b>9</b>
2.1 Configuration.....	9
2.2 Configuration barcodes .....	9
2.3 How to read NFC Tags.....	10
<b>3. WARRANTY.....</b>	<b>11</b>
<b>4. CONTACT INFORMATION .....</b>	<b>13</b>



## COPYRIGHT, LICENSE, and WARNING PAGE

**Copyright®** 2002-2018 by KOAMTAC, Inc. All rights reserved.

No part of this publication may be reproduced or used in any form, or by any electrical or mechanical means, without permission in writing from KOAMTAC, Inc. The material in this manual is subject to change without notice. KOAMTAC reserves the right to make changes to any product to improve reliability, function, or design. KOAMTAC does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein. Follow all warnings and instructions marked on manual and units. Use only the power source specified in this manual or marked on the units.

Certain KDC products may be covered by the following issued US patents numbers 7769917, 7954710, 8126399, 8295368, 8346979, 8347366, 8371506, 8483614, 8832323; Korea patents numbers 10-1383407, 10-1354252 and may be patent pending elsewhere, UK publication GB2492615, Korea publication 1020120128598.

KDC® is a registered trademark and property of KOAMTAC, Inc.

KoamTac® is a registered trademark and property of KOAMTAC, Inc.

### CAUTION:

Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC RF Exposure Information**

This equipment complies with FCC RF exposure limit requirements set for in an uncontrolled environment

**FCC ID: VH9KDCSLED-HF**

## 1. Introduction

### KDCSLED-HF

KDCSLED-HF is a communication module which includes NFC module which is reading from and writing to the RFID(NFC) tag. It conforms to various industry standard RF protocols of NFC. When it is connected to KDC Sled model(as like KDC470), it enables user to collect data with NFC Tag.

To find out more about KOAMTAC, Inc. and our family of products, visit us at [www.KOAMTAC.com](http://www.KOAMTAC.com).



## 1.1 Specification

Frequency	13.56MHz
Supported standard	ISO/IEC 14443A, 14443B, 15693 MIFARE 1K/4K, Ultralight
Interfaces	I2C
Supply Voltage	3.3V
Dimensions	104.5mm(L)x60mm(W)x10mm(H)
Weight	39.5g
Drop Spec	4 feet(1.22M)
Operating Temperature	32°F (0°C) ~ 113°F (45°C)
Storage Temperature	-4°F (-20°C) ~ 113°F (45°C)
Humidity	5% ~ 85% (noncondensing)

## 1.2 Package

The standard KDCSLED-HF package contains:

1. One KDCSLED-HF
2. 4 screws + 1 extra



## 1.3 Installation

- Align KDCSLED-HF screw holes to screw holes on KDC SLED.(As like KDC470)



- Use 4 screws to fasten KDCSLED-HF to KDC SLED.



\* One spare screw is provided



## 2. Operating your KDCSLED-HF

### 2.1 Configuration

#### NFC Power

- Turning NFC Power on or off
- Options: Enable/Disable







#### Data Format

- Options: Data only/Packet data.

#### UID Only

- Enable or Disable UID Only menu
- The KDC only sends UID data to the host device when the KDC is in UID Only mode.

### 2.2 Configuration barcodes

<p>Enable NFC Power</p>  <p>└MKDCN0001.</p>	<p>Disable NFC Power</p>  <p>└MKDCN0010.</p>
<p>NFC Data Format = Data only</p>  <p>└MKDCN1001.</p>	<p>NFC Data Format = Packet data</p>  <p>└MKDCN1000.</p>
<p>UID Only = Enable</p>  <p>└MKDCN3001.</p>	<p>UID Only = Disable</p>  <p>└MKDCN3000.</p>

<p>New Data Format = Enable</p>  <p>└MKDCN4001.</p>	<p>New Data Format = Disable</p>  <p>└MKDCN4010.</p>
--	--

## 2.3 How to read NFC Tags

1. Enable the **NFC Power** option in the **NFC Config** menu.
2. Touch the NFC tag to the back of the KDCSLED-HF case and make sure the tag and case are within 5cm of each other.



*Location for reading NFC Tag*

3. The KDC will show the NFC tag UID and the user will hear a short beep if it has been read successfully.

### 3. Warranty

#### LIMITED WARRANTY AND DISCLAIMERS

BY OPENING THE PACKAGE OF THIS PRODUCT YOU AGREE TO BECOME BOUND BY THE LIABILITY AND WARRANTY CONDITIONS AS DESCRIBED BELOW.

UNDER ALL CIRCUMSTANCES, THIS MANUAL SHOULD BE READ ATTENTIVELY, BEFORE INSTALLING AND OR USING THE PRODUCT.

#### Serial Number

A serial number appears on the KDC label. This official registration number is strictly related to the device purchased. Make sure that the serial number appearing on your KDC is not removed. Removing the serial number will affect the warranty conditions and liability disadvantageously, so please maintain the label with serial number on the KDC. Units with the serial number label removed should not be operated.

#### Warranty/Warranty Period/Liability

KOAMTAC, Inc. ("KOAMTAC") manufactures its hardware products in accordance with industry-standard practices. Unless otherwise agreed in a contract, KDC is warranted for a period of one year after purchase, covering defects in material and workmanship except rechargeable battery. KOAMTAC will repair or, at its opinion, replace products that prove to be defective in material or workmanship under proper use during the warranty period. KOAMTAC will not be liable in cases (i) in which the unit has been repaired or altered unless done or approved by KOAMTAC, (ii) in which the unit has not been maintained in accordance with any operating or handling instructions supplied by KOAMTAC, (iii) in which the unit has been subjected to unusual physical or electrical stress, misuse, abuse, power shortage, negligence or accident or (iv) in which the unit has been used other than in accordance with the product operating and handling instructions. Preventive maintenance is the responsibility of the customer and is not covered under this warranty. Under no circumstance will KOAMTAC be liable for any direct, indirect, consequential or incidental damages arising out of use or inability to use either the hardware or software, even if KOAMTAC has been informed about the possibility of such damages.

#### Warranty Coverage and Procedure

During the warranty period, KOAMTAC will repair or replace defective products returned to KOAMTAC warehouse. International customers should contact the local KOAMTAC office or support center. If warranty service is required, KOAMTAC will issue a Return Material Authorization Number. Products must be shipped in the original or comparable package, shipping and insurance charges prepaid. KOAMTAC will ship the repaired or replacement product freight and insurance prepaid. Customer accepts full responsibility for its software and data including the appropriate backup thereof. Repair or replacement of a product during warranty will not extend the original warranty term.

CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.



## 4. Contact Information



### CORPORATE HEADQUARTERS

116 Village Blvd., Suite 305

Princeton, NJ 08540, USA

Phone: 609-256-4700, FAX: 609-228-4373

Email: [support@koamtac.com](mailto:support@koamtac.com)

**For more information, visit our website - [www.KOAMTAC.com](http://www.KOAMTAC.com)**