





## Quick Start Guide

1. Plug the power adapter into the back of the Autonet unit and then into your power source.
2. The Blue status light on top will begin to blink. Once this light remains constantly on, your Autonet unit is connected to the Internet.
3. Connect your computer to the wireless network that contains the name "autonet".
4. Open your web browser and connect to any web site. Click "Login" after you read the safety policy to connect to the Internet.

For additional information and support, please refer to Autonet Users Guide.  
For Technical Support call 1-800-977-2987

Autonet Mobile assumes no responsibility for the configuration, security, or data files on your wireless device resulting from connection to Autonet Mobile's network. Antivirus, privacy, and security protection is the responsibility of the user.

**Do not operate while driving** or perform any function that takes your attention away from safely driving your vehicle. Any function that requires prolonged attention should be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in an accident.

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference and,
- 2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: V01-AHMA5PLS-02



Autonet Serial No.  
MODEL: AA-4877M (V4.0)  
V01-AHMA5PLS-02

If found please call 1-800-977-2107



