



Official Licensed Product



WIRELESS CONTROLLER (2.4GHz) MANETTE SANS FIL (2.4GHz)

Carefully read the information on this package before use. For detailed connection and usage methods, refer to the instructions for the PlayStation®2 system.
Soigneusement lire l'information sur ce paquet avant l'usage. Pour les instructions détaillées et méthodes d'usage, se référer aux instructions si dessous ainsi que le livret instructions pour la système Playstation®2.

COMPATIBLE MODELS / MODELES COMPATIBLES
PlayStation®2, PSone™, PlayStation®

REQUIRES 3 AAA BATTERIES (NOT INCLUDED) / 3 PILES AAA (NON FOURNIES)

HOW TO USE

- Battery Installation & Pairing Instruction:
- Remove battery compartment cover and place batteries in compartment. Make sure that your batteries are placed in the correct direction in the battery compartment.
- Replace the battery cover once complete.
- Insert the transceiver into the controller port on your PlayStation®2 system.
- Turn on your PlayStation®2 system.
- The Link LED will flash for a few seconds and the receiver will begin to search for the controller.
- Once the controller is paired with the receiver, the LED indicator will glow and will remain lit.
- The LED will turn off when the controller is powered off or is in sleep mode.
- In order to avoid conflicts between working controllers, each is issued a unique ID. However, if there is a need to re-pair the controller and the receiver, simply press the "Force Link" button on the receiver first, then on the controller. The Link LED will flash for a few seconds and the receiver will begin to search the controller.
- Safety Precaution: Follow the battery manufacturer's instructions as well as these important safety tips. Do not open or mutilate batteries as they might leak dangerous chemicals.

Sleep Mode:

- The controller will revert to sleep mode after five minutes of inactivity or when the controller is without an active link for a period of two minutes.
- The Pad will wake from sleep mode by pressing any of the following keys "Mode", "Select", "Start", "L3" or "R3".

Low Power Warning Function:

- Under low battery conditions, the Mode LED will flash and the vibration motors will automatically turn off.

Vibration:

- The controller's default vibration setting is on.
- To turn off the vibration function, press the vibration button once. The controller will vibrate twice to confirm.
- To turn the vibration on, press the vibration button once and the controller will vibrate once to indicate vibration is active.
- Safety Precaution: Stop using this unit immediately if you begin to feel tired or if you begin to feel discomfort or pain during use. Do not use the vibration function if you have an ailment or injury to the bones, joints or muscles of your hands or arms.

MODE D'EMPLOI

L'Installation de Pile Instruction:

- Enlever la couverture de compartiment de pile et installer les piles dans le compartiment (assurer que vos piles sont placées dans la direction indiquée). Remplacer la couverture de pile une fois complète.
- Insérer le connecteur de récepteur dans au port de contrôleur sur votre système de Playstation®2.
- Allumer votre système Playstation®2.

- Le lien "Link" clignotera sur le contrôleur pour quelques secondes et le récepteur commencera à chercher le signal.

- Une fois le contrôleur est à mis avec le récepteur, l'indicateur "Link" restera allumé.

- La lumière "Link" éteindra quand le contrôleur est éteint ou est dans le mode de sommeil.

- Afin d'éviter des conflits entre le fonctionnement de contrôleurs, chaque est distribué une ID unique. Cependant, s'il y a un besoin de metre en liens le contrôleur et le récepteur, simplement appuyer le bouton « Force Link » sur le récepteur en premier, et alors sur le contrôleur. La lumière "Link" clignotera pour quelques secondes et le récepteur commencera à chercher le signal.

- Précaution de sûreté: Suivre les instructions du fabricant de pile ainsi que celle dans votre livret de Playstation®2.

Mode Sommeil:

- Le contrôleur reviendra en mode Sommeil quand le contrôleur n'est pas utilisé pour une période de deux minutes. Vous pouvez révéillé le contrôleur du mode de sommeil en appuyant n'importe quel clefs suivant, "Mode", "Select", "Start", "L3" ou "R3".

Avertissement bas pouvoir:

- Sous les conditions basses de pouvoir, la lumière "Link" clignotera et le mode de vibration éteindra automatiquement.

Vibration:

- Les mode de base du fonction vibration du contrôleurs est active.

- Pour éteindre la fonction de vibration, appuyer le bouton de vibration une fois. Le contrôleur vibrera deux fois pour confirmer.

- Pour allumer la fonction vibration, appuyer le bouton de vibration une fois et le contrôleur vibrera une fois pour indiquer que la vibration est active.

- Précaution de sûreté: Arrêter utilisant cette unité tout de suite si vous sentez fatigué ou si vous commencez à sentir le malaise ou la douleur pendant l'usage. La fonction de Vibration de ce produit peut aggraver des blessures. Ne pas utiliser la fonction de vibration si vous avez une indisposition ou une blessure aux os, les joints ou les muscles de vos mains ou de vos bras.

- Katana garantit à l'acheteur d'origine que ce produit n'aura aucun vie de materiel ni de fabrication pour une période d'un (1) an à partir du date de l'achat.

LIMITED WARRANTY

Katana warrants the original purchaser that this product will be free from defects in material and workmanship for a period of one (1) year from the date of purchase. If this product is deemed to be defective by Katana during the warranty period, Katana's liability will be limited to the repair or replacement of this product. This warranty shall not apply if the product is a) used for commercial purposes (including rental) or is modified or tampered with b) is damaged by misuse, abuse, negligence, accident, wear and tear, or other causes unrelated to defective materials or workmanship.

GARANTIE LIMITEE

Katana garantit à l'acheteur d'origine que ce produit n'aura aucun vie de materiel ni de fabrication pour une période d'un (1) an à partir du date de l'achat. Cette garantie ne s'appliquera pas si ce produit a) est utilisé à des fins commerciales b) subi des dommages résultants d'un cas de force majeure, de l'utilisation impropre ou abusive. La preuve d'achat sous forme de coupon de caisse ou de facture qui prouve que l'unité est encore couverte par la durée de la dite garantie doit être présentée afin d'obtenir le service sous garantie.

WARNING

Changes or modification to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter. This equipment complies with FCC/IC radiation exposure limits set forth for uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that are deemed to comply without testing for specific absorption ratio (SAR).

Declaration of Conformity

Trade Name: Katana Game Accessories
Model Number: P2CO-045
Standards: FCC Part 15: 2005, Subpart C (15.249) ANSI C63.4: 2003
FCC ID: VUSP2CO-045

FOR CUSTOMERS IN CANADA

This is a Class B device and complies with Canadian ICES-003 2004.
POUR DES CLIENTS AU CANADA
Cet appareil conforme avec les normes Canadiennes ICES-003 2004.

This product is manufactured under license from Freedom Wave LLC under one or both of the following US Patents: 6,280,327 and 6,878,066.
Ce produit est fabriqué sous licence de Freedom Wave LLC sous les permis de US suivant: 6,280,327 et 6,878,066.

"PlayStation", "PSone" and the "PS" family logo are registered trademarks of Sony Computer Entertainment Inc. Manufactured & distributed under license by Sony Computer Entertainment America Inc.

Les Logo de la gamme de produit "Playstation", "PSone" et le logo de famille de "PS" sont des marques déposées de Sony Computer Entertainment Inc. Ce produit est fabriqué avec l'autorisation de Sony Computer Entertainment America Inc. et sous licence par Sony Computer Entertainment America Inc.



Katana Game Accessories, Inc.
190 Statesman Drive
Mississauga, ON
L5S 1X7 Canada
www.katana-accessories.com

CUSTOMER SERVICE / SERVICE À LA CLIENTELE

1-866-779-1217
from / appelez nous 8am-8pm EST or au allez à
www.katana-accessories.com