

Frog-Shaped Ultrasonic Humidifier

Operating Instructions



- FOR HOUSEHOLD USE ONLY -

IMPORTANT SAFEGUARDS

Signal Word Definitions

NOTE: These are general definitions only; all may not pertain to the actual product purchased.

DANGER - Indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury. Usage of this signal word is limited to the most extreme situations.

WARNING - Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury.

CAUTION - Indicates a potentially hazardous situation, which, if not avoided, may result in minor/moderate injury or product/property damage. It also alerts against unsafe practices.



READ ALL INSTRUCTIONS BEFORE USE.



WARNING- To reduce the risk of fire, electric shock, or serious personal injury:

- This product is intended for non-commercial household use in humidifying the air. Do not use the product for any other purpose.
- Keep the product out of the reach of children and pets. This product is not intended for use by children.
- Do not leave the product unattended while it is in use. Always unplug the product from the electrical outlet when it is not in use.
- Always make sure the product is unplugged from the electrical outlet before relocating, servicing, or cleaning it.
- Always place the product on a flat, stable, heat-resistant surface.
- Never block the air openings of the product or place it on a soft surface (e.g., a bed, couch, or car seat) where the air openings may be blocked. Wipe the air openings clean if they become clogged. Failure to keep the air openings clean and free of blockage may deny the product airflow.
- Do not place or store the product where it can fall, or be pulled into a tub or sink. If the product falls into water, immediately unplug it from the

- electrical outlet. Do not touch or reach into the water.
- Do not use attachments not recommended or sold by the product manufacturer.
- Do not operate this product if the Power Cord is cut, damaged, or if the wires are exposed.
- Do not immerse the Power Cord or plug in, or expose them to, water or other liquids.
- Do not plug the product into, or unplug it from, an electrical outlet while your hands are wet.
- To disconnect the product from an electrical outlet, pull directly on the plug; do not pull on the Power Cord.
- Do not put any stress on the Power Cord where it connects to the item, as the Power Cord could fray and break.
- Never operate this product if it has a damaged Power Cord or plug, is not working properly, has been dropped, damaged, or exposed to water or other liquids. Do not attempt to examine or repair this product yourself. Take the product to the appliance repair shop of your choice for inspection and repair.



CAUTION- To reduce the risk of personal injury or product/property damage:


- Do not place the product in areas or on surfaces (e.g., carpets) that may be damaged by water or moisture. The user is solely and exclusively liable for any and all damage that may occur from water-related mishaps that occur during use of this product.
- Do not place the product in direct sunlight.
- Use only distilled or softened water. Minerals in tap water (hard water) may cause a “white dust” to appear on furnishings.
- Do not add medications, chemicals, ointments, oils, or any other additives or substances to the water.

WARNING: This product is equipped with a polarized plug (one blade is wider than the other blade) to reduce the risk of electrical shock. This is a safety feature. The plug will fit into a polarized outlet only one way. If you are unable to insert the plug into the electrical outlet, try reversing the plug. If the plug still does not fit, contact a qualified electrician. Never use the plug with an extension cord unless you can fully insert the plug into the extension cord. Do not alter the plug. Do not attempt to defeat the safety purpose of the polarized plug.



SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

Parts




To Use


1. Before using, clean the humidifier Base and the water tank with a soft, non-abrasive, slightly damp cloth.
2. Do not place the humidifier on wooden furniture or other surfaces that can be damaged by water. Place the unit on a flat and stable surface. The humidifier should be approximately four inches away from walls and on a waterproof surface.



3. Do not plug in yet. Gently remove the Lid that contains the Variable Mist Control Knob.




4. Remove the Water Tank from the Base by the Handle, turn the Water Tank upside down, and twist the Tank Cap off.




5. Fill the Water Tank with distilled or purified room temperature water. The temperature of the water should NEVER be too hot or too cool. Replace the Tank Cap tightly.

6. Turn the Water Tank right side up and return the Water Tank to the Base of the unit. Make sure the Water Tank is securely positioned into the Base.
7. Ensure the On/Off Switch, located in the front of the Base, is in the OFF position. Plug the power cord into a standard 120-volt AC electrical outlet. Rotate the On/Off Switch clockwise to ON; the Power Indicator will illuminate to indicate the unit is ON.



8. To control the cool mist output, rotate the Variable Mist Control Knob counterclockwise to decrease mist output. To maximize mist output, rotate the Knob clockwise to the largest opening.



9. Rotate the On/Off Switch to OFF when the desired room humidity is achieved. Always turn the unit off when the Water Tank becomes empty. The unit will stop creating mist when the water level in the Base falls below the water level sensor.
10. Do not leave water stored in the product. Always unplug the unit and drain any remaining water from the Water Tank.

Care and Maintenance

WARNING: To avoid the risk of electric shock, always ensure the product is unplugged from the electrical outlet before assembling, disassembling, relocating, or cleaning it.

CAUTION: To avoid damage to the product, do not use abrasive cleaners or scouring pads to clean the product parts.

- Clean the Base by wiping it with a damp cloth. To avoid product damage, do not immerse the Base into water or other liquids or place it in a dishwasher.
- When the unit is completely dry, store the humidifier in a cool, dry place.

Troubleshooting

Problems	Possible Cause	Solution
Power on/off knob is turned to “ON”, and the Power Indicator is off	<ul style="list-style-type: none">• Unit is not plugged in• No power at AC outlet	<ul style="list-style-type: none">• Plug unit in• Check the circuits, try a different AC outlet
Little or no mist output	<ul style="list-style-type: none">• No water inside tank• Device is not placed on a level surface• Mineral deposits on the water sensor/transducers• Water tank is cleaned with detergent• No connection to blower• Hard water/soft water content is too high	<ul style="list-style-type: none">• Fill the water tank• Place unit on a level surface• Clean the water sensor/transducers as stated in instructions• Rinse the tank with clean water thoroughly, and wipe dry• Make sure the water at the unit base is enough to immerse water sensor
Water leakage	<ul style="list-style-type: none">• Improper placement of rubber ring on tank cap• Loose cap• Refilled with hot water	<ul style="list-style-type: none">• Reposition the rubber ring• Tighten the cap again• Refill with cool distilled or filtered tap water
White dust accumulation (caused by suspension of minerals in water and not due to a defect in the humidifier)	<ul style="list-style-type: none">• Hard water used	<ul style="list-style-type: none">• Switch to distilled or filtered tap water

Note: Depending on constant or occasional use, clean the device on a weekly or daily basis. Failure to keep unit clean from mineral deposits in the water supply will result in poor efficiency of the unit.

Specifications

Voltage	Frequency	Wattage
120VAC	60 Hz	35W

LIMITED WARRANTY

This item is warranted to be free from defects in materials or workmanship for a period of one year from the original date of purchase under normal conditions of household use. Within the warranty period, we will repair/replace the product or refund your money, at our option, at the place of purchase upon presentation of sales receipt or other proof of purchase. This warranty extends only to the original retail purchaser, and excludes any damage to the product resulting from accident or misuse. The product is not warranted when used in a commercial or business environment.

The above warranty is complete and exclusive. The warrantor expressly disclaims liability for any special, incidental, indirect, or consequential damages in connection with the purchase or use of this product or costs over the original purchase price.

Any implied warranties arising by operation of law shall be limited in duration to the term of this warranty.

This warranty gives you specific legal rights and you may have other rights that vary by jurisdiction. This warranty is valid only within the United States of America (USA) and Canada.

Item #A58C0138
Model #WA-85

WIC #547126
SVC Code: 2225

©2007 All Rights Reserved

Distributed By:
East West Distributing Co.
Deerfield, IL 60015-4616

Made in China

For product information, questions, or customer service,
call toll free 1-800-645-3867 or e-mail: info@product-info.us

Model: WA-85 Frog humidifier
Task: manual
size: 140*210 mm(1page)
File Name: AR1126-WA-85 manual
Color: Black
Scale: 100%
Date: Aug.20.2007

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B ISM equipment, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.