









ATmega128RFA1 MCU card








Move jumper to pos 2&3 when doing par. programming.
Leave jumper in pos 1&2 otherwise



Remove jumper to do current measurements between pins 1 and 2



```
Board-id: 0x19
BOARD_ID4 = / (A+B) = not (BOARD_ID0 or BOARD_ID1)
BOARD_ID5 = / (A XOR B) = not (BOARD_ID0 xor BOARD_ID1)
```



ATMEL Norway AS
Vestre Rosten 79
N-7075 TILLER
Norway



Title	STK600-ATMEGA128RFA1
-------	----------------------

Size	Document Number
------	-----------------

A3	<Doc>
----	-------

Date: Wednesday, May 13, 2009

Sheet 1 of 1