

# Tobii Dynavox I-Series+

## User's Manual

I-12+

I-15+



**tobii** dynavox

## User's manual Tobii Dynavox I-Series+

Version 1.0

04/2015

All rights reserved.

Copyright © Tobii AB (publ)

No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form, by any means (electronic, photocopying, recording, or otherwise) without the prior written permission of the publisher.

Copyright protection claimed includes all forms and matters of copyrightable material and information allowed by statutory or judicial law or hereafter granted, including without limitation, material generated from the software programs which are displayed on the screen such as screen displays, menus, etc.

The information contained in this document is proprietary to Tobii Dynavox. Any reproduction in part or whole without prior written authorization by Tobii Dynavox is prohibited.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Content subject to change without notice.

Please check Tobii Dynavox web site [www.TobiiDynavox.com](http://www.TobiiDynavox.com) for updated versions of this document.

The following products are protected by U.S. Patent 7,572,008:

- I-12+ ETR
- I-15+ ETR

You can locate the Type of Tobii Dynavox I-Series+ device on the label on the back side.

# Table of Contents

<b>1</b>	<b>Introduction.....</b>	<b>7</b>
1.1	Explanation of Admonitions.....	7
1.2	Symbols and Markings.....	7
1.3	Intended Use .....	9
1.3.1	Portable Use .....	9
1.3.2	Mounted Use.....	10
1.4	Package Contents.....	10
1.4.1	Tobii Dynavox I-Series+ with Tobii Dynavox Communicator .....	10
1.4.2	Tobii Dynavox I-Series+ with DynaVox Compass.....	10
<b>2</b>	<b>Safety .....</b>	<b>12</b>
2.1	Avoiding Hearing Damage .....	12
2.2	Temperature .....	12
2.3	Power Supply and Batteries.....	13
2.4	Mounting.....	13
2.5	Emergency .....	14
2.6	Infrared .....	14
2.7	Epilepsy .....	14
2.8	Electricity .....	14
2.9	Child Safety.....	14
2.10	Environmental Control.....	14
2.11	Gaze Interaction.....	14
<b>3</b>	<b>Overview of the Tobii Dynavox I-12+ and I-15+ .....</b>	<b>15</b>
3.1	Key Features.....	15
3.2	Product Layout.....	15
3.2.1	The Tobii Dynavox I-12+ and Tobii Dynavox I-15+.....	15
3.2.2	Ports, Sensors and Device Buttons .....	16
3.3	Preinstalled Software .....	18
3.4	Configuring the Device.....	18
3.5	Accessing the microSD-Card .....	19
3.5.1	Removing the microSD-card.....	19
3.5.2	Inserting the microSD-Card.....	20
3.6	Tobii Dynavox Quick Release Adapter Plate.....	20
3.6.1	Mounting the Tobii Dynavox QR Adapter Plate .....	21
3.6.2	Removing the Tobii Dynavox QR Adapter Plate .....	21
<b>4</b>	<b>Batteries in the Tobii Dynavox I-Series+ .....</b>	<b>22</b>
4.1	Batteries .....	22
4.1.1	Hot Swappable.....	22
4.2	Charging.....	22
4.2.1	Checking Charge Level .....	23
4.3	Inserting and Releasing the Batteries .....	23
4.3.1	Inserting the Batteries.....	23
4.3.2	Releasing the Batteries .....	23
<b>5</b>	<b>Using the Tobii Dynavox I-Series+ .....</b>	<b>25</b>
5.1	Starting the Device .....	25
5.1.1	Password Information .....	25
5.1.2	Tobii Dynavox I-Series+ Welcome Guide .....	25

5.2	Shutting Down the Device .....	25
5.3	Using Gaze Interaction.....	26
5.3.1	Positioning .....	26
5.3.2	Track Box.....	26
5.3.3	Track Status Viewer.....	27
5.3.3.1	Showing Track Status .....	27
5.3.4	Positioning Guide.....	27
5.4	Using Windows Control .....	28
5.4.1	Windows Control Type .....	28
5.4.2	Starting and Disabling Windows Control.....	29
5.4.3	Using Gaze Selection .....	29
5.4.3.1	Gaze Selection Taskbar .....	29
5.4.3.2	Task Buttons .....	31
5.4.3.3	Functions Overlay in Windows 8 .....	31
5.4.3.3.1	Snap Window/Close App.....	33
5.4.3.3.2	To Snap More Apps .....	35
5.4.3.4	Selection Methods — Gaze and Switch .....	37
5.4.3.4.1	Sticky Tasks & Default Left Click / Tap for Switch .....	37
5.4.3.4.2	Activating a Task with a Keyboard button instead of a Switch .....	38
5.4.3.5	Gaze Keyboard .....	38
5.4.3.6	Gaze Selection in Combination with Region Based Keyboards.....	39
5.4.4	Using Mouse Emulation .....	39
5.4.4.1	Placing the Mouse Emulation Menu .....	39
5.4.4.2	Clicking with Windows Control in Mouse Emulation Mode.....	40
5.4.4.3	Magnifying with Windows Control in Mouse Emulation Mode.....	40
5.4.4.4	Selecting Mouse Emulation Functions.....	40
5.4.4.5	Pausing Windows Control in Mouse Emulation Mode .....	41
5.4.4.6	Scrolling with Windows Control in Mouse Emulation Mode.....	41
5.5	Wake the Tobii Dynavox I-Series+ from Sleep with Gaze Interaction.....	41
5.6	Pause/Resume Gaze Interaction and Put the Tobii Dynavox I-Series+ to Sleep with Gaze Interaction.....	42
5.7	Using the Cameras.....	43
5.8	Using the GEWA Programmable IR Remote Control.....	43
5.8.1	Handling I-Series Product Key .....	43
5.9	Adjusting the Volume .....	44
5.10	Adjusting the Sound .....	44
5.11	Performing a Factory Recovery.....	44
5.12	Calibrating the Touch Screen.....	45
6	Configuring the Tobii Dynavox I-Series+ with the I-Series Control Center .....	46
6.1	Buttons.....	47
6.1.1	Play Sound when Pressed.....	47
6.1.2	Disable All Buttons.....	47
6.2	Display.....	48
6.2.1	Brightness Adjustment.....	48
6.2.2	Display Rotation.....	48
6.3	Switches.....	49
6.3.1	Play Sound when Pressed.....	49
6.3.2	Configuring a Switch to Power On .....	50

6.3.3	Configuring a Switch to Power Off .....	50
6.4	Wake-on-Gaze® .....	50
6.5	Wireless .....	51
6.5.1	WLAN .....	51
6.5.1.1	Handling Tobii Dynavox Product Key .....	51
6.5.1.2	Enabling and Disabling the WLAN Communication .....	52
6.5.1.3	Connecting to a WLAN .....	52
6.5.2	Bluetooth® for Mobile Phone Communication .....	52
6.5.2.1	Handling I-Series Product Key .....	52
6.5.2.2	Enabling and Disabling Bluetooth® Communication .....	52
6.5.2.3	Connecting to a Bluetooth® Device .....	53
6.6	Safety .....	53
6.6.1	Audio .....	53
6.6.2	Temperature Control .....	53
6.6.2.1	Device Usage .....	54
6.7	I-Series Product Key .....	54
6.8	Setup & Updates .....	55
6.8.1	I-Series Welcome Guide .....	55
6.8.2	I-Series Update Notifier .....	55
6.9	System .....	57
6.9.1	Version & Model .....	57
6.9.2	Backup .....	57
6.9.2.1	User Profile Card .....	58
6.9.2.2	Backup Manually by the User .....	58
6.9.2.3	Restoring Backup Files by the User .....	58
6.9.2.4	Backup Failed .....	58
6.9.3	Eye Tracker .....	58
6.10	Creating Shortcuts to Actions .....	58
6.10.1	Available Actions .....	59
6.10.2	Selecting Actions .....	59
7	<b>Gaze Interaction Settings .....</b>	<b>61</b>
7.1	Accessing the Gaze Interaction Settings .....	61
7.2	Calibration .....	62
7.2.1	Starting Calibration .....	62
7.2.2	Interrupting Calibration .....	62
7.2.3	Customizing Active Eye .....	62
7.2.4	Improving Calibration Point(s) .....	63
7.2.5	Removing Calibration Point(s) .....	64
7.2.6	Customizing the Calibration .....	64
7.2.7	Customizing the Calibration Area .....	65
7.3	Interaction .....	66
7.4	User Profile .....	67
7.4.1	Creating a New Profile .....	67
7.4.2	Selecting Current User Profile .....	68
7.4.3	Deleting a Profile .....	68
7.5	Windows Control .....	68
7.5.1	Auto Start .....	68
7.5.2	Windows Control Type .....	68
7.5.2.1	Gaze Selection .....	69
7.5.2.2	Mouse Emulation .....	69

	7.5.2.2.1	Mouse Control Speed .....	69
	7.5.2.2.2	Magnifier Size and Zoom .....	70
	7.5.2.2.3	Auto Switch from Right to Left Click.....	70
	7.5.2.2.4	Turn off Scroll Functionality.....	70
	7.5.2.2.5	Custom Cursors.....	70
	7.5.2.2.6	Hide Menu.....	70
7.6	System Settings.....		71
	7.6.1	System Off-Screen Menu.....	71
	7.6.2	Positioning Guide.....	71
7.7	System Information.....		72
	7.7.1	Upgrade Eye Tracker Firmware .....	72
8	Gaze Selection Settings.....		73
8.1	The General Settings Tab.....		73
8.2	The Keyboard Settings Tab.....		74
8.3	The Taskbar Settings Tab.....		74
	8.3.1	Maximize Left Click/Tap .....	75
9	Product Care .....		76
9.1	Temperature & Humidity .....		76
	9.1.1	General Use .....	76
	9.1.2	Transportation and Storage .....	76
9.2	Cleaning .....		76
	9.2.1	Cleaning of the Speakers .....	76
9.3	Placement .....		76
9.4	Transporting the Tobii Dynavox I-Series+ Device.....		76
9.5	Disposing of the Batteries .....		77
9.6	Disposing of the Tobii Dynavox I-Series+ Device.....		77
Appendix A	Support, Warranty, Training Resources .....		78
Appendix B	Compliance Information .....		79
	B1.1	For P15B Equipment .....	79
	B1.2	For Portable Devices .....	79
Appendix C	Computer Device States of Operation.....		85
Appendix D	Maximum Allowed Temperature .....		87
Appendix E	Technical Specifications .....		88
Appendix F	Approved Accessories .....		91

# 1 Introduction

Thank you for purchasing a Tobii Dynavox I-Series+ device from Tobii Dynavox!

To ensure the optimal performance of this product, please take the time to read this manual carefully.

The Tobii Dynavox I-Series+ device is available in two different sizes: the Tobii Dynavox I-12+ with a 12.1" screen and the Tobii Dynavox I-15+ with a 15.0" screen. The Tobii Dynavox I-Series+ is a Gaze Interaction device but can be ordered without the Gaze Interaction function.

This User's Manual covers:

- The Tobii Dynavox I-Series+ device, models Tobii Dynavox I-12+ and Tobii Dynavox I-15+.
- The I-Series Control Center (for controlling the device and the I-Series Product Key).
- The Gaze Interaction functions

## 1.1 Explanation of Admonitions

In this manual we use five (5) levels of admonitions as follows:



Is used for notifying the user of something important or of something that needs special attention.



Is used to inform of something that could cause harm to, or malfunction of, the equipment.



Is used to inform of something in which there is a conceivable risk of harm to the user if the Warning is ignored.



Is used to inform of something that can cause damage to hearing.

















Is used to inform of something that cause permanent bodily harm with prolonged skin contact if the Warning is ignored.






## 1.2 Symbols and Markings

This section provides information about the symbols that are used on the Tobii Dynavox I-Series+, its accessories or packaging.

Symbol or Markings	Description
	USB 3.0 Port
	USB 2.0 Ports
	Power On
	RJ 45 Ethernet Port
	3.5 mm Switch port 1

Symbol or Markings	Description
<b>SW2</b>	3.5 mm Switch port 2
	Power Connector
	Head phone jack 3,5 mm
	Connector for an HDMI 1.3 cable
	To release the right battery
	To release the left battery
	Dispose of in accordance with your country's requirements.
<b>CE</b>	CE is the abbreviation of the European Communities and this mark tells customs officials in the European Union that the product complies with one or more of the EC Directives
<b>FCC</b>	This mark is a certification mark employed on electronic products manufactured or sold in the United States which certifies that the electromagnetic interference from the device is under limits approved by the Federal Communications Commission.
	UL Classification Marks for Canada and the United States
	RoHS Compliant
	Consult User's Manual
	Li-Ion rechargeable battery. Must be recycled or disposed properly
	Recyclable material
	Type L and Type R Listing Marks for Canada and the United States
	Conforms to relevant Australian EMC requirements
	Japanese certification for electrical/electronic appliances and components



Symbol or Markings	Description
	Dispose of in accordance with your country's requirements.
	Safety Class II equipment (reinforced insulation)
	This mark show the pin out polarity on the AC/DC Power Adapter.
	Recognized component mark for Canada and the United States
	The most recognized International Safety mark. This safety listing signifies that the product was tested to IEC 60601-1
<b>IP43</b>	Enclosure ingress protection code per IEC 60529

### 1.3 Intended Use

The Tobii Dynavox I-Series+ is an Augmentative and Alternative Communication (AAC) product, a purpose built Speech Generating Device (SGD) designed to provide to its users increased communication ability and greater independence.

The Tobii Dynavox I-Series+ is intended primarily to provide, and act as, a compliment to everyday communication for people that have challenges in their ability to speak due to injury, disability or illness. This intended use is reflected in design features such as long lasting batteries, superior sound quality, high durability, built in environmental control and connectivity features.

The Tobii Dynavox I-Series+ is a Gaze Interaction device with a built-in Tobii Eye Tracker (optional) and a capacitive touch screen for touch access. The device is intended to be used in two orientations: one, upright and mounted (or standing upright, vertically, on an appropriate surface) for Gaze Interaction use, and two, lying flat (resting in a horizontal orientation) for touch access optimization. Gaze Interaction and touch can be used in combination with switches, keyboard and/or scanning as additional input methods.

The Tobii Dynavox I-Series+ is designed primarily for face-to-face communication and secondarily for long distance communication, computer access and on-line social interaction. The Tobii Dynavox I-Series+ allows the user to communicate via text or symbols to generate synthesized (computer voice) or digitized (recorded voice) speech for face-to-face communication. The variety of communication methods allows Tobii Dynavox I-Series+ users the ability to realize their full potential.

The Tobii Dynavox I-Series+ allows its user many options of communication through text message, chat and voice calls via Bluetooth® to cell phone, WiFi to Skype®, Internet to E-mail and other third party applications such as Facebook®.

With the Tobii Dynavox I-Series+, users have the freedom and flexibility provided via the Microsoft® Windows environment, as well as the option to control TV's and other household appliances via the GEWA Programmable IR Remote Control.

The Tobii Dynavox I-Series+ meets the definition for durable medical equipment; and is registered as a Class 1 medical device. The Tobii Dynavox I-Series+ is available in two (2) sizes; and is available as a dedicated (locked) Speech Generating Device.




The Tobii Dynavox I-Series+ device does not sustain or support life.

In case of failure of the Tobii Dynavox I-Series+ device, the user cannot communicate using it.


#### 1.3.1 Portable Use

A portable Tobii Dynavox I-Series+ can be used in two (2) different positions.

- Upright orientation
- Resting orientation



**Upright Orientation**



**Resting Orientation**

The **Upright** orientation is optimized for Gaze Interaction users and the **Resting** orientation is optimized for Touch or Scan users.

### 1.3.2 Mounted Use

The Tobii Dynavox I-Series+ can be mounted on to several mounting systems. Mount the Tobii Dynavox Quick Release (QR) adapter plate on to the device. The Tobii Dynavox QR adapter plate can be attached to the following support systems:

- Daessy
- REHAdapt

For more information, see 3.6 *Tobii Dynavox Quick Release Adapter Plate*, page 20 and Appendix F *Approved Accessories*, page 91.

## 1.4 Package Contents



### Keep the original packaging materials for the Tobii Dynavox I-Series+.

In case the device needs to be returned to Tobii Dynavox for Warranty related issues or repair, it is required that the original packaging (or equal equivalent) is used for shipping.

### 1.4.1 Tobii Dynavox I-Series+ with Tobii Dynavox Communicator

The items below are included with your Tobii Dynavox I-Series+ package:

- 1 Device (12" or 15")
- 1 Eye tracker (built in)
- 1 Tobii Dynavox QR adapter plate
- 2 Batteries
- 1 Power Supply
- 1 Windows 8.1 Home Premium license
- 1 Tobii Dynavox Communicator (pre-installed)
- 1 Tobii Dynavox Sono Suite (pre-installed)
- 1 Tobii Dynavox I-Series+ User's Manual (on the device as a PDF document)
- 1 Quick Start Manual (printed)
- Safety and Compliance documents
- Warranty Document

### 1.4.2 Tobii Dynavox I-Series+ with DynaVox Compass

The items below are included with your Tobii Dynavox I-Series+ package:

- 1 Device (12" or 15")
- 1 Eye tracker (built in)
- 1 Tobii Dynavox QR adapter plate
- 2 Batteries
- 1 Power Supply
- 1 Windows 8.1 Home Premium license
- 1 Tobii Dynavox Compass (pre-installed)
- 1 Tobii Dynavox I-Series+ User's Manual (on the device as a PDF document)
- 1 Quick Start Manual (printed)
- Safety and Compliance documents
- Warranty Document

## 2 Safety

The Tobii Dynavox I-Series+ device has been tested and approved as compliant to all the Specifications and Standards listed in *Appendix B Compliance Information, page 79* of this manual and in the *Appendix E Technical Specifications, page 88* -- including, but not limited to, the Medical Device Standard (Class 1/Type B). Nevertheless, in order to ensure safe operation of your Tobii Dynavox I-Series+ device, there are a few safety warnings to bear in mind:



### **No modification of this equipment is allowed**



The Tobii Dynavox I-Series+ is not to be used as a life supporting Device, and it shall not be relied on in case of loss of function due to power loss or other causes.



There could be a choking hazard risk if small parts detach from the Tobii Dynavox I-Series+ device.



The Tobii Dynavox I-Series+ device shall not be exposed to or used in heavy rain or weather conditions outside the Technical Specification of the Tobii Dynavox I-Series+ device.



The Tobii Dynavox I-Series+ device shall only be used with Tobii Dynavox I-Series+ specific Accessories that have a mounting instruction included with the accessory.



Young children or people with cognitive disabilities should not have access to, or the use of, the Tobii Dynavox I-Series+ device without parental or guardian supervision.



Do not attach any decorations, post-it notes or similar on the screen side of the Tobii Dynavox I-Series+ device, that may interfere with the Gaze Interaction or touch screen performance.

### 2.1 Avoiding Hearing Damage



Permanent hearing loss may occur if earphones, headphones or speakers are used at high volume. To prevent this, the volume should be set to a safe level. You can become desensitized over time to high sound levels which may then sound acceptable yet still could be damaging your hearing. If you experience symptoms such as ringing in your ears, please lower the volume or stop using the earphones/headphones. The louder the volume, the less time is required before your hearing could be affected.

Hearing experts suggest the following measures to protect your hearing:

- Limit the amount of time you use earphones or headphones at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you cannot hear people speaking near you.

To establish a safe volume level:

- Set your volume control at a low setting.
- Slowly increase the sound until you can hear it comfortably and clearly, without distortion.

### 2.2 Temperature



This device can be made to operate in two different modes, Portable and Mounted. When the device is in Mounted mode it is allowed to run at a higher temperature; it sets the maximum allowable environmental temperature to its highest level. The risk with running the device in this mode is that it can reach temperatures in which prolonged use with direct skin contact may cause permanent bodily harm. Portable mode sets the maximum device temperature shut down limit to a lower temperature, reducing the risk for permanent bodily harm caused by prolonged exposure to the skin. Only choose Mounted mode when the device is mounted on a wheelchair, table, etc, with a proper mounting system.



Due to use in direct sunshine or in any other hot environment the Tobii Dynavox I-Series+ device may have hot surfaces. There is a built in temperature sensor that monitors the temperature. If the sensor detects temperatures above the temperature specified in *Table D.1 Maximum Allowed Temperature, page 87* for portable mode and mounted mode the device will automatically trigger a Windows Shut Down or Hibernate (depending on Windows Power Button configuration) to not cause the User any risk of harm. It may take a while before Tobii Dynavox I-Series+ device can be restarted as the unit may first need time to cool down.

## 2.3 Power Supply and Batteries



The Tobii Dynavox I-Series+ device uses Lithium Ion batteries. These batteries have a storage temperature range of between -20 °C/-4 °F and 40 °C/104 °F within 6 months.

If you are in a hot environment, be aware that it can affect the ability to charge the batteries. The internal temperature has to be between 0 °C/32 °F and 45 °C/113 °F for the batteries to charge. If the internal battery temperature raises above 45 °C/113 °F the batteries will not charge at all.

Move the Tobii Dynavox I-Series+ device and the batteries to a cooler environment to let the batteries charge properly.



Avoid exposing the batteries to fire or to temperatures above 50 °C/122 °F. These conditions may cause a battery to malfunction, generate heat, ignite or explode. Be aware that it is possible, in a worst case scenario, for temperatures to reach greater than those stated above in, for example, the trunk of a car on a hot day. So, storing the device, with batteries installed, in a hot car trunk could conceivably lead to a malfunction.



Do not disassemble or harm the battery. Pay attention to the environmental laws and regulations which apply in your area when disposing of batteries.



For safe operation of the Tobii Dynavox I-Series+ device, use only charger, batteries and accessories approved by Tobii Technology.



Do not open, or modify, the metal casing of the Tobii Dynavox I-Series+ device or of the power supply, since you may be exposed to potentially hazardous electrical voltage. The device contains no serviceable parts. If the Tobii Dynavox I-Series+ device or its accessories are mechanically damaged, **do not to use them**.



If the batteries are not charged or the Tobii Dynavox I-Series+ is not powered up by the power supply, the Tobii Dynavox I-Series+ device will shut down.



If the Power Supply Cord is damaged, replaceable by Service Personnel only



Do not connect any devices with a non-medical grade power supply to any connector on the Tobii Dynavox I-Series+ device.



The appliance coupler of the power supply or separable plug is used as the Mains Disconnection Device, please do not to position the Tobii Dynavox I-Series+ device so that it is difficult to operate the disconnection device.



Special regulations apply to shipping Lithium-ion batteries. If dropped, crushed, or short-circuited, these batteries can release dangerous amounts of heat and may ignite, and are dangerous in fires.

Please reference IATA regulations when shipping lithium metal or lithium ion batteries or cells: [http://www.iata.org/whatwedo/cargo/dangerous\\_goods/Pages/lithium\\_batteries.aspx](http://www.iata.org/whatwedo/cargo/dangerous_goods/Pages/lithium_batteries.aspx)

## 2.4 Mounting



The Tobii Dynavox I-Series+ should be mounted according to MANUFACTURER instructions of approved mounts. Tobii Dynavox or its agents are not liable for damage or injuries to a person or its property due to a Tobii Dynavox I-Series+ falling from a mounted configuration. The mounting of a Tobii Dynavox I-Series+ is done entirely at the user's own risk.

## 2.5 Emergency



Do not rely on the device for emergency calls or banking transactions. We recommend having multiple ways to communicate in emergency situations. Banking transactions should only be carried out with a system recommended by, and approved according to the standards of, your bank.

## 2.6 Infrared



The Tobii Dynavox I-Series+ emits pulsed infrared (IR) light both from the eye tracker and from the Environmental Control Unit. Other devices controlled by IR or susceptible to disturbance by IR light might be affected by the IR light emitted from the Tobii Dynavox I-Series+. Do not use the Tobii Dynavox I-Series+ in the vicinity of such devices if their functionality is of critical importance.

## 2.7 Epilepsy



Some people with **Photosensitive Epilepsy** are susceptible to epileptic seizures or loss of consciousness when exposed to certain flashing lights or light patterns in everyday life. This may happen even if the person has no medical history of epilepsy or has never had any epileptic seizures.

A person with Photosensitive Epilepsy would also be likely to have problems with TV screens, some arcade games, and flickering fluorescent bulbs. Such people may have a seizure while watching certain images or patterns on a monitor, or even when exposed to the light sources of an eye tracker. It is estimated that about 3-5% of people with epilepsy have this type of Photosensitive Epilepsy. Many people with Photosensitive Epilepsy experience an "aura" or feel odd sensations before the seizure occurs. If you feel odd during use, move your eyes away from the eye tracker.

## 2.8 Electricity



Do not open the casing of the Tobii Dynavox I-Series+ device, since you may be exposed to potentially hazardous electrical voltage. The device contains no serviceable parts.

## 2.9 Child Safety



The Tobii Dynavox I-Series+ are advanced computer systems and electronic devices. As such they are composed of numerous separate, assembled parts. In the hands of a child certain of these parts have the possibility of being separated from the device, possibly constituting a choking hazard or another danger to the child.

Young children should not have access to, or the use of, the device without parental or guardian supervision.

## 2.10 Environmental Control



The GEWA Programmable IR Remote Control — Environmental Control Unit (ECU) is not to be relied on as the only method of interaction with IR controlled devices.

## 2.11 Gaze Interaction



Some people may experience a certain amount of fatigue (due to intentional eye focusing and hard concentration) or even a dryness of the eyes (due to less frequent blinking) when first getting used to Gaze Interaction. If you are experiencing fatigue or dry eyes start off slowly and limit the length of your Gaze Interaction sessions to your comfort level. Remoisturizing eye drops can be helpful to combat dryness.

## 3 Overview of the Tobii Dynavox I–12+ and I–15+

### 3.1 Key Features


The Tobii Dynavox I-Series+ has several built-in features. Some of these come standard and some can be ordered as additional features.

**Standard features:** 2 × Camera, 1 × microphone, 2 × speakers, 1 × ECU (Environmental Control Unit), 1 × Bluetooth® (for mobile phones etc) and 1 × WLAN (Wireless Local Area Network)

### 3.2 Product Layout

A Tobii Dynavox I-Series+ device has a color Capacitive touch, LED Backlight screen. The Tobii Dynavox I–12+ has a 12.1" screen with a 1024 × 768 pixel resolution. The Tobii Dynavox I–15+ has a 15.0" screen with a 1024 × 768 pixel resolution.

#### 3.2.1 The Tobii Dynavox I–12+ and Tobii Dynavox I–15+



### 3.2.2 Ports, Sensors and Device Buttons




Figure 3.1 Front and Back

Position	Description	Position	Description
1	Webcam 2 MP Fixed Focus (FF)	6	GEWA Programmable IR Remote Control (Transmitter)  This port is just for Transmitting IR Signals. To program the device, use port in Position 27 in <i>Figure 3.2 Bottom, Left and Right Side, page 17</i>
2	Light sensor	7	Camera 5 MP Auto Focus (AF)
3	Microphone	8	Mounting
4	Eye Tracker	9	Speakers
5	Carrying grip	30	Label






Figure 3.2 Bottom, Left and Right Side

Position	Description	Position	Description
10	Power button	20	Menu button
11	Volume Up button	21	USB 3.0 connector
12	Volume Down button	22	2 × USB 2.0 connector
13	Head phone jack 3,5 mm	23	RJ45 Network connector
14	Connector for an HDMI 1.3 cable	24	Battery
15	Switch Port 1	25	Slide lock for battery
16	Switch Port 2	26	Battery indicator
17	Power Connector	27	GEWA Programmable IR Remote Control (Transmitter and Receiver)  Use this port when programming the GEWA from within Tobii Dynavox Communicator /Tobii DynaVox Compass.
18	Quick Access Button 1 (Configurable)	28	microSD-card (under lid)
19	Quick Access Button 2 (Configurable)	29	I/O covers (for fulfilling IP43)



Never force a connector into a port. If the connector and port do not join with reasonable ease, they probably do not match. Make sure that the connector matches the port and that you have positioned the connector correctly in relation to the port.

Be extra careful with the USB connectors.

### 3.3 Preinstalled Software

The Tobii Dynavox I-Series+ device is delivered with all preordered and required software installed and ready to use. Should a reinstallation become necessary at any stage perform a Factory Recovery. For more information, see *5.11 Performing a Factory Recovery, page 44*.

The product number for Windows® can be found on the back of the Tobii Dynavox I-Series+ device.


### 3.4 Configuring the Device

Use the preinstalled **I-Series Control Center** to configure the hardware functions on the device. You can access **I-Series Control Center** in one of the following ways:

- Double-click on the **I-Series Control Center** shortcut on the desktop,  .

or

1. Go to **Start menu > Control Panel**.



2. Double-click **I-Series Control Center**,  , if the Control Panel is in Classic View. If the Control Panel is in Category view, select **View by: > Small icons or Large icons**, and Double-click **Tobii Dynavox I-Series+ Control Center**


or

1. Go to **Start menu > Tobii Dynavox >**.

2. Click **I-Series Control Center**,  .

or


- Through the communication software installed on the device.



In the list to the left, select which hardware configuration you want to change. In the area to the right, the different settings will be revealed. The changes are instantly executed.

For more information about configuring the Tobii Dynavox I-Series+ with the I-Series Control Center, see *6 Configuring the Tobii Dynavox I-Series+ with the I-Series Control Center*, page 46.




Anywhere you see this icon, , an information box is displayed when you briefly rest the mouse pointer on the icon or by touching the icon on the screen.

## 3.5 Accessing the microSD-Card

The microSD-Card (position 28 in *Figure 3.2 Bottom, Left and Right Side*, page 17) is installed in the Tobii Dynavox I-Series+ device by default.

### 3.5.1 Removing the microSD-card




To remove the microSD-card:

1. Place the Tobii Dynavox I-Series+ device face down on a flat surface.
2. Use a Phillips screwdriver to remove the screw that fastens the lid in place.
3. Remove the lid.
4. Press to release the microSD-card.
5. Pull the card out of the socket.
6. Replace the lid.

7. Tighten the screw with a Phillips screwdriver to fasten the lid in place.

### 3.5.2 Inserting the microSD-Card



To install the microSD-card:

1. Place the Tobii Dynavox I-Series+ device face down on a flat surface.
2. Use a Phillips screwdriver to remove the screw that fastens the lid in place.
3. Remove the lid.
4. Carefully push the microSD-card into the socket.




Do not use force when pushing in the microSD-card. If the microSD-card and socket do not join with reasonable ease, they probably do not line up.


5. Replace the lid.
6. Tighten the screw with a Phillips screwdriver to fasten the lid in place.

## 3.6 Tobii Dynavox Quick Release Adapter Plate

Tobii Dynavox QR adapter plate has two sides:




Daessy



REHAdapt

Make sure the required side of the Tobii Dynavox QR adapter plate is face away from the Tobii Dynavox I-Series+ for the mounting system to use.

### 3.6.1 Mounting the Tobii Dynavox QR Adapter Plate



To mount the Tobii Dynavox QR adapter plate:

1. Place the Tobii Dynavox I-Series+ device face down on a flat surface.
2. Select the required side of the plate, see *1.3.2 Mounted Use, page 10*.
3. Place the plate onto the device with the required side facing away from the unit.
4. Tighten the three (3) screws using a Torx T20 screwdriver to that fasten the plate to the unit.

### 3.6.2 Removing the Tobii Dynavox QR Adapter Plate

To remove the Tobii Dynavox QR adapter plate:

1. Place the Tobii Dynavox I-Series+ device face down on a flat surface.
2. Use a Torx T20 screwdriver to remove the three (3) screws that fasten the plate to the unit.
3. Remove the plate.

## 4 Batteries in the Tobii Dynavox I-Series+

### 4.1 Batteries

The Tobii Dynavox I-Series+ device has two battery compartments. The batteries are of the same size and capacity for both the Tobii Dynavox I-12+ and I-15+, see *Appendix E Technical Specifications, page 88*.




Figure 4.1 Battery with Indicator for Remaining Capacity

#### 4.1.1 Hot Swappable

You can remove/replace one battery without switching off the Tobii Dynavox I-Series+ device, providing that the remaining battery is sufficiently charged. The remaining battery requires being at least ~10% charged to maintain device operation.



Please allow the Tobii Dynavox I-Series+ device a few seconds to detect the newly inserted battery before removing the other battery.

### 4.2 Charging

The batteries shall only be charged using the included adapter, or by using the I-Series Table Charger (not included, separate purchase required). When the Tobii Dynavox I-Series+ device is shut down and the adapter is plugged in, the charging of completely discharged batteries may take up to 5 hours. The device can be used while the batteries are being charged, though this may affect the time a battery takes to reach full capacity.



To be sure that charging takes place in both the Tobii Dynavox I-Series+ device and when using the I-Series Table Charger, be sure to plug the adaptor into both the wall socket and the device or Charger **BEFORE** you insert the batteries.




The batteries will only charge when its capacity is 95% or lower.

The expected battery lifetime is 500 charge/discharge cycles. After that, the capacity of the battery will decrease by about 20% in usage time.

For battery storage and charging temperatures, see *2 Safety, page 12*.

## 4.2.1 Checking Charge Level



Click on the battery icon, , in the Notification area to see the remaining charge of the battery, which is installed in the device.



You may also, at any time, check the status of a battery by pressing the indicator button on the face of the battery. Five LEDs (light-emitting diodes) will indicate the remaining charge level. For example, three lit LEDs indicate a 60% remaining charge, see *Figure 4.1 Battery with Indicator for Remaining Capacity*, page 22.

When charging, the highest capacity LED indicator will be blinking.



The lowest capacity LED indicator (the "20" LED), will also blink when the indicator button is pressed if the battery's capacity has dropped below 10%. So don't rely upon the blinking of the 20% indicator as a guarantee for charging.




If the batteries have been deeply discharged (this can happen by leaving an empty battery inserted in the Tobii Dynavox I-Series+ device without the power adapter connected) you may not see any indication of charging when you reconnect the adapter properly to the Tobii Dynavox I-Series+ device or the Table Charger. It may take some time (even up to 20 minutes) before you see an LED indication that any charging is taking place. The battery IS being charged during this duration though it is a recovery charge raising the level enough to begin normal charging.

## 4.3 Inserting and Releasing the Batteries

For safety reasons, the Tobii Dynavox I-Series+ device is delivered without the batteries inserted. The batteries are delivered only partially charged. The Tobii Dynavox I-Series+ device can be used right away. It is nevertheless recommended that the batteries are charged for at least two hours before using the device.


### 4.3.1 Inserting the Batteries



To insert the batteries:

1. Insert a battery in the battery compartment.
2. Press the battery until it locks in place. You should hear a click that confirms that the battery is in a locked place.

### 4.3.2 Releasing the Batteries



If the Tobii Dynavox I-Series+ is in Upright orientation:

1. Press the battery slide lock to the side.

2. Pull the battery out (the battery will stop after ~1 cm / 0.4").
3. Push the battery up a little bit (Do not push the battery all the way in again).
4. Pull the battery out of the battery compartment..

If the Tobii Dynavox I-Series+ is in Resting orientation:

1. Place the Tobii Dynavox I-Series+ device face down on a flat surface.
2. Press the battery slide lock to the side.
3. Pull the battery out of the battery compartment.



# 5 Using the Tobii Dynavox I-Series+

No skill other than reading is necessary for setting up the Tobii Dynavox I-Series+ device. Follow this User's Manual and the Quick Start Manual.

## 5.1 Starting the Device

Start the device in one of the following ways:

- Press the power button on the right side of the device. (Position 9 in *Figure 3.2 Bottom, Left and Right Side, page 17*)
- Activate a configured Switch (see *6.3 Switches*).

When you have started the device, the Power LED will shine blue or green depending on if the device is connected to AC or on batteries. For more information about the LED Behavior, see *Appendix C Computer Device States of Operation, page 85*.

### 5.1.1 Password Information

The Tobii Dynavox I-Series+ device is configured to start up, using the operating system present, without a password. Though unusual, there are situations in which the password window could plausibly pop up; for example, when creating a new user in the operating system, when returning from the operating system's sleep mode or when downloading software updates from the internet.



Creating a new windows user and downloading updates from the internet could possibly compromise the system and software settings of the operating system that have been set and installed at Tobii Technology.

Should the password window pop up, requiring a password, the default password on all Tobii Dynavox I-Series+ devices is, "**Tobii Dynavox**" (case sensitive). In order to type in the password use the Windows On-Screen Keyboard or an external USB keyboard (not included).

If you decide to change the password, be sure to write it down in a safe place for later use.

Suggested place to keep new password: \_\_\_\_\_

Without the operating system's access password, Tobii Dynavox Support may be unable to assist you with any future difficulties.

### 5.1.2 Tobii Dynavox I-Series+ Welcome Guide

When you start your Tobii Dynavox I-Series+ Device for the first time you will be greeted by the Tobii Dynavox I-Series+ Welcome Guide. The guide is a setup wizard that will walk you through some steps that will help you make the most of your device.

Follow the instructions and select on **Next** to get to the next page of the Guide.

## 5.2 Shutting Down the Device

The device should be shut down using one of the following ways:

- Use the start menu in Windows (recommended when possible).
- Press a configured Switch for two to seven seconds.



Pressing the Switch for more than 7 seconds will shut down the device immediately, disregarding any unsaved changes.

- Through the communication software installed on the device

Should you be unable to shut the device down using either of the above, you can hold the power button on the right side of the device down for seven seconds. The device will consequently shut down immediately, without waiting for open applications to close.



This will not work if the side buttons have been disabled in the Tobii Dynavox I-Series+ Control Center. For more information, see *6.1.2 Disable All Buttons, page 47*.



This is not considered a "clean" Windows shut down and is thus not recommended unless completely necessary.

## 5.3 Using Gaze Interaction

The Tobii Dynavox I-Series+ operate with precision regardless of glasses, contact lenses, eye color or light conditions. Gaze Interaction enables you to control the computer with your eyes using either Gaze Enabled applications (like Tobii Dynavox Communicator /Tobii DynaVox Compass) or through the two types of Windows Control. See 5.4.1 *Windows Control Type*, page 28.

### 5.3.1 Positioning




Figure 5.1 Positioning

The Tobii Dynavox I-Series+ is designed to work optimally when it is parallel to the user's eyes at a distance of about 60 cm (23.5 inches), see *Figure 5.1 Positioning*, page 26.




Figure 5.2 Positioning when Users Leaning Sideways or Those Lying Down

This means that for those users leaning sideways or those lying down the Tobii Dynavox I-Series+ also needs to be tilted in order to keep the users eyes parallel to the screen and at the optimal distance, see *Figure 5.2 Positioning when Users Leaning Sideways or Those Lying Down*, page 26.



Make sure the user is placed comfortably in relation to the optimal positioning of, and distance from, the unit. Be aware also that the user's comfort, as well as the Gaze Interaction performance, will be enhanced if the sun is not shining directly on the screen or into the user's eyes.

The user should be positioned at the optimal distance to allow for the best possible Gaze Interaction.

### 5.3.2 Track Box


The Tobii Dynavox I-Series+ allows for extensive Freedom of Head Movement. Once the Tobii Dynavox I-Series+ is properly calibrated and placed in front of the user, no further adjustments are required.

The Tobii Dynavox I-Series+ produces an industry leading sized track box with the approximate dimensions of 30 cm × 20 cm × 20 cm / 11.8 in × 7.9 in × 7.9 in (Width × Height × Depth). The Track Box is an invisible box positioned approximately 60 cm (23.5 in) straight out from a point just above the middle of the screen.

At 70 cm (27.5 in) the Tobii Dynavox I-Series+ allows for lateral Freedom of Head Movement in an area of about 50 × 36 cm (20 × 14 in).

In order to function properly for Gaze Interaction the user needs at least one eye in the track box at all times.

### 5.3.3 Track Status Viewer



Use the Track Status viewer (see 5.3.3.1 *Showing Track Status*, page 27 for more information on how to open the Track Status viewer) to help determine the optimal height and horizontal positioning for Gaze Interaction with the Tobii Dynavox I-Series+.

- Ideally, the two dots that represent the user's eyes should be in the middle of the Track Status viewer.
- Use the distance meter on the right hand side of the Track Status viewer to determine the optimal distance the user should be from the Tobii Dynavox I-Series+.
- The white triangle in the distance meter should hover near the center, within the green, when the optimal distance from the Tobii Dynavox I-Series+ is reached.



For information about calibration of the Tobii Dynavox I-Series+ see 7.2 *Calibration*, page 62. Also check the lighting conditions, related to what is mentioned above, when calibrating.

#### 5.3.3.1 Showing Track Status

The track status viewer is a window/dialog where you can verify that the Gaze Interaction recognizes your eyes and that you are well positioned in front of the device.

Open the track status viewer in one of the following ways:

- Open **Tobii Dynavox Gaze Interaction Settings > Calibration** and select the **Track status** button.
- Right-click (long-hold finger on icon for touch screen right clicking) on the **Tobii Dynavox Gaze Interaction Settings**



icon, in the Notification area and select **Show track status**.



### 5.3.4 Positioning Guide

For extra assistance in positioning, there is a **Positioning guide** that will show itself automatically in the bottom-right corner of your monitor.

The **Positioning guide** is a visual guide that combines the function of the Track Status viewer with six different image based instructions to help the user with correct positioning.

The 6 instructions direct the user to:

1. Move head down.
2. Move head up.
3. Move head to the right.
4. Move head to the left.
5. Move head closer to the monitor.
6. Move head farther away from the monitor



Move head closer to the monitor.



Move head to the right.

The **Positioning guide** will automatically disappear when the user's positioning is improved in the way that is directed by the guide.

Some users may not want the **Positioning guide** to pop up every time their eyes leave optimal positioning.

To turn On or Off the automatic **Positioning guide**, see *7.6 System Settings, page 71*

## 5.4 Using Windows Control

Windows Control allows you to access the desktop and all applications of your Windows computer with Gaze Interaction.

### 5.4.1 Windows Control Type

Windows Control can be used in two different modes

- Gaze Selection
- Mouse Emulation

To select which type of Windows Control you wish to use and to customize Windows Control:

- Open **Tobii Dynavox Gaze Interaction Settings > Windows Control**, see *7.5 Windows Control, page 68*
- Select your preferred type of Windows Control under **Windows Control Type**

## 5.4.2 Starting and Disabling Windows Control

To start Windows Control, right-click on the **Tobii Dynavox Gaze Interaction Settings** icon,  , in the Notification area and select **Enable Windows Control**.



Or

Double-click on the **Windows Control** shortcut on the desktop,  , This will immediately start Windows Control.

To disable Windows Control, right-click on the **Tobii Dynavox Gaze Interaction Settings** icon,  , in the Notification area and select **Disable Windows Control**.

You can also start Windows Control from Tobii Dynavox Communicator /Tobii DynaVox Compass or alternative communication software, which has implemented the functions provided by the Tobii Dynavox Eye Control SDK 2

### Auto start

- Open **Tobii Dynavox Gaze Interaction Settings > Windows Control**.
- Check the **Auto start windows control at boot** check box if you want Windows Control to auto start when the Tobii Dynavox Gaze Interaction Software starts.

## 5.4.3 Using Gaze Selection

The Gaze Selection mode of Windows Control makes it possible for the user to control a standard Windows desktop operating system with a two step selection method which reduces the risks of unwanted clicks. It also prevents the following of the mouse cursor with your gaze as opposed to the controlling of it (there is no floating mouse cursor in Gaze Selection).

1. The first step is to select the desired Task from the docked Taskbar by looking at it.
2. The second step is to look at the desired portion of the screen (or icon on the screen) where you want to execute the Task. An automatic zoom function is enabled, ending in the selection of the icon or execution of the task.



All functions in Gaze Selection are Touch and Mouse enabled which makes it easier for a Caregiver or Assistant to help the user if needed. The Caregiver or Assistant can select a Function/Task or change the settings for the user much easier.

### 5.4.3.1 Gaze Selection Taskbar

At the top of the Gaze Selection Taskbar there is a Track Status viewer. It allows you to verify that the eye tracker recognizes your eyes and that you are well positioned in front of the device.


The Task Buttons in the Gaze Selection Taskbar can be in three different modes as shown in *Figure 5.3 The Modes for the Gaze Selection Taskbar*, page 30.


- **Normal (Unselected)** - No Task Button for Gaze Selection is chosen.
- **Primary Selection (Blue/black)** - The marked Task Button is selected and the Task will be executed after the automatic zoom when the user looks at the desired position on the screen or icon on it. If the selection method is set to Switch in the Gaze Selection Settings Dialog, the chosen Task Button will still remain active after executing the Task.



The Functions Overlay Task will not perform any zooming. When selecting Functions Overlay with Primary Selection, the Functions Areas/Commands will be active but not visible.

- **Secondary Selection(Blue/white)** - Same as **Primary Selection** but with a higher precision. **Primary Selection** means that the zoom will progress deeper before the final execution of the Task, making the desired portion of the screen bigger and easier to select within. Activate this mode by resting your gaze on the Task Button until the color changes according to the image below.

 The Functions Overlay Task will not perform any zooming. When selecting Functions Overlay with Secondary Selection, the Functions will be active and the areas of each Function will be visible to the user.

 The Functions Overlay will not perform any zoom, some other tasks won't either in some situations (scroll, settings, keyboard).













Figure 5.3 The Modes for the Gaze Selection Taskbar

### 5.4.3.2 Task Buttons

Task Button	Action	Description
	Gaze Drag & Drop	<p>Task that performs two "clicks", where the first one represents the starting position for the drag and the second the drop position (to move objects or select areas).</p> <ul style="list-style-type: none"> <li>• Select the Task</li> <li>• Look at the object you want to move or the starting point for the area selection</li> <li>• Execute the Gaze Selection (first "click") by Switch or Gaze</li> <li>• Look immediately at the drop position for the object or end point for the area selection.</li> <li>• Execute the second "click" by Switch or Gaze</li> </ul>
	Gaze Scroll	<p>Task that, if performed on a scrollable window, enables a gaze-controlled way to scroll the page</p> <ul style="list-style-type: none"> <li>• Select the Task</li> <li>• Look at any scrollable area and hold your gaze, the Gaze Scroll icon will appear where you looked</li> <li>• Look above the icon to scroll up</li> <li>• Look below the icon to scroll down</li> <li>• Look to the left of the icon to scroll left</li> <li>• Look to the right of the icon to scroll right</li> <li>• While scrolling, look back at the icon (on the screen, not the Taskbar icon) to toggle between up/down or left/right</li> <li>• Look back at the Gaze Selection Taskbar (or outside of the screen) to end scrolling</li> </ul> <p> Use the Gaze Scroll Task to scroll vertically and horizontally in Modern UI apps and the Modern UI Windows Start Screen.</p>
	Left Click / Tap	Task that performs a single left-click, or for touch based devices, the equivalent of a single finger Tap. When in Switch mode Left Click / Tap is Default on and Sticky" (see 5.4.3.4.1 <i>Sticky Tasks &amp; Default Left Click / Tap for Switch</i> , page 37)
	Functions Overlay	Task that activates the Functions Overlay. Primary Selection activates the Functions Overlay. Secondary Selection activates the Functions Overlay and makes it (and its individual Functions and areas) visible over the top of anything else on the screen to assist in selecting them. The individual Functions available on the Functions Overlay are different for Windows 7 (see ).
	Right Click	Task that performs a single right-click
	Double Click	Task that performs a double left-click. When in Switch mode Double Click is a "sticky Task" (see 5.4.3.4.1 <i>Sticky Tasks &amp; Default Left Click / Tap for Switch</i> , page 37)
	Gaze Keyboard	Task that opens an on-screen Gaze enabled keyboard for Gaze typing
	Settings	<p>Task that opens the Gaze Selection Settings Dialog</p> <p>For more information, see 8 <i>Gaze Selection Settings</i>, page 73</p>

### 5.4.3.3 Functions Overlay in Windows 8

Windows 8 Gaze Selection is a revolutionary new method of Gaze Interaction. It is expressly created for the modern and intuitive touch enabled environment of tablets, as well for maximizing and enhancing the complete Gaze Interaction experience of ultrabooks, laptops, and desktop PCs.

It is created as a wholistic, full OS control, Gaze Interaction solution; enabling fully hands-free control of your Windows 8 OS. From emulated touch gestures, click types, taps and side swipes, to Charms and split screen Snapping. From real "Gaze-on/ Hands-off" multitasking to true access and control of all available legacy or current Desktop applications and settings.

Windows 8 Gaze Selection opens the tens of thousands of the current, social, professional, entertaining and educational Windows 8 Modern Apps to Eye Controlled use.


Built around making use of the intuitive power of Microsoft's new touch-centric interface for Windows 8 touch screen devices, the new Gaze Selection brings hands free use into the modern consumer computer environment.








While it is centrally built around fully hands-free use cases, Gaze Selection is also made for even faster access with Switches, as well as being completely touch (and mouse) enabled for multimodal input and third party assistance.














When selecting the Functions Overlay with **Primary Selection**, the Functions Areas/Commands will be active but not visible.

When selecting the Functions Overlay with **Secondary Selection**, the Functions will be active and the areas of each Function will be visible to the user.

 The Functions Overlay will not perform any zoom.

Functions	Action	Description
	App Switcher	<p>Function that opens the App Switcher bar where all running Modern User Interface (UI) Apps are visible including the Desktop.</p> <p> All software running in the Desktop, will not be visible here. They are only visible from the Desktop.</p> <p> The App Switcher will not show if there is only one or less Apps open.</p> <p> The App Switcher will not be accessible if the App Switcher is turned Off in the PC Settings.</p>
	Show App Bar	Function that makes the App Bar for active App visible. The App Bar is context based for the active App and therefore will consist of different actions for each App.
	Charms Menu	Function that opens the Charms Menu.
	Move Taskbar	Function that moves the Taskbar from right/left.



Functions	Action	Description
	Snap Window/Close App	<p>Function that performs three (3) different actions.</p> <ul style="list-style-type: none"> <li>Select the  to move and dock the active App to the selected Target area.</li> <li>Select the  to move the active App to the bottom of the screen and to Close the active App.</li> <li>Select the  to move and dock the active App into Full-screen view.</li> </ul> <p>For more information, see 5.4.3.3.1 <i>Snap Window/Close App</i>, page 33.</p>
	Windows Button	<p>Function that toggles between the Modern Windows UI and the previous Modern UI App or Desktop.</p> <p> All software running in the Desktop, will not be visible here. They are only visible from the Desktop.</p>
	Hide Taskbar	<p>Function that hides the Taskbar for Full Screen view. To Bring back the Taskbar, select  or  depending on which side the Taskbar is located.</p>
	Flip Previous App	<p>Function that swipes through all running Modern UI Apps and the Desktop.</p> <p> All software running in the Desktop, will not be visible here. They are only visible from the Desktop.</p>

#### 5.4.3.3.1 Snap Window/Close App

The Snap Window feature in Windows 8 makes it possible to split and divide the screen to be able to run two to four Modern Apps at the same time. This feature is limited to the resolution of screen of the device, see *Table 5.1 Number of Apps on Screen Windows 8.1*, page 33 for information on how many Apps are possible to run on which screen resolution in Windows 8.1. The lowest resolution needed to be able to Snap Windows is 1024×768 (Windows 8.1) and 1366×768 (Windows 8.0).

Table 5.1 Number of Apps on Screen Windows 8.1

Number of Apps	Screen Resolution (Pixels)
2	< 1499
3	1500 — 1999
4	>=2000



Windows 8.0 can only run two Apps at the same time.



The Snap Window/Close App can only control visible Apps on the screen.






This will look different depending on how many Apps are Snapped at the same time.

#### To Snap the Apps:

- Select the  (Functions Overlay) Task from the Taskbar.

2. Select one of the following actions:

- Select the  to move and dock the active App to the selected Target area.
- Select the  to move the active App to the bottom of the screen and to Close the active App.
- Select the  to move and dock the active App in Full-screen view.




Figure 5.4 Overview

#### To Move and Close the Apps:




For example: If an App is Snapped in the middle, Select:

1. The  function

2. Select the middle area.



3. Select:




- Select to move the App into  (Full-screen) view
- Select one of the  (Target) to move the App to the new Target area.
- Drag the App to the  (Close) icon in the bottom middle of the screen to close the App.




**For example: If an App is Snapped to the left or right, select:**

1. The  function



2. Select the left or right area.

3. Select:

- Select to move the App into  (Full-screen) view
- Select one of the  (Target) to move the App to the new Target area.
- Drag the App to the  (Close) icon in the bottom middle of the screen to close the App.



#### 5.4.3.3.2 To Snap More Apps

To be able to Snap more than two Apps on the screen, the  (Drag and Drop) Task from the Taskbar must be used, see *Table 5.1 Number of Apps on Screen Windows 8.1, page 33* for more information about how many Apps can be visible at the same time on the screen. With the  (Drag & Drop) it is possible to customize the width of each Snap area also.

1. Start an App from the Modern UI Start Screen or from Recent Apps/App Switcher. It will place itself in the center, see *Figure 5.5 Selected Third App, page 36*.



You can always Right Click an App in the App Switcher and choose the Target area from the Drop Down list.







Figure 5.5 Selected Third App

2. Select the  (Drag & Drop) Task from the Taskbar.
3. Drag and then Drop the App where you want it to be
  - Right — Select the App with the  (Drag & Drop) Task from the Taskbar. Drop it to the right side of the screen to place it in the right-hand target, see *Figure 5.6 Snap Right, page 36*
  - Left — Select the App with the  (Drag & Drop) Task from the Taskbar. Drop it to the left side of the screen to place it in the left-hand target, see *Figure 5.7 Snap Left, page 37*




Figure 5.6 Snap Right




Figure 5.7 Snap Left

#### 5.4.3.4 Selection Methods — Gaze and Switch

There are two methods to execute the chosen Task. The method of choice is set from within the Gaze Selection Settings Dialog, see *8 Gaze Selection Settings, page 73*.

Before executing a selection you select a Task from the Taskbar to execute. Gaze at your chosen task until it is highlighted as “Primary” or “Secondary Selection”.

- **Gaze** - To execute the chosen Task, rest your gaze at the desired portion of the screen (or icon on the screen) where you want to execute the Task. An automatic zoom function is enabled, ending in the selection of the icon or execution of the task.
- **Switch** - Two different execution modes.
  - **Single activation of the Switch** - the zoom function will execute in the same way as with the Gaze method and according to the settings made in the Gaze Selection Settings Dialog, see *8 Gaze Selection Settings, page 73*.
  - **Activate and hold the Switch** - the zoom function will zoom continuously and end only upon the release / deactivation of the switch.



The Functions Overlay will not perform any zoom.



When using the Gaze method, you have to look back to the Taskbar to select a new Task after the execution of the Task, even if it is the same as you have just used.



When precision is set to zero in Gaze Selection Settings - no zoom is performed. For more information, see *8 Gaze Selection Settings, page 73*.

##### 5.4.3.4.1 Sticky Tasks & Default Left Click / Tap for Switch

When using the Switch method, a feature is made use of called "sticky tasks". If a Task becomes "sticky" it means that you do not have to look back at the Taskbar if you want to repeat the execution of the selected Task, only if you want to change the Task to another.

When using the Switch method, the Left Click / Tap Task is "sticky" by default. This means that Left Click / Tap is always on and will always be activated by the activation of the switch, if nothing else is selected. If another Task is selected it will be active only once (for one selection) and then Gaze Selection will automatically default back to Left Click / Tap for the subsequent selections.

The exception to this is the Double Click Task; when it is selected when using Switch mode it will also become sticky, meaning that it will stay selected until another Task is selected (after which it will again default back to Left Click / Tap).

This allows for excellent use cases such as quick/continual surfing of the internet by activating the Switch and thus the Left Click / Tap Task once and then repeatedly selecting anything desired, without having to choose the Left Click / Tap Task again multiple times.

#### 5.4.3.4.2 Activating a Task with a Keyboard button instead of a Switch




Selecting the “F12 Keyboard Button”, on an attached keyboard will activate a Task selection. It can be used in exactly the same way as a connected switch. For more information on Switches, see 5.4.3.4 *Selection Methods — Gaze and Switch*, page 37.

#### 5.4.3.5 Gaze Keyboard

By selecting the Gaze Keyboard button on the Taskbar, the Gaze Keyboard will launch as an on-screen keyboard. The Gaze Keyboard will be positioned either at the top or at the bottom of the screen depending on where the user has placed the last mouse click (or last cursor position) before launching the Gaze Keyboard. The keyboard will place itself on the opposite side from where the mouse/cursor is.

The Gaze Keyboard consists of four keyboard pages in a rotating loop. The user can easily switch between the different keyboard pages by selecting the next page buttons located to the far left and right on all pages of the Gaze Keyboard.

The key on the keyboard where the user is looking will be indicated by a light frame around the character/function on the key.



While the user is typing, the last 5-10 characters will be displayed in blue on the indicated/highlighted key. This feature assists the user in easily spotting misspellings and reduces the need for looking at the actual spot where the text is inserted, thus increasing typing speed.

The four keyboard pages are:



Figure 5.8 Default Startup Page




Figure 5.9 First Page to the Right





Figure 5.10 Second Page to the Right or Left



Figure 5.11 First Page to the Left

**i** The Shift, Ctrl, Alt, Win and Alt Gr keys will become "sticky" once selected. This means that they will stay selected until the user selects a new key from the keyboard. They will stay sticky if the next selected key is another sticky key.

**i** To write a letter with an accent:

1. Select the accent
2. Select the character
3. The character will appear with the chosen accent.

**i** To delete a full word at a time instead of one character at a time:

1. Select the Ctrl key
2. Select the Backspace key

#### 5.4.3.6 Gaze Selection in Combination with Region Based Keyboards


Gaze Selection can be used in combination with other eye controlled applications. "Gaze Enabled" regions in other applications are active as long as there is no active Task in the Gaze Selection Toolbar. If you are using Gaze Selection with switch the Task Buttons will be "sticky", if you need to deselect a Task just look back at the selected Task for a short moment.


### 5.4.4 Using Mouse Emulation


The Mouse Emulation mode makes it possible for the user to emulate and control a standard PC mouse pointer on the screen. To configure the Mouse Emulation, go to Tobii Dynavox Gaze Interaction Settings. For more information, see [7.5.2.2 Mouse Emulation, page 69](#)

#### 5.4.4.1 Placing the Mouse Emulation Menu

The menu can be placed anywhere on the desktop or docked along the edge of the screen. You dock the Mouse Emulation

Menu by dragging it to the edge of the screen. You can also do this by pressing and dragging the Move icon . When the menu is docked you have to look outside the screen to bring up the Mouse Emulation Menu items.



 If the Mouse Emulation Menu is docked at the same side as the System Off-Screen Menu (For more information, see [5.6 Pause/Resume Gaze Interaction and Put the Tobii Dynavox I-Series+ to Sleep with Gaze Interaction, page 42](#)), the Mouse Emulation Menu might not function at all.

#### 5.4.4.2 Clicking with Windows Control in Mouse Emulation Mode

Select what type of mouse click you want to perform from the **Button** drop down list in the Mouse Emulation Menu.




Right-click simulates a right mouse click.



Left-click simulates a left mouse click.

#### 5.4.4.3 Magnifying with Windows Control in Mouse Emulation Mode

To use the magnifier, select the magnifier icon, , in the Mouse Emulation Menu.

If you want to perform a click with the magnifier:

1. Select the magnifier.
2. Select the other options as usual. The options will now have changed to reflect the magnification state.



Right Click Zoom



Left Click Zoom

#### 5.4.4.4 Selecting Mouse Emulation Functions

You can set different functions for clicking:



Mouse cursor



No cursor movement on screen



Single-click



Double-click





Drag and drop

#### 5.4.4.5 Pausing Windows Control in Mouse Emulation Mode

To pause Windows Control select the Pause icon in the Windows Control Menu.





Pause




Pausing Gaze Interaction can also be accomplished by looking at (about) the Tobii logo at the bottom of the Tobii Dynavox I-Series+, then selecting, using Gaze Interaction, the pause icon that pops up.


For more information, see *7.6.1 System Off-Screen Menu, page 71*

#### 5.4.4.6 Scrolling with Windows Control in Mouse Emulation Mode

The scroll buttons appear automatically in the upper right corner in any object which can be scrolled. The buttons will only appear on the window which has focus. To activate the scroll select the  or  icon. If the icons show up when they are not

desired you can use the  icon to hide them.

When scroll mode is activated you will see a shaded gradient over the window which will be scrolled.



To scroll, look in the direction you want to scroll.



To toggle between left/right or up/down scroll, select the  or  icon for the desired direction.

Scroll functionality can be turned off in

**Tobii Dynavox Gaze Interaction Settings > Windows Control > Turn off scroll functionality.**

## 5.5 Wake the Tobii Dynavox I-Series+ from Sleep with Gaze Interaction

It is possible to wake the Tobii Dynavox I-Series+ from sleep with Gaze Interaction. This makes it possible for the user to be more independent and secure while alone or without a caregiver; during the night for example. If the user wants attention from the caregiver when the user wakes at night, the user could wake the Tobii Dynavox I-Series+ with Gaze Interaction and use the

Tobii Dynavox I-Series+ to communicate quickly to alert the caregiver. Waking the device from sleep in this way is called: **Wake-on-Gaze®**




Figure 5.12 Wake-on-Gaze® Area

To Wake-on-Gaze®:

1. Make sure the Wake-on-Gaze® is activated, see 6.4 *Wake-on-Gaze®, page 50*.
2. Look at the area in between the two illuminators of the Eye Tracker at the bottom of the Tobii Dynavox I-Series+, see *Figure 5.12 Wake-on-Gaze® Area, page 42*.



The Eye Tracker will search for the users eyes every 3 seconds.

The Tobii Dynavox I-Series+ will wake up from Sleep and will be ready to use.

## 5.6 Pause/Resume Gaze Interaction and Put the Tobii Dynavox I-Series+ to Sleep with Gaze Interaction

While using Gaze Interaction it is possible to both Pause/Resume Gaze Interaction (if the user wants to rest their eyes for a while) and to put the Tobii Dynavox I-Series+ to Sleep (to reduce battery consumption, or in situations where the device is not needed). Putting the device to sleep in this way is called **Sleep-on-Gaze**.




Figure 5.13 System Off-Screen Area

To Pause Gaze Interaction:

1. Make sure the **Pause/Resume** System Off-Screen menu is activated, see 7.6.1 *System Off-Screen Menu, page 71*

2. Look at the area where the System Off-Screen menu has been configured for your Tobii Dynavox I-Series+, see *Figure 5.13 System Off-Screen Area, page 42*  
For more information and for how to configure the System Off-Screen menu, see *7.6.1 System Off-Screen Menu, page 71*.



3. Selecting, using Gaze Interaction, the (Pause) icon that pops up.

To Sleep-on-Gaze:

1. Make sure the **Sleep-on-Gaze** function is activated, see *6.4 Wake-on-Gaze®, page 50*
2. Look at the area where the System Off-Screen menu has been configured for your Tobii Dynavox I-Series+, see *Figure 5.13 System Off-Screen Area, page 42*  
For more information and for how to configure the System Off-Screen menu, see *7.6.1 System Off-Screen Menu, page 71*.



3. Selecting, using Gaze Interaction, the (Sleep-on-Gaze) icon that pops up.
4. Select **Yes** for Sleep or **No** for Cancel

## 5.7 Using the Cameras

The two built-in cameras allows you to take snapshots of items in front of the Tobii Dynavox I-Series+ device and also from the display side.

Use **Tobii Dynavox Communicator /Tobii DynaVox Compass** or other relevant software to operate the cameras.

## 5.8 Using the GEWA Programmable IR Remote Control

The Tobii Dynavox I-Series+ device includes a GEWA Programmable IR Remote Control — Environmental Control Unit (ECU) with two (2) filter windows:

- 1 Transmitter filter window — Position 6 in *Figure 3.1 Front and Back, page 16*
- 1 Transmitter and Receiver filter window — Position 27 in *Figure 3.2 Bottom, Left and Right Side, page 17*



Use the Transmitter and Receiver filter window (position 27 in *Figure 3.2 Bottom, Left and Right Side, page 17*) when programming the GEWA Programmable IR Remote Control in **Tobii Dynavox Communicator /Tobii DynaVox Compass**.

The GEWA Programmable IR Remote Control is a programmable Infrared device that can be used to control equipment with an IR Remote Control such as TV-sets or DVDs.

For more information about how to use and program the GEWA Programmable IR Remote Control, see the **Tobii Dynavox Communicator 5 Getting Started** or the **Compass User Guide**.



If the device you are trying to control is not responding, try tilting the Tobii Dynavox I-Series+ device up or down slightly to change the angle at which the IR signal is being sent.

The ECU is not to be relied on as the only method of interaction with IR controlled devices.

### 5.8.1 Handling I-Series Product Key

To use the GEWA Programmable IR Remote Control, a I-Series Product Key is required. To view or enter a I-Series Product Key, go to the I-Series Product Key section in the **I-Series Control Center**. See *6.7 I-Series Product Key, page 54*

When the I-Series Product Key is in place, the GEWA IR Programmable Remote Control is ready to use.

## 5.9 Adjusting the Volume

To adjust the volume use the Volume Up button (Position 11) and volume down button (Position 12) on right hand side of the Tobii Dynavox I-Series+ device. For position references, see *Figure 3.2 Bottom, Left and Right Side, page 17*



Volume adjustments can also be done in **Tobii Dynavox Communicator /Tobii DynaVox Compass**.

## 5.10 Adjusting the Sound

You can configure the built-in speakers using the **Windows 8.1 Control Panel > Sound**.



We refer to Microsoft's information on how to configure the sound in the Windows 8.1 Control Panel.



Sound adjustments can also be done in **Tobii Dynavox Communicator /Tobii DynaVox Compass**.

## 5.11 Performing a Factory Recovery

Every Tobii Dynavox I-Series+ device has a factory image stored on the disk. If you need to restore the device back to its original state, this can be done by using our OEM Factory Recovery Application.



This will delete any personal data or software installed after the device was delivered.


Factory Recovery means that the device will be reset to the factory mode, without anything installed. In this mode you have to re-enter your Tobii Dynavox Product Key and licenses to perform the SW installation you have ordered.




Make sure you've connected the Power Supply before you start the process - do not run the device on batteries, as it might run out of power during the Factory Recovery. In such a scenario, you might have to send the unit back to Tobii Dynavox for repair.

To perform a Factory Recovery for your Tobii Dynavox I-Series+ device, follow this procedure:

1. Backup your personal data such as documents and Tobii Dynavox Communicator /Tobii DynaVox Compass settings etc.
2. Make sure you have the Tobii Dynavox I-Series+ Product Key available
3. Shut down the device
4. Connect a keyboard
5. Start up device again




6. Hold down the  (Arrow Down) keyboard button continually during startup until you get into "Windows Boot Manager"

7. Select "Factory Reset" and press the  (Enter) keyboard button.
8. The Tobii Dynavox I-Series+ Software Installation dialogue will be loaded
9. Follow the instructions on the screen. These steps are identical to the initial setup you did when you first received the device.

or

To perform a Factory Recovery for your Tobii Dynavox I-Series+ device, follow this procedure:

1. Backup your personal data such as documents and Tobii Dynavox Communicator /Tobii DynaVox Compass settings etc.

2. Make sure you have the Tobii Dynavox I-Series+ Product Key available
3. Shut down the device
4. Connect a keyboard
5. Start up device again
6. Hold down the  (F8) keyboard button continually during startup until you get into “Advanced Boot Options”
7. Press the  (Esc) keyboard button to get to the “Windows Boot Manager”
8. Select "Factory Reset" and press the  (Enter) keyboard button.
9. The Tobii Dynavox I-Series+ Software Installation dialogue will be loaded
10. Follow the instructions on the screen. These steps are identical to the initial setup you did when you first received the device.

The Factory Recovery process will now start. This will take about 40 minutes. After the restore process is finished, the device will be reset to its original image as it was when you first received it from Tobii Dynavox. If you have installed any additional Software or Tobii Dynavox Product Keys after you ordered the device, these will have to be manually installed again

## 5.12 Calibrating the Touch Screen

There are two ways of calibrating the Touch Screen depending on if the Windows Control Panel is in Category view or Classic view with Small/Large icon.

To calibrate the Touch screen from Category View in Windows Control Panel, follow this procedure:

1. Select **Start > Control Panel**
2. Select **Hardware and Sound**
3. Select **Tablet PC Settings**
4. Select the **Calibrate...** button under Display options
5. Follow the on-screen instructions

To calibrate the Touch screen from Classic View with small/Large icons in Windows Control Panel, follow this procedure:

1. Select **Start > Control Panel**
2. Select **Tablet PC Settings**
3. Select the **Calibrate...** button under Display options
4. Follow the on-screen instructions

## 6 Configuring the Tobii Dynavox I-Series+ with the I-Series Control Center


The I-Series Control Center is the program on your Tobii Dynavox I-Series+ Device where you can access and change the settings that you have chosen during your first setup with the I-Series Welcome Guide. You can also run the Welcome Guide again at any time of your choosing.


To open the I-Series Control Center:

- Double-click on the **I-Series Control Center** shortcut on the desktop, .

or

1. Go to **Start menu > Control Panel**.



2. Double-click **I-Series Control Center**, , if the Control Panel is in Classic View. If the Control Panel is in Category view, select **View by: > Small icons or Large icons**, and Double-click **I-Series Control Center**.

or


1. Go to **Start menu > Tobii Dynavox**.

2. Click **I-Series Control Center**, .

or

- Through the communication software installed on the device

## 6.1 Buttons



You can create shortcuts to tasks, called actions, by programming the Quick Access buttons. The Quick Access buttons are located on the left side of the Tobii Dynavox I-Series+ device, named **1**, **2** and **Menu**.

For more information about how to program an action for a button, see *6.10 Creating Shortcuts to Actions, page 58*

### 6.1.1 Play Sound when Pressed

To enable Play sound when pressed:

1. Open the **I-Series Control Center > Button**.
2. Select the **Play sound when pressed** check box to allow Audio feedback when the button is activated.

To disable Play sound when pressed:

1. Open the **I-Series Control Center > Button**.
2. Select to clear the **Play sound when pressed** check box.

### 6.1.2 Disable All Buttons

To avoid unintentional actions, all buttons on the Tobii Dynavox I-Series+ device can be disabled.

To Disable all buttons:

1. Open the **I-Series Control Center > Button**.
2. Select the **Disable All Buttons** check box.



The Power button will work for starting the device even if all buttons are disabled.




Pressing the Power button for more than 7 seconds will shut down the device immediately, disregarding any unsaved changes, even if all buttons are disabled.

To Enable all buttons:

1. Open the **I-Series Control Center > Button**.
2. Select to clear the **Disable All Buttons** check box to allow all buttons again.

## 6.2 Display



### 6.2.1 Brightness Adjustment

There is a sensor on the device which will automatically adjust the screen brightness according to the surrounding light, relative to the selected level from Windows®.

To disable Automatic Brightness Adjustment:

1. Open the **I-Series Control Center > Display**.
2. Select to clear the **Enable automatic brightness adjustment (recommended)** check box.

To enable Automatic Brightness Adjustment:

1. Open the **I-Series Control Center > Display**.
2. Select the **Enable automatic brightness adjustment (recommended)** check box.

To manually adjust Brightness:

1. Open the **I-Series Control Center > Display**.
2. Select the **Windows Power Options** link.
3. Make the Brightness adjustments



Using a darker setting can improve battery runtime.

### 6.2.2 Display Rotation

The display can rotate automatically when turned 180 degrees, to facilitate using device in Upright orientation or Resting on the speakers.



With the Automatic display rotation activated, it could take a couple of seconds (the screen could also turn black) before the display is rotated.

To enable Automatic rotation according to device position:

1. Open the **I-Series Control Center > Display**.
2. Select the **Automatic rotation according to device orientation** radio button.





The external display will rotate when the Tobii Dynavox I-Series+ is rotated if the Tobii Dynavox I-Series+ is set up like this:

- External display connected via HDMI
- The Tobii Dynavox I-Series+ is set to Automatic rotation in I-Series Control Center
- Dual screens is set to Clone/Duplicate mode in Windows

To be able to rotate the Tobii Dynavox I-Series+ without rotating the external display, set the Dual screen to Extended mode in Windows. In Extended mode the rotation function is independent on each display.

To set Fixed device position:


1. Open the **I-Series Control Center > Display**.
2. Select the **Fixed in upright orientation** or the **Fixed in resting orientation** radio button.



Gaze Interaction is optimized to work properly in the Upright orientation.

For more information about Upright orientation and Resting orientation, see *1.3.1 Portable Use, page 9*.

## 6.3 Switches



You can enable the switches to act as power ON (see *6.3.2 Configuring a Switch to Power On, page 50*) or OFF (see *6.3.3 Configuring a Switch to Power Off, page 50*) button.

Select the **Play sound when pressed** checkbox to allow Audio feedback when the switch is activated.

Select actions for the switches by selecting **Set action**.

For more information about how to program an action for a Switch, see *6.10 Creating Shortcuts to Actions, page 58*

### 6.3.1 Play Sound when Pressed

To enable Play sound when pressed:

1. Open the **I-Series Control Center > Button**.
2. Select the **Play sound when pressed** check box to allow Audio feedback when the button is activated.

To disable Play sound when pressed:

1. Open the **I-Series Control Center > Button**.

2. Select to clear the **Play sound when pressed** check box.

### 6.3.2 Configuring a Switch to Power On

To enable a connected Switch to power on the device:

1. Open the **I-Series Control Center > Switches**.
2. Select the **Enable switch “1 or 2” to act as Power On Button** check box.

To disable a connected Switch to power on the device:

1. Open the **I-Series Control Center > Switches**.
2. Select to clear the **Enable switch “1 or 2” to act as Power On Button** check box.

### 6.3.3 Configuring a Switch to Power Off


To enable a connected Switch to power off the device:

1. Open the **I-Series Control Center > Switches**.
2. Select the **Enable switch “1 or 2” to act as Power Off Button** check box.

To disable a connected Switch to power off the device:

1. Open the **I-Series Control Center > Switches**.
2. Select to clear the **Enable switch “1 or 2” to act as Power Off Button** check box.

## 6.4 Wake-on-Gaze®



The Tobii Dynavox I-Series+ device can be set to wake automatically from Sleep mode when your eyes are registered as looking at the display.

To enable Wake-on-Gaze for the device:

1. Open the **I-Series Control Center > Wake-on-Gaze**.
2. Select the **Enable automatic Wake-on-Gaze** check box.
3. Select **Windows Power Options** link to adjust the Power Options (if needed)

To disable Wake-on-Gaze for the device:

1. Open the **I-Series Control Center > Wake-on-Gaze**.
2. Select to clear the **Enable automatic Wake-on-Gaze** check box.

For information about how to use Wake-on-Gaze®, see *5.5 Wake the Tobii Dynavox I-Series+ from Sleep with Gaze Interaction, page 41*.

The Tobii Dynavox I-Series+ device can also be set to go to sleep using your gaze (to reduce battery consumption, or in situations where the device is not needed).

To enable Sleep-on-Gaze for the device:


1. Open the **I-Series Control Center > Wake-on-Gaze**.
2. Make sure Wake-on-Gaze is activated
3. Select the **Enable Sleep-on-Gaze** check box.

To disable Wake-on-Gaze for the device:

1. Open the **I-Series Control Center > Wake-on-Gaze**.
2. Select to clear the **Enable Sleep-on-Gaze** check box.

For information about how to use Sleep-on-Gaze®, see *5.5 Wake the Tobii Dynavox I-Series+ from Sleep with Gaze Interaction, page 41*.

## 6.5 Wireless



### 6.5.1 WLAN



The built-in WLAN (Wireless Local Area Network) support enables connection to wireless networks (such as Wi-Fi™ networks and access points) in compliance with the standard 802.11 b/g/n for both the I-12+ and the I-15+.

#### 6.5.1.1 Handling Tobii Dynavox Product Key

To be able to use WLAN communication, a I-Series Product Key is required. To view or enter a I-Series Product Key, go to the I-Series Product Key section in the **I-Series Control Center**. See *6.7 I-Series Product Key, page 54*

### 6.5.1.2 Enabling and Disabling the WLAN Communication


To enable WLAN communication:

1. Open the **I-Series Control Center > Wireless**.
2. Select the **Enable Wireless Local Area Network (WLAN)** check box.

To disable WLAN communication:

1. Open the **I-Series Control Center > Wireless**.
2. Clear the **Enable Wireless Local Area Network (WLAN)** check box or select the **Disable all wireless units** check box for disabling all wireless units.

### 6.5.1.3 Connecting to a WLAN

1. Click on the WLAN icon,  , in the Notification area on the Desktop.
2. Select **Connect to a network**.
3. Select a network to connect to.



A wireless access point which supports antenna diversity is recommended when setting up a wireless network to use with a Tobii Dynavox I-Series+ device, for reliable performance. Such access points are generally recognized by having two antennas on the router device.



Using an antivirus program is strongly recommended.

## 6.5.2 Bluetooth® for Mobile Phone Communication



The built-in Bluetooth® enables connection to a mobile phone which complies with mobile Bluetooth® standards.



Only for use with **Tobii Dynavox Communicator** for mobile phone communication.

For more information about how to use and program an Mobile phone to work with Bluetooth® on the Tobii Dynavox I-Series+ device, see **Tobii Dynavox Getting Started Communicator 5**.

For information about the Mobile phones that complies with the Tobii Dynavox I-Series+ device, see [www.tobiidynavox.com](http://www.tobiidynavox.com)

### 6.5.2.1 Handling I-Series Product Key

To use Bluetooth® communication in the device, a I-Series Product Key is required. To view or enter a I-Series Product Key, go to the I-Series Product Key section in the **I-Series Control Center**. See *6.7 I-Series Product Key, page 54*

### 6.5.2.2 Enabling and Disabling Bluetooth® Communication

To enable Bluetooth® communication:

1. Open the **I-Series Control Center > Wireless**.
2. Select the **Enable Bluetooth** check box.


To disable Bluetooth® communication:

1. Open the **I-Series Control Center > Wireless**.
2. Clear the **Enable Bluetooth** check box or select the **Disable all wireless units** check box for disabling all wireless units.

### 6.5.2.3 Connecting to a Bluetooth® Device

For more information see **Getting Started with Essentials for Communicator 4**.

## 6.6 Safety



Upon starting the device for the first time, the safety settings in the **I-Series Control Center** will be a part of the I-Series Welcome Guide. To be able to run through the guide these safety settings must be confirmed. The safety settings exist for the safety of the customer. Be sure to read the safety details before accepting any changes.

### 6.6.1 Audio

Before you can use the speaker functionality and adjust speaker output settings you need to confirm the Audio safety details (if not already done during first start up).

To confirm:

1. Open the **I-Series Control Center > Safety**
2. Click on the **Audio safety details** text. A new dialog box opens and displays the safety text. Please read this thoroughly.
3. Select the **I have read and understand the safety details and I want to enable the speaker functionality** check box to confirm that you have read and understood the safety text.

### 6.6.2 Temperature Control

Before you can set the device usage in **I-Series Control Center > Temperature Control** you need to confirm the Temperature control safety details (if not done during first start up).

To confirm:

1. Open the **I-Series Control Center > Safety**
2. Click on the **Temperature Control safety details** text. A new dialog opens and displays the safety text. Please read this thoroughly.
3. Select the **I have read and understand the safety details and I want to enable the temperature control functionality** check box to confirm that you have read and understood the safety text.



You can use the device in a portable or mounted mode. Your choice will affect the maximum allowed device temperature. While having the device mounted, it is allowed to run at a higher temperature.

Both the I-12+ and the I-15+ can be used both as a portable and mounted device and can be operated in both portable and mounted mode.



If the device gets overheated the device will shut down. It may take a while before it can be restarted as the unit may first need time to cool down. If the device is still too hot, the power button will flash purple for a couple of seconds when trying to restart the Tobii Dynavox I-Series+ device. For more information, see *Appendix C Computer Device States of Operation*, page 85 and *Table D.1 Maximum Allowed Temperature*, page 87.

### 6.6.2.1 Device Usage


Specifying device usage mode takes place outside of the **Safety** settings but within **I-Series Control Center**.

To specify device usage:

1. Open the **I-Series Control Center > Safety**.
2. Click on preferred option for **Device usage**.
  - **Portable** — Portable mode sets the maximum device temperature shut down limit to a lower temperature, reducing the risk for permanent bodily harm caused by prolonged exposure to the skin
  - **Mounted** — Mounted mode sets the maximum device temperature to a higher temperature shut down limit

For more information, see *Table D.1 Maximum Allowed Temperature*, page 87

## 6.7 I-Series Product Key



The following features on the Tobii Dynavox I-Series+ needs a licence for use:

- Eye tracker
- Bluetooth®
- WLAN
- IR
- Tobii Dynavox Communicator
- Tobii Dynavox Compass

To view existing I-Series Product Key:

- Open the **I-Series Control Center > I-Series Product Key**.



If the symbol is visible after a feature, the I-Series Product Key(s) on the device are valid for that feature.


To add a I-Series Product Key:

1. Open the **I-Series Control Center > I-Series Product Key**.
2. In the **Enter a I-Series product key** box, type the new I-Series Product Key.

To type the I-Series Product Key use either a connected keyboard or enable the on-screen keyboard by selecting this button



## 6.8 Setup & Updates



Manage Tobii Dynavox applications related to setting up your device and updating to the latest software.

### 6.8.1 I-Series Welcome Guide

The I-Series Welcome Guide guides the user through the setup procedure, such as License Agreement and Safety Setting etc.



If the I-Series Welcome Guide is not finished, it will automatically start up next time the Tobii Dynavox I-Series+ is powered up.

To run the I-Series Welcome Guide at next start up, follow these step:

1. Open the **I-Series Control Center > Setup & Updates**.
2. Select the **Run at next startup** check box.

To run the I-Series Welcome Guide at once, follow these steps:

1. Open the **I-Series Control Center > Setup & Updates**.
2. Select the **Run now** button.

### 6.8.2 I-Series Update Notifier

The I-Series Update Notifier is a program that notifies you when the latest software updates for your Tobii Dynavox Software are available (either automatically, on a regular basis, or manually, at a time of your choosing) and assists you in installing the updates.

If you have chosen to "Enable automatic updates" in either the I-Series Welcome Guide or, later, in the I-Series Control Center, the I-Series Update Notifier will actively search Tobii Dynavox's sites for version Updates of your software.



To keep your Tobii Dynavox I-Series+ device running properly it is highly recommended that you update your Tobii Dynavox Software on a regular basis and it is therefore highly recommended that you enable automatic updates.

To Enable automatic search for updates:

1. Open the **I-Series Control Center > Setup & Updates**.
2. Select the **Enable automatic search for updates (recommended)** check box.

If an update is found the following I-Series Update Notifier window will pop up:

The update or updates available will show themselves in the Step One window of I-Series Update Notifier as large button with a green check mark on the right side. You will also be able to see the version number of the software that you currently have and the version number of the update.

If you choose not to download one or more of the available updates you can click on the button of the update you do not want and the check mark will turn into a red "X" mark.

Proceed in the following way:

- Click the **Download** button to download the updates to your Device and continue to Step Two.
- In Step Two, Click the **Install** button to install the chosen updates on your device and proceed to Step Three.
- Step Three informs you that your system has been updated, select the **Done** button to close the I-Series Update Notifier.

If you choose not to "Enable automatic updates" you can still check for updates for your Tobii Dynavox software and update them manually using the I-Series Update Notifier.

To open and activate the I-Series Update Notifier manually (this opens the Step One window shown above and starts the same automatic update process):

- Navigate in Windows from your desktop to **Start Menu Tobii Dynavox** and select the I-Series Update Notifier icon,




or

1. Open the **I-Series Control Center > Setup & Updates**.
2. Select the **Run now** button.



## 6.9 System



### 6.9.1 Version & Model

To view the version and model of the device:

- Open the **I-Series Control Center > System**.



Please have this information available if you have problems with the device and need to contact Customer Support.

To save the version and model of the device to a file:

1. Open the **I-Series Control Center > System**.
2. Select the **Save information to file** button.



You can attach the file containing all the information into a an e-mail.

### 6.9.2 Backup

This is a system backup specific to your Tobii Dynavox software-related files. The device automatically and regularly, once a week, backs up the data that is associated with your Tobii Dynavox communications applications ( Tobii Dynavox Communicator /Tobii DynaVox Compass Page Sets, files, settings, etc.), your Gaze Interaction files (profiles, calibration settings, interaction settings, etc.) and your device specific settings from the I-Series Control Center. You can manually start the backup below and/or restore the data from one of the three latest backups. Be aware that the changes made since the latest backup will be reverted if you choose to restore from a previous backup. All files in the My Documents folder will be backed up as well, if space is available on the microSD-card, as a second priority after the Tobii Dynavox software-related files. **To back up all files on your device please use Microsoft's own Windows Backup and Restore application.**

The backup process executes once a week (every Sunday at 15.00) and the three latest backups are saved on the microSD-card.



If your Tobii Dynavox I-Series+ device is not up and running at this time the backup will be performed at next start up.

The process backs up files for all users. If the backup drive does not have enough space some files will not be backed up. Image files have the lowest priority (backed up last). The largest file size for the backup of individual files is 100 MB, files larger than this will be excluded.

The backup files are placed in the directory **Q:\Backup\<date> (On the microSD-card)**.



Tobii Dynavox will not take responsibility for any other data than the “Tobii Dynavox applications data”

### 6.9.2.1 User Profile Card

The Tobii Dynavox I-Series+ device comes with a 32 GB microSD-card installed. The purpose of this card is to backup personal settings and data. In the case of fatal damage to the Tobii Dynavox I-Series+ device. The microSD-card can be removed and inserted into a new device for quick and easy retrieval and restoration of personal data and settings.

### 6.9.2.2 Backup Manually by the User

To perform a manual backup of the system:

1. Open the **I-Series Control Center > System**.
2. Select the **Backup now** button.

When the backup is finished, the following will show up on the screen:



**Backup finished.**

### 6.9.2.3 Restoring Backup Files by the User

To restore one of the three last backup of the system:

1. Open the **I-Series Control Center > System**.
2. Select the **Restore from backup** button.
3. Select the one of the last backups by selecting the **Restore from this backup** button next to the date of the stored backup.

When the restore is finished, the following text will show up on the screen: **Restore finished** and the



symbol will show up next to the date that was selected to restore from.

Copies of these backup files can be saved anywhere you wish, to an external hard drive, for example, or to a USB stick. Copy the folders in the directory **Q:\Backup\<date>** to any external directory or drive of your choosing.

### 6.9.2.4 Backup Failed

One likely reason that the backup failed is that there are too many files in the My Documents folder. Try moving the files that are not backup- critical to another location (such as pictures, music files, etc).

## 6.9.3 Eye Tracker

To enable the Eye tracker:

1. Open the **I-Series Control Center > System**.
2. Select the **Enable Eye Tracker** check box.

To disable the Eye tracker:

1. Open the **I-Series Control Center > System**.
2. Clear the **Enable Eye Tracker** check box.

## 6.10 Creating Shortcuts to Actions

You can create shortcuts, called actions, by programming the Quick Access buttons and connected Switches. The Quick Access buttons are located on the left side of the Tobii Dynavox I-Series+ device, named **1**, **2** and **Menu**.

Switches are connected to the Switch connectors.

### 6.10.1 Available Actions

This is a short description of each action available to set:

- Send input – Allows the user to send input to an alternative program (keystroke, mouse click or text).
- Start Program – Allows the user to start a program.
- Volume – Allows the user to adjust the volume up or down or to set mute on or off.
- Backlight – Allows the user increase or decrease the backlight of the screen.
- Gaze Interaction – Allows the user to show and hide the track status window, calibrate or pause the Gaze Interaction ON or OFF.
- Wireless – Allows the user to either set all radio connections on or off, or a specific wireless connection.
- Tobii Dynavox Communicator /Tobii DynaVox Compass — Actions are set and customized in Tobii Dynavox Communicator /Tobii DynaVox Compass.

The available actions are the same for the Quick Access buttons and Switches.


To create a shortcut to an action:

1. Open the **I-Series Control Center**.
2. Select **Buttons** or **Switches**, depending on which one you want to customize.
3. Click **Set action** to view the dialog box where you can select the action you would like the button to perform. By selecting one of the actions, the options for this action will be revealed below the chosen action.



If you would like the Quick Access button to make a sound when pressed, select the **Play sound** check box after having set an action.

### 6.10.2 Selecting Actions



- **No Action Selected** — Default — choose to delete a previous set task
- **Send Input** — choose either to send a keyboard input, a mouse click or specified text by selecting the option you want the device button or Switch to perform.
  - **Send keyboard input** — In the **Send keyboard input list**, select the keystroke you want to send to an alternative program.
  - **Send mouse click** — In the **Send mouse click list**, select the desired mouse click: left, middle or right mouse click.
  - **Send text** — In the **Send text box**, type the text you want to send to an alternative program.
- **Start Program** — Click **Browse** the first time you are using this option to find and select a program.

The next time you select the **Start Program** option a list of previously selected programs will be displayed. You can then directly select a program from the list or select **Browse** if you want to start a program not in the list.

For the selected program it is possible to add program arguments. However, this is normally not required. If the program should require program arguments and you do not know what to enter, please contact the company you purchased the software from.

- **Volume** — choose to increase, decrease or mute the volume by selecting the preferred option.
- **Backlight** — choose to either increase or decrease the screen backlight by selecting the preferred option.
- **Gaze Interaction** – choose to toggle track status window, calibrate Gaze Interaction, Pause the Gaze Interaction or toggle Windows Control ON/OFF.



To enable this option the Tobii Dynavox I-Series+ device must have an Eye Tracker and the Tobii Dynavox Gaze Interaction Software installed.

- **Wireless** — you can either set all radio connections on/off or each individual wireless unit on/off one by one, by selecting the options.
- **Communicator /Compass** — Actions are set and customized in Tobii Dynavox Communicator /Tobii DynaVox Compass



If actions for a Switch are customized both in the **I-Series Control Center** and in **Tobii Dynavox Communicator /Tobii DynaVox Compass** or in alternative communication software all actions will be performed simultaneously. Ensure that the specified action for a Switch does not conflict with an action set for the same Switch in **Tobii Dynavox Communicator /Tobii DynaVox Compass** or in alternative communication software.






To get back from slide in menus, just select the arrows in the greyed out areas.

# 7 Gaze Interaction Settings

## 7.1 Accessing the Gaze Interaction Settings

**Gaze Interaction Settings** is a program for quick and easy access to control functions such as Track Status, Calibration and common settings.

Start **Gaze Interaction Settings** for Windows 8.1 in one of the following ways:

- Go to **Start menu > Tobii Dynavox**.
- Double-click on the **Gaze Interaction Settings** icon, , in the Notification area, or on the shortcut, , on the Desktop (if one has been made).
- Right-click (long-hold finger on icon for touch screen right clicking) on the **Gaze Interaction Settings** icon, , in the Notification area and then select **Settings**.




- Through the communication software installed on the device.


In the list to the left in **Gaze Interaction Settings**, select which option you want to change. In the list to the right, the available options will be revealed.

Click **OK** to save changes. This will also close Gaze Interaction Settings.

Click **Cancel** to cancel the changes. This will also close Gaze Interaction Settings.

Click **Apply** to save changes. Gaze Interaction Settings will remain open.




Anywhere you see this icon, , there is an information box with additional information for the feature.

## 7.2 Calibration

This section will describe how to calibrate an individual, enabling optimal Gaze Interaction with the Tobii Dynavox I-Series+ device.

### 7.2.1 Starting Calibration

The calibration can be started in one of the following ways:

- Open **Gaze Interaction Settings > Gaze Interaction** and then select the **Start Calibration...** button.
- Right-click (long-hold finger on icon for touch screen right clicking) on the **Gaze Interaction Settings** icon,  , in the Notification area and select **Start Calibration**.



- Through the communication software installed on the device.


### 7.2.2 Interrupting Calibration

Interrupt the calibration in one of the following ways:

- Press **Esc**.
- Left-click on the screen using a mouse.
- Touch the screen (on a touch screen device).

### 7.2.3 Customizing Active Eye


Based on certain conditions, or disabilities, you may only have one eye that functions well with Gaze Interaction. In this case, and if you know which eye is most functional, you can select which eye to track for Gaze Interaction.



To select the eye you want to be tracked by the eye tracker, follow these steps:

1. Open **Gaze Interaction Settings > Calibration**.
2. Select the **Track only this eye for Gaze Interaction** check box under Left or Right Eye Calibration Result box.

## 7.2.4 Improving Calibration Point(s)



After calibration, you may want to improve one or more points.

There is a color scheme used that will help you to understand the quality of your calibration.



All three color statuses are the result of a **successful** calibration.

- If the background color of the Calibration Result is light red, you have achieved a successful, but relatively low quality calibration. You can improve one or more points individually, or recalibrate completely, to achieve better Gaze Interaction results.



Improving even one (or more) of the calibrations points can significantly improve the calibration.


- If the background color of the Calibration Result is light yellow, you have achieved successful and good quality calibration. You might be able achieve better Gaze Interaction results by improving one or more points individually.
- If the background color of the Calibration Result is green, you have achieved a successful and high quality calibration.



Be aware that no matter what quality of calibration you have achieved you will be able to select **OK** or **Apply** and begin using Gaze Interaction. It is the accuracy and functionality of the Gaze Interaction that is affected by the quality of the calibration results. Try for the best calibration possible.

**Remember!** In the end it is the personal experience that counts!

The closer the lines within the calibration point are to a dot in the center of the circle of the calibration point, the better the cali-

bration is of that point, . You can choose the points to be improved and calibrate only those points again.

To improve one or more calibration points, follow these steps :

1. Open **Gaze Interaction Settings > Calibration**.
2. Select the point(s) you want to improve under **Calibration Result**.
3. Select the **Improve Point(s)** button and a calibration for the selected point(s) will start.




## 7.2.5 Removing Calibration Point(s)

If there is a calibration point that is consistently bad after calibration (the green lines are scattered all around and outside the circle of the calibration point) you can remove that point completely from the calibration, this *may* improve the calibration of the other points. Be aware that if you remove a point, that area of the screen will be uncalibrated and Gaze Interaction will not function properly there.

To remove one or more calibration points, follow these steps:

1. Open **Gaze Interaction Settings > Calibration**.
2. Select the point(s) you want to remove under **Calibration Result**.
3. Select the **Remove Point(s)** button.

## 7.2.6 Customizing the Calibration



To customize the calibration, follow these steps:

1. Open **Gaze Interaction Settings > Calibration**.
2. Select the **Settings...** button

### General

3. Select calibration background by selecting the background color button and select the desired color.
4. Specify the number of points you want to calibrate with (two, five or nine) from the **Calibration points** drop down list. The higher number of points, the more accurate the calibration.
5. Select if you want to have sound feedback or not from the **Sound feedback** drop down list.

### Stimulus

6. Select the stimulus type from the **Stimulus type** drop down list. There are three types available, each with different customizing options:
  - Dot:
    - Select color of the dot by selecting the **Stimulus color** button.
    - Select size of the dot by selecting from the **Stimulus size** drop down list.
    - Select speed of the dot by selecting from the **Stimulus speed** drop down list.
  - Image:




- Select primary stimulus by selecting **Browse** and selecting an image.
- Select secondary stimulus by selecting **Browse** and selecting an image.
- Select size of the image by selecting from the **Stimulus size** drop down list.
- Select speed of the image by selecting from the **Stimulus speed** drop down list.
- Video:
  - Select primary stimulus by selecting **Browse** and selecting a video.
  - Select secondary stimulus by selecting **Browse** and selecting a video.
  - Select size of the video by selecting from the **Stimulus size** drop down list.
  - Select speed of the video by selecting from the **Stimulus speed** drop down list.
- 7. Check the **Animate stimuli** check box if you want the stimuli to be animated (as opposed to static).
- 8. If you want to control the calibration, i.e. decide when to move the calibration stimuli, with a keyboard, check the **Keyboard step-through** check box.
  - For **Keyboard step-through**, use the 'S' key to step (to move the calibration stimuli) and the 'Esc' key, the Left mouse button or touching the touch screen to interrupt calibration. When using Image or Video calibration, use the 'T' key to toggle between primary and secondary stimulus images.



To get back from slide in menus, just select the arrows in the greyed out areas.

## 7.2.7 Customizing the Calibration Area




Customizing the calibration area can be useful if you have discovered that the user cannot access certain areas of the screen using Gaze Interaction. By sizing the calibration area to exclude the areas that the user cannot access it can improve the overall calibration.


To customize the calibration area, follow these steps:

1. Open **Tobii Dynavox Gaze Interaction Settings > Calibration**.
2. Select the **Setting...** button.
3. Select the Calibration area: **Change...** button.

4. A blue semi-transparent area is displayed on the desktop. You can move and resize the blue area to make it fit your preferred calibration area.



## 7.3 Interaction



To adapt the interaction method and visual feedback for Gaze Interaction, follow these steps:

1. Open **Gaze Interaction Settings > Interaction**.

### Scope

If different settings are needed for different Gaze Interaction applications, make the adaptations here.

2. Select how the interactions settings should be reflected:
  - Select **Default settings of the currently selected user profile** if you want to apply the new settings to the whole user profile and not only to a particular application.
  - Select **Application specific settings of the currently selected user profile** if you want to apply the new settings to a specific application of a user profile. Then select the available application in the **Application** drop down list.


## Method

3. Select the activation method from the **Activation method** drop down list. There are three methods available, each with different activation times:
  - Dwell. Adjust the dwell time by moving the **Dwell time** slider.
  - Switch. Adjust the minimum time for a click duration and the minimum time between clicks by moving the respective slider.
  - Blink. Adjust the minimum and maximum duration for a blink by moving the respective slider.

## Visual Feedback

4. Select the symbol for visual feedback from the **Dwell feedback type** drop down list.
5. Select the color of the feedback symbol in the **Feedback color** drop down list.
6. Specify the dot size and opacity of the feedback symbol by moving the respective slider.
7. Select the **Show visible outline around the activated region** check box to see a dashed line around the activated area in all instances of Gaze Interaction selection
8. Select **Simulate activation** if you want to see how the activation method will appear on the screen. The example is shown above the **Simulate activation** button.

## 7.4 User Profile



### 7.4.1 Creating a New Profile

Use of different profiles allows you to store multiple people's calibrations and feedback preferences on one device. Alternatively, one person might want to store multiple profiles for him/herself if that person wears glasses occasionally or uses multiple means of accessing the device.

To create a new profile:

1. Open **Gaze Interaction Settings**, select **User Profiles**.
2. Enter a new name in the **Profile name** field.
3. Select an existing profile in the **Based on profile** drop down list. The new profile will inherit all settings from the selected profile. Note that if no profiles have been created previously, the only one to select is the default profile.
4. Click **Create** to save the new profile. The new profile is saved directly upon selecting **Create**.

## 7.4.2 Selecting Current User Profile

To select current user profile:

1. Open **Gaze Interaction Settings**.
2. Select a user profile in the **Current User Profile** drop down list.
3. Select **Apply**

## 7.4.3 Deleting a Profile

To delete a profile:

1. Open **Gaze Interaction Settings > User Profiles**.
2. Select a profile in the **Profile to delete** drop down list.
3. Click **Delete** to delete the selected profile. The profile is deleted directly upon selecting Delete. Note that the default profile cannot be deleted.

## 7.5 Windows Control

Windows Control allows you to access the desktop and all applications of your Windows computer with Gaze Interaction.

### 7.5.1 Auto Start

To enable Windows Control automatically when the your device starts up:

- Select the **Auto start Windows Control at boot** check box.

To disable Windows Control automatically when the your device starts up:


- Select to clear the **Auto start Windows Control at boot** check box.

### 7.5.2 Windows Control Type

Select which type of Windows Control you wish to use:

- **Gaze Selection** — Select the Gaze Selection radio button. For more information about using Gaze Selection, see [5.4.3 Using Gaze Selection, page 29](#)
- **Mouse Emulation** — Select the Mouse Emulation radio button. For more information about using Mouse Emulation, see [5.4.4 Using Mouse Emulation, page 39](#)

### 7.5.2.1 Gaze Selection




The settings for Gaze Selection are found in the Gaze Selection Taskbar, docked to the screen when Gaze Selection



Windows Control is running. Gaze at the settings icon to select it and the Gaze Selection Settings will open. For information about the Gaze Selection Settings, see *8 Gaze Selection Settings, page 73*

### 7.5.2.2 Mouse Emulation



#### 7.5.2.2.1 Mouse Control Speed

Customize the mouse control speed by moving the **Mouse control speed** slider. Move the slider to the right to increase the speed and to the left to decrease it.



#### 7.5.2.2.2 Magnifier Size and Zoom

Customize the size of the magnifier by moving the **Magnifier Size slider**. Move the slider to the right to increase the size and to the left to decrease it.

Customize the zoom factor by moving the **Zoom Factor slider**. Move the slider to the right to increase the zoom factor and to the left to decrease it.

#### 7.5.2.2.3 Auto Switch from Right to Left Click

Check this check box if you want Windows Control Mouse Emulation mode to automatically switch the desired mouse click se-

lection back to a left click, , after a right click, , has been chosen and performed.

#### 7.5.2.2.4 Turn off Scroll Functionality

Check the **Turn off scroll functionality** check box if you do not want Gaze Interactions scrolling to be active.

#### 7.5.2.2.5 Custom Cursors



Custom cursors is a feature that turns the regular mouse cursor into a number of different cursors when using Windows Control in Mouse Emulation mode.

The different cursors visually represent the type of "mouse click" for Gaze Interaction that you have chosen from the Mouse Emulation Menu (for the definitions of the Mouse Emulation Menu symbols see 5.4.4.2 *Clicking with Windows Control in Mouse Emulation Mode, page 40*, 5.4.4.3 *Magnifying with Windows Control in Mouse Emulation Mode, page 40* and 5.4.4.4 *Selecting Mouse Emulation Functions, page 40*).

 or  +  = cursor type  (move cursor, no clicking)





 +  = cursor type  (single left click)

 +  = cursor type  (single right click)

 +  = cursor type  (double left click)


 +  = cursor type  (double right click)

 or  +  = cursor types  (drag) and  (drop)


 or  +  = cursor type  (no movement)

Check the Custom cursors check box to activate custom cursors for Windows Control in Mouse Emulation mode.

#### 7.5.2.2.6 Hide Menu

Check the **Hide Menu** check box if you want the Mouse Emulation menu to be hidden during use. The  (F2) key on the keyboard can also be used to toggle On and Off (hide/show) the Mouse Emulation Menu instantly during use.

## 7.6 System Settings



### 7.6.1 System Off-Screen Menu

Select the **Position** Drop down menu to make changes to where the System Off-Screen menu appear on the screen.

The System Off-Screen menu can be set to appear:

- Bottom (Default)
- Top
- Left
- Right
- None



Set the System Off-Screen menu to None to disable the System Off-Screen menu.




Figure 7.1 System Off-Screen Menu Areas

### 7.6.2 Positioning Guide

To turn On the Positioning Guide:

1. Open **Gaze Interaction Settings > System Settings**.


2. Select the **Enable positioning guide** check box.

To turn Off the Positioning Guide:

1. Open **Gaze Interaction Settings > System Settings**.
2. Select to clear the **Enable positioning guide** check box.

For more information about the Positioning Guide, see 5.3.4 *Positioning Guide*

## 7.7 System Information



To view the version and model of the device:

Open the **Gaze Interaction Settings > System Information**.

Please have this information available if you have problems with the device and need to contact Customer Support.

By clicking **Copy all information** you can paste the information into a document (such as Notepad or WordPad) or directly into an e-mail.

### 7.7.1 Upgrade Eye Tracker Firmware

If there is a new Firmware for the Eye Tracker module, the **Upgrade** button will be selectable.

Select the **Upgrade** button to start upgrading the Firmware for the Eye Tracker.




A Pop up notification will be shown when starting the Tobii Dynavox Gaze Interaction Settings if there is a Upgrade for the Eye Tracker Firmware.



# 8 Gaze Selection Settings

The Gaze Selection Settings Dialog is controlled by Gaze Interaction and the user can make all changes without using a keyboard and/or a mouse.

## 8.1 The General Settings Tab



### Selection

- **Gaze** - Choose Gaze to use your gaze position to activate the zooming function that ends with the execution of the desired Task.
- **Switch** - Choose Switch to use a switch to activate the zooming function that ends with the execution of the desired Task.

### Precision

The zoom precision can be set to 8 different levels, just look at the desired position to change the setting. Changing the Precision will adjust how deep the zoom will go before executing the Task. The further to the right on the scale the deeper the zoom.




If the Precision is set to zero, no zooming will happen. It will be an instant click with Primary Selection. With Secondary Selection it will still be a zoom.

### Speed

The zoom speed can be set to 8 different levels, just look at the desired position to change the setting. Changing the Speed will affect how fast the zoom is before the execution of the Task. The further to the right on the scale the faster the zoom.

## 8.2 The Keyboard Settings Tab



### Keyboard layout

The selected language keyboard layout is shown. Select the Change button to change the keyboard layout to another language. There are a number of different language keyboard layouts available.

### Gaze typing speed


The Gaze typing speed can be set to 8 different levels, just look at the desired position to change the setting. Changing the Gaze typing speed will adjust how long the user must fix their gaze on a button before the Task is executed. The scale presents lower Gaze typing speeds to the left and higher to the right.

### Sound feedback

- **On** - Choose On to activate sound feedback when selecting a button on the Gaze keyboard.
- **Off** - Choose Off to deactivate sound feedback when selecting a button on the Gaze keyboard.

To finish, select **OK** to save or **Cancel** to abort you changes.

## 8.3 The Taskbar Settings Tab



Select which tasks to use on the Taskbar. For more information about the tasks, see 5.4.3.2 *Task Buttons*, page 31.



Be aware that the more Tasks used on the Taskbar the more difficult they might become to select on smaller screens.

Toggle the On/Off check box to On for each Task to enable it for use on the Taskbar.

Toggle the On/Off check box to Off for each Task to disable its use and visibility on the Taskbar.

### 8.3.1 Maximize Left Click/Tap

Use the **Maximize Left Click/Tap** feature to expand and emphasize the Left Click/Tap Task on the Taskbar. If it is toggled to Off, all selected Tasks will be spaced evenly along the Taskbar. If it is toggled to On, all Tasks other than Left Click/Tap will retain their original/smaller sizes and the Left Click/Tap Task will fill the remaining space on the Taskbar. Activating this feature can greatly expand the active region of the Left Click/Tap Task making it much easier to select.

# 9 Product Care

## 9.1 Temperature & Humidity

### 9.1.1 General Use

The Tobii Dynavox I-Series+ is best kept in dry conditions at room temperature. The recommended range for temperature and the humidity value for the device is as follows:

Portable mode:

- Ambient temperature: 0°C to 30°C (32°F to 86°F)
- Humidity: Max 70% (no condensation on the device)

Mounted mode:

- Ambient temperature: 0°C to 37°C (32°F to 99°F)
- Humidity: Max 70% (no condensation on the device)

### 9.1.2 Transportation and Storage

For transportation and storage excluding batteries the recommended range for temperature and the humidity value for the device is as follows:

- Temperature: -40°C to 70°C (-40°F to 158°F)
- Humidity: 20% to 70% (no condensation on the device)

The Tobii Dynavox I-Series+ is not waterproof or fully water resistant. The device should not be kept in excessively humid, damp or otherwise wet conditions. Do not submerge the device in water or in any other liquid. Be careful not to allow liquids to be spilled upon the device especially in the connector areas without the I/O covers in place (Position 29 in *Figure 3.2 Bottom, Left and Right Side, page 17*). The device is registered as IP Class 43 (with I/O covers in place).

## 9.2 Cleaning

Before cleaning the Tobii Dynavox I-Series+ device shut it down, unplug all cables, attach the I/O covers (Position 29 in *Figure 3.2 Bottom, Left and Right Side, page 17*) and remove the batteries. Use a soft, slightly damp, lint-free cloth or Alcohol Cleaning Wipes (i.e. damp cloth with 96% alcohol). Avoid getting moisture in openings on the device. Don't use window cleaners, household cleaners, aerosol sprays, solvents, alcohol, ammonia, or abrasives to clean the device.

### 9.2.1 Cleaning of the Speakers

If the openings for the speakers are clogged carefully use cotton sticks and/or a toothbrush to avoid damaging the IP-protection for Tobii Dynavox I-Series+ speakers.

## 9.3 Placement

Only use the recommended mounts specified by the your local reseller or sales represent and make sure that they are mounted and fastened correctly according to the instructions. Do not place the device on unstable and uneven surfaces.

## 9.4 Transporting the Tobii Dynavox I-Series+ Device

Disconnect all the cables and use the handle on the back side of the device to hold the device while carrying it.

When you transport the device for repair, shipment or traveling, use the original casing and packaging materials.



### **Keep the original packaging materials for the Tobii Dynavox I-Series+.**

In case the device needs to be returned to Tobii Dynavox for Warranty related issues or repair, it is required that the original packaging (or equal equivalent) is used for shipping.

## 9.5 Disposing of the Batteries

Do not dispose of the batteries in general household or office waste. Follow your local regulations for the disposal of batteries.

## 9.6 Disposing of the Tobii Dynavox I-Series+ Device

Do not dispose of the Tobii Dynavox I-Series+ Device in general household or office waste. Follow your local regulations for the disposal of electrical and electronic equipment.

# Appendix A Support, Warranty, Training Resources

## A1 Customer Support

For support, please contact your local representative or Support at Tobii Dynavox. In order to receive assistance as quickly as possible, make sure you have access to your Tobii Dynavox I-Series+ device and, if possible, an Internet connection. You should also be able to supply the serial number of the device, which you find on the back of the device, in the I-Series Control Center or Gaze Interaction Settings, see 6.9 *System*, page 57 and 7.7 *System Information*, page 72.

For further product information and other support resources, please visit the Tobii Dynavox website [www.tobiidynavox.com](http://www.tobiidynavox.com).

## A2 Warranty

Please read the Manufacturer's Warranty paper included in the package.

Please read this User's Manual carefully before using the device. The warranty is only valid if the device is used according to the User's Manual. Disassembling the Tobii Dynavox I-Series+ device will void the warranty.



### **Keep the original packaging materials for the Tobii Dynavox I-Series+.**

In case the device needs to be returned to Tobii Dynavox for Warranty related issues or repair, it is required that the original packaging (or equal equivalent) is used for shipping.

## A3 Training Resources

Tobii Dynavox offers a range of training resources for the Tobii Dynavox I-Series+ products and related communication products. You can find them on the Tobii Dynavox website, [www.tobiidynavox.com](http://www.tobiidynavox.com), including Getting Started Guides, webinars and Quick guides. The Tobii Dynavox I-Series+ Quick Start Manual is delivered with, and stored on, the Tobii Dynavox I-Series+ device.

# Appendix B Compliance Information

## B1 FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.



Modifications not expressly approved by Tobii Dynavox could void the user's authority to operate the equipment under FCC rules.

### B1.1 For P15B Equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### B1.2 For Portable Devices

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device was tested for typical hand held operations with the device contacted directly to the human body to the sides of the device. To maintain compliance with FCC RF exposure compliance requirements, avoid direct contact to the transmitting antenna during transmitting.

## B2 Radio Wave Exposure and Specific Absorption Rate (SAR) Information

The Tobii Dynavox I-Series+ device has been tested as a Class 1 Medical Device. Medical electrical equipment such as this requires special caution regarding Electro-magnetic Compatibility (EMC) and thus needs to be installed and placed into service according to the information provided in this manual.



Using other cables and accessories other than those provided or that are integrated in the device may affect EMC performance.

The SAR (Specific Absorption Rate) limit as dictated by the FCC (in the USA) is 1.6W/kg averaged over 1 gram of tissue. In Europe/EU (CE regulations) it is 2.0 W/kg averaged over 10 grams of tissue. The Devices, Tobii Dynavox I-12+ (FCC ID: W5MTDI12A) and Tobii Dynavox I-15+ (FCC ID: W5MTDI15) have been tested against these SAR limits to maintain compliance with FCC/CE RF exposure requirements.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

The highest SAR value for the I-12+ device is 0.8 W/kg. The highest SAR value for the I-15+ device is 0.8 W/kg.

Guidance and manufacturer's declaration – electromagnetic emissions		
The Tobii Dynavox I-Series+ is intended for use in the electromagnetic environment specified below. The customer or the user of the Tobii Dynavox I-Series+ device should assure that it is used in such an environment.		
Emissions Test	Compliance	Electromagnetic environment – guidance
RF (Radio Frequency emissions CISPR 11	Group 1	The Tobii Dynavox I-Series+ must emit electromagnetic energy in order to perform its intended function. Nearby electronic equipment may be affected
RF emissions CISPR 11	Class B	
Harmonic emissions IEC 61000-3-2	Not Applicable	The product has an active power of $P \leq 75$ W at rated load conditions. Therefore no limits are applicable.
Voltage Fluctuations/flicker emissions IEC 61000-3-3	Not Applicable	The product has an active power of $P \leq 75$ W at rated load conditions. Therefore it is not likely to produce voltage fluctuations or flicker above the limit values.




The Tobii Dynavox I-Series+ device should not be used adjacent to or stacked with other equipment.

Guidance and manufacturer's declaration – electromagnetic immunity			
The Tobii Dynavox I-Series+ device is intended for use in the electromagnetic environment specified below. The customer or the user of the Tobii Dynavox I-Series+ device should assure that it is used in such an environment.			
IMMUNITY test	IEC 60601 test level	Compliance level	Electromagnetic environment – guidance
Electrostatic discharge (ESD)  IEC 61000-4-2	$\pm 6$ kV contact $\pm 8$ kV air	$\pm 6$ kV contact $\pm 8$ kV air	Floors should be wood, concrete or ceramic tile. If floors are covered with synthetic material, the relative humidity should be at least 30 %.
Electrical fast transient/burst  IEC 61000-4-4	$\pm 2$ kV for power supply lines $\pm 1$ kV for input/output lines	$\pm 2$ kV for power supply lines $\pm 1$ kV for input/output lines	Mains power quality should be that of a typical commercial or hospital environment.
Surge  IEC 61000-4-5	$\pm 1$ kV line to line	$\pm 1$ kV line to line	Mains power quality should be that of a typical commercial or hospital environment.



Guidance and manufacturer's declaration – electromagnetic immunity			
The Tobii Dynavox I-Series+ device is intended for use in the electromagnetic environment specified below. The customer or the user of the Tobii Dynavox I-Series+ device should assure that it is used in such an environment.			
IMMUNITY test	IEC 60601 test level	Compliance level	Electromagnetic environment – guidance
Voltage dips, short interruptions and voltage variations on power supply input lines.  IEC 61000-4-11	< 5 % UT (>95 % dip in UT) for 0.5 cycles. 40 % UT (60 % dip in UT) for 5 cycles. 70 % UT (30 % dip in UT) for 25 cycles. < 5 % UT (>95 % dip in UT) for 5 s	< 5 % UT (>95 % dip in UT) for 0.5 cycles. 40 % UT (60 % dip in UT) for 5 cycles. 70 % UT (30 % dip in UT) for 25 cycles. < 5 % UT (>95 % dip in UT) for 5 s	Mains power quality should be that of a typical commercial or hospital environment. If the user of the Tobii Dynavox I-Series+ device requires continued operation during mains interruptions, it is recommended that the Tobii Dynavox I-Series+ device batteries are in place or that the device be powered from an uninterruptable power supply (UPS).  UT is at 100 VAC 60 Hz or 230 VAC 50 Hz.
Power frequency (50/60 Hz) magnetic field  IEC 61000-4-8	3 A/m	3 A/m	Power frequency magnetic fields should be at levels characteristic of a typical location in a typical commercial or hospital environment.

Guidance and manufacturer's declaration – electromagnetic immunity			
The Tobii Dynavox I-Series+ device is intended for use in the electromagnetic environment specified below. The customer or the user of the Tobii Dynavox I-Series+ device should assure that it is used in such an environment.			
Immunity test	IEC 60601 test level	Compliance level	Electromagnetic environment - guidance
Conducted RF IEC 61000-4-6	3 Vrms 150 kHz to 80 MHz	3 V	Portable and mobile RF communications equipment should be used no closer to any part of the Tobii Dynavox I-Series+ device, including cables, than the recommended separation distance calculated from the equation applicable to the frequency of the transmitter.  Recommended separation distance $d = \frac{3,5}{3} \sqrt{P}$ for 150 kHz to 80 MHz $d = \frac{3,5}{3} \sqrt{P}$ for 80 MHz to 800 MHz
Radiated RF IEC 61000-4-3	3 V/m 80 MHz to 2.5 GHz	3 V/m	

Guidance and manufacturer's declaration – electromagnetic immunity			
The Tobii Dynavox I-Series+ device is intended for use in the electromagnetic environment specified below. The customer of the user of the Tobii Dynavox I-Series+ device should assure that it is used in such an environment.			
Immunity test	IEC 60601 test level	Compliance level	Electromagnetic environment - guidance
			$d = \frac{7}{3} \sqrt{P}$ <p>for 800 MHz to 2.5 GHz</p> <p>where "P" is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer and "d" is the recommended separation distance in meters (m).</p> <p>Field strengths from fixed RF transmitters, as determined by an electromagnetic site survey,<sup>i</sup> should be less than the compliance level in each frequency range.<sup>ii</sup></p> <p>Interference may occur in the vicinity of equipment marked with the following symbol.</p> 

**NOTE 1** At 80 MHz and 800 MHz, the higher frequency range applies.

**NOTE 2** These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflected from structures, objects and people.

- i. Field strengths from fixed transmitters, such as base stations for radio (cellular/cordless) telephones and land mobile radios, amateur radio, AM and FM radio broadcast and TV broadcast cannot be predicted theoretically with accuracy. To assess the electromagnetic environment due to fixed RF transmitters, an electromagnetic site survey should be considered. If the measured field strength in the location in which the Tobii Dynavox I-Series+ device is used exceeds the applicable RF compliance level above, the Tobii Dynavox I-Series+ device should be observed to verify normal operation. If abnormal performance is observed, additional measures may be necessary, such as reorienting or relocating the Tobii Dynavox I-Series+ device.
- ii. Over the frequency range 150 kHz to 80 MHz, field strengths should be less than 3 V/m.

Recommended separation distances between portable and mobile RF (Radio Frequency) communications equipment and the Tobii Dynavox I-Series+ device.			
The Tobii Dynavox I-Series+ device is intended for use in the electromagnetic environment in which radiated RF disturbances are controlled. The customer or the user of the Tobii Dynavox I-Series+ device can help prevent electromagnetic interference by maintaining a minimum distance between portable and mobile RF communication equipment (transmitters) and the Tobii Dynavox I-Series+ device as recommended below, according to the maximum output power of the communications equipment.			
Rated maximum output power of transmitter W	Separation distance according to frequency of transmitter		
	150 kHz to 80 MHz	80 MHz to 800 MHz	800 MHz to 2.5 GHz
0.01	0.12 m	0.12 m	0.24 m
0.1	0.37 m	0.37 m	0.74 m
1	1.2 m	1.2 m	2.4 m
10	3.7 m	3.7 m	7.4 m
100	11.7 m	11.7 m	23.4 m

Under test specifications specified in 6.2.1.10 EN 60 601-1-2 (2007) the Tobii Dynavox I-Series+ device shall not:

- Exhibit component failure

- Exhibit changes in its programmable parameters
- Reset unintentionally to factory defaults
- Emit false alarms
- Initiate any unintended operation, even if accompanied by alarm

With regard to the test specifications specified in 6.2.1.10 EN 60 601-1-2 (2007) the cessation or interruption of any intended operation, even if accompanied by an alarm, is allowed in the Tobii Dynavox I-Series+ device due to it not performing any safety critical operations.

Also with regard to the test specifications specified in 6.2.1.10 EN 60 601-1-2 (2007) errors of a displayed numerical value sufficiently large to affect diagnosis or treatment is not applicable for the Tobii Dynavox I-Series+ device.

In order to maintain compliance as a Class 1 Medical device, the switches that are used in combination with the Tobii Dynavox I-Series+ device must fulfill the isolation requirements of IEC/EN 60601-1 based on 15 V DC. They must be electrically floating switches (switches that are not grounded).

## B3 Industry Canada Statement

Low-power license-exempt radio communication devices (ICES-003)

De faible puissance exempts de licence des appareils de communication radio (CNR-210)

- Common information  
Operation is subject to the following two conditions:
  - This device may not cause interference, and
  - This device must accept any interference, including interference that may cause undesired operation of the device.
- Operation in 2.4 GHz band  
To prevent radio interference to the licensed service, this device is intended to be operated indoors and installation outdoors is subject to licensing.
- Informations communes  
Son fonctionnement est soumis aux deux conditions suivantes:
  - Ce dispositif ne peut causer des interférences, et
  - Ce dispositif doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement du dispositif.
- Le fonctionnement en bande de 2,4 GHz  
Pour prévenir les interférences radioélectriques aux services sous licence, cet appareil est destiné à être exploité à l'intérieur et à l'extérieur d'installation est soumise à licence.

This device has been tested to the safety requirements for exposure to radio waves (SAR) in RSS-102 to the General Public (Uncontrolled Environment) limits (1.6W/Kg). The highest SAR value for the I-12+ device is 0.8 W/kg. The highest SAR value for the I-15+ device is 0.8 W/kg. This device can be operated safely with a minimum distance 0 cm between the equipment and the user's body.

Ce dispositif a été testé aux exigences de sécurité pour l'exposition aux ondes radio (SAR) dans le CNR-102 à le grand public (environnement non contrôlé) des limites (1.6W/Kg). La valeur maximale mesurée de SAR pour le I-12+ dispositif est: 0.8 W/kg. La valeur maximale mesurée de SAR pour le I-15+ dispositif est: 0.8 W/kg. Ce dispositif peut être exploité en toute sécurité avec un 0cm distance minimale entre le matériel et les corps de l'utilisateur.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme CNR-210 du Canada.

## B4 CE Statement

This equipment complies with the requirements relating to electromagnetic compatibility, EN 300386 class B for ITE, the essential protection requirement of Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to electromagnetic compatibility and R&TTE Directive 1999/5/EC to meet the regulation of the radio equipment and telecommunications terminal equipment.

## B5 Standards

We, Tobii Technology AB, hereby declare that the Tobii Dynavox I-Series+ products listed in this manual complies with the following directives:

- 93/42/EEC (MDD) - Medical Device Directive, as amended by 2007/47/EC
- 2011/65/EU (RoHS 2) - Restriction of Hazardous Substances Directive
- 2004/108/EC (EMC) - Electromagnetic Compatibility Directive
- 2006/95/EC (LVD) - Low Voltage Directive
- R&TTE 1999/5/EC (R&TTE) - European Radio equipment and Telecommunications Terminal Equipment Directive
- 2002/96/EC - WEEE Directive
- 2006/121/EC - Reach Directive

The following standards have been used:

- ISO 14971:2007
- CAN/CSA-C22.2No. 60601-1:08
- ANSI/AAMIES60601-1:2005
- IEC 60601-1 ed.3
- IEC 60601-1:2005
- IEC 60601-1-11:2010
- EN 60601-1:2006
- EN 60601-1-2:2007+AC:2010
- IEC60950-1:2005+A1:2009
- EN 60950-1:2006+A11:2009+A1:2010+A12:2011
- EN 55011:2009+A1:2010
- EN 61000-3-2:2006+A1:2009+A2:2009
- EN 61000-3-3:2013
- EN 55022:2010+AC:2011 (EMC)
- EN 55024:2010 (EMC)
- ETSI EN 301 489-1:V1.9.2 (09-2011) (EMC)
- ETSI EN 301 489-17:V2.1.1 (09-2012) (EMC)
- ETSI EN 300 328: V1.8.1 (2012-06)(BT-WLAN)
- FCC 47 CFR Part 15 Subpart B
- FCC 47 CFR Part 15 Subpart C (BT-WLAN)
- FCC 47 CFR Part 18 Subpart C
- 47 CFR Part §2.1093
- ANSI C63.4:2009
- CISPR22:1997 (EMC)
- ANSI/IEEE C95.1-1999
- IEEE Std 1528-2003 (SAR)
- IEEE Std 1528a-2005 (SAR)
- EN62479 2010
- RSS-102 Issue 4, March 2010 (SAR)
- EN 62209-2:2010 (SAR)
- Canada RSS-210 ISSUE 8: Dec., 2010 Canada RSS-Gen ISSUE 4: Nov., 2014
- Canada RSS-Gen Issue 3: Dec.2010
- ACMA Radiocom. (Short Range Devices):2004
- AS/NZS60950.1
- AS/NZS 4268 (BT-WLAN)
- AS/NZS CISPR22:2009 (EMC)
- ICES-003: issue 5 (EMC)
- IEC 60529 Ed 2.1:2001 (IP)
- CNCA-01C-020:2010
- EN 60825-1:2007 (Near Infra Red (NIR) Radiation)
- MEPS (Australia and NZ)
- VCCI (Japan)

# Appendix C Computer Device States of Operation


Table C.1 Computer Device States of Operation

Advanced Configuration and Power Interface (ACPI) State	Description
S0 (Working)	Normal operating state - Windows session is running Display will dim and turn off after a time of idle. The 1, 2, Menu and Volume Up and Down buttons are however always illuminated in state S0.
S3 (Sleep)	The device is sleeping. The Windows session is suspended to RAM, allowing a quick resume to state S0 by: <ol style="list-style-type: none"> <li>1. Pressing the power button</li> <li>2. Pressing a button connected to a switch port configured to have power on functionality</li> <li>3. Wake on Gaze (if enabled)</li> </ol> The device is consuming a small amount of power in state S3. Fully charged batteries (no AC adapter attached) will last a minimum of 24 h in state S3. Windows Critical battery level is monitored in state S3 to prevent the batteries from being fully drained. The device will enter state S4 (Hibernate) if the critical value is reached.
S4 (Hibernate)	The device is in hibernation. The Windows session is suspended to the SSD (hard drive) and the device is powered off. The session can be resumed to state S0 by: <ol style="list-style-type: none"> <li>1. Pressing the power button</li> <li>2. Pressing a button connected to a switch port configured to have power on functionality</li> </ol>
S5 (Soft Off)	Windows is shut down. The device is powered off. Batteries (not drained) and/or AC adapter attached.
G3 (Mechanical Off)	All power sources removed (no batteries and no AC adapter attached).

Table C.2 Power Button Normal Operation, LED Behavior

ACPI State	Power Button Illumination		Button 1, 2, Menu, Volume Up and Volume Down Buttons White Illumination
	No Battery Charging	Battery Charging	
S0 (Working)	Green Light	Blue Light	ON
S3 (Sleep)	Green Blinking Light	Blue Blinking Light	OFF
S4 (Hibernate)	OFF	Blue Light	OFF
S5 (Soft off)	OFF	Blue Light	OFF

Table C.3 Power Button Error or Warning, LED Behavior

Error or Warning	ACPI State and condition	Power Button Illumination	Comment
<b>Chassis near overheating</b>	In state <b>ACPI S0 (Working)</b> , when the chassis temperature is $\leq 1$ degree Celsius from the Maximum Threshold according to the Safety Settings specified in <i>Table D.1 Maximum Allowed Temperature</i> , page 87.	Purple Light	Purple light as a warning to the user when the Device is close to the overheat threshold.
<b>Chassis overheats</b>	In state <b>ACPI S0 (Working)</b> , when the chassis temperature is $>$ the Maximum Threshold according to the Safety Settings specified in <i>Table D.1 Maximum Allowed Temperature</i> , page 87.	Purple Quick Blinking Light	The Device will blink the LED during the hibernate or shutdown process.
<b>Chassis overheated</b>	In state <b>ACPI S4 (Hibernate)</b> and <b>ACPI S5 (Soft Off)</b> , when the power button <sup>i</sup> is pressed.	Purple Quick Blinking Light for 5 seconds.	<p>The Device will blink the LED and remain in the state <b>ACPI S4 (Hibernate)</b> or <b>ACPI S5 (Soft Off)</b>.</p> <p> The Device will start up and be operational for up to 9 minutes if the temperature does not drop below the Maximum Threshold according to the Safety Settings specified in <i>Table D.1 Maximum Allowed Temperature</i>, page 87 within the 9 minutes.</p>
<b>Low Battery Level for Battery Packs</b>	<p>In state <b>ACPI S4 (Hibernate)</b> and <b>S5 (Soft off)</b>, when the power button<sup>i</sup> is pressed and:</p> <ol style="list-style-type: none"> <li>1. No DC plug inserted, and</li> <li>2. Battery level is at or below the critical level</li> </ol>	Blue Quick Blinking Light for 5 seconds.	

i. Or a switch port configured to have power button functionality.



# Appendix D    Maximum Allowed Temperature

Table D.1 Maximum Allowed Temperature

Allowable maximum temperature for the Tobii Dynavox I-Series+ metal external surfaces which are likely to be touched	Maximum Temperature °C/°F	
	Portable Mode	Mounted Mode
<b>Mounted Mode temperature threshold:</b> External surfaces temperature allowed  External surfaces temperature allowed in an area unlikely to be touched, see position 1 in <i>Figure D.1 Temperature Threshold Area, page 87</i> for the position of this area.		55/131  60/140
<b>Portable Mode temperature threshold:</b> External surfaces temperature allowed  External surfaces temperature allowed in an area unlikely to be touched, see position 1 in <i>Figure D.1 Temperature Threshold Area, page 87</i> for the position of this area.	43/109  46/115	




Figure D.1 Temperature Threshold Area

# Appendix E Technical Specifications


## E1 Standard Tobii Dynavox I-Series+

Standard	Tobii Dynavox I-12+	Tobii Dynavox I-15+
Type/Model	I-12+ ETR	I-15+ ETR
<b>Screen</b>	12.1", Aspect ratio: 4:3, LED Backlight Unit, White Luminance 500 cd/m <sup>2</sup>	15.0", Aspect ratio: 4:3, LED Backlight Unit White Luminance 400 cd/m <sup>2</sup>
<b>Screen Resolution</b>	1024 × 768 pixels (XGA)	
<b>Touch Panel</b>	Projected Capacitive Touch with Gorilla® Glass, 10 point multi touch	
<b>Dimensions (WxHxD)</b>	30,7 × 27,4 × 10,5 cm 12.1 × 10.8 × 4.1 inches	36,9 × 32,6 × 11,2 cm 14.5 × 12.8 × 4.4 inches
<b>Weight</b>	2,8 kg 6.2 lbs	3,8 kg 8.4 lbs
<b>Speakers</b>	2 × 3 W Closed Box Speakers	
<b>Microphone</b>	1 × Analog Microphone	
<b>Processor</b>	Intel® Celeron Quad Core Processor J1900 (2M Cache, 2 Ghz)	
<b>RAM</b>	4 GB DDR3	
<b>Operating system</b>	Microsoft Windows 8.1	
<b>Hard disk drive</b>	2.5" SSD 120 GB minimum	
<b>SD-Card</b>	MicroSD-Card 32 GB	
<b>Connectors</b>	1 × Connector for an HDMI 1.3 Connector Type A cable 2 × USB 2.0 (Current limit = 1000 mA) 1 × USB 3.0 (Current limit 1500 mA) 1 × RJ45 100/1000 Mbit/s (Ethernet) 2 × 3.5 mm Switch connector interface, (Pin out for mono plug: Sleeve = Common ground, Tip = Signal) 1 × 3.5 mm" Headphone jack (stereo) with jack detection 1 × 24 VDC in 2.5/5.5 mm (Power connector)	
<b>Buttons</b>	1 × Power On 1 × Volume Up 1 × Volume Down 1 × Menu 2 × Programmable	
<b>WLAN (optional)</b>	IEEE 802.11 b/g/n Dual antenna diversity system	
<b>Bluetooth® (optional)</b>	Bluetooth® 3.0+HS Dedicated for Mobile Phone Communication	
<b>IR Remote Control (Environmental Control Unit)</b>	GEWA Programmable IR Remote Control (Environmental Control Unit), 19 – 455 kHz, 940 nm, compatible with a wide range of remote controls Resting Orientation: 1 × IR filter window with 1 × IR Receive Sensor, 3 × IR Transmit Diodes and 1 × Red Status LED Upright Orientation: 1 × IR filter window with 4 × IR Transmit Diodes	



Standard	Tobii Dynavox I-12+	Tobii Dynavox I-15+
Type/Model	I-12+ ETR	I-15+ ETR
Camera	User Camera (back) 5 MP AF (Auto Focus) Web Camera (front) 2 MP FF (Fixed Focus)	
Eye Tracker	Tobii IS20 Module	
Battery Run Time <sup>i</sup>	~9 h	~9.5/8 <sup>ii</sup> h
Battery Charge Time	Maximum 5.4 h (0-100%)	
Battery Storage Time	Maximum 6 months @ charge ≥ 40%	
Deskstand	Integrated	
Mounting Systems Supported	Tobii Dynavox QR adapter plate for Daessy and REHAdapt	
Power Supply	Adapter Technology Co. Ltd, ATM065-A240 Input: Universal 100 ~ 240 VAC / 50 ~ 60 Hz Output: +24VDC / 0~2.71A	
IP class	IP 43 (with I/O covers in place)	
i. Indoor with continuous communication and with Gaze Interaction if applicable. ~24 hours with a Power optimized scenario.		
ii. 9.5 hours without the Eye tracker activated, 8 hours with the Eye tracker activated		

## E2 Battery pack

Item	Specification	Remark
<b>Battery Technology</b>	Li-Ion rechargeable battery pack with gas gauge (SMBus v1.1 interface)	
<b>Cell</b>	6× Panasonic NCR18650 (3S2P)	
<b>Battery Pack Capacity</b>	62.64 Wh	Initial capacity, new battery pack
<b>Nominal Voltage</b>	10.8 V	
<b>Charge Time</b>	Maximum 5.4 h	Charge from 0 to 100%
<b>Cycle Life</b>	500 cycles	Minimum 75% of initial capacity remaining
<b>Allowable Operating Temperature</b>	0 – 45 °C, 45-85%RH -20 – 60 °C, 45-85%RH	Charge condition Discharge condition
<b>Storage Temperature</b>	-20 – 35 °C, 45-85%RH -20 – 40 °C, 45-85%RH -20 – 45 °C, 45-85%RH -20 – 50 °C, 45-85%RH	1 year 6 months 1 month 1 week
<b>Storage Time<sup>i</sup></b>	Maximum 6 months @ charge ≥ 40%	 Do not long time store battery packs with less than 40% charge level
i. Batteries shall not be stored in the device		

## E3 Eye Tracker

Technical Specifications	Tobii IS20 Module
<b>Working Distance</b>	40 - 90 cm 18 - 35 inches
<b>Freedom of Head Movement<sup>i</sup> @ 70 cm / 27.5 inches (Width x Height)</b>	50 × 36 cm 20 × 14 in
<b>Head Movement Speed (optimal)</b>	11.8 in/s 30 cm/s
<b>Gaze Data Rate</b>	30 Hz
<b>Gaze Accuracy<sup>ii</sup></b> Under ideal conditions Across 30 × 20 × 20 cm head box	0.4° (Std dev 0.1°) 0.5° (Std dev 0.2°)
<b>Screen Size</b> Distance (from screen) Track box size (Width × Height) Track box depth	<22" 45 — 85 cm 17.7 — 33.5 in 27 × 23 — 52 × 44 cm 10.6 × 9.1 — 20.5 × 17.3 in 40 cm 15.7 in
<b>Gaze Precision (=sample to sample noise)<sup>iii</sup></b> Under ideal conditions, without filter, on artificial eyes Across head box, without filter, on human eyes	Pending 0.4° (Std dev 0.1°)
<b>Mounting</b>	Built in
<b>Power Supply</b>	Built in

- i. Freedom of head movement describes the volume in front of the tracker in which the user must have at least one of the eyes. The numbers are specified parallel/orthogonal to screen surface, assuming eye tracker is at 20 degree angle to screen.
- ii. Gaze accuracy describes the angular average distance from the actual gaze point to the one measured by the eye tracker. Accuracy under ideal conditions is measured with users placed in the center of the eye tracker track box with the head resting on a chin rest, and the room and screen illumination constant at 300 lux.  
  
Accuracy across head box is measured with users after calibration systematically positioned at varying positions ranging from center of the head box up to +/- 15 cm horizontal, +/- 10 cm vertical and +/- 10 cm distance.  
  
Accuracy across varying background illumination is measured with users' head resting on a chin rest, and after calibration modifying background illumination from 1 to 1000 lux.
- iii. Gaze Precision describes the point-to-point variation between individual gaze samples (here specified with binocular data, ie both eyes, and measured on artificial eyes). Gaze Precision with Stampe filter is with Stampe stage 2 noise-reduction algorithm applied to raw data (Stampe , Behavior Research Methods, Instruments & Computers 1993, 25 (2), 137-142). Precision without filter is based on raw data, without any de-noising filter applied, either inside or outside the eye tracker.  
  
Precision under ideal conditions is measured with users placed in the center of the eye tracker track box with the head resting on a chin rest, and the room and screen illumination constant at 300 lux.  
  
Precision across head box is measured with users after calibration systematically positioned at varying positions ranging from center of the head box up to +/- 15 cm horizontal, +/- 10 cm vertical and +/- 10 cm distance.

## Appendix F    Approved Accessories

Description	Model	Tobii Dynavox Part No.
Tobii Dynavox I-Series+ AC Adapter (Power Supply)	AdapterTech ATM065–A240	12002664
Battery pack	TISB1	12004072

For information about the latest approved Tobii Dynavox Accessories, please visit the [www.tobiidynavox.com](http://www.tobiidynavox.com) website or contact your local Tobii Dynavox reseller.



Copyright © Tobii AB (publ). Illustrations and specifications do not necessarily apply to products and services offered in each local market. Technical specifications are subject to change without prior notice. All other trademarks are the property of their respective owners.

## Support for Your Tobii Dynavox Device

### Get Help Online

See the product-specific Support page for your Tobii Dynavox device. It contains up-to-date information about issues and tips & tricks related to the product. Find our Support pages online at: [www.TobiiDynavox.com](http://www.TobiiDynavox.com) or [www.myTobiiDynavox.com](http://www.myTobiiDynavox.com).

### Contact Your Sales Representative or Reseller

For questions or problems with your product, contact your Tobii Dynavox sales representative or authorized reseller for assistance. They are most familiar with your personal setup and can best help you with tips and product training. For contact details, visit [www.TobiiDynavox.com/contact](http://www.TobiiDynavox.com/contact)