


Receiver

Parts Identification



((Point to Note))

Reset Button

Restore to manufacturer's original setting:

Volume (2-level); Brightness (highest level); Chime (Pin-Pon-Pin-Pon)

Installation Location

⚠ Caution

To avoid fire or leakage of electricity, avoid heat sources over 40°C or high humidity or locations where may wet the unit.

((Tips))

- Signal Transmitting Distance will be shortened when placed near metals. Avoid metals and other electric appliances when install.

Channel Setting


8 channels (A-H) are available for each Receiver. Setting/changing channel is done on the tact switch panel inside.

There are 2 tact switches in the Receiver. The one on the Right hand side (SW2) is for setting of channel. Please be careful not to pick the wrong one.

※ Changing channel is not required normally. Change channel only when the channel of the Receiver and Eliminator have been changed. Please consult the retail shop for further details.

1 Remove Power plug from any power source.

2 Set Channel on the tact switch on your Right hand side. (SW2)



3 All Receiver being sold are set with channel A. Change channel if necessary.


[Switch Panel setting for each channel]

A Channel				B Channel				C Channel				D Channel			
ON	■	■	■	ON	■	■	■	ON	■	■	■	ON	■	■	■
OFF	□	□	□	OFF	□	□	□	OFF	□	□	□	OFF	□	□	□
	1	2	3		1	2	3		1	2	3		1	2	3
	4				4				4				4		
E Channel				F Channel				G Channel				H Channel			
ON	■	■	■	ON	■	■	■	ON	■	■	■	ON	■	■	■
OFF	□	□	□	OFF	□	□	□	OFF	□	□	□	OFF	□	□	□
	1	2	3		1	2	3		1	2	3		1	2	3
	4				4				4				4		

Chime Setting

9 different chimes are available to suit shops of different style.


※Setting is controlled by Eliminator unit. Refer to P22 for instruction.



Volume Setting

16 levels of chime volume are available for setting.

※Setting is controlled by Eliminator unit. Refer to P20 for instruction.



((((Point to Note)))

Volume Indication:


Level of volume is indicated by 4 LEDs.

Volume	LED
1~4	1 light On
5~8	2 lights On
9~12	3 lights On
13~16	4 lights On

Brightness Setting

16 levels of brightness of number display LED are available for setting.

※ Setting is controlled by Eliminator unit. Refer to P20 for instruction.



((Point to Note))

Brightness Indication:

Level of brightness is indicated by 4 LEDs.

Brightness	LED
1~4	1 light On
5~8	2 lights On
9~12	3 lights On
13~16	4 lights On

((Point to Note))

● Memory Backup function during power failure

Memory is backup automatically, when power failed at 0.1s for up to 2 hours. Call signals received from customer are stored, and display again when power restored.

● Reset Button

Restore to manufacturer's original setting:

Volume (2-level); Brightness (highest level); Chime (Pin-Pon-Pin-Pon)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE:

Changes or Modifications not expressly approved by the party responsible could void the user's authority to operate this device.