

# REMOTE GRILL TEMP<sup>o</sup> METER



## INSTRUCTION MANUAL

### Technical data

- Food and cooking temperature of the wireless transmission functions.
- Food and temperature, TIMER display.
- Temperature gauge alarm functions.
- Timer time alarm functions.
- Meat type and Taste Level selection.
- °C/°F temperature display selected.
- Backlight function.
- Temperature range: 0°C ~ 250°C
- RF transmission range: 30 meters

### MONITOR

1. Remove the battery compartment cover on the back of the monitor.
2. Place 2 fresh AAA size (UM-4) batteries in the compartment as indicated by the polarity symbols (+and-).
3. Replace the cover.
4. Switch the "POWER" switch on the back to control the power on / power off.




### TRANSMITTER


1. Slide off the battery compartment cover.
2. Place 2 fresh AAA size(UM-4) batteries in the compartment as indicated by the polarity symbols (+and-)
3. Replace the battery compartment cover.
4. Switch the "POWER" switch on the bottom to control the power ON/OFF. Red LED light on front of Transmitter will flash three times, indicating monitor can receive temperature.

### Important information:

- **LED INDICATOR**  
The red LED in the center of the transmitter flashes to indicate that it is on and is transmitting.
- **TRANSMITTER TRANSMIT RULES**  
If the temperature remains unchanged, temperature signal transmission will be every 30 seconds. If the temperature probe the senses a change of more than 1°C, the transmitter will transmit a signal.




- **CONNECTING THE PROBE**  
Locate the probe socket on the right side of the Transmitter. Insert the meat probe connector-plug into the socket.



### OPERATION

Plug the probe connector to the transmitter socket. Insert tip of the probe into the center of the meat, taking care not to pierce through it. Do not expose any part of the probe to open flames.



### To Select Meat Type Taste Level

1. Press "MEAT" button to navigate and select the desired meat types.
2. Each press will change the display in the following sequence:

### To Select Taste Level

1. Press "TASTE" button to select the doneness level (Rare, Medium Rare, Medium, Medium Well or Well Done). The target temperature appears on the LCD screen.
2. Begin cooking.  
The cooking alerts will sound when the meat has reached the target temperature.

### After Cooking

- Once cooking is finished, remove the probe using an oven mitt.
- Clean the probe with water and a mild detergent.
- To clean the main unit and sensor, wipe with a damp cloth

### Manually Set Target Temperature

1. Insert the probe into the meat as shown above. Press and hold down "MODE" button for 3 seconds to switch to manually set the temperature patterns,
2. Press "MIN" and "SEC" to select your desired temperature.
3. Press "MODE" button to confirm your setting Your target temperature will appear on the LCD screen, Begin cooking. The cooking alerts will sound as described above.

### °C/°F Temperature Display

The temperature is displayed either in °C or °F. To select Fahrenheit or Celsius, briefly pressing the "MODE" button allows you to switch between the individual models.

### Count-Up/Countdown Timer

The count-up and countdown timers operate independently of the temperature sensor.

#### To set a count-up timer:

If no countdown time is set the timer will act as a count up timer.

#### To set a countdown time:

Use MIN and SEC to set the countdown time.

#### To start timer:

1. Press "START" button to begin.
2. Press "START" button again to pause,
3. Once paused, press "CLEAR" button to reset to zero.
4. Once a countdown has finished, the unit will beep, to silence the alert press any button.

**NOTE:** The countdown timer will count up to 99:59.

### Backlight

Press any button to illuminate the screen for 5 seconds.

### FCC WARNING

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

### FCC STATEMENT

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.



JLR Gear  
1451 Doolittle Drive  
San Leandro, CA 94577  
[www.jlrgear.com](http://www.jlrgear.com)  
[customerservice@jlrgear.com](mailto:customerservice@jlrgear.com)  
© 2008 JLR Gear  
Made in China