

User's manual

Install 2 AA battery into battery compartment, the transmitter will send temperature & humidity signal. After sending signal once, then it will send temperature & humidity signal once every other minute. Press the button "RESET", then press and hold the button "TX" for 6 seconds, the transmitter will enter testing mode, it will send temperature & humidity signal once every 3 seconds.

FCC INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.