

.User Manual

A. Remocon peration(Pairing)

Within 5 seconds operation completion after power on

1. POWER + Mute press on 2 Seconds
2. Remocon LED ON
- 3 .RF Address Request send
4. RF RX(SET top box) module send ACK to remocon
5. RF RX(SET top box) module send RF Address to remocon
6. Remocon send ACK to RF RX
7. Remocond led on/off display 2 times.

B. Set top box reset

1. POWER + exit press on 5 ~ 6 Seconds
2. Set top box reset command send
3. Set top box reset