

User manual



Open the battery cover. There is a 9 tri-states switch. User can set the 9 switches to high, middle or low state which matches the receiver.



Close the battery cover. User can click the push button. A signal transmits out. If the inside 9 tri-states switch matches the receiver 9 tri-states switch, the receiver will work.

FCC NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.