

# AV80R

## Basic Operation



1. **LOCK** – Make sure the LOCK tab is in the unlocked position (down). In the locked (up) position, all controls are disabled including the **POWER** button.
2. **POWER** – Hold the **POWER** button down until the startup screen shows to turn power on. Hold the **POWER** button down until **POWER OFF** mode shows to turn power off. To put AV80R into **SLEEP** mode, hold the **POWER** button down until **SLEEP** mode shows. To cancel **SLEEP** mode, push and release the **POWER** button.
3. **MENU** – Press the MENU button from any page to return to the Main Menu page.
4. **VOLUME** – Rotate the VOLUME knob clockwise to increase the volume and counter-clockwise to decrease the volume.
5. **SD CARD Slot** – Make sure the correct SD card is inserted into the **SD CARD** slot.
6. **RST** button – Push the RST button on the back of the case to reboot the system.

## MAIN MENU



- Tap on the **GO fly** icon for Aviation mode.
- Tap on the **GO drive** icon for Automotive Mode.
- Tap on the **Multimedia** icon to listen to music, view a movie, look at photos or view an E-Book.



- Tap on the **Settings** icon to view the **GPS Status**, adjust the **Backlight**, view the **System Info**, adjust the **Bluetooth** settings or to go into **Initial Setup** mode. Refer to the user guide to configure the initial setup options.

