

## Wireless Remote Control User Manual (WXD-189RX)

Thank you for your purchase of Phottix product and viewing this instruction manual, be sure to read and understand this manual and the instruction manual of the camera entirely before use, so that you can use it correctly and expertly. We will spare no effort to add oges to your photograph. You can realize the use method and precautions easily through this manual.

### 1. Product description:

Cleon is a remote control with radio frequency, the Working voltage as well as the electric current of the receiver is low, so it saves power safety, with strong anti interference ability. Smart code setting: Frequency pre-set in production. so you can use the remote instantly. in case change code in usage, press five times continuously the Set/ switch on receiver until light blinks, press the shutter button on transmitter one time to confirm the code. you can do this way to unlimited receivers with one transmitter. the Smart code system has up to 16,000,000 combination codes, it can operate within the working distance of 100 meters (without obstacles) with no interference. In order to adapt to the specific shooting environment.

### 2. Parts of product:



### 3. Specification:

- 1). battery: one CR2 3V battery
- 2). standby current: 1.2mA; Dormancy current: 1uA
- 3). max. distance: 100m (without obstacles)
- 4). frequency: 433.92Mhz
- 5). Receiving sensitivity: -98dBm

### 4. Operating Instructions:

**SET/POWER button** Set/⏏: has two functions, that is on/off and code setting.

After installing the battery, keep pressing the button for 3 seconds, it is starting up, then keep pressing it for 3 seconds, it is turned off; when it is on, we press it continuously 5 times, then the indicator light blinks, we can have code setting now, then press the release button on the transmitter to confirm working..

#### 1). use method of wired remote:

- ① Set to ON position on receiver, take the 2.5mm cable to connect the 2.5mm socket of receiver and the shutter port of camera.
- ② Pressing the release button on the receiver manually to autofocus and take photos.

The usage of Long Exposure: switch the receiver to the Hold position, then the camera has long exposure.

#### 2). the usage of wireless remote:

- ①When the camera is off,switch the receiver to the ON position,take the 2.5mm cable to connect the 2.5mm socket of receiver and the shutter port of camera,after that,turn on the camera and the receiver;
- ②after the successful code setting,the transmitter can control the receiver,so that it can control the camera's sets,such as single shot mode, 2 seconds delay, continuous, as well as bulb mode for long exposures.

**Precautions:**

- 1)This product belongs to the accessory of electronic product,maybe Because of the external environment factors,there is something wrong with the cameras,but it is a small probability event,do not panic.
- 2)please turn off the receiver,and take out the battery for long time unused.
- 3)Don't drag the cable when it is connected to the camera.
- 4)Don't put it in the high temperature places,such as the Enclosed vehicles and the control panels.
- 5)keep dry:Don't touch the product with wet hands,and it may be malfuction if immersed in or exposed to water.
- 6)Don't use it in the places where the materials can easily get fire and explosion.

**FCC ID: XBYWXD189RX**

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

Contact Tel : (86) 0755-61116103

Contact Fax : (86) 0755-61116101

E-Mail: cybzc@163.com