


SET UP

1. Remove the transmitter holder on the rear side of transmitter



2. Find the location would like to install ,it occupies space around 10W*14H*10Deep cm, fix the holder by two screws included in package
3. Slide battery cover off on rear side ,insert 3 “AAA” batteries following (+) and (-) indicated on inside of battery compartment, close cap
DO NOT mix old and new batteries, DO NOT mix alkaline, standard(carbon-zinc) or rechargeable(Ni-Cad, Ni-mh,etc)batteries.
DO NOT dispose of batteries in fire, batteries may explode or leak
4. Slide the switch to choose the delayed time ,after motion/dusk is detected, 4 options :1 minute; 5 minutes ,15 minutes, 30 minutes
5. Slide the switch to choose the channel labeled on the package ,or receiver can not turn on/off correctly
6. Twist the switch on the front side to choose the mode. There are 4 options :
 - A. Random mode. Will turn on the receiver for a period of 10 minutes to 2 hours, then keep off for a period of 10 minutes to 2 hours
 - B. CDS mode. Will turn on the receiver when dusk and turn off when dawn
 - C. Auto mode. will turn on the receiver when motion is detected at night . blue light will turn on telling you: “ I see you motion”
 - D. Motion mode. will turn on the receiver once motion is detected, blue light will turn on telling you: “ I see you motion”.
7. Mount transmitter back to holder, adjust the position and make the window towards the most area you would like to be detected.
8. Plug in receiver ,and connect receiver with load ,such as light etc, the distance between receiver and transmitter is up to 100 feet in the open area.

Ratings:

433.92MHz
120V, 60Hz,
12A, 1440W resistive
3A, 360W tungsten

Caution: Use of this product is licensed by the Federal Communications Commission (FCC). Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.