


**MERITRC**

**MT-300**

**FHSS 2.4GHz**



**3 CHANNEL COMPUTER RADIO SYSTEM**

## SERVICE AND SUPPORT

If you have any questions or concerns, we're here to help. If you encounter a problem with your radio control system, please contact us directly.

NO.1058 TAOGAN RD  
SHESHAN TOWN  
SONGJIANG DISTRICT SHANGHAI

Telephone:+86-21-57793858  
Fax:+86-21-57793769  
Email:sales@meritrc.com

## INTRODUCTION

Congratulations! We appreciate your purchase of the MERITRC **MT-300** 2.4GHz radio control system. This Operating Manual is intended to acquaint you with the many unique features of your radio control system. Please read this Operating Manual carefully so that you may obtain maximum success and enjoyment from the operation of your new radio control system. The **MT-300** 2.4GHz radio control system has been designed for the utmost in comfort and precise control of all types of model cars and boats. We wish you the best of success and fun with your new purchase.

## GENERAL SAFETY

This is a high-output full-range radio control system that should well exceed the range needed for any surface model. For safety, the user should perform a range test at the area of operation to ensure that the radio control system has complete control of the model at the farthest reaches of the operational area. Rather than operating the model, we recommend that the user enlist the help of a fellow modeler to walk the model to the farthest reaches of the track (or for boats, to walk the shore line well in excess of the operational distance of the boat), then test for proper operation.

- 'Safety First' for yourself, for others, and for your equipment. Your model can cause serious damage or injury, so please use caution and courtesy at all times.
- Observe all the rules of the field, track, or lake where you operate your radio control equipment.
- If at any time during the operation of your model, should you feel or observe erratic operation or abnormality, end your operation as quickly and safely as possible. DO NOT operate your model again until you are certain the problem has been corrected. TAKE NO CHANCES.
- Please waterproof the receiver and servos by placing them in a water-tight radio box when operating R/C model boats.
- If you have little to no experience operating R/C models, we recommend you seek the assistance of experienced modelers or your local hobby shop for guidance.
- The Low Voltage Alarm will sound when the transmitter battery voltage drops to 4.2 volts. If this occurs, stop using the transmitter as soon as possible, then replace or recharge the transmitter batteries.

## FCC COMPLIANCE STATEMENT

This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions :

- 1) This device may not cause harmful interference, and....
- 2) This device must accept any interference received, including interference that may cause undesired operation.

**WARNING:** Changes or modifications made to this equipment not expressly approved by MERITRC may void the FCC authorization to operate this equipment.

### RF Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## SYSTEM FEATURES

Unique and functional pistol grip transmitter design  
Well balanced for precise control  
Non-slip foam steering wheel  
Well placed digital trim & D/R levers  
Optimum third channel switch location  
Low Battery warning  
Quick Binding and Fail Safe Setup  
High performance micro 3 channel receiver  
NiCd charger jack in transmitter  
Sound Beep

## SYSTEM SPECIFICATIONS

### Transmitter

**Model:** MT-300

**FHSS Output Power:** <100mW

**Operating Voltage:** 4.2V~7V

**Power Supply:** 4 Cell Alkaline/Ni-Cd/Ni-MH

**Weight:** 13.9 oz (394 gr) with Alkalines

**Frequency/Modulation Type:** 2.4GHz FHSS

### Receiver

**Model:** MR-300

**Frequency:** 2.4GHz FHSS

**Operating Voltage:** 3.6V~7V

**Weight:** 0.26 oz (7.4gr)

**Dimensions:** 1.38 x 1 x 0.5 in (35.1 x 25.3 x 13 mm)

**Fail Safe:** Yes (All Channels)

## FEATURES DESCRIPTIONS

**Receiver Antenna Wire:** The antenna wire receives the transmitter signal. The antenna wire should be installed through a nylon tube (antenna tube) in the vertical position for the best reception.

**Auxiliary Channel 3 Switch:** Controls Auxiliary Channel 3 High and Low servo travel.

**Battery Compartment:** Houses the 4 'AA' Alkaline batteries that power the transmitter.

**Bind Button:** Used in the process of Binding the transmitter and receiver.

**Bind LED:** Displays the current status of the transmitter and receiver pair.

**Steering Dual Rate(D/R):** The Dual Rate Keys are used to adjust the Steering Dual Rate quickly and easily during use.

**Grip:** The Grip is molded in an ergonomic shape for increased comfort, control and feel.

**Power Indicator:** Indicates that there is Power to the transmitter.

**Power Switch:** Turns the transmitter ON and OFF.

**Steering Trim Lever (CH1):** Used to adjust the center Trim of the Steering servo.


**Steering Wheel(CH1):** Proportionally operates the model's right and left steering control. The Steering Wheel features a molded grip for increased comfort, control and feel.



**Throttle Trigger(CH2):** Controls the speed of the model, both forward and backward, or the model's brake.

**Throttle Trim Lever (CH2):** Used to adjust the center Trim of the Throttle servo.

## TRANSMITTER AND RECEIVER DIAGRAMS

Use the diagram below to familiarize yourself with the different parts of your **MT-300** transmitter and **MR-300** receiver. Descriptions of these parts can be found in the transmitter and receiver layout.


 The transmitter antenna is mounted internally and is located in the front portion of the transmitter. When you're driving your model, hold the transmitter so that it's orientated as close to vertical as possible at all times and try not to 'follow' your model with the transmitter. This provides the best RF signal between the transmitter and the receiver. Do NOT cover the front of the transmitter in any way during use! Doing so can block the RF signal, resulting in the loss of control of your model.



### Channel Output

"1": Steering (CH1)  
 "2": Throttle (CH2)  
 "3": AUX (CH3)  
 "B": Power

## TRANSMITTER BATTERY INSTALLATION



1. Press down on the battery cover and slide in the direction of the arrow to remove.
2. Install 4 AA alkaline cells (or Ni-Cd, or Ni-MH) as indicated inside the battery compartment. Make sure to match the polarity (+ and -) as shown in the battery compartment or the transmitter will not function.

3. Install the battery cover in place and slide to close.

**WARNING:** Improper installation of transmitter batteries can cause serious damage to your system.

## RECEIVER CONNECTIONS AND MOUNTING

Use the diagram below to familiarize yourself with how to connect the switch harness, servos (available separately), and the 4 cell battery holder to your **MR-300** 3-Channel receiver.

- 1) Install four fresh 'AA' Alkaline batteries into the battery holder, making sure that the polarity is correct. The direction that each battery should be installed is molded into the battery holder (+ Positive and - Negative).

The **MR-300** 3-Channel receiver's Nominal Input Voltage is **3.6v~7v**, therefore, the receiver can be powered using a 4 or 5 cell Ni-Cd or Ni-MH battery pack (available separately).

- We suggest Binding the transmitter and receiver and setting the Fail Safe position, prior to mounting the receiver in your model.




- The receiver should be mounted as far away from any electrical components as possible.

- Route the antenna wire up through a plastic tube so that it is in the vertical position.

- To protect the receiver from vibration and other damage, we recommend wrapping the receiver in shock absorbing foam rubber when installing it in your model.

Set your model on a stand so the wheels are off the ground before turning on your radio control system or connecting your motor for the first time.

The receiver does not feature BEC circuitry. If using an electronic speed control, verify that it features BEC circuitry to drop the receiver voltage between 3.6v~7v.




## RECEIVER'S ANTENNA INSTALLATION


The wave length of the 2.4GHz is much shorter than that of the conventional frequencies, it is very susceptible to loss of signal which results in a receiving error.

To obtain the best results, please refer to the following instructions;

1. The antenna must be kept as straight as possible. Otherwise it will reduce the effective range.
2. The antenna should be perpendicular to the model. Larger models can have large metal objects that can attenuate the RF signal. In this case the antennas should be placed at sides of the model. Then the best RF signal condition is obtained at any attitude.
3. The antennas must be kept away from conductive materials, such as metal and carbon by at least a half inch. The coaxial part of the antennas does not need to follow these guidelines, but do not bend it in a small radius.
4. Keep the antennas away from the motor, ESC, and other noise sources as much as possible.



\*The main purpose of the photo demonstrates how the antenna should be placed. For actual installation the receiver must be wrapped with a sponge or placed with floating material to protect it from vibration.



The receiver contains precision electronic parts. It is the most delicate radio component on-board the model and should be protected from vibration, shock and temperature extremes. To protect the receiver, wrap it in R/C foam rubber or other vibration-absorbing material. If appropriate, waterproof the receiver by placing it in a plastic bag and closing the open end with a rubber band before wrapping it in foam. If moisture enters the receiver, intermittent operation or a failure may result. Wrapping the receiver in a plastic bag also protects it from fuel and exhaust residue which, in some models, can work its way into the model.

## STEERING TRIM(CH1)

Steering neutral adjustments can be made by moving the steering trim lever to the left or right.

When you install a servo, always check to be sure the servo is at its neutral position. Adjust the servo horn position and linkage so both are parallel. Be sure the steering trim on the transmitter is at the neutral position.

### Trim Operation And Maximum Travel

Changing the trim can affect the overall settings. When adjustments are made with the trims, recheck your installation for maximum travel. (Steering D/R at 100%)

### When Trim Usage Is Extreme

If it takes most of your trim movement to get a servo to the neutral position, reposition the servo horn on the servo and inspect your linkage installation.

#### Steering Trim Lever

L25 - 0 - R25



CH1

## THROTTLE TRIM(CH2)

Throttle neutral adjustments can be made by moving the throttle trim lever to the up or down.

When using an electronic speed control, set the throttle trim to neutral and make adjustment to the speed control. On a gas powered model, set the trim to neutral and adjust the linkage to the point where the carburetor is fully closed in accordance with the engine instruction manual.

### Trim Operation And Travel

Trim adjustments will affect the overall servo travel. Check the brake side (backward) movement when changes are made.

#### Throttle Trim Lever

F25  
0  
B25



CH2

### When Trim Movement Is Extreme

If you use most of the trim movement to get the servo to the neutral position, recenter the servo horn closer to the neutral position and inspect your throttle linkage.

## STEERING DUAL RATES(D/R-CH1)

Use this function to adjust the steering travel of your model. If the model understeers while cornering, add steering by pressing the lower side of the D/R button. When the model oversteers, take away steering by pressing the upper side of the D/R button.

#### Steering D/R Lever



## THROTTLE END POINT ADJUSTMENT(EPA-CH2)


This function is used to adjust the forward and brake side servo travel. Each direction can be adjusted independent of each other. Use this feature to set the throttle servo travel.



Be sure that your throttle linkage does not apply excessive force to the servo. If your linkage installation causes an unreasonable amount of force to be applied to the servo, the servo may be damaged and result in loss of control.

#### Throttle EPA

Backward Forward  
Range : 30 - 120%





## TRANSMITTER AND RECEIVER BINDING

The Binding function allows you to Bind the transmitter and receiver pair. When new, it is necessary to pair the transmitter and receiver to prevent interference from radio controllers operated by other users. This operation is referred to as 'binding'. Once the binding process is complete, the setting is remembered even when the transmitter and receiver are turned OFF. Therefore, this procedure usually only needs to be done once.




Before beginning the binding process, connect the switch harness, servos, and the receiver battery to your **MR-300** 3-Channel receiver, using the diagram on page 5. Make sure that both the transmitter and the receiver are turned OFF.

1) Turn the transmitter ON. The Power Indicator on the transmitter will illuminate solid red.

2) Press and hold the receiver setup button, then turn the power switch on the ON position. The receiver LED will flash quickly. Release the setup button after 1 second.



3) Press and hold the binding button on the transmitter for 1 second until the LED on the receiver is continuously lit.



When the binding process is successful, the Bind LED on the receiver will stay solid red when both the transmitter and receiver are turned ON. If the Bind LED on the receiver is flashing rapidly or not illuminated at all, the transmitter and receiver are not paired. In this case, turn both the transmitter and receiver OFF, then repeat the binding process.



Under some circumstances, the receiver may not operate after turning the transmitter and receiver ON. If this occurs, perform the binding process again.

## FAIL SAFE SETUP

Please note the setup must be based on pair procedure well.

1. Turn the power switch on the transmitter & receiver to the ON position, the LED on transmitter & receiver are continuously lit.

2. Move the steering wheel or throttle trigger to the position where you want the servo to move, press and hold the receiver setup button for 2 second until the red LED on the receiver flash slowly, then press and hold the receiver setup button again within 5 seconds (Note: after 5 seconds F/S setup will reset, you have to start over at step one above) until the receiver LED is continuously lit, that's mean the F/S function has been correctly set.

3. Verify if the failsafe function has been correctly set. Turn off the transmitter, then check if the servos moves to the position that you set.

4. Any new binding (pair procedure) will clear the preset Fail-Safe.