



iCade jr.

QUICKSTART GUIDE
ENGLISH

GUÍA DE INICIO RÁPIDO
ESPAÑOL

GUIDE D'UTILISATION RAPIDE
FRANÇAIS

GUIDA RAPIDA
ITALIANO

KURZANLEITUNG
DEUTSCH

SNELSTARTGIDS
NEDERLANDS

QUICKSTART GUIDE (ENGLISH)

BOX CONTENTS


Make sure that the items listed below are included in the box:

- iCade jr.
- 2 AA Batteries
- Quickstart Guide
- Safety Instructions & Warranty Information Booklet

READ SAFETY INSTRUCTION BOOKLET BEFORE USING THE PRODUCT

FRONT PANEL CONTROLS

1. **Power** - Turns iCade jr. on/off. This blinks when in pairing mode and stays lit solid when paired and powered.
2. **Cradle** - Holds iPhone®/iPod Touch® in portrait mode.
3. **Ledge** - Holds iPhone/iPod touch in landscape mode.
4. **Joystick** - Miniature removable four-way joystick and d-pad.
5. **Button Controls** - Miniature arcade-style buttons.




iPhone and iPod touch are trademarks of Apple, Inc., registered in the U.S.A. and other countries.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by ION Audio is under license. Other trademarks and trade names are those of their respective owners.


REAR PANEL

1. **Pairing Buttons** – Hold these buttons down for 5 seconds to pair with a Bluetooth device.



BOTTOM PANEL

1. **Charge Cable Pass-Through** - For your iPhone/iPod touch charging cable to pass through.
2. **Battery compartment** – Install 2 AA batteries here to power iCade jr.



DOWNLOAD APP

1. Open the App Store on your iPhone/iPod touch (not included).
2. Download any ION Arcade-compatible game. For a full list of ION Arcade compatible games, visit: www.ionaudio.com/icadegames.
3. Tap "Install App".
4. Follow **INITIAL SETUP** instructions below before launching app.

INITIAL SETUP

1. For portrait mode, place iPhone/iPod touch into the cradle so it fits securely. For landscape mode, place iPhone/iPod touch on iCade jr.'s ledge.
2. Turn iPhone/iPod touch on and go to **Settings > General > Bluetooth**.
3. Slide the Bluetooth slider to "**On**."
4. Hold down the 4 buttons on the rear panel simultaneously for 5 seconds or until iCade jr.'s Bluetooth light starts blinking, then release all four buttons.
5. iCade jr. will appear in iPhone/iPod touch as a Bluetooth device (not paired). Tap to select it.
6. iPhone/iPod touch will then show iCade jr. as "**Connected**."

GAME ON!

1. Launch the previously installed ION Arcade-compatible app.
2. Start gaming with the awesome iCade jr.!

PAIRING WITH OTHER BLUETOOTH DEVICES

1. Power on iCade jr.
2. Go to your phone's Bluetooth settings menu to turn on Bluetooth.
3. Hold down the 4 buttons on the rear panel of iCade jr. simultaneously on iCade jr. for 5 seconds or until iCade jr.'s Bluetooth light starts blinking, then release all four buttons.
4. Enable your phone to scan for Bluetooth devices.
5. iCade jr. will appear as "ION iCade jr." Select it to pair it with your Bluetooth device.

Notes:

- After a period of inactivity, iCade jr. will enter "power saver" mode. To wake it up, simply move any of its controls. Both iCade jr. and iPhone/iPod touch will turn on again.
- After iCade jr. is connected to iPhone/iPod touch as a Bluetooth device, you can remove iPhone/iPod touch, move it to another location, turn it off, etc. Next time you want to use iCade jr. with the same device, simply activate Bluetooth on your device, turn iCade jr. on, and press any button on iCade jr. iCade jr. will reconnect instantly with your device as long as it is within range.
- To use iCade jr. with a different iPhone/iPod touch, or to re-establish a manually deactivated Bluetooth connection, repeat the INITIAL SETUP steps.
- Avoid storing the unit in high temperature with the batteries installed.

For an up-to-date list of additional ION Arcade-compatible games, visit:

www.ionaudio.com/icadegames

www.ionaudio.com


MANUAL DRAFT 1.0

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all Instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachment/accessories specified by the manufacturer.
12. Use only the cart, stand, tripod, bracket or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Power Sources - This product should be connected to a power supply only of the type described in these operating instructions, or as marked on the unit.
16. Internal/External Voltage Selectors - Internal or external voltage selector switches, if any, should only be reset and re-equipped with a proper plug for alternative voltage by a qualified service technician. Do not attempt to alter this yourself.
17. Water and Moisture - This product should be kept away from direct contact with liquids. The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.
18. **CAUTION** – Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type. Batteries (a battery pack or an installed battery) shall not be exposed to excessive heat such as sunshine, fire, etc.
19. Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
20. Protective earthing terminal: The apparatus should be connected to a mains socket outlet with a protective earthing connection.
 - a. Finland (Suomi): Laite on liitettävä suojamaadoituskoskettimilla varustettuun pistorasiaan.
 - b. Norway (Norge): Apparatet må tilkoples jordet stikkontakt.
 - c. Sweden (Sverige): Apparaten skall anslutas till jordat uttag.
21. Do not install this equipment in a confined or "boxed-in" space such as a bookcase or similar unit, and maintain good ventilation conditions. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, tablecloths, curtains, etc.
22. This apparatus is for professional use only.
23. When moving or not using the appliance, secure the power cord (e.g., wrap it with a cable tie). Be careful not to damage the power cord. Before using it again, make sure the power cord has not been damaged. If the power cord has been damaged at all, bring the unit and cord to a qualified service technician for repair or replacement as specified by the manufacturer.
24. Do not place any open or exposed flame sources (such as lighted candles) on the apparatus.
25. When disposing of the battery, follow the laws and environmental regulations of your region.
26. **WARNING:** Excessive sound pressure (high volumes) from headphones can cause hearing loss.
27. **WARNING:** Please refer to any important information (e.g., electrical, safety, etc.) printed on the exterior bottom enclosure or rear panel before installing or operating the product.



SERVICE INSTRUCTIONS

- Disconnect power cord before servicing.
- Replace critical components  only with factory parts or recommended equivalents.
- For AC line powered units – Before returning repaired unit to user, use an ohmmeter to measure from both AC plug blades to all exposed metal parts. The resistance should be more than 2,000,000 ohms.

SAFETY NOTICES

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE ANY COVER. NO USER- SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL ONLY.



DANGEROUS VOLTAGE: The lightning flash with arrowhead symbol within the equilateral triangle is intended to alert the user to the presence of un-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



SA 1965

INSTRUCTIONS: The exclamation point within the equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying this appliance.



SA 1966

WARNING: To reduce the risk of fire or electrical shock, do not expose this appliance to rain or moisture. Electrical equipment should NEVER be kept or stored in damp environments.

CAUTION (for U.S.A. & CANADIAN models only): TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

NOTICE CONCERNING LASER PRODUCTS: DANGER: INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCK FAILED OR DEFEATED. AVOID DIRECT EXPOSURE TO BEAM. USE OF CONTROLS OR ADJUSTMENTS OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

NOTICE CONCERNING FCC REGULATIONS:

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Move this unit.
- Increase the separation between the equipment and receiver.
- Plug this unit into a different outlet so that it is on a different circuit from the other equipment.
- Be sure that all cables are properly shielded, using a choke or ferrite where appropriate.
- Consult the dealer or an experienced radio/television technician for help.

FCC ID: Y40-ICG10: THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.



ESD / EFT Warning: This unit may contain a microcomputer for signal processing and control functions. In very rare situations, severe interference, noise from an external source, or static electricity may cause it to lock up. In the unlikely event that this should happen, turn off the unit, wait at least five seconds, and then turn it back on again.

In an environment with radio frequency interference, the unit may malfunction and resume normal operation after removal of the interference.

For best audio quality, avoid using this device in a high RF-radiated environment.


This unit does not exceed the Class B limits for radio noise emission from digital apparatus set out in the radio interference regulations of the Canadian Department of Communications.

For 240-volt use in U.K., use NEMA-style 240-volt plug. For other countries use proper plug for local outlet.

DOUBLE INSULATED – When servicing use only identical replacement parts.

Correct Disposal of this product:

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



VERY IMPORTANT:

- Do not use excessively long cables (i.e. over 32ft/10m).
- Under rare circumstances, if this product is exposed to electromagnetic interference during use, there may be a slight drop in signal-to-noise ratio.
- Intended electromagnetic environments: residential, commercial, light industrial, urban outdoors.