


LED POWER BASS  
Portable Bluetooth Stereo Speaker



- FEATURES:
1. Increase Light Brightness
  2. LED mode
  3. Decrease Light Brightness
  4. Bluetooth LED indicator light
  5. Charging LED indicator light
  6. Next Long Press Volume +
  7. Play / Pause / Power / End Call
  8. Previous Long Press Volume -
  9. Microphone

1

Thank you for purchasing the Hype LED Power Bass Bluetooth® Stereo Speaker. Please read all instructions carefully before using and retain this manual for future use and reference.

**PACKAGE CONTENTS**

- LED Power Bass Portable Bluetooth® Stereo Speaker
- Different 3.5mm Aux Cable
- Micro USB Charging Cable
- Operation Manual

**KEY FEATURES**

- Color Changing LED light
- Compatible with most Bluetooth® enabled devices
- Light weight and portable design
- Great for travel

**SAFETY INSTRUCTIONS**

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Report to electrical equipment should only be performed by a qualified technician. Improper repair may place the user at risk of serious loss.

Do not puncture or harm the exterior surface of the product in any way.

Keep the unit free from dust, dirt, etc.

Do not use this unit for anything other than its intended use or purpose. Doing so may damage the device.

This product is not a toy. Keep out of reach of children.

Do not use the unit or excessive levels as this may damage hearing.

2

Do not expose batteries, battery pack, or batteries to indirect or excessive heat, such as direct sunlight, or open flame.

**CHARGING THE SPEAKERS**

The speaker comes with built-in rechargeable battery, before using it for the first time, we recommend you charge the battery. Use only with the supplied USB cable to charge the speaker.

Connect the USB cable to a computer USB port and the USB plug to the charging jack of the speaker. The red LED light will illuminate while the speaker is charging.

A full charge of the battery takes around 2-3.5 hours. When the battery is fully charged the red LED charging indicator light will turn off. At this point, disconnect the speaker. The speaker will then be ready for use.

**SPEAKER OPERATION**

1. Connect one end of a micro USB cable (included) to your computer or a compatible USB AC/DC Adapter (not included) & the other end of the micro USB cable to the speaker. For portable use, insert 3 AA-size batteries (not included) into the battery compartment located on the back of the device.
2. Switch the device to the "ON" position. The green power indicator light of the back will come on.
3. Plug the audio cord into the audio playing device.
4. Press the power button on the speaker.
5. Adjust the volume control on the audio playing device as needed.

**TUNING SPEAKERS ON/OFF**

Power On: Switch the power button to the "ON" position.

Power Off: Switch the power button to the "OFF" position.

**PAIRING THE SPEAKERS**

1. Turn on the power switch, until the red and blue LED light begins flashing. This indicates the speaker has entered pairing mode.
2. Ensure that Bluetooth is enabled on your device or tablet. Search for "HYPERBASS" to find your speaker. You will hear a beeping register to indicate that the pairing is successful.

3

3. If your speaker is connected to your mobile phone, you can answer calls while you are playing music. The music will pause during your call and resume after you end the call. To stop, use the Play/Pause button.

4. When connected using the 3.5mm cable, you can do this through your phone or tablet.

5. To adjust the LED light patterns, click the LED light mode button located on the side of the speaker to the desired setting.

6. To adjust LED brightness, also use the buttons located on the side of the speaker until you reach your desired brightness.

**LISTENING TO MUSIC**

Once the speaker is paired to your device, you can stream music wirelessly to the speaker. Select the track you wish to listen to on your device to listen via speaker. Should you encounter any problems while streaming, please refer to your device's user manual.

**BATTERY MAINTENANCE**

1. In order to protect battery life, turn off your speaker when it is not in use.
2. If the speaker is not used for a long period of time, store it in a dry, safe location. The speaker will need to be charged every 2 months to maintain battery life.

**CARE AND MAINTENANCE**

- Do not expose the unit to liquid, moisture, humidity to avoid damage to the product's internal circuitry.
- Do not use abrasive cleaning solvents to clean the unit.
- Do not expose the unit to extremely high or low temperatures.
- Do not dispose of the unit in fire as it may explode or combust.
- Do not expose the unit to contact with sharp objects as this will cause scratches and damage.
- Do not let the unit fall from high places, as doing so may damage the internal circuitry.
- Do not attempt to disassemble the unit.

4

In the event that the unit does not function properly, return to the store where it was purchased.

**SPECIFICATIONS**

Bluetooth® Specification: V1.0 HDM  
Bluetooth® Communication Range: More than 10M  
Frequency Range: 2.400GHz-2.480GHz  
Speaker Output: 8W/2.2W/2W  
Speaker Power: 30W/2  
Signal And Noise Ratio of power amplifier: 10:1dB  
3.5mm Audio Input  
Built-in rechargeable battery: 3.7V 1800MAH  
Charging voltage: 5V  
Charging time: 4-6 H  
Charging method: MICRO USB CABLE  
Standby current: 30-40MAH  
Working current: 30-500MAH  
Play time with lights: Up to 5 hours  
Play time without lights: Up to 8 hours  
Product size: 180X70X50MM

**FCC Compliance Statement**

The device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. The device may not cause harmful interference, and
2. The device must accept any interference received, including interference that may cause undesired operation.

5

**TROUBLESHOOTING**

Please refer to the below frequently asked questions to see if these basic troubleshooting tips help solve your problems.

I can't pair the Bluetooth Speaker with my Bluetooth device, but cannot hear any music.

Make sure your device supports the A2DP mode.

I cannot get the Bluetooth Speaker into pairing mode.

Make sure the Bluetooth Speaker is turned off before beginning the pairing process. Slide the power switch to the On position and wait for the LED light to flash blue at least 5 seconds. Quickly press the MODE button after this, and the LED light will alternate between red and blue.

My mobile phone is not able to pair with the Bluetooth Speaker.

Make sure that you fully charged the speaker before use. Keep your Bluetooth speaker and mobile phone within 3 feet of each other during the pairing process. Check that your phone's Bluetooth is enabled. By repeating the pairing process.

**MAINTENANCE**

Power this product off when not in use.

DO NOT expose this product to water or liquid.

DO NOT use abrasive cleaning solvents to clean this speaker. Clean with a dry cloth if necessary.

If you are not using the speaker for a long period of time, store it in a dry, safe location. Charge the speaker every 2 months when in storage to maintain battery life.

6

**WARRANTY INFORMATION**

The condition of the warranty and our responsibilities under this warranty are as follows:

Supplier's warranty is non-transferable. And the warranty is limited to the original purchaser only.

\* You must be able to prove the date of original purchase of the unit with a dated receipt.

\* The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or misuse and/or misused third party.

\* The responsibility of a supplier is limited to the replacement of a defective product and is not limited to the repair or replacement of the product as its sole duty.

\* Specifically exempt from any warranty are limited liability consumable components subject to normal wear and tear such as batteries, decoders and other accessories.

\* A supplier will not be responsible for the value of the unit if it has resulted from accident, abuse, misuse, or any unauthorized repair, modification or alteration.

\* Modification and reuse of the unit should be done by authorized and qualified service personnel. Center or returned to the manufacturer.

\* The warranty gives you specific legal rights, and you may also have other rights which vary under local laws.

The following conditions comprise the requirements and scope of our warranty conditions and do not affect our legal and contractual warranty obligations. We offer a warranty on our products in accordance with the following conditions:

- 1) Hype™ products are covered by a 12 month warranty. We will replace damaged or defective Hype™ products free of charge within 12 months of the purchase date under the following warranty conditions: for any damage or defect determined later than 12 months after the purchase date, proof of a manufacturing fault must be admitted for repair under warranty.
- 2) The warranty does not cover batteries and other parts which are considered consumables, parts that break easily such as glass or plastic or defects based

7

on normal wear and tear. There is no warranty obligation in the event of marginal differences compared to the target appearance and workmanship. Also provided these have no negative effect on the product's fitness for use. In the event of damage caused by chemical or electrochemical effects, by water or generally from abnormal conditions.

3) The warranty will be performed in such a way that we will not decide whether to repair the defective part or to replace them with working parts free of charge.

4) Hype™ reserves the right to exchange the product for a replacement product of equal value if the product sent in cannot be repaired within a reasonable time or if a reasonable cost. Requests cannot be made for repair to be carried out on site. Parts that have been replaced or exchanged become our property.

5) The warranty claim does not apply if repairs or other work is carried out by unauthorized persons or if our products are equipped with additional parts or accessories that are not approved for our product.

6) Warranties that have been activated do not cause the warranty period to be extended, nor do they trigger a new warranty period. The warranty period for any replacement parts included ends with the warranty period for the entire product.

7) Any other further claims are excluded, especially those for reimbursement due to damage caused to the outside of the product, provided there is no obligatory legal liability. We therefore accept no liability for accidents, indirect or other consequential damage of any kind, which leads to usage restrictions, claim loss and loss of earnings or interruption to business.

**Returning a warranty claim**

1) To make use of the warranty service for hardware issues, you must contact the Hype™ Service Center by email at [support@hype.com](mailto:support@hype.com).

2) Hype™ will try to diagnose and solve your problem. If it is determined that a warranty claim exists, you will be given an RMA number (Return Material Authorization) and will be asked to send the product to Hype™.

3) The warranty does not cover batteries and other parts which are considered consumables, parts that break easily such as glass or plastic or defects based

8

Please observe the following when sending the product:

- 1) Send the product suitably packaged with cartage and insurance paid. Do not enclose any accessories with the product (cables, chargers, manuals, etc.) unless the Hype™ Service Center specifies otherwise.
- 2) Make the RMA number on the outside of the package it such a way that it is visible and clearly legible.
- 3) You must include a copy of the sales slip as proof of purchase.
- 4) Check Hype™ has received the product. It will meet its warranty obligations in accordance with the warranty conditions and will return the product to the sender with cartage and insurance paid.

**Service outside of warranty**

Hype™ can refuse any service claim made that is not covered by the warranty.

If Hype™ agrees to provide a service outside the warranty, the customer will be involved for all repair and transport costs. Hype™ will not accept any packages that have not first been approved by Hype™ (by means of an RMA Return Material Authorization).

**RCE STATEMENT**

The equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. The equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

9

Re-orient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Do not attempt to repair or modify this equipment.

**WARNING:** Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment and invalidate the warranty claim.

10