

# **Touch Book 7.0 3G**

## **User's Manual**

# Contents

1 Safety Precautions .....	3
2 Overview .....	4
3 Charging .....	4
4 Inserting a Memory Card .....	5
5 Power on / Power off .....	6
6 Android Home Screen Guides .....	7
7 Changing OSD Language & System Time.....	8
8 Connecting to Wi-Fi.....	9
9 Connecting to Hotspot.....	8
10 Transferring Contents from PC .....	9
11 Troubleshooting.....	9

## Notice


The device' pictures, as well as data on the device' appearance, color and design features found in the manual are for reference only. We reserve the right to change the appearance and technical parameters of the product without prior notice.

# 1 Safety Precautions

- Keep the device away from extreme heat, cold, moisture and dust.
- Do not spill any liquids on the device as it may damage the device or cause a fire.
- Do not use liquids and chemical cleaners for cleaning the device.
- Do not insert any objects into the device, or it may result in short circuit or it might damage the circuit.
- Do not keep the device near magnetic sources, heaters, microwave ovens, heating up kitchen appliances, or in high pressure containers, as it may cause the battery leaking, the device overheating and inflammation.
- Power off the device if you want to install or remove some external devices which do not support hot-plug. Do not disassemble the device. Only a certified service technician should perform repairs on your device.
- Use only the AC adapters, power cords and batteries that are approved for use with this device. Use of another type of battery or AC adapter may cause fire or explosion.
- To prevent possible hearing damage, do not listen at high volume levels for long periods. another type of battery or AC adapter may cause fire or explosion.



## 2 Overview



### **3 Charging**

- Plug the DC end of adapter to the power jack or USB port (if there is no power jack) of the device and plug the AC end to the wall socket for charging.
- Normally it takes approximately 5 hours to fully charge the device. Operating the device during charging with the AC adapter may extend the time of full charging.
- The adapter shall be installed near the equipment and shall be easily accessible.

### **4 Inserting a Memory Card**

- The device supports micro SD/SDHC cards.
- To insert a micro SD card, place the card connector towards the front side of the device and the printing side of the card towards the rear side of the device.
- To remove the micro SD card, gently press the edge of the card to release the safety lock and pull the card out of the slot.

#### **Notice**

Don't remove the micro SD card while viewing the file inside, or the device could fail to operate correctly.

## 5 Power on / Power off

- 1) To turn on the device, press and hold the **Power** button until you see the start-up screen then release, it will automatically enter the Home screen. If it is the first time to use it, it will enter set-up guide menu. Please follow the on-screen instructions.
- 2) Press the **Power** button once to enter sleep mode and press it again to open the device.
- 3) Press and hold the **Power** button, and then tap on **OK** to power off the device.

### Notice

If the system halts, press and hold the **Power** button until it is turned off completely.

## 6 Android Home Screen Guides

**Status Bar:** Slide down to see more.


Web Information search

**Status Bar:** Slide down to open quick settings menu.



**Shortcuts:** touch to open; touch&hold to move.

: tap to enter Home screen.

: tap to return to the previous page.

: tap to open recent APPs list menu.


: tap to enter APPs Menu.

### Home Screen

Your Home screen is the starting point to access all of

the tablet's features. The Home screen can have multiple panels. To view other panels, slide left or right.

### **Add an app icon to home screen**

On the Home screen, tap  to open APPs list menu, tap and hold an application icon, and then drag it into a panel preview.


### **Set wallpaper**

Tap and hold the blank area on the Home screen. Tap

**WALLPAPERS** and select one of the following: **Black Hole**, **Bubbles**, **Holo Spiral**, **Magic Smoke**, **Nexus**, **Phase Beam**, **Spectrum**, **Water**, **Vedio Wallpaper**.

Select an image and tap **SET WALLPAPER**.

## **7 Changing OSD Language & System Time**


On the home screen tap  and select **Settings** icon to access the list of options.

- Select **Settings---Language & input---Language** to change OSD language.




- Select **Settings---Date & time** to change system time.


## 8 Connecting to Wi-Fi

- On the home screen tap  and select **Settings** icon to access the list of options. Select **Wi-Fi**.
- If the Wi-Fi is off, tap on the Wi-Fi line to turn it on.
- The device will scan for available Wi-Fi networks and display them on the screen.
- Tap on the network you want to connect to. Then tap on the wireless password field to enter the required network information and tap on **Enter---Connect**.
- Your device will now attempt to establish a connection to the Wi-Fi access point with the network parameters you entered.

## 9 Connecting to Hotspot

- On the home screen tap  and select **Settings** icon to access the list of options. Select **More** to enter the list of option and tap **Tethering & Portable hotspot**.
- If the **Wi-Fi hotspot** is off, tap on the Wi-Fi hotspot line to turn it on and then external devices can share the network that you're using now.

## 10 Transferring Contents from PC

- Connect the device to your PC/Notebook via USB cable.
- Select the contents you want to transfer from your PC/Notebook.
- Drag the contents from the PC/Notebook to the device.
- Please do not disconnect the USB cable during loading. It may cause malfunction of the device and files. Left click on  to disconnect the device from PC/Notebook safely.

## 11 Troubleshooting

Q1: What if water enters the device?

A:

- 1) DO NOT turn on the device.
- 2) Disconnect the outlet cable in order to turn it off instead of pressing the power button. Disconnect all external devices and then send to the service center for advice.

Q2: How to check the device if it won't turn on?

A:

- If the power is low, connect the adapter to charge.
- Remove the micro-SD card and any other external device.

Q3: How to restore the factory default settings?

A: Go to **Settings---Backup & reset---Factory data reset** to recover the system to the default status.

Q4: How to prolong the usage time of the battery?

A:

- Adjust the brightness of the touch screen to proper level on **Settings---Display---Brightness** menu.
- Turn down the volume.
- Set the sleep time to proper level on **Settings---Display---Sleep** menu.

Q5: What to do if the SD card can't be read?

A: Please turn off the device and re-insert the card.

Q6: Why are the Bluetooth and 3G function disabled?  
(Applicable only for model with Bluetooth and 3G function)

A: Check if the "Airplane mode" is enabled, if it is then the Bluetooth and 3G function can't be activated.

## **FCC Regulations**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined

by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **FCC RF Exposure Information (SAR)**

This device is designed and manufactured not to exceed the emission limits for exposure to radio

frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 0 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg.

Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of [www.fcc.gov/oet/ea/fccid](http://www.fcc.gov/oet/ea/fccid) after searching on: FCC ID: YHLBLUTB703G

For this device, the highest reported SAR value for usage against the head is 0.32 W/kg, for usage near the body is 1.51 W/kg.