

EDIFIER

W330NB

Active Noise Cancelling Neckband Bluetooth Earbuds

Operating Instructions

EDIFIER International Limited  
www.edifier.com  
© 2018 Edifier International Limited. All rights reserved.  
Printed in China

NOTICE:  
For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.  
Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. Picture for reference only, actual product prevails.

Ver1.0 IB-200-W0330N-00

Before using the headphone, please carefully read this user manual and keep securely for further reference.

■ Features

- Fashionable neckband Bluetooth earphones
- High-efficiency 13mm driver unit
- Active noise cancelling (ANC) technology to minimize noise
- Bluetooth V4.2 with CSR technology
- In-ear design with soft neckband
- 8 hours of continuous audio playback
- Three-buttons operation to control call/volume/music switch

■ Specifications

Bluetooth version: Bluetooth V4.2  
Bluetooth profiles: HFP, HSP, A2DP, AVRCP  
Bluetooth distance: 10m  
Playback time: Up to 8 hours  
Charging time: About 2 hours  
Input: 5.0V/≈500mA  
Frequency response: 20Hz-20KHz  
Sensitivity: 100dB  
Impedance: 32Ω  
Driver unit: Φ13mm

Note:

- Playback time and charging time will be varied by playing environment, volume and audio sources.
- The design and specifications may be changed without prior notice in order to make improvements.

1

■ Box contents

Headphone x 1 PCS

USB charging cable x 1 PCS

Storage bag x 1PCS

User manual x 1 PCS

Silicone earmuffs x 3 Pairs

■ Operational instructions

1. Volume/previous track  
2. Volume/next track  
3. Multifunction button  
4. Noise cancelling ON/OFF  
5. MicroUSB charging port  
6. Indicator

■ How to wear

- Headphone cable downward, wear the neckband from the back of the neck;
- Place the earbuds into the ear properly and adjust to a comfortable angle.

2

■ How to operate

I. Charging

During using, if red indicator instead of blue indicator is lit, it indicates low battery level and please use it after fully charged.

- Insert USB charging cable into USB port of standard power source.
- Connect USB charging cable to microUSB charging port on the headphone.

Red light steady lit = charging      Red light off = fully charged

- Charging time: about 2 hours for a full charging

Warning: To avoid battery life shortage, it is recommended to fully charge the headphone before the first time use; and if not used for long periods of time, please at least charge the headphone once per three months.

Warning: The rechargeable batteries that provide power for this product must be disposed properly for recycling. Do not dispose of batteries in fire to prevent an explosion.

Function	Operation	Indicator
Power ON	Press and hold the multifunction button for 3 seconds	Blue light constantly lit for 3 seconds
Power OFF	Press and hold the multifunction button for 3 seconds	Red light constantly lit for 3 seconds
Turn on noise cancelling	Slide toggle switch to "green"	/
Turn off noise cancelling	Slide toggle switch to "black"	/

3

III. Pairing

- Please follow the steps below to let the headphone enter pairing mode:

Function	Operation	Indicator
Enter pairing mode	When turned off, press and hold the multifunction button for about 5 seconds; in standby, press and hold the multifunction button for about 5 seconds.	Red and blue light flash alternately

- Set your Bluetooth headphone to search for and pair with "EDIFIER W330NB", wait until hearing a prompt tone and the blue light will flash slowly, then the pairing is successful.

Note:

- It will exit pairing mode if fail to pair within 2 minutes, and the headphone will auto-turn off if not connected within 5 minutes after timeout.
- Pin code for connection is "0000" if needed.
- After pairing is complete, the headphone and mobile phone will remember each other, and the headphone will auto-connect to the last connected device when used next time;

Connect two Bluetooth devices simultaneously

- Pair the headphone with the first device.
- Turn off the headphone, then press and hold the multifunction button to let the headphone enter pairing status, and pair with the second device.
- Then operate the first device to select "EDIFIER W330NB", and it completes to connect two Bluetooth devices simultaneously.

IV. Calling

Basic call operation

Function	Headphone status	Operation
Answer incoming call	Incoming call ringing	Press the multifunction button
Reject incoming call	Incoming call ringing	Press and hold the multifunction button for about 1.5 seconds
Hang up call	Talking	Press the multifunction button
Turn on voice assistant	Connected to device	Double press the multifunction button
Turn off voice assistant	Voice assistant is on	Double press the multifunction button

4

V. Play music

Function	Headphone status	Operation
Increase volume	Play music	Press "+" button
Decrease volume	Play music	Press "-" button
Previous track	Play music	Press and hold "-" button
Next track	Play music	Press and hold "+" button
Pause playing	Play music	Press the multifunction button
Resume playing	Pause playing	Press the multifunction button

VI. Restore to factory settings

During charging, press and hold "+" button and multifunction button simultaneously for 3 second until blue light blinks rapidly, then the headphones have restored to factory settings.

Note:

After factory settings are restored, pairing list of the headphone will be cleared. When powered on again, the headphone will auto-enter pairing mode and will not connect automatically, if needs to connect with certain device, please re-pair it with the headphone.

5

■ Maintenance

During using, please read the following advices carefully to help you comply with warranty terms and extend the product's service life.

- Keep the product away from humid places to avoid affecting internal circuit.
- Do not put the product in places exposed to sun or with high temperature. High temperature will shorten service life of electronic components, damage battery and deform plastic components.
- Do not put the product in cold places to avoid damaging internal circuit board.
- Do not dismantle the product. Non-professional personnel may damage the product.
- Do not drop, strongly vibrate, strike the product with hard object to avoid damaging internal circuit.
- Do not use drastic chemicals or cleaner to clean the product.
- Do not use sharp objects to scratch product surface to avoid damaging shell and affecting looking.

If the product cannot operate properly, please send it to your qualified maintenance agency for repair.

6

■ FAQs

Red light instead of blue light flashes.

- It indicates the headphone is in low battery level, please recharge the headphone.

Red light is off during charging.

- Please ensure the charging device is correctly connected with the headphone.
- When the headphone is not used for long periods of time, the battery will enter sleep state. It needs to charge about 30 minutes and then the orange light will be lit.

No sound heard from the headphone.

- Check if the headphone volume is at an appropriate level.
- Check if the headphone is correctly connected with mobile phone.
- Check if the headphone is operated within normal working range.

The headphone calling effect is bad.

- Check if mobile phone is in an area with strong signal.
- Please ensure the headphone is within effective distance (10m ) and no obstacle between the headphone and mobile phone.

7

CAUTION

Danger of explosion if battery is incorrectly replaced.  
Replace only with the same or equivalent type.

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

1. "To prevent possible hearing damage, do not listen at high volume levels for long periods."

2. "Fully understand user manual before use."

3. "Ensure your player at low volume levels or power off before you leaving"

8

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

ID Peringatan!

Untuk menjamin keselamatan diri Anda, jangan memakai atau menyimpan earphone di sekitar (dekat dari 10 cm) alat pacu jantung.

Jangan masukkan steker ke stopkontak listrik.

Awasi anak-anak saat menggunakan peralatan, produk ini bukan mainan.

Mendengarkan earphone pada tingkat volume tinggi – khususnya, selama waktu yang lama – dapat merusak pendengaran Anda.

Penggunaan sakelar pada sistem hi-fi Anda, atau penyumbatan pada earphone dapat menimbulkan klik yang pada pengaturan volume tinggi dapat memengaruhi pendengaran Anda.

Karena itu, selalu mengatur kontrol volume paling rendah sebelum beralih di antara berbagai sumber (penala, pemutar piringan hitam, pemutar CD, dll) atau penyumbatan pada earphone.

Untuk keselamatan lalu lintas, jangan gunakan earphone selama mengemudi atau berkendara.

14

NL Waarschuwing!

Om uw persoonlijke veiligheid te garanderen, dient de koptelefoon niet te worden bewaard of gedragen in de buurt van (minder dan 10 cm) een pacemaker. Steek de stekker in een stopcontact.

Houd toezicht op kinderen tijdens het gebruik van het apparaat; dit product is geen speelgoed.

Luisteren met de koptelefoon op hoog volume – met name gedurende een langere periode – kan leiden tot schade aan uw gehoor.

De bediening van de schakelaars op uw hifysysteem of het insteken van uw koptelefoon kan leiden tot harde klikgeluiden wat uw gehoor kan aantasten.

Om deze reden dient de volumeknop altijd op een minimum te worden geschakeld, voordat er tussen de verschillende bronnen (tuner, draaitafel, cd-speler, enz.) wordt geschakeld of de koptelefoon wordt aangesloten.

Met het oog op verkeersveiligheid dient de koptelefoon niet te worden gebruikt tijdens het rijden of fietsen.

15

KR 경고!

안전상의 이유로,이 헤드폰은 심장박동 조절장치 근처 (10cm 이내)에 두어서는 안됩니다.

캐 플러그를 전류가 흐르는 소켓에 삽입하지 마십시오.

어린이가 헤드폰을 사용할 때는 보호자의 주의 깊은 관찰이 필요합니다.이 제품은 장난감이 아닙니다.

헤드폰을 높은 볼륨상태에서 특히 장기간 사용할 경우 청각에 해가 될수 있습니다.

하이파이 오디오 시스템상에서 스위치를 바꾸거나 헤드폰을 하이파이 오디오 시스템에 연결할 경우,높은 볼륨상 태에서는 장악에 해를 줄수 있는 클릭소리가 날수 있습니다.그리므로 하이파이 오디오 시스템상의 한 소스기기에 서 다른 소스기기(라디오,레코드 플레이어,CD-플레이어...)를 선택하거나 헤드폰을 연결시킬 경우에는 항상 볼륨을 최저상태로 조정해 놓으십시오.

여러분의 운전상태와 다른 운전자들의 안전을 보호하기 위해 운전 중이거나 운전거를 타고 이동할 시에는 헤드폰 착용을 삼가 해 주십시오.

16

DE Sicherheitshinweis!

Um Ihre persönliche Sicherheit zu garantieren, achten Sie bitte darauf, dass dieser Kopfhörer nicht in nächster Nähe (näher als 10cm) zu Ihrem Herzschrittmacher getragen oder aufbewahrt wird.

Klinkenstecker nicht in stromführende Buchsen einführen.

Beaufsichtigen Sie Ihre Kinder bei der Benutzung des Geräts. Das Produkt ist kein Spielzeug.

Die Verwendung von Kopfhörern kann bei großer Lautstärke – vor allem im Dauerbetrieb – zur Schädigung des Gehörs führen.

Bei Umschaltvorgängen an Ihrer HiFi-Anlage oder bei Anschluss des Kopfhörers an die Anlage können knackgeräusche auftreten, die bei hoher Lautstärke das Gehör beeinträchtigen. Drehen Sie daher den Lautstärkeknopf immer auf Minimum, wenn Sie an Ihrer HiFi-Anlage zwischen verschiedenen Quellen (Radio, Plattenspieler, CD-Player...) wählen oder den Kopfhörer anschließen.

Um Ihre Fahrtüchtigkeit und die Sicherheit anderer Verkehrsteilnehmer nicht zu gefährden, verwenden Sie Kopfhörer keinesfalls beim Lenken eines Kfz oder beim Radfahren.

17

ES ¡Atención!

Por su propia seguridad, procure no llevar ni guardar estos auriculares muy cerca de su marcapasos (a menos de 10cm).

No introducir el conector Jack en los casquillos conductores de corriente.

Vigile a sus hijos al utilizar el equipo. Este producto no es un juguete.

La utilización de auriculares a un volumen muy alto – sobre todo al utilizarlos durante largos periodos – puede conducir al deterioro del oído.

Al operar los interruptores de su sistema HiFi o al conectar los auriculares al sistema puede hacer clic, lo que a un volumen muy alto puede deteriorar el oído. Por lo tanto disminuya el nivel de volumen al mínimo al seleccionar entre diferentes fuentes (radio, tocadiscos, reproductor de CD ...) en su sistema HiFi o al conectar los auriculares.

Para no poner en peligro ni su capacidad de conducir, ni la seguridad de otros usuarios de la vía pública, no utilice en ningún caso sus auriculares al conducir un vehículo o al andar en bicicleta.

18

RU Предупреждение!

В целях гарантии вашей безопасности просим не надевать и не держать наушники вблизи (ближе 10 см) кардиостимулятора.

Запрещается вставлять штекер в электрические розетки.

При использовании прибора присматривайте за детьми, так как это оборудование не является игрушкой.

Прослушивание музыки через наушники на высокой громкости, особенно длительное время, может навредить вашему слуховому аппарату.

Включение и выключение переключателей на высококачественной системе воспроизведения или подключение наушников может привести к возникновению щелчков, которые на высокой громкости могут нанести вред вашему слуховому аппарату.

Таким образом, всегда устанавливайте громкость на минимальный уровень, прежде чем производить переключение между различными источниками (тuner, диск проигрывателя, CD-проигрыватель и т.д.) или подключать наушники в систему.

Для безопасности дорожного движения не используйте наушники во время езды на велосипеде и вождения автомобиля.

19

SA تحذير

لضمان سلامتك الشخصية، يرجى عدم ارتداء سماعات الرأس أو الاحتفاظ بها بالقرب من (أقرب من 10 سم) جهاز تنظيم ضربات القلب.

لا تدخل الفايث في مأخذ أريائية.

احرص على الإشراف على الأطفال عند استخدام الجهاز، فالمنتج ليس لعبة.

الاستماع من خلال سماعات الأذن عند مستويات الصوت العالية، خاصة على مدى فترات طويلة، قد يضر بسمعك.

تشغيل المفتاح في نظام واي فاي الخاص بك أو إدخال سماعات الرأس قد يسبب نفرات والتي قد تؤثر على سمعك في مستويات الصوت العالية.

لذلك، قم دائما ب ضبط زر التحكم في مستوى الصوت على الحد الأدنى قبل التبديل بين المصادر المختلفة (مؤلف، قرص دوار، مشغل أقراص ممجمة، إلخ) أو عند توصيل سماعات الرأس من أجل السلامة المرورية، لا تستخدم سماعات الرأس أثناء

20

JP 安全指摘事項!

安全のために、このヘッドフォンス・メカの近く(10cm以内)で 使用または保管することは避けてください。

差し込プラグをコンセントに差し込まないようにしてください。

お子様が使用になる場合は、必ず大人が付き添ってください。本製品は玩具ではありません。

大きな音量のヘッドフォンの使用は、特に長時間使用する場合において聴覚障害の原因となる恐れがあります。

Hifi機器の切り替え時、あるいは機器にヘッドフォンを接続する際に、音量が大きい場合にはガリガリという騒音が発生し、聴覚に悪影響を与える恐れがあります。Hifi機器で各ソース(ラジオ、レコードプレーヤー、CDプレーヤー...)を選ぶ際、あるいはヘッドフォンを接続する際には、音量のつまみを常に最少にしてください。

安全なドライブ、そして他の運転手の安全のためにも、お車を運転する場合、あるいは自転車に乗る場合にはヘッドフォンは絶対に使用しないでください。

21

PL Ostrzeżenie!

Aby zapewnić sobie bezpieczeństwo, nie należy nosić ani trzymać słuchawek w pobliżu (w odległości mniejszej niż 10cm) od rozrusznika serca.

Nie wkładaj wtyczki do gniazdek elektrycznych.

Nadzorować dzieci podczas korzystania ze sprzętu, produkt to nie zabawka.

Słuchanie w słuchawkach przy wysokich poziomach głośności, szczególnie przez długie okresy czasu, może spowodować uszkodzenie słuchu.

Dlatego należy zawsze ustawiać głośność na minimalnym poziomie przed przełączaniem między różnymi źródłami dźwięku (tunerem, gramofonem, odtwarzaczem CD itp.) lub podłączeniem słuchawek.

Dla zachowania bezpieczeństwa s stwa jazdy nie należy używać słuchawek podczas prowadzenia samochodu czy jazdy na rowerze.

22