

## USER MANUAL

- 1、 Use on AC 120-277V, 50-60Hz, never use on  $\pm 5\%$  or other voltage.
- 2、 Environment temperature  $-10\sim +50^{\circ}\text{C}$ , Installation site should not be corrosive, flammable, easy violent gas and severe vibration environment.
- 3、 See the labels of the products installed void take the line to prevent errors and configuration to control damage to the device with the ballast.
- 4、 Never use for no waterproof device outdoor environment.
- 5、 Never used with dimmer and frequent on and off.
- 6、 Prohibited in the rain, completely sealed, insulated vessels in use.
- 7、 Never disassemble or modify-any changes could void the user's authority to operate this device.
- 8、 This product could produce interference when used near a TV, Radio, Wireless remote control or maritime safety communications equipment or other critical navigation or communication equipment operating between 0.45-30MHz. Of interference should occur, move the lamp away from the appliance a distance of three feet or more, Or, Plug the ballast or the appliance into a different outlet.
- 9、 Warning: This device complies with Part 18 of FCC rules.