

Voicelok™ User Guide



ACCESSING SETUP MODE FOR THE FIRST TIME

Insert Voicelok into computer
Press trigger to activate color code input
Voicelok will flash both LEDs rapidly for 1 second
LEDs will cycle through RED/GREEN/RED+GREEN pattern
Enter RED/RED/RED/RED/RED (press trigger when RED LED cycles through)
Both LEDs will flash rapidly for 2 seconds; press trigger DURING flashing to enter SETUP mode

WHILE IN SETUP MODE— Training Voice Password

Red LED will flash regularly to indicate Voicelok in Voice Training mode
Say voice password; RED LED will flash rapidly
Say password again; RED LED will flash rapidly
A solid GREEN LED indicates that voice password has been stored; a solid RED LED indicates that there was a problem storing the password; repeat until solid GREEN LED achieved

WHILE IN SETUP MODE—Training Color Code

The LEDs will start cycling through RED/GREEN/RED+GREEN pattern; press trigger on the color desired for color code
Repeat five additional times
Both LEDs will flash rapidly for 1 second

Using Voice Password

Insert Voicelok into computer
When red LED flashes regularly, say voice password; both LEDs will flash rapidly for 2 seconds to indicate correct password

Using Color Code

Insert Voicelok into computer
Press trigger to activate color code input
Voicelok will flash both LEDs rapidly for 1 second
LEDs will cycle through RED/GREEN/RED+GREEN pattern
Enter color code by pressing trigger when appropriate LED cycles through
Both LEDs will flash rapidly for 2 seconds to indicate correct password

Accessing Setup Mode

Enter voice password or color code; both LEDs will flash rapidly for 2 seconds
Press trigger DURING flashing to enter SETUP mode

My Voice Password : _____

My Color Code : _/_/_/_/_/_/_/_

FAQs

Why isn't my password being accepted?

It might be too noisy, or your voiceprint is outside the sensitivity threshold, which could be triggered by lack of sleep, stress or illness

What passwords work well?

Short phrases that are tonally distinct would be ideal. For example, "Wrench Monkey" or "1381" is a good password while "Bye bye" or "Hi" would be too simplistic

I accidentally interrupted the setup process, how do I access Voicelok?

In the event of an interruption during setup, the color code sequence defaults to RED/RED/RED/RED/RED/RED

To the user

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.