



3. If the memory card is write-protected, data will not be formatted and written, please remove the write protection before such operations
4. Major brands memory card is recommended to avoid the card is not compatible to this device.
5. please well note that the APK (such as application software and games) is default installed to the device. (not the memory card)

1.2.8 Connected to the computer

One end of the USB line connect to the computer, the other end connect the MID device, select Settings>Developer options>USB debugging, the device will connect with computer, and you can copy files to the device.



1.2.9 Browse the file in the device



1.2.10 Startup programs

Click all the application icon you want to start and it can switch on.

1.2.11 Close programs

Press the icon continuously or the ESC key, the device will close the active program. You can also use the corresponding function in the management currently running applications to close the program.

1.2.12 Screen operation

- Zoom in and zoom out : In applications which support zoom gestures, such as photo , IE browser, mail and map etc. you can zoom in or out the screen contents by opening or closing your two fingers.
- Rolling: In applications which support rolling gestures, such as photo , IE browser, mail and map etc. you can scroll the screen contents by sliding your fingers on the screen. If you want to stop the rolling screen, you just need to touch it.

1.2.13 Home screen

- Switch home screen
- In the home state, you can change the home interface by sliding your fingers on the screen quickly.
- Custom Home Screen

Press the blank area on the home screen interface for a few seconds, it will appear Choose wallpaper from menu, then you can set

the home screen.

- Move application icons in screen

Press the icons of applications you need to move for several seconds, it will enter into the moving model (the icon of application will be turn big), then drag the icon to desired position directly.

- Move application icons screen to screen

Press the icons of applications you need to move for several seconds, and you can drag the icon to the left side or right side.

- Delete applications

Press the icon of application you need to remove for several seconds, drag the icon to × (when the icon was turn big, the bottom of screen will appear ×, then you can delete the application).

#### 1.2.14 Screen gestures

- Click

When you need to input by the on-screen keyboard, you just need to select applications or press the button on the screen, then click the items.

- Press

When you want to start the available options of a project (such as web page link), you only need to press the project.

- Slide

Sliding on the interface with your fingers to make vertical or horizontal dragging action.

- Drag


Before you start dragging, you must press the items with your fingers, and can not let fingers leave the screen before dragging to the desired position.

- Rotation

Changing the screen orientation by rotating the device laterally.


#### 1.2.15 Security

You can set the unlock pattern, each time you open or wake your MID device, you must draw pattern to unlock the screen. In Settings > Security > Screen lock, it support many unlock ways.




If use the pattern, as below:

1. You must ensure the four-point connection when you draw the unlock pattern.



2. Click Continue and draw again to confirm it



3. Click confirm to complete unlock pattern designing.
4. Each time you open or waking your MID device, you must draw pattern to unlock the screen.


### 1.2.16 Display setting

Click Settings>Display, you can set the brightness/wallpaper/Auto rotate screen/sleep/font size of the screen.


### 1.2.17 Wireless And Network Settings

#### a) WIFI

Click Settings>Wi-Fi, turn on the wifi, the device will find available wireless network in the right interface.



Select the desired wireless network, the system will directly connect the network or popup the password input window according to network access security settings. Please consult your wireless network administrator for the password.



## 1.3 Technical specifications

Size	L 7.6 x W 4.6 x H 0.48 inches
Weight	0.86 lbs
LCD Display	7.0 inch 800*480- Multi-point capacitive touch screen
PC Interface	High speed Micro USB
OS	Android 4.0
Hard Drive Capacity	4GB
System Memory	512 MB
Capacity Expansion	Support T-F flash card 32GB(max)
Music Function	Format Mp3, WMA, OGG, AAC, WAV etc. Max. Resolutions 20Hz-20KHz
Video Function	Format Mp4, MKV, WMA, RMVB, AVI etc. Max. Resolutions 1920 *1080
Photo browse	Screen Ratio 16:9 JPG/BMP/JPEG/GIF Support
WIFI	802.11b/g/n Transmission rate Max 150Mbps Work Frequency 2.4GHz
Camera Function	Front 0.3 megapixel camera
Recording Function	Support
Working temperature	-20 -60°C
Languages	Simplified Chinese/Traditional Chinese/English/French/German/ Spanish.

## Warranty

### Warranty Terms and Conditions

Envizen Digital ("Envizen") warrants your Envizen products against defects in material and workman ship during the warranty period from the original date of purchase, subject to the following terms and conditions. If a product proves to be defective in material of workmanship during the warranty period, Envizen will, at its discretion, repair or replace the product with the same model provided the purchaser adheres to certain return authorization procedures and guidelines.

### Warranty Period

All Envizen televisions/media players/DVD players/speaker systems/digital photo frames/2.4G wireless devices/Tablet PC are warranted for one (1) year for parts and ninety(90)days for labor, starting from the original date of purchase/invoice. After warranty period, the customer is responsible for parts and labor charges. Rechargeable batteries are warranted for ninety (90) days for parts and labor.

Non-rechargeable batteries are not covered by warranty.

A new warranty does not start with the replacement of a new product.

### This Warranty Does Not Apply to:

1. Any product, on which the serial number has been defaced, modified or removed.
2. Damage, deterioration or malfunction resulting from:
  - a) Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
  - b) Repair or attempted repair by anyone not authorized by Envizen.
  - c) Any damage of the product due to shipment.
  - d) Removal from or installation to the product.
  - e) Causes external to the product, such as electric power fluctuations or failure.
  - f) Use of supplies or parts not meeting Envizen's specifications.
  - g) Normal wear and tear.
  - h) Any other cause which does not relate to product defect.
3. Cosmetic damage by purchaser, such as marking, discoloration, scratches, dents, gouges or any other defacement.
4. Physically damaged products by purchaser, such as broken PCB, Housing, damaged LCD Module.
5. No Defect Found (product returned to Envizen as defective but failure is not duplicated by Envizen's test method).
6. Product without proof of purchase. (The proof of purchase should be one of the following documents: purchase receipt, gift receipt, sales invoice, and packing list that contains the product model number, price, vendor, and purchase date.)
7. Any damage caused by battery leakage.

### How to Get Warranty Service

1. To obtain the warranty service, you will be required to reach Envizen's Customer Service by phone at **1-866-709-1999** or by email at **service@envizendigital.com** for assistance.

a) Customer information (name, day-time phone number, e-mail address and/or residential address)

b) Proof of purchase (purchase receipt, gift receipt, sales invoice, order No# And/or packing list)

c) Product model number

d) Product serial number

e) A description of the problem

f) Payment information (If any payment is required, you will be asked to provide this information beforehand. At this moment, we only accept personal check, money order, credit card or cashier's check. Sorry for the inconvenience.)

2. We will issue you an RMA number for your returned item. Please take or ship product with the RMA number to Envizen service center. All products should be returned in secured packaging, preferably in the original package, with the complete set of accessories.

3. Upon receiving the product, depending on the condition of the defects, Envizen will repair or replace product, and ship it back to the customer within 2-4 weeks.

4. For additional information, please contact Envizen Customer Service.

### Out of Warranty Repair

For additional information on obtaining an extended warranty service, contact Envizen Customer Service Department by e-mailing

**service@envizendigital.com** or call **1-866-709-1999**.

Products out of warranty requiring replacement will be reviewed individually, but all will require the shipping and handling fee.

During the period of product warranty, We will answer your basic

configuration, setup and troubleshooting questions; and when necessary, we

will provide you with all the instructions on how to return your product for repair. For more customer service and support inquiries, please call **1-866-**

**709-1999** or e-mail us at **service@envizendigital.com**.